



**BMW
MOTORRAD**

RIDER'S MANUAL (US MODEL)

F 850 GS



MAKE LIFE A RIDE

Vehicle data

Model

Vehicle identification number

Color number

First registration

License plate

Retailer data

Contact in Service

Ms./Mr.

Phone number

Retailer's address/Phone (company stamp)

WELCOME TO BMW

We are pleased that you have chosen a BMW Motorrad vehicle and welcome you to the family of BMW riders. Familiarize yourself with your new vehicle so that you can ride safely and confidently in all traffic situations.

About these operating instructions

Read these operating instructions before starting your new BMW. It contains important notes about operating the vehicle that will enable you to make full use of the technical assets of your BMW.

You will also obtain preventive maintenance and care instructions, which are beneficial to operating and road safety and help retain the value of your vehicle as much as possible.

If you should decide to sell your BMW one day, please remember to hand over these operating instructions as well. They are an important part of your vehicle.

We wish you many miles of safe and enjoyable riding with your BMW

BMW Motorrad.

01 GENERAL INSTRUCTIONS	2	04 OPERATION	48
Quick & easy reference	4	Ignition switch/steering lock	50
Abbreviations and symbols	4	Ignition with Keyless Ride	51
Equipment	5	EWS Electronic immobilizer	54
Technical data	5	Emergency-off switch	55
Timeliness of the status of this manual	6	Lights	56
Additional sources of information	6	Hazard warning flasher	57
Certificates and operating permits	6	Turn indicators	57
Data memory	6	Traction control (DTC)	58
		Electronic chassis and suspension adjustment (D-ESA)	60
02 OVERVIEWS	12	Riding mode	62
Overall view, left side	14	PRO riding mode	64
Overall view, right side	15	Adaptive cruise control	66
Underneath the seat	16	Anti-theft alarm system (DWA)	68
Multifunction switch, left	17	Tire pressure control (RDC)	71
Multifunction switch, right	18	Heated grips	71
Instrument cluster	19	Seat	72
		05 TFT DISPLAY	74
03 DISPLAYS	20	General notes	76
Indicator and warning lights	22	Principle	77
TFT display in Pure Ride view	23	Pure Ride view	83
TFT display in the View menu	24	General settings	84
Indicator lights	25	Bluetooth	86
		My Vehicle	89
		Onboard computer	92
		Navigation	92
		Media	94
		Phone	95

Displaying software version	96
Displaying license information	96

06 SETTING	98
-------------------	-----------

Mirrors	100
Headlight	100
Windshield	101
Clutch	101
Brake	102
Spring preload	103
Damping	103

07 RIDING	106
------------------	------------

Safety instructions	108
Regular check	111
Starting	112
Breaking in	115
Shifting gears	116
Off-road use	117
Brakes	118
Parking your motorcycle	120
Refueling	121
Securing motorcycle for transportation	127

08 TECHNOLOGY IN DETAIL	130
--------------------------------	------------

General notes	132
Anti-lock braking system (ABS)	132
Traction control (DTC)	135
Dynamic engine brake control	137
Dynamic ESA	137
Riding mode	138
Dynamic Brake Control	140
Tire pressure control (RDC)	141
Gear Shift Assistant	143

09 MAINTENANCE	146
-----------------------	------------

General notes	148
Onboard vehicle tool kit	148
Service tool set	149
Front-wheel stand	149
Rear-wheel stand	150
Engine oil	150
Brake system	152
Clutch	156
Coolant	157
Tires	159
Rims	160
Wheels	161
Drive chain	172
Air filter	174
Light source	176
Trim panel components	176

Jump-starting	177	Transmission	216
Battery	178	Rear-wheel drive	216
Fuses	182	Frame	217
Diagnostic socket	184	Chassis	217
		Brakes	218
<hr/>		Wheels and tires	218
10 ACCESSORIES	186	Electrical system	219
General notes	188	Dimensions	221
Onboard power sockets	188	Weights	222
USB charging socket	189	Performance data	222
Cases	190		
Topcase	193	<hr/>	
Navigation system	196	13 SERVICE	224
		Reporting safety defects	226
<hr/>		BMW Motorrad Service	227
11 CARE	202	BMW Motorrad Electronic service history (eSH)	227
Care products	204	BMW Motorrad Mobility Services	228
Washing your motorcycle	204	Maintenance procedures	228
Cleaning sensitive motorcycle parts	205	Maintenance schedule	230
Care of paintwork	206	Maintenance confirmations	231
Paint preservation	207	Service confirmations	245
Storing the motorcycle	207		
Putting the motorcycle into operation	207		
<hr/>			
12 TECHNICAL DATA	208		
Troubleshooting chart	210		
Screw connections	212		
Fuel	214		
Engine oil	214		
Engine	215		
Clutch	216		

APPENDIX	248
Certificate for electronic immobilizer	249
Certificate for Keyless Ride	251
Declaration of conformity for tire pressure control	255
Certificate for tire pressure control	261
Certificate for TFT instrument cluster	262
Declaration of conformity for anti-theft alarm	265

INDEX	270
--------------	------------

GENERAL IN- STRUCTIONS

01


QUICK & EASY REFERENCE	4
ABBREVIATIONS AND SYMBOLS	4
EQUIPMENT	5
TECHNICAL DATA	5
TIMELINESS OF THE STATUS OF THIS MANUAL	6
ADDITIONAL SOURCES OF INFORMATION	6
CERTIFICATES AND OPERATING PERMITS	6
DATA MEMORY	6


4 GENERAL INSTRUCTIONS


QUICK & EASY REFERENCE


Chapter 2 of these operating instructions will provide you with an initial overview of your motorcycle. All maintenance and repair procedures carried out on your motorcycle will be documented in the chapter "Service". Documentation of the maintenance work performed is a prerequisite for generous treatment of claims. If you should decide to sell your BMW at some point in the future, please remember to hand over these operating instructions; they are an important part of the motorcycle.


ABBREVIATIONS AND SYMBOLS



 **CAUTION** Hazard with low risk. Failure to avoid this hazard can result in minor or moderate injury.

 **WARNING** Hazard with moderate risk. Failure to avoid this hazard can result in death or serious injury.

 **DANGER** Hazard with high risk. Failure to avoid this hazard results in death or serious injury.

 **ATTENTION** Special instructions and precautionary measures. Non-compliance can cause damage to the vehicle or accessories and warranty claims may be denied as a result.

 **NOTICE** Special information on operating and inspecting your motorcycle as well as maintenance and adjustment procedures.

- Instruction.
- » Result of an activity.
- ▣ Reference to a page with more detailed information.
- ◁ Indicates the end of accessory or equipment-dependent information.
-  Tightening torque.
-  Technical data.
- NV National-market version.

OE	Optional equipment. BMW Motorrad optional equipment is already completely installed during motorcycle production.
OA	Optional accessories. BMW Motorrad optional accessories can be purchased and retrofitted at your authorized BMW Motorrad retailer.
ABS	Anti-Lock Brake System.
D-ESA	Electronic chassis and suspension adjustment.
DTC	Dynamic Traction Control.
DWA	Anti-theft alarm.
EWS	Electronic immobilizer.
TPC	Tire Pressure Control (TPC).

EQUIPMENT

When you ordered your BMW Motorrad motorcycle, you chose various items of custom equipment. These operating instructions describe optional equipment (OE)

offered by BMW and selected optional accessories (OA). This explains why the manual may also contain descriptions of equipment which you have not ordered. Please note, too, that your motorcycle might not be exactly as illustrated in this manual on account of country-specific differences. If your motorcycle features equipment that is not described here, you can find these features described in a separate manual.

TECHNICAL DATA

All dimensions, weights and performance data contained in these operating instructions refer to the German Institute for Standardization i.e. DIN (Deutsches Institut für Normung e. V.) and comply with their tolerance specifications. The technical data and specifications in these operating instructions serve as points of reference. The vehicle-specific data may vary, for instance due to the selected optional equipment, national-market version or country-specific measuring procedures. Detailed values can be obtained from the registration documents or requested

6 GENERAL INSTRUCTIONS

from your BMW Motorrad retailer or other qualified service partner or specialist workshop. The information on the vehicle documents always takes precedence over the information in these operating instructions.

TIMELINESS OF THE STATUS OF THIS MANUAL

The high safety and quality level of BMW motorcycles are ensured by consistent, ongoing development efforts embracing their design, equipment and accessories. For this reason, some aspects of your motorcycle may vary from the descriptions in these operating instructions. In addition, BMW Motorrad cannot guarantee the total absence of errors. We hope you will appreciate that no claims can be recognized that are based on the data, illustrations or descriptions in this manual.

ADDITIONAL SOURCES OF INFORMATION

BMW Motorrad retailer

Your BMW Motorrad retailer is always happy to answer any of your questions.

Internet

The Operating Instructions for your motorcycle, the operating and installation instructions for optional accessories and general BMW Motorrad information related to the technology or other features are available at **bmw-motorrad.com/manuals**.

CERTIFICATES AND OPERATING PERMITS

The certificates for the vehicle and the official operating permits for possible accessories are available at **bmw-motorrad.com/certification**.

DATA MEMORY

General information

Control units are installed in the vehicle. Control units process data received from vehicle sensors, self-generated data or data exchanged between control units, for example. Some control units are required for safe vehicle operation or provide riding assistance, such as driver assistance systems. Control units also make comfort and infotainment functions possible.

Information about the stored or exchanged data can be ob-

tained from the vehicle manufacturer, such as in the form of a separate booklet.

Personal references

Every vehicle is marked with a unique vehicle identification number. Depending on the country, the vehicle owner can be identified using the vehicle identification number and license plate and with the help of the relevant authorities. There are also other ways to trace data obtained from the vehicle back to the driver or vehicle owner, such as via the ConnectedDrive Account that was used.

Data privacy laws

In accordance with applicable data privacy laws, vehicle users have certain rights over the vehicle manufacturer or company that collects or processes personal data.

Vehicle users have the right to obtain comprehensive information without charge from the locations that store the vehicle user's personal data.

These locations may be:

- The vehicle manufacturer
- Qualified service partners
- Specialist workshops
- Service providers

Vehicle users may request information about the type of personal data that is stored, the purpose for which the data will be used and the source of the data. This information can only be obtained by a registered owner or a person with written proof authorizing use of the vehicle.

The right to information also includes information related to data transmitted to other companies or locations.

The vehicle manufacturer's website contains the appropriate privacy policy notices.

The privacy policy notices contain information on the right to delete or correct data. The vehicle manufacturer also provides the manufacturer contact information and the contact information of the data security officer.

The vehicle owner can have a BMW Motorrad retailer or other qualified service partner or specialist workshop read out the data stored in the vehicle for a fee if required.

8 GENERAL INSTRUCTIONS

The vehicle data is read out via the vehicle's legally mandated socket for onboard diagnosis (OBD).

Legal requirements for the disclosure of data

The vehicle manufacture is required by the law applicable in this context to provide authorities with the data stored by the manufacturer. Providing this data within the scope required is on a case-by-case basis, for instance to clarify a criminal offense.

Government agencies are authorized by the law applicable in this context to read out the data from the vehicle themselves in individual cases.

Operating data in the vehicle

Control units process data so that the vehicle can run.

Examples of this include:

- Status messages from the vehicle and its individual components, such as wheel RPM, wheel speed and deceleration
- Environmental conditions, such as temperature

The data is processed only in the vehicle itself and is usually temporary. The data is not stored beyond the period in which the vehicle is operating.

Electronic components such as control units contain components for storing technical information. This may be information about the vehicle's condition, component load, events or faults stored temporarily or permanently.

This information generally documents the condition of a component, module, system or the surrounding area; for example:

- Operating conditions of system components, such as fill levels and tire pressure
- Malfunctions and faults in key system components, such as lights and brakes
- Vehicle responses in specific riding situations, such as the activation of driving stability control systems
- Information about events causing damage to the vehicle

The data is necessary for providing control unit functions. In addition, it is used by the vehicle manufacturer to detect and eliminate malfunctions as well as to optimize vehicle functions.

The majority of this data is temporary and is processed only within the vehicle itself. Only a small amount of event-driven data is stored in the

event data recorder and fault memory.

When a vehicle is serviced, such as for repairs, servicing processes, warranty cases and quality assurance measures, this technical information can be read out from the vehicle together with the vehicle identification number.

The information can be read out by a BMW Motorrad retailer or other qualified service partner or specialist workshop. The vehicle's legally mandated socket for onboard diagnosis (OBD) is used to read out the data.

The data is collected, processed and used by the respective retailer network locations. The data documents the vehicle's technical states and helps with fault finding, compliance with warranty obligations and quality improvements.

The manufacturer also has product monitoring obligations arising from product liability law. The vehicle manufacturer requires technical data from the vehicle in order to fulfill these obligations. The data from the vehicle can also be

used to verify customer warranty and guarantee claims. The fault memory and event data recorder in the vehicle can be reset by a BMW Motorrad retailer or other qualified service partner or specialist workshop as part of a repair or servicing.

Data input and data transfer in the vehicle

General information

Depending on the equipment, comfort settings and individualized settings in the vehicle can be saved and changed or reset at any time.

Examples of this include:

- Windshield position settings
- Chassis and suspension adjustment settings

It is possible to introduce data into the vehicle entertainment and communication system via a smartphone, for instance. Depending on the individual equipment, this includes:

- Multimedia data, such as music for playback
- Address book data for use in conjunction with a communication system or integrated navigation system
- Entered navigation destinations

10 GENERAL INSTRUCTIONS

–Data about the use of Internet services. This data can be stored locally in the vehicle or is on a device connected to the vehicle, such as a smartphone, USB stick or MP3 player. If this data is saved in the vehicle, it can be deleted at any time.

This data is transmitted to third parties only upon personal request as part of the use of online services. The data transmitted depends on the selected settings when using the services.

Integrating mobile end devices

Depending on the equipment, mobile end devices connected to the vehicle, such as smartphones, are controlled using the vehicle's operating elements.

This enables audio and visual output from mobile end devices through the multimedia system. At the same time, certain information is transmitted to the mobile end device. This includes for instance position data and other general vehicle data, depending on the type of integration, and makes it possible to optimize the use of se-

lected apps, such as those for navigation or audio playback. The way the data is processed further is determined by the provider of the particular app used. The range of possible settings depends on the particular app and the operating system of the mobile end device.

Services

General information

If the vehicle has a mobile phone connection, this connection makes it possible to exchange data between the vehicle and other systems. The mobile phone connection is made possible through the vehicle's transmitter and receiver or via personally integrated mobile end devices such as smartphones. Online functions, as they are called, are used over this mobile phone connection. These include online services and apps provided by the vehicle manufacturer or other providers.

Vehicle manufacturer services

In the case of the vehicle manufacturer's online services, the particular functions are described at the appropriate location, such as in the operating instructions or on manufactur-

er's website. The relevant legal information on data privacy is also provided there. Personal data may be used in order to provide online services. The data is exchanged over a secure connection, i.e. with the vehicle manufacturer's IT systems which are intended for this purpose.

Any collection, processing and use of personal data that goes beyond the provision of services take place only as permitted by law, on the basis of a contractual agreement or as a result of consent. It is also possible to have the entire data connection activated or deactivated. This is not the case for legally prescribed functions.

Services of other providers

When using the online services of other providers, these services are subject to the responsibility and the data protection and usage conditions of the respective provider. The vehicle manufacturer has no control over the content exchanged via these services. Information about the type, scope and purpose of collecting and using personal data as part of third-party services can be

obtained from the particular service provider.

OVERVIEWS

02


OVERALL VIEW, LEFT SIDE	14
OVERALL VIEW, RIGHT SIDE	15
UNDERNEATH THE SEAT	16
MULTIFUNCTION SWITCH, LEFT	17
MULTIFUNCTION SWITCH, RIGHT	18
INSTRUMENT CLUSTER	19

OVERALL VIEW, RIGHT SIDE


- 1 Spring preload setting
(103)
- 2 Brake fluid reservoir for rear wheel brake (155)
- 3 Brake fluid reservoir for front wheel brake
(154)
- 4 Vehicle identification number, type plate (on steering head)
- 5 Coolant level indicator (behind the side trim panel)
(157)

16 OVERVIEWS

UNDERNEATH THE SEAT



- 1 Onboard vehicle tool kit
(148)
- 2 Payload table
- 3 Battery (178)
- 4 Main fuse (182)
- 5 Diagnostic socket
(184)
- 6 Fuses (183)

MULTIFUNCTION SWITCH, LEFT

- 1 High beams and headlight flasher (→ 56)
- 2 Adaptive cruise control (→ 66)
- 3 Hazard warning flasher (→ 57)
- 4 DTC (→ 58)
- 5 Dynamic ESA (→ 60)
- 6 Turn indicators (→ 57)
- 7 Horn
- 8 Rocker button MENU (→ 77)
- 9 Multi-Controller Operating elements (→ 77)

18 OVERVIEWS

MULTIFUNCTION SWITCH, RIGHT



- 1 Operating heated grips
([▣▣▣▣ 71](#))
- 2 Select riding mode
([▣▣▣▣ 63](#))
- 3 Emergency-off switch
([▣▣▣▣ 55](#))
- 4 Starter button ([▣▣▣▣ 112](#))

INSTRUMENT CLUSTER

- 1** Indicator and warning lights (➡ 22)
- 2** TFT display (➡ 23)
(➡ 24)
- 3** DWA LED (➡ 69)
–with Keyless Ride^{OE}
Indicator light for radio-operated key (➡ 52)
- 4** Photosensor (for adjusting brightness of instrument lighting)

DISPLAYS


03

INDICATOR AND WARNING LIGHTS	22
TFT DISPLAY IN PURE RIDE VIEW	23
TFT DISPLAY IN THE VIEW MENU	24
INDICATOR LIGHTS	25




22 DISPLAYS

INDICATOR AND WARNING LIGHTS



- 1 Turn indicator, left (➡ 57)
- 2 High beams (➡ 56)
- 3 General warning light (➡ 25)
- 4 Turn indicator, right (➡ 57)
- 5 DTC (➡ 43)
- 6 ABS (➡ 42)
- 7 Auxiliary headlight


TFT DISPLAY IN PURE RIDE VIEW



- | | |
|--|--|
| 1 Changing operating focus (►►► 81) | 12 Muting (►►► 84) |
| 2 Tachometer (►►► 83) | 13 Operating assistance |
| 3 Rider info. status line (►►► 81) | 14 Heated grip settings (►►► 71) |
| 4 Speedometer | 15 Outside temperature warning (►►► 31) |
| 5 Riding mode (►►► 62) | 16 Outside temperature |
| 6 Upshift recommendation (►►► 84) | |
| 7 Gear indicator, "N" is displayed while in neutral position. | |
| 8 Speed Limit Info (►►► 83) | |
| 9 Adaptive cruise control (►►► 66) | |
| 10 Clock (►►► 85) | |
| 11 Connection status (►►► 87) | |

24 DISPLAYS

TFT DISPLAY IN THE VIEW MENU




- 1 Speedometer
- 2 Adaptive cruise control (►►► 66)
- 3 Speed Limit Info (►►► 83)
- 4 Riding mode (►►► 62)
- 5 Rider info. status line (►►► 81)
- 6 Upshift recommendation (►►► 84)
- 7 Gear indicator, "N" is displayed while in neutral position.
- 8 Clock (►►► 85)
- 9 Connection status (►►► 87)
- 10 Muting (►►► 84)
- 11 Operating assistance
- 12 Menu area
- 13 Heated grip settings (►►► 71)
- 14 Outside temperature warning (►►► 31)
- 15 Outside temperature

INDICATOR LIGHTS

Layout

Warnings are displayed by the corresponding warning lights. Warnings are indicated by the general warning light in conjunction with a dialog in the TFT display. The general warning light lights up in either yellow or red depending on the urgency of the warning.


 The general warning light lights up for whichever warning is most urgent at the current time. You will find an overview of the potential warnings on the following pages.



Check Control display

The messages in the display are shown differently in the display. Different colors and characters are used depending on the priority:

- Green CHECK OK **1**: no message, values optimal.
- White circle with small "i" **2**: information.
- Yellow warning triangle **3**: warning message, value not optimal.
- Red warning triangle **3**: warning message, value critical



Value display


The symbols **4** differ in their display. Different colors are used depending on the assessment of value. Instead of numerical values **8** with units **7**, texts **6** are also displayed:

Color of the symbol


- Green: (OK) current value is optimal.
- Blue: (Cold!) current temperature is too low.
- Yellow: (Low! /High!) current value is too low or too high.
- Red: (Hot! /High!) current temperature or value is too high.


26 DISPLAYS

–White: (---) there is no valid value. Instead of the value, dashes **5** are displayed.

 The evaluation of the individual values is possible in part only after a certain riding duration or speed. If a measured value cannot yet be displayed due to unfulfilled measurement conditions, dashes are displayed instead as placeholders. As long as no valid measured value is available, no evaluation is carried out in the form of a colored symbol.

ing the Multi-Controller to the left.

–Check Control messages are dynamically attached as additional tabs to the pages in the menu *My vehicle* ( 79). The message can be called up again as long as the error persists.



Check Control dialogue

Messages are output as Check Control dialogue **1**.




















–If several Check Control messages of the same priority are present, the messages change in the order in which they occur, until they are acknowledged.




















–If the symbol **2** is active, this can be acknowledged by tilt-

Overview of warning indicators














Indicator and warning lights	Display text	Meaning
	is displayed.	Outside temperature warning (▮▮▮ 31)
lights up yellow.	Remote key not in range.	Radio-operated key outside reception range (▮▮▮ 31)
lights up yellow.	Remote key battery at 50%.	Replacing the battery of the radio-operated key (▮▮▮ 32)
lights up yellow.	Remote key battery low.	
lights up yellow.	is displayed in yellow.	Vehicle voltage too low (▮▮▮ 32)
lights up red.	Vehicle voltage low.	Vehicle voltage critical (▮▮▮ 32)
lights up red.	is displayed in red.	
lights up red.	Vehicle voltage critical!	
lights up red.	is displayed in red.	Charging voltage critical (▮▮▮ 33)
lights up yellow.	Vehicle voltage critical!	Bulb faulty (▮▮▮ 33)
lights up yellow.	The faulty light source is displayed.	
Anti-theft alarm batt. capacity low.	Anti-theft alarm battery low charge (▮▮▮ 34)	

28 DISPLAYS

Indicator and warning lights	Display text	Meaning
 lights up yellow.	 Anti-theft alarm battery discharged.	Anti-theft alarm battery discharged (▣▣▣ 35)
 lights up red.	 Coolant temperature too high!	Coolant temperature too high (▣▣▣ 35)
	 Engine!	Drive malfunction (▣▣▣ 35)
 flashes red.		Severe drive malfunction (▣▣▣ 36)
 lights up yellow.	 No communication with engine control.	Engine control failure (▣▣▣ 36)
 lights up yellow.	 Fault in the engine control.	Engine in emergency operation mode (▣▣▣ 36)
 flashes red.	 Serious fault in the engine control.	Serious fault in the engine control (▣▣▣ 37)
 lights up yellow.	 Displayed in yellow.	Tire pressure is at limit of approved range (▣▣▣ 38)
	 Tire pressure not at set-point.	
 flashes red.	 Displayed in red.	Tire pressure is outside the approved tolerance range (▣▣▣ 39)
	 Tire pressure not at set-point.	
	 Tire Press. Monitor. Loss of pressure.	

Indicator and warning lights	Display text	Meaning
	 "----"	Transmission fault (▶▶▶▶ 40)
 lights up yellow.	 "----"	Sensor faulty or system fault (▶▶▶▶ 40)
 lights up yellow.	 TPM sensors battery low.	Battery of the tire pressure sensor weak (▶▶▶▶ 41)
	 Fall sensor faulty.	Fall sensor defective (▶▶▶▶ 41)
	 Side stand monitoring faulty	Side stand monitoring faulty (▶▶▶▶ 41)
 flashes.		ABS self-diagnosis not completed (▶▶▶▶ 41)
 lights up.	 Limited ABS availability!	ABS fault (▶▶▶▶ 42)
 lights up.	 ABS failure!	ABS failure (▶▶▶▶ 42)
 lights up.	 ABS Pro failure!	ABS Pro failure (▶▶▶▶ 42)
 flashes rapidly.		DTC intervention (▶▶▶▶ 43)
 flashes slowly.		DTC self-diagnosis not completed (▶▶▶▶ 43)
 lights up.	 Off!	DTC switched off (▶▶▶▶ 43)
	 Traction control deactivated.	

30 DISPLAYS

Indicator and warning lights	Display text	Meaning
 lights up.	 Traction control limited.	Limited DTC availability (▶▶▶▶▶ 43)
 lights up.	 Traction control failure!	DTC error (▶▶▶▶▶ 44)
 lights up yellow.	 Spring strut adjustment faulty!	D-ESA fault (▶▶▶▶▶ 44)
	 Fuel reserve is being used up. Ride to the nearest gas station	Fuel down to reserve volume (▶▶▶▶▶ 44)
	 flashes.	Gear not taught in (▶▶▶▶▶ 45)
 flashes in green.		Hazard warning lights system switched on (▶▶▶▶▶ 45)
 flashes in green.		
	 is displayed in white. Service due!	Service due (▶▶▶▶▶ 46)
 lights up yellow.	 is displayed in yellow. Service overdue!	Service appointment missed (▶▶▶▶▶ 46)

Outside temperature

The outside temperature is displayed in the status line of the TFT display.

Engine heat can lead to spurious readings the outside temperature when the motorcycle is stationary. If the effect of the engine heat becomes excessive, dashes are temporarily displayed instead of the value.



If the outside temperature falls below the following limit value, there is a risk of black ice formation.



Limit value for outside temperature

Approx. 37 °F (Approx. 3 °C)

The first time the temperature drops below this value, the outside temperature display and ice crystal symbol will flash in the status line of the TFT display.

Outside temperature warning



is displayed.

Possible cause:

The ambient temperature measured at the motorcycle is lower than 37 °F (3 °C).



WARNING

Risk of black ice, even above 37 °F (3 °C)

Accident hazard

- At a low outside temperature, icy conditions must be expected on bridges and in shady road areas.

- Ride proactively.

Radio-operated key outside reception range

—with Keyless Ride^{OE}



lights up yellow.



Remote key not in range. It is not possible to turn on the ignition again.

Possible cause:


The communication between the radio-operated key and the engine electronics is faulty.


- Check the battery in the radio-operated key. —with Keyless Ride^{OE}
- Replacing the battery of the radio-operated key (► 54).
- Use the spare key for further travel. —with Keyless Ride^{OE}
- Battery of the radio-operated key is drained or the radio-operated key is lost (► 53).


32 DISPLAYS

- If the Check Control dialogue appears while riding, remain calm. You can continue riding, the engine will not turn off.
- Have any faulty radio-operated keys replaced by a BMW Motorrad retailer.

Replacing the battery of the radio-operated key —with Keyless Ride^{OE}

 lights up yellow.


 Remote key battery at 50%. No functional limitation.


 Remote key battery low. Limited central locking function. Change battery.


Possible cause:

- The battery for the radio-operated key is no longer charged to full capacity. Operation of the radio-operated key is only ensured for a limited time.
- Replacing the battery of the radio-operated key (➔ 54).

Vehicle voltage too low

 lights up yellow.

 is displayed in yellow.

 Vehicle voltage low. Switch off unneeded consumers.


The vehicle voltage is too low. If you continue riding, the motorcycle electronics will discharge the battery.

Possible cause:


Consumers with high electrical consumption, e.g. heating vests, are in operation; too many consumers are in operation at the same time, or the battery is defective.

- Switch off consumers that are not needed or disconnect them from the electrical system.
- If the malfunction persists or occurs without any consumers connected, have the malfunction corrected as soon as possible at a specialist workshop, preferably an authorized BMW Motorrad retailer.

Vehicle voltage critical

 lights up red.

 is displayed in red.

 Vehicle voltage critical! Consumers were switched off. Check battery condition.

**WARNING****Failure of vehicle systems**

Accident hazard

- Do not continue riding.

The vehicle voltage is critical. If you continue riding, the motorcycle electronics will discharge the battery.

Possible cause:

Consumers with high electrical consumption, e.g. heating vests, are in operation; too many consumers are in operation at the same time, or the battery is defective.

- Switch off consumers that are not needed or disconnect them from the electrical system.
- If the malfunction persists or occurs without any consumers connected, have the malfunction corrected as soon as possible at a specialist workshop, preferably an authorized BMW Motorrad retailer.

Charging voltage critical

lights up red.



is displayed in red.



Vehicle voltage critical! Battery is not being charged. Check battery status.

**WARNING****Failure of vehicle systems**

Accident hazard

- Do not continue riding.

The battery is not being charged. If you continue riding, the motorcycle electronics will discharge the battery.

Possible cause:

Alternator or alternator drive is faulty, battery is faulty or fuse is blown.

- Have the malfunction corrected as soon as possible at a specialist workshop, preferably an authorized BMW Motorrad retailer.

Bulb faulty

lights up yellow.



The faulty light source is displayed:










High beam faulty!



Turn indicator front left faulty! or Turn indicator front right faulty!

34 DISPLAYS

-  Low beam faulty!
 -  Front parking lamp faulty!
 -  Daytime running light faulty!
 -  Tail light faulty!
 -  Brake light faulty!
 -  Rear left turn signal faulty! or Rear right turn signal faulty!
 -  License plate light faulty!
- Have checked by a specialist workshop.



WARNING

Overlooking the vehicle in traffic due to a defective light source on the vehicle

Safety risk

- Replace defective bulbs as soon as possible; it is best always to carry a complete set of spare bulbs on the motorcycle.

Possible cause:

Light source defective.

- Locate faulty light sources by means of a visual inspection.
- Have the LED light source replaced in full; for details please contact a specialist workshop, preferably an authorized BMW Motorrad retailer.

Anti-theft alarm battery low charge

-with anti-theft alarm system (DWA)^{OE}



Anti-theft alarm batt. capacity low. No limitations. Arrange an appointment at a specialist workshop.



This fault message is only shown for a short time immediately following the Pre-Ride-Check.

Possible cause:

- The anti-theft alarm battery no longer has its full capacity. The operation of the anti-theft alarm system is only ensured for a limited time with the motorcycle battery disconnected.
- Contact a specialist workshop, preferably an authorized BMW Motorrad retailer.

Anti-theft alarm battery discharged

–with anti-theft alarm system (DWA)^{OE}



lights up yellow.



Anti-theft alarm battery discharged. No independent alarm. Arrange an appointment at a specialist workshop.



This fault message is only shown for a short time immediately following the Pre-Ride-Check.

Possible cause:

The anti-theft alarm system battery is completely discharged. Operation of the anti-theft alarm system is no longer ensured when the motorcycle battery is disconnected.

- Contact a specialist workshop, preferably an authorized BMW Motorrad retailer.

Coolant temperature too high



lights up red.



Coolant temperature too high! Check coolant level. Carry on at moderate pace to cool.



ATTENTION

Riding with overheated engine

Engine damage

- Be sure to observe the measures listed below.

Possible cause:

Coolant level is too low.

- Checking coolant level (▣▣▣▣ 157).

If coolant level is too low:

- Topping up coolant (▣▣▣▣ 158).

Possible cause:

The coolant temperature is too high.

- If possible, continue riding in the partial load range to cool down the engine.
- In traffic jams, switch off the engine, but keep the ignition switched on so that the radiator fan continues to operate.
- Should the coolant temperature frequently be too high, have the fault rectified as quickly as possible by a specialist workshop, preferably an authorized BMW Motorrad retailer.

Drive malfunction



Engine! Have checked by a specialist workshop.

36 DISPLAYS

Possible cause:

The engine control unit has diagnosed a fault that affects pollutant emission and/or performance.

- Have the malfunction corrected at a specialist workshop, preferably an authorized BMW Motorrad retailer.
- » You may continue driving if the pollutant emission is above the setpoint values.

Severe drive malfunction



flashes red.

Possible cause:

The engine control unit has diagnosed a fault which can lead to damage of the exhaust system.

- Have the malfunction corrected as soon as possible at a specialist workshop, preferably an authorized BMW Motorrad retailer.
- » Continued riding is possible, however it is not recommended.

Engine control failure



lights up yellow.



No communication with engine control. Multiple sys. affected.

Ride carefully to the next specialist workshop

Engine in emergency operation mode



lights up yellow.



Fault in the engine control. Onward journey possible. Ride carefully to next specialist workshop.



WARNING

Unusual handling when the engine is in emergency operation

Accident hazard

- Avoid rapid acceleration and passing maneuvers.

Possible cause:

The engine control unit has diagnosed a fault. In exceptional cases, the engine stops and can no longer be started. Otherwise, the engine runs in emergency operation.

- Continued riding is possible, however the accustomed engine power may not be available.
- Have the malfunction corrected as soon as possible at a specialist workshop,

preferably an authorized BMW Motorrad retailer.

Serious fault in the engine control



flashes red.



Serious fault in the engine control. Onward journey possible. Damage possible. Have checked by a workshop.



WARNING

Damage to engine during emergency operation

Accident hazard

- Drive slowly and avoid rapid acceleration and passing maneuvers.
- If possible, have the vehicle picked up and the fault eliminated at a specialist workshop, preferably an authorized BMW Motorrad retailer.

Possible cause:

The engine control unit has diagnosed a fault, which can lead to a severe secondary fault. The engine is in emergency operation.

- Avoid high load and engine speed ranges if possible.
- Have the malfunction corrected as soon as possible

at a specialist workshop, preferably an authorized BMW Motorrad retailer.

» Continued driving is possible, however it is not recommended.

Tire pressure

–with tire pressure monitor (TPM)^{OE}

For the tire pressure display, in addition to the MY VEHICLE menu window and the Check Control messages, there is also the TIRE PRESSURE window:



The values on the left relate to the front wheel and the values on the right relate to the rear wheel.

In addition to the actual tire pressure values, the setpoint tire pressure values are displayed based on the vehicle load.

Immediately after switching on the ignition, only dashes are displayed. The transfer of the

38 DISPLAYS

actual tire pressure values does not begin until the following minimum speed is exceeded for the first time:



RDC sensor is not active

min 19 mph (min 30 km/h)
(The RDC sensor transmits its signal to the vehicle only once the minimum speed has been exceeded.)



The tire pressures are shown in the TFT display with temperature compensation and are always based on the following tire air temperature:

68 °F (20 °C)



If the tire symbol appears yellow or red at the same time, the display is a warning.



The tolerance ranges of the tire pressures refer to one-up operation.



If the level concerned is borderline in terms of the permissible tolerance, the general warning light also lights up yellow.



If the monitored tire pressure is outside the specified range, the general warning light will flash red.

For further information about the BMW Motorrad tire pressure control (RDC), see the Technology in detail (»» 141) chapter.

Tire pressure is at limit of approved range

–with tire pressure monitor (TPM)^{OE}



lights up yellow.



Displayed in yellow.



Tire pressure not at setpoint. Check tire pressure.

Possible cause:

The measured tire pressure is within the limit range of the permissible tolerance.

- Correct the tire pressure.
- Before adjusting the tire pressure, check the information on temperature compensation and tire pressure adjustment in the Technology in detail chapter:

» Temperature compensation (»» 142)

- » Tire pressure adjustment (▮▮▮▮▶ 142)
- » The target tire pressures can be found in the following locations:
 - On the back cover of the operating instructions
 - Instrument cluster in the TIRE PRESSURE view
 - Sign underneath the seat

Tire pressure is outside the approved tolerance range

- with tire pressure monitor (TPM)^{OE}



flashes red.



Displayed in red.



Tire pressure not at setpoint. Stop immediately! Check tire pressure.



Tire Press. Monitor. Loss of pressure. Stop immediately! Check tire pressure.



WARNING

Tire pressure is outside the approved tolerance range.

Risk of accident, deterioration in the handling characteristics of the vehicle.

- Adjust the driving style.

Possible cause:

The measured tire pressure is outside of the permissible tolerance.

- Check tire for damage and ridability.

If the tire is still ridable:

- Correct the tire pressure at the next opportunity.
- Before adjusting the tire pressure, check the information on temperature compensation and tire pressure adjustment in the Technology in detail chapter:

- » Temperature compensation (▮▮▮▮▶ 142)

- » Tire pressure adjustment (▮▮▮▮▶ 142)

- » The target tire pressures can be found in the following locations:

- On the back cover of the operating instructions
- Instrument cluster in the TIRE PRESSURE view
- Sign underneath the seat
- Have the tire checked by a specialist workshop for damage, preferably by an authorized BMW Motorrad retailer.



The RDC warning message can be deactivated in the off-road mode.

If you are unsure about the tire's ridability:

40 DISPLAYS

- Do not continue riding.
- Contact roadside service.

Transmission fault

–with tire pressure monitor (TPM)^{OE}



"----"


Possible cause:

The vehicle has not reached the minimum speed (→ 141).



RDC sensor is not active

min 19 mph (min 30 km/h)
(The RDC sensor transmits its signal to the vehicle only once the minimum speed has been exceeded.)

- Observe the RDC display at higher speed.
-  This is a permanent fault only when the general warning light also lights up. In this case:
 - Have the malfunction corrected at a specialist workshop, preferably an authorized BMW Motorrad retailer.

Possible cause:

The radio link to the RDC sensors is disrupted. There are radio systems in the surrounding area that are causing interference to the connection

between the TPM control unit and the sensors.

- Observe the RDC display in different surroundings.



This is a permanent fault only when the general warning light also lights up. In this case:

- Have the malfunction corrected at a specialist workshop, preferably an authorized BMW Motorrad retailer.

Sensor faulty or system fault

–with tire pressure monitor (TPM)^{OE}



lights up yellow.



"----"

Possible cause:

Wheels without installed TPC/RDC sensors are mounted.

- Retrofit wheel set with RDC sensors.

Possible cause:

1 or 2 RDC sensors have failed or there is a system fault.

- Have the malfunction corrected at a specialist workshop, preferably an authorized BMW Motorrad retailer.

Battery of the tire pressure sensor weak

—with tire pressure monitor (TPM)^{OE}



lights up yellow.



TPM sensors battery low. Function limited. Have checked by a specialist workshop.



This fault message is only shown for a short time immediately following the Pre-Ride-Check.

Possible cause:

The battery for the tire pressure sensor is no longer charged to full capacity.

Operation of the RDC is only ensured for a limited time.

- Contact a specialist workshop, preferably an authorized BMW Motorrad retailer.

Fall sensor defective



Fall sensor faulty. Have checked by a specialist workshop.

Possible cause:

The fall sensor is not functioning.

- Contact a specialist workshop, preferably an authorized BMW Motorrad retailer.

Side stand monitoring faulty



Side stand monitoring faulty. Onward journey possible. Stop engine when stationary! Have checked by workshop.

Possible cause:

The side-stand switch or its wiring is damaged. The engine is switched off when the speed falls below 5 km/h. The journey cannot be continued.

- Contact a specialist workshop, preferably an authorized BMW Motorrad retailer.

ABS self-diagnosis not completed



flashes.

Possible cause:


The ABS is not available because the self-diagnosis has not been completed. To check the wheel sensors, the motorcycle must be driven a few yards.

- Ride off slowly. It must be noted that the ABS function is not available until the self-diagnosis has been completed.

42 DISPLAYS

ABS fault

 lights up.

 Limited ABS availability! Onward journey possible. Ride carefully to next specialist workshop.


Possible cause:

The ABS control unit has detected an error. The ABS function is limited.

- You may continue riding. Observe additional information on special situations that can lead to an ABS fault memory entry (➡ 133).
- Have the malfunction corrected as soon as possible at a specialist workshop, preferably an authorized BMW Motorrad retailer.

ABS failure

 lights up.

 ABS failure! Onward journey possible. Ride carefully to next specialist workshop.

Possible cause:

The ABS control unit has detected an error.


- You may continue riding. It must be noted that the ABS function is not available. Ob-

serve additional information on special situations which can lead to ABS fault memory entries (➡ 133).

- Have the malfunction corrected as soon as possible at a specialist workshop, preferably an authorized BMW Motorrad retailer.

ABS Pro failure

 lights up.


 ABS Pro failure! Onward journey possible. Ride carefully to next specialist workshop.

Possible cause:

The ABS Pro control unit has detected a fault. The ABS Pro function is not available. The ABS remains available, but function is limited. ABS only supports braking in straight-ahead riding.

- You may continue riding. Observe additional information on special situations that can lead to an ABS Pro fault memory entry (➡ 133).
- Have the malfunction corrected as soon as possible at a specialist workshop, preferably an authorized BMW Motorrad retailer.

DTC intervention

 flashes rapidly. DTC has detected instability at the rear wheel and responded by reducing the torque. The indicator and warning light flashes longer than the DTC intervention lasts. This provides the rider with visual feedback for the control action that was taken even after the critical situation has passed.

DTC self-diagnosis not completed

 flashes slowly.

Possible cause:



DTC self-diagnosis not completed


The DTC function is not available, as the self-diagnosis function has not been completed. (To check wheel speed sensors, motorcycle must reach a minimum speed with engine running: min 3 mph (min 5 km/h))

- Ride off slowly. It must be noted that the DTC function is not available until the self-diagnosis has been completed.

DTC switched off

 lights up.

 Off!

 Traction control deactivated.


Possible cause:

The DTC system was deactivated by the rider.

- Switching on DTC (▶▶▶ 59).

Limited DTC availability

 lights up.

 Traction control limited. Onward journey possible.

Ride carefully to next specialist workshop.

Possible cause:

The DTC control unit has detected an error.

**ATTENTION****Damage to components**

Damage to sensors, for example, with the resultant malfunctions

- Do not carry along any objects under the rider's or passenger's seat.
- Secure vehicle tools.


- Do not damage the rotational speed sensor.

44 DISPLAYS

- It must be noted that only limited DTC function is available.
- You may continue riding. Observe additional information on situations that can lead to a DTC fault (➡ 135).
- Have the malfunction corrected as soon as possible at a specialist workshop, preferably an authorized BMW Motorrad retailer.

DTC error

 lights up.


 Traction control failure! Onward journey possible. Ride carefully to the next specialist workshop.


Possible cause:

The DTC control unit has detected an error.

- It must be noted that the DTC function is not available at all or is restricted.
- You may continue riding. Observe additional information on situations that can lead to a DTC fault (➡ 135).
- Have the malfunction corrected as soon as possible at a specialist workshop, preferably an authorized BMW Motorrad retailer.

D-ESA fault

 lights up yellow.


 Spring strut adjustment faulty! Onward journey possible. Ride carefully to next specialist workshop.

Possible cause:

The D-ESA control unit has detected a fault. Damping action and/or the spring adjustment may be the cause. In this state, the motorcycle is probably heavily damped and is uncomfortable to drive, particularly on poor roads. Alternatively, the spring preload may be set incorrectly.

- Have the malfunction corrected as soon as possible at a specialist workshop, preferably an authorized BMW Motorrad retailer.

Fuel down to reserve volume

 Fuel reserve is being used up. Drive to the nearest filling station.

**WARNING****Rough engine running or switching off of the engine due to a fuel shortage**

Accident hazard, damage to catalytic converter

- Do not drive to the extent that the fuel tank is completely empty.

Possible cause:

At the most, the fuel tank still contains the reserve fuel quantity.



Reserve fuel quantity

Approx. 3.7 quarts (Approx. 3.5 l)

- Refueling procedure (►► 122).

Gear not taught in

—with Gearshift Assistant Pro^{OE}

N The gear indicator flashes. The Gear Shift Assistant Pro has no function.

Possible cause:

—with Gearshift Assistant Pro^{OE}

The transmission sensor has not been completely taught in.

- Engage idle position **N** and allow the engine to run for at least 10 seconds while parked to train the idle position.

- Shift all gears with clutch control and ride for at least 10 seconds in each engaged gear.

» The gear display stops flashing when the transmission sensor has been successfully taught in.

—If the transmission sensor is completely trained, the Gear Shift Assistant Pro functions as described (►► 143).

- If the teach-in procedure is unsuccessful, have the fault corrected at a specialist workshop, preferably an authorized BMW Motorrad retailer.

Hazard warning lights system switched on

flashes in green.



flashes in green.

Possible cause:

The hazard warning flasher was switched on by the rider.


- Operating the hazard warning lights (►► 57).

Service display


If service is overdue, the due date or the odometer reading at which service was due is accompanied by the 'General' warning light in yellow.

46 DISPLAYS

If service is overdue, a yellow Check Control message is displayed. The displays for service, service appointment and remaining distance are also marked with exclamation marks in the MY VEHICLE and SERVICE REQUIREMENTS menu windows.

 If the service display appears more than a month before the service date, the current day's date must be reset in the instrument cluster. This situation can occur if the battery was disconnected.

Service due


 is displayed in white.


Service due! Have a service performed at a specialist workshop.
Possible cause:

Service is due because of the mileage or the date.

- Have service performed regularly by a specialist workshop, preferably an authorized BMW Motorrad retailer.
- » The operating and road safety of the vehicle remains unchanged.
- » The best-possible value retention of the vehicle is ensured.

Service appointment missed

 lights up yellow.

 is displayed in yellow.

Service overdue! Have a service performed at a specialist workshop.
Possible cause:

Service is overdue because of the riding performance or the date.

- Have service performed regularly by a specialist workshop, preferably an authorized BMW Motorrad retailer.
- » The operating and road safety of the vehicle remains unchanged.
- » The best-possible value retention of the vehicle is ensured.

OPERATION

04

IGNITION SWITCH/STEERING LOCK	50
IGNITION WITH KEYLESS RIDE	51
EWS ELECTRONIC IMMOBILIZER	54
EMERGENCY-OFF SWITCH	55
LIGHTS	56
HAZARD WARNING FLASHER	57
TURN INDICATORS	57
TRACTION CONTROL (DTC)	58
ELECTRONIC CHASSIS AND SUSPENSION ADJUST- MENT (D-ESA)	60
RIDING MODE	62
PRO RIDING MODE	64
ADAPTIVE CRUISE CONTROL	66
ANTI-THEFT ALARM SYSTEM (DWA)	68
TIRE PRESSURE CONTROL (RDC)	71
HEATED GRIPS	71
SEAT	72

50 OPERATION

IGNITION SWITCH/STEERING LOCK

Ignition key

You receive two ignition keys. Should you lose your keys, please refer to the notes regarding the electronic immobilizer (EWS) (▶▶▶ 54). The ignition lock, fuel filler cap and seat lock are operated with the same key.

- with case^{OA}
- with topcase^{OA}

The cases and the topcase can also be ordered with locks for the same key on request. Please contact a specialist workshop for this purpose, preferably a BMW Motorrad retailer.

Locking handlebars

- Turn handlebars to left.



- Turn key to position **1** while moving handlebars slightly.

- » Ignition, lights and all electrical circuits switched off.
- » Steering lock locked.
- » Key can now be removed.

Switching on the ignition



- Turn the radio-operated key to position **1**.
- » Parking lights and all function circuits switched on.
- » Engine can be started.
- » Pre-Ride-Check is carried out. (▶▶▶ 113)
- » ABS self-diagnosis is performed. (▶▶▶ 114)
- » DTC self-diagnosis is performed. (▶▶▶ 114)

Welcome light

- Switch on the ignition.
- » The parking lamp briefly lights up.
- with LED additional headlight^{OA}
- » The supplementary LED headlights briefly light up.◁

Switch off ignition




- Turn key to **1** position.
 - » Light switched off.
 - » Handlebars not locked.
 - » Key can now be removed.
 - » Electrically powered accessories remain operational for a limited period of time.
 - » Battery charging possible via the on-board socket.

IGNITION WITH KEYLESS RIDE

—with Keyless Ride^{OE}

Ignition key


 The indicator light for the radio-operated key flashes as long as the radio-operated key is being searched for. If the radio-operated key or the spare key is detected, it goes out.

If the radio-operated key or the spare key is not detected, it lights up briefly.

You are provided with one radio-operated key and one

spare key. Should you lose your keys, refer to the notes regarding the electronic immobilizer (EWS) (→ 54).

The ignition, fuel filler cap and anti-theft alarm system are activated with the radio-operated key. The seat lock, Topcase and case can be operated manually.

 When the range of the radio-operated key is exceeded (e.g. in case or Topcase), the vehicle cannot be started.

If the radio-operated key continues to be missing, the ignition is switched off after approx. 1.5 minutes to protect the battery charge.

It is advisable to carry the radio-operated key directly on your person (e.g. in a jacket pocket) and to also carry the spare key as an alternative.

 Range of Keyless Ride radio-operated key

—with Keyless Ride^{OE}


Approx. 3.3 ft (Approx. 1 m) ◁

52 OPERATION

Locking handlebars

Requirement

Handlebars are turned to the left. Key remote is within reception range.




- Press and hold button **1**.
 - » Steering lock audibly locks.
 - » Ignition, lights and all electrical circuits switched off.
- To unlock the steering lock, briefly press button **1**.

Switching on the ignition

Requirement

The radio-operated key is within reception range.



- There are **two** ways to activate the ignition.

Version 1:

- Briefly press button **1**.
 - » Parking lights and all function circuits are switched on.
 - with LED additional headlight^{OA}
 - » LED auxiliary headlights are switched on.<
 - » Pre-Ride-Check is carried out. (▮▮▮▮▶ 113)
 - » ABS self-diagnosis is performed. (▮▮▮▮▶ 114)
 - » DTC self-diagnosis is performed. (▮▮▮▶ 114)


Version 2:

- Steering lock is engaged, press and hold button **1**.
 - » Steering lock is unlocked.
 - » Parking lights and all function circuits switched on.
 - » Pre-Ride-Check is carried out. (▮▮▮▮▶ 113)
 - » ABS self-diagnosis is performed. (▮▮▮▮▶ 114)
 - » DTC self-diagnosis is performed. (▮▮▮▶ 114)

Switch off ignition

Requirement

Key remote is within reception range.



- The ignition can be deactivated in **two** ways.

Version 1:

- Briefly press button **1**.
 - » Light is switched off.
 - » Handlebars are not locked.

Version 2:

- Turn handlebars to left.
- Press and hold button **1**.
 - » Light is switched off.
 - » Steering lock is locked.


Battery of the radio-operated key is drained or the radio-operated key is lost

- If you lose your keys, refer to the notes regarding the electronic immobilizer (**EWS**).
- Should you loose the radio-operated key while riding, the motorcycle can be started by using the spare key.
- If the battery in the radio-operated key is drained, the vehicle can be started by simply dipping the folded-in radio-

operated key into the ring antenna under the seat.



- Removing seat (➡ 72).
- Insert spare key or the dead folded-in radio-operated key **1** into the ring antenna **2**.

 The spare key or dead folded-out radio-operated key must be **inserted** into the opening of the ring antenna.



Period in which the engine must be started. Then unlocking must be repeated.

30 s


- » Pre-Ride-Check is carried out.
 - Key has been detected.
 - Engine can be started.
- Starting the engine (➡ 112).

54 OPERATION

Replacing the battery of the radio-operated key

If the radio-operated key does not respond when a button is pressed for a short or long time:

- The battery for the radio-operated key is not charged to full capacity.

 Remote key battery low. Limited central locking function. Change battery.

- Replace battery.



- Press button **1**.
 - » Key bit folds open.
- Press battery cover **2** upward.
- Remove battery **3**.
- Dispose of the old battery in accordance with legal regulations. Do not dispose of the battery in the household waste.

ATTENTION

Unsuitable or improperly inserted batteries

Component damage

- Use a battery compliant with the manufacturer's specifications.
- When inserting the battery, make sure that the polarity is correct.

- Insert the new battery with the positive terminal facing upwards.

 Battery type

For Keyless Ride radio-operated key


CR 2032

- Install battery cover **2**.
 - » Red LED in instrument cluster flashes.
 - » The radio-operated key is working again.

EWS ELECTRONIC IMMOBILIZER

The motorcycle's electronics monitor the data stored in the ignition key through a ring antenna incorporated in the ignition lock/wireless lock. The engine control unit does not enable an engine start until the ignition key has been recog-

nized as "authorized" for your motorcycle.

 An additional ignition key attached to the same ring as the ignition key / radio-operated key used to start the engine could "irritate" the electronics, in which case the enabling signal for an engine start is not issued.

Always store further vehicle keys separately from the ignition key / radio-operated key.

If you lose an ignition key, you can have it disabled by your BMW Motorrad retailer. When having a radio-operated key disabled you should also bring all of the motorcycle's remaining keys with you.

The engine can no longer be started using a disabled ignition key; however, a disabled ignition key can be enabled again.

Ignition keys can only be obtained from an authorized BMW Motorrad retailer. The keys are part of an integrated safety system, so the retailer is under an obligation to check the legitimacy of all applications for replacement/extra ignition keys.

EMERGENCY-OFF SWITCH



1 Emergency-off switch



WARNING


Operation of the emergency ON/OFF switch when riding

Danger of falling due to blocking of rear wheel

- Do not operate the emergency ON/OFF switch when riding.

The engine can be switched off easily and quickly using the emergency-off switch.

56 OPERATION




- A** Engine is switched off
B Operating position

LIGHTS


Low beams and parking lights

The parking lights come on automatically when the ignition is switched on.

 The parking lights are a strain on the battery. Do not leave the ignition switched on longer than absolutely necessary.

The low beams come on automatically under the following conditions:

- If the engine starts.
- If the vehicle is pushed while the ignition is on.

 With the engine switched off, you can switch on the lights by switching on the high-beam headlight with the ignition switched on or by operating the headlight flasher.

High beams and headlight flasher

- Switching on the ignition (▶▶ 50).



- Press switch **1** forward to switch on high beams.
- Pull switch **1** toward rear to actuate headlight flasher.

Headlight courtesy delay feature

- Switch off the ignition.



- Immediately after turning off the ignition, pull switch **1** back and hold until the headlight courtesy delay feature turns on.

- » The vehicle lights light up for one minute and then turn off automatically.
- This can be used, for example, to illuminate the path to your front door after the vehicle is parked.

Parking lights

- Switch off ignition (→ 51).





- Immediately after switching off the ignition, push button **1** to left and hold it until the parking lamps come on.
- Switch ignition on and then off again to switch off the parking lights.

HAZARD WARNING FLASHER

Operating the hazard warning lights

- Turn on the ignition.

 The hazard warning flashers place a strain on the battery. Do not use the hazard warning flashers for longer than absolutely necessary.

 If a turn indicator button is pressed when hazard warning lights are on, the turn indicator function replaces the hazard warning light function for the duration of turn indicator operation. Once the turn indicator button is no longer being pressed, the hazard warning light function will resume.



- Press button **1** to switch on the hazard warning lights.
- » Ignition can be switched off.
- To switch off the hazard warning flasher, switch on the ignition, as required, and press button **1** once again.

TURN INDICATORS

Operating turn indicators

- Turn on the ignition.

58 OPERATION



- Press button **1** to the left to switch on the left-side turn indicators.
- Press button **1** to the right to switch on the right-side turn indicators.
- Move button **1** to center position to switch off turn indicators.

Comfort turn indicators



When button **1** is pushed to the right or left, the turn indicators automatically turn off under the following conditions:


- Speed is under 18 mph (30 km/h): after distance of 165 ft (50 m) is covered.
- Speed is between 18 mph and 60 mph (30 km/h and 100 km/h): after a speed-dependent distance is covered or during acceleration.
- Speed is above 60 mph (100 km/h): after turn indicator flashes five times.

When button **1** is pushed to the right or left and held slightly longer, the turn indicators will only turn off automatically after the speed-dependent distance is covered.

TRACTION CONTROL (DTC)

Switching off DTC

- Turn on the ignition.

 The Dynamic Traction Control (DTC) can also be deactivated while riding.



- Press and hold button **1** until the DTC indicator light changes its behavior. Immediately after pressing button **1**, the DTC system status **ON** is displayed.



lights up.

Possible DTC system status **OFF!** is displayed.

- Release button **1** after changeover of the status.



continues to light up.

The new DTC system status **OFF!** is displayed for a short time.

- » The DTC function is switched off.

Switching on DTC



- Press and hold button **1** until the DTC indicator light changes its behavior. Immediately after pressing button **1**, the DTC system status **OFF!** is displayed.



goes out, and if self-diagnosis has not been completed, it begins to flash.

Possible DTC system status **ON** is displayed.

- Release button **1** after changeover of the status.



remains off or continues to flash.

The new DTC system status **ON** is displayed for a short time.

- » The DTC function is switched on.
- As an alternative, the ignition can also be switched off and then on again.

60 OPERATION



If the DTC indicator light lights up after switching the ignition off and on and then continuing to ride at the following minimum speed, a DTC fault has occurred.

min 3 mph (min 5 km/h)

- More detailed information on the Dynamic Traction Control can be found in the Technology in detail (►► 135) chapter.

ELECTRONIC CHASSIS AND SUSPENSION ADJUSTMENT (D-ESA)

—with Dynamic ESA^{OE}


Adjustment options

Using the electronic suspension adjustment Dynamic ESA, you can adjust the damping on the rear wheel comfortably to the road surface. Three damper settings and three spring preload steps are available.

Displaying chassis and suspension adjustment



- Switching on the ignition (►► 50).
- Press button **1** briefly to display current setting.



Immediately after pressing the button **1**, the chassis and suspension adjustment options for damping **2** and spring preload **3** are displayed.


- » The display automatically disappears again after a short time.

Adjusting the suspension

- Switching on the ignition (➡ 50).



- Press button **1** briefly to display current setting.
- To adjust the damping rate:
- Repeatedly press button **1** briefly until the desired setting is displayed.

 The damping cannot be adjusted while the motorcycle is being ridden.



The selection arrow **4** is displayed.

- » The selection arrow **4** goes away after the changeover of the status.

The following settings are available:


- Road: damping for comfortable road travel
- Dynamic: damping for dynamic road travel
- Enduro: damping for off-road riding. Only available in the riding modes **ENDURO** or **ENDURO PRO**, and cannot be further adjusted in these riding modes.

A message is output if no adjustments are possible in the selected riding mode. Example: In **ENDURO** riding mode damp. not adjustable.



To adjust the spring preload:

- Starting the engine (➡ 112).
- Repeatedly press and hold button **1** until the desired setting is displayed.

 The spring preload cannot be adjusted while the motorcycle is being ridden.

62 OPERATION

The following settings are available:



One-up




One-up with luggage



Two-up (with luggage)

The following message is displayed if no setting is possible: Load adjust. only avail. when halted.



The selection arrow **4** is displayed.

- » The selection arrow **4** goes away after the changeover of the status.
- Wait for the adjustment routine to finish before starting off again.
- » If the button **1** is not pressed for an extended period, the damping action and the spring preload will be

adjusted to the displayed settings.

RIDING MODE

Use of the riding modes

BMW Motorrad has developed riding scenarios for your motorcycle from which you can select the one matching your situation:

Standard


- RAIN: Riding on roads that are slick from rain.
- ROAD: Riding on dry roads.

–with riding modes Pro^{OE}

With Pro riding modes

- DYNAMIC: Dynamic riding on dry roads.
- ENDURO: For off-road riding with road tires.
- ENDURO PRO: riding off-road with coarse-tread off-road tires.

The optimum interaction between engine characteristics, ABS control, and DTC control is provided for each of these scenarios.

 You can find more detailed information regarding the selectable riding modes in the "Technology in detail" chapter.

–with Dynamic ESA^{OE}
The chassis and suspension adjustments can also be adapted in the selected scenario.

Riding mode preselection

–with riding modes Pro^{OE}
With the aid of the riding mode preselection, individually preferred riding modes can be compiled in a preselection. Two to a maximum of four riding modes can be added to the riding mode preselection. Factory setting: RAIN, ROAD, DYNAMIC and ENDURO

Configuring the riding mode preselection

–with riding modes Pro^{OE}

- Switching on the ignition (➡ 50).
- Go to menu Settings, Vehicle settings, Riding mode preselection.
- Activate or deactivate riding modes for the riding mode preselection.
 - » The activated riding modes are available for selection.
 - » If fewer than two riding modes are activated, the following message appears: Action not possible. Min. number reached.
 - » If more than four riding modes are activated, the

following message appears:

Action not possible.

Max. number reached.


- » The compilation of the riding modes in the riding mode preselection is retained, even after the ignition is switched off.

Select riding mode

- Switching on the ignition (➡ 50).



- Press button 1.



The active riding mode 2 fades into the background and is displayed in pop-up 3. The guide 4 shows how many riding modes are available.

64 OPERATION




ATTENTION

Turning on off-road mode (ENDURO and ENDURO PRO) when in road mode

Risk of falling due to unstable riding conditions when braking or accelerating in the ABS or DTC control range

- Switch on off-road mode (ENDURO and ENDURO PRO) during off-road riding only.
- Press button **1** repeatedly until the desired riding mode is shown in the pop-up.

 Depending on the riding mode or its configuration, the intervention of electronic stability control systems can be restricted.

Possible restrictions are displayed as a pop-up message, e.g. Caution! ABS & DTC setting..

You can find more detailed information regarding electronic stability control systems such as ABS and DTC in the "Technology in detail" chapter.

- with riding modes Pro^{OE}
- » The availability of the riding modes depends on the individual configuration of the riding mode preselection.<
- » When at a vehicle standstill, the selected riding mode is activated after approx. 2 seconds.
- » The new riding mode is activated while the vehicle is in motion under the following conditions:
 - Throttle grip is at neutral.
 - Brake is not engaged.
 - Adaptive cruise control is deactivated.
- » The riding mode selected and its associated engine characteristics ABS, DTC and Dynamic ESA are retained even after the ignition has been switched off.

PRO RIDING MODE

- with riding modes Pro^{OE}

Adjustment options

The PRO riding modes can be adjusted individually.

Configuring the riding mode ENDURO PRO

- Switching on the ignition (➡ 50).
- Go to menu Settings, Vehicle settings, Riding mode preselection.
- Select and activate ENDURO PRO riding mode.
- Select Configuration and confirm.



The Engine system is selected. The current setting is displayed as a diagram **1** with explanations on the system **2**.

- Select and confirm the system.



You can browse through the possible settings **3** and the related descriptions **4**.

- Adjust the system.
 - » The Engine, DTC and ABS systems can all be adjusted in the same way.
- The settings can be reset to factory settings:
- Riding mode settings reset (➡ 65).

Riding mode settings reset


- Configuring the ENDURO PRO (➡ 65).
- Select and confirm Reset.
 - » The following factory settings apply for ENDURO PRO riding mode:
 - DTC: ENDURO PRO
 - ABS: ENDURO PRO
 - Engine: ROAD

66 OPERATION

ADAPTIVE CRUISE CONTROL

–with speed control^{OE}

Display while adjusting (Speed Limit Info not active)



The symbol **1** for the adaptive cruise control is displayed in the Pure Ride view and in the upper status line.

Display while adjusting (Speed Limit Info active)




The symbol **1** for the adaptive cruise control is displayed in the Pure Ride view and in the upper status line.

Switching on the adaptive cruise control


Requirement

Adaptive cruise control only becomes available after changing out of the riding modes Enduro or Enduro Pro.




- Slide switch **1** to the right.
- » Button **2** can be operated.


Storing speed



- Briefly push button **1** forward.


 Adjustment range of the adaptive cruise control

19...130 mph (30...210 km/h)

 The indicator light for adaptive cruise control illuminates.


- » The motorcycle maintains your current cruising speed and the setting is saved.

Accelerating



- Briefly push button **1** forward.
 - » Speed is increased by 1 mph (1.6 km/h) each time the button is pressed.
- Press button **1** forward and hold.
 - » The speed increases steplessly.
 - » If button **1** is no longer pressed, the speed reached is maintained and saved.

Decelerating




- Briefly press button **1** backward.


- » Speed is reduced by 1 mph (1.6 km/h) each time the button is pressed.
- Press button **1** back and hold.
 - » The speed is reduced continuously.
 - » If button **1** is no longer pressed, the speed reached is maintained and saved.

Deactivating the adaptive cruise control

- Actuate the brakes, coupling or throttle grip (ease the throttle beyond the default setting) to deactivate the adaptive cruise control.
 - » The indicator light for adaptive cruise control goes out.


Resuming previous cruising speed



- Briefly push button **1** back to return to the speed saved beforehand.
-  Cruise control is not deactivated by accelerating. If you release the throttle grip, the motorcycle will decelerate.

68 OPERATION

ate only to the cruising speed saved in memory, even though you might have wanted to slow down to a lower speed.

 The indicator light for adaptive cruise control illuminates.

Switching off the adaptive cruise control



- Push switch **1** to the left.
 - » The system is switched off.
 - » Button **2** is locked.


ANTI-THEFT ALARM SYSTEM (DWA)

Activation

–with anti-theft alarm system (DWA)^{OE}

- Switching on the ignition (☛ 50).
- Adjusting the anti-theft alarm system (☛ 70).
- Switch off the ignition.
 - » If DWA is activated, DWA is automatically activated after the ignition is switched off.

- » Activation takes approximately 30 seconds to complete.
 - » Turn indicators are illuminated twice.
 - » Confirmation tone sounds twice (if programmed).
 - » The anti-theft alarm system is active.
- with Keyless Ride^{OE}



- Switch off the ignition.
- Press button **1** on the radio-operated key twice.
 - » Activation takes approximately 30 seconds to complete.
 - » Turn indicators are illuminated twice.
 - » Confirmation tone sounds twice (if programmed).
 - » The anti-theft alarm system is active.



- To deactivate the movement sensor (for example if you are about to transport the motorcycle on a train and the swaying movement of the moving train could trip the alarm signal), press button **1** on the radio-operated key during the activation phase.
 - » Turn indicators are illuminated three times.
 - » Confirmation tone sounds three times (if programmed).
 - » Movement sensor is deactivated.◁

Alarm signal

–with anti-theft alarm system (DWA)^{OE}

The DWA alarm signal can be set off by:


- Motion sensor
- Switch-on attempt with an unauthorized ignition key.
- Disconnecting the DWA from the vehicle battery (DWA battery takes over the power

supply – alarm tone only, turn indicators do not flash)

If the DWA battery is discharged all functions remain operational; the only difference is that the alarm cannot be set off if the system is disconnected from the motorcycle battery.

The duration of the alarm signal is approx. 26 seconds. During the alarm, an alarm tone sounds and the turn indicators flash. The type of alarm sound can be set by an authorized BMW Motorrad retailer.

–with Keyless Ride^{OE}



A triggered alarm signal can be canceled at any time by pressing the button **1** of the radio-operated key without deactivating the DWA.

70 OPERATION

If an alarm was activated while the motorcycle was unattended, the rider is notified accordingly by an alarm tone sounding once when the ignition is switched on. The DWA LED then indicates the reason for the alarm for one minute.


Light signals on DWA LED:

- 1 flash: motion sensor 1
- 2 flashes: motion sensor 2
- 3 flashes: ignition turned on with unauthorized ignition key
- 4 flashes: anti-theft alarm system disconnected from vehicle battery
- 5 flashes: motion sensor 3


Deactivation

- with anti-theft alarm system (DWA)^{OE}
- Switching on the ignition (☰▶ 50).
 - » Turn indicators are illuminated once.
 - » Confirmation tone sounds once (if programmed).
 - » The anti-theft alarm system is turned off.

- with Keyless Ride^{OE}



- Press button **1** of the radio-operated key once.

 If the alarm function is deactivated using the radio-operated key and the ignition is not then switched on, it will reactivate automatically after 30 seconds if "activation after ignition off" is programmed.

- » Turn indicators are illuminated once.
- » Confirmation tone sounds once (if programmed).
- » The anti-theft alarm system is turned off.◀

Adjusting the anti-theft alarm system

- with anti-theft alarm system (DWA)^{OE}
- Switching on the ignition (☰▶ 50).
- Call up the Settings, Vehicle settings, Alarm system menu.

» The following adjustments are available:

- Adapt Warning signal
- Switch Tilt sensor on and off
- Switch Arming tone on and off
- Switch Arm automatically on and off


» Adjustment options (▶▶▶ 71)

Adjustment options

- with anti-theft alarm system (DWA)^{OE}

Warning signal: Set rising and falling or intermittent alarm tone.

Tilt sensor: Activate the tilt alarm sensor to monitor the tilt of the vehicle. The anti-theft alarm system responds if, for example, if the wheel is stolen or the motorcycle is towed.

 Deactivate the tilt sensor when transporting the vehicle to avoid triggering the DWA.

Arming tone: Confirmation alarm tone after activating/deactivating the DWA in addition to flashing turn indicators.

Arm automatically: Automatic activation of the alarm function when the ignition is turned off.

Factory settings

The anti-theft alarm system is delivered with the following factory settings:

- Confirmation alarm tone after activation/deactivation of the DWA: no.
- Alarm tone: rising.

TIRE PRESSURE CONTROL (RDC)

- with tire pressure monitor (TPM)^{OE}
- with riding modes Pro^{OE}

Switching setpoint pressure warning on or off


- When the minimum tire pressure is reached, a target pressure warning can be displayed.
- Call up the Settings, Vehicle settings, RDC menu.
- Switch Target pressure warn. on or off.

HEATED GRIPS


- with heated grips^{OE}


Operating heated grips

- Starting the engine (▶▶▶ 112).

 The heated grips option can only be activated when the engine is running.

72 OPERATION

 The increase in power consumption caused by the heated grips can drain the battery if you are riding at low engine speeds. If the battery is inadequately charged, the heated grips are switched off to ensure starting capability.



- Press the button **1** repeatedly until the desired heating level **2** is shown in front of the heated grip icon **3**. The handlebar grips can be heated at three different levels. High heater output is used for fast heating of the grips; the switch should then be switched back to a lower heater output.



High heater output



Medium heater output




Low heater output

- » If no further changes are made, the selected heating level is set.
- To switch off the heated grip, press button **1** repeatedly until heated grip icon **3** is not shown anymore in the display.


SEAT

Removing seat Requirement

Motorcycle is parked, ensuring that support surface is firm and level.




- Turn the ignition key clockwise in the seat lock **1**.
- » Seat bench is unlocked.



- Press the seat bench **2** in direction of arrow **4** out of the brackets **3**.
- Remove seat bench in direction of arrow **5** and place on the rubber buffers on a clean surface.

Installing seat



- Push seat bench **2** in direction of arrow **4** into the brackets **3**.
- Forcibly push seat bench in direction of arrow **5**.
 - » The seat bench will audibly engage.

TFT DISPLAY

05

GENERAL NOTES	76
PRINCIPLE	77
PURE RIDE VIEW	83
GENERAL SETTINGS	84
BLUETOOTH	86
MY VEHICLE	89
ONBOARD COMPUTER	92
NAVIGATION	92
MEDIA	94
PHONE	95
DISPLAYING SOFTWARE VERSION	96
DISPLAYING LICENSE INFORMATION	96

76 TFT DISPLAY

GENERAL NOTES

Warnings

WARNING

Operation of a smartphone while riding or with the engine running

Accident hazard

- Observe the relevant road traffic regulations.
- Do not use while riding (except for applications without operation such as telephony via the hands-free system).

WARNING


Distraction from traffic conditions and loss of control


Risk of accident through the use of integrated information systems and communication devices during the journey

- Operate these systems or devices only if the traffic situation allows.
- If necessary, stop and operate the system or devices at a standstill.

Connectivity functions


Connectivity functions include media, telephony and navigation. Connectivity functions can be used if the TFT display is connected with a mobile end device and a helmet (☞ 86). You can find more information about the Connectivity functions at: bmw-motorrad.com/connectivity

 If the fuel tank is between the mobile end device and the TFT display, the Bluetooth connection may be restricted. BMW Motorrad recommends storing the mobile end device above the fuel tank (e.g. in the jacket pocket).

 Depending on the mobile end device, the scope of the Connectivity functions may be limited.

BMW Motorrad Connected App

With the BMW Motorrad Connected App, you can call up information about the vehicle and usage. To use some features such as navigation, the app must be installed on the mobile end device and be connected to the TFT display. The app starts the route guidance and adapts the navigation.

 On some mobile devices, e.g. with operating system iOS, the BMW Motorrad Connected App must be called up before using.


Notice concerning current status

After the editorial deadline, there may be updates to the TFT display. For this reason, some aspects of your motorcycle may vary from the descriptions in these Operating Instructions. Updated information at:

bmw-motorrad.com/service

PRINCIPLE

Operating elements



All contents of the display are controlled by the Multi-Controller **1** and the rocker button **MENU 2**.

The following functions are possible depending on the context.

Functions of the Multi-Controller

Turn the Multi-Controller up:

- Move the mouse pointer up in lists.
- Make settings.
- Increase volume.

Turn the Multi-Controller down:

- Move the mouse pointer down in lists.
- Make settings.
- Reduce volume.

Tilt Multi-Controller to the left:


- Activate the function according to the Check Control messages.
- Activate function to the left or back.
- After settings, return to menu view.
- In the menu view: move up one hierarchy level.
- In the My Vehicle menu: leaf to the next menu sheet.

Tilt Multi-Controller to the right:

- Confirm selection.
- Confirm settings.
- Leaf to the next menu step.
- Scroll to right in lists.
- In the My Vehicle menu: leaf to the next menu sheet.

78 TFT DISPLAY

Rocker button MENU functions

 Navigation instructions are displayed as a dialog if the Navigation menu has not been called up. Operation of the MENU rocker button is temporarily restricted.

Briefly press the MENU up:

- In the menu view: move up one hierarchy level.
- In the Pure Ride view: Change display for rider info. status line.

MENU long press up:

- In the View menu: Open Pure Ride view.
- In the Pure Ride view: change the operating focus to the navigator.


MENU short press down:

- Change a hierarchy level down.
- No function when lowest hierarchy level is reached.


MENU long press down:

- Return to the last menu, after a menu change has been previously carried out by long press of the rocker button MENU at the top.

Operating instructions in the main menu



The operating instructions indicate whether and which interactions are possible.




Meaning of the operating instructions:

- Operating instruction 1: the left end has been reached.
- Operating instruction 2: you can leaf to the right.
- Operating instruction 3: you can leaf down.
- Operating instruction 4: you can leaf to the left.
- Operating instruction 5: the right end has been reached.

Operating instructions in submenus

In addition to the operating instructions in the main menu, there are additional operating instructions in submenus.



Meaning of the operating instructions:

- Operating instructions **1**: the current display is in a hierarchical menu. The number of icons indicates up to three submenu levels. The color of the icon changes depending on whether it is possible to return to the top.
- Operating instructions **2**: another submenu level can be called up.
- Operating instructions **3**: there are more entries than can be displayed.

Show Pure Ride view

- Press and hold the top MENU rocker button.

Switching functions on and off




Some items are preceded by a box. The box indicates whether the function is switched on or off. Action symbols after the menu items illustrate what is switched by briefly tilting the Multi-Controller to the right.

Examples for switching on and off:

- Symbol **1** indicates that the function is switched on.
- Symbol **2** indicates that the function is switched off.
- Symbol **3** indicates that the function can be switched off.
- Symbol **4** indicates that the function can be switched on.

80 TFT DISPLAY

Calling up the menu




- Show Pure Ride view (▬▬▬ 79).
- Briefly press button **2** downward.


The following menus can be called up:

- My vehicle
- Navigation
- Media
- Telephone
- Settings

- Press Multi-Controller **1** repeatedly briefly to the right until the desired menu item is marked.
- Briefly press button **2** downward.


 The Settings menu can only be called up when stationary.

Moving the mouse pointer in lists



- Calling up the menu (▬▬▬ 80).
- To move the mouse pointer down in lists, turn the Multi-Controller **1** down until the desired entry is marked.
- To move the mouse pointer up in lists, turn the Multi-Controller **1** up until the desired entry is marked.

Confirming the selection



- Select desired entry.
- Multi-Controller **1** short press to right.

Calling up the last menu used

- In the Pure Ride view: press and hold the bottom of the MENU rocker button.
- » The last used menu is called up. The last marked entry is selected.

Changing operating focus

—with preparation for navigation system^{OE}

When the Navigator is connected, you can switch between the operation of the Navigator and the TFT display.


Changing the operating focus

—with preparation for navigation system^{OE}

- Securely fastening navigation device (▮▮▮ 196).
- Show Pure Ride view (▮▮▮ 79).
- Press and hold the top MENU rocker button.
- » Operating focus changes to the Navigator or the TFT display. The active device is marked in the upper left status line. Operating actions affect the active device until the operating focus is changed again.
- » Operating the navigation system (▮▮▮ 197)

System status displays

The system status is displayed in the lower menu area when a function has been switched on or off.



Example of the meaning of the system statuses:

—System status **1**: DTC function is turned on.

Changing the display for rider info. status line

Requirement

The vehicle is at a standstill. The Pure Ride view is displayed.

- Switching on the ignition (▮▮▮ 50).
- » All of the information necessary for operating the vehicle on public roads is made available from the on-board computer (e.g. TRIP **1**) and the travel on-board computer (e.g. TRIP **2**) in the TFT display. The information can be dis-


82 TFT DISPLAY

played in the upper status line.

–with tire pressure monitor (TPM)^{OE}

» In addition, information from the RDC can be displayed.<

• Selecting content of driver info. status line (▶▶ 82).




- Press and hold button **1** to display the Pure Ride view.
- Press button **1** briefly to select the value in the upper status line **2**.


The following values can be displayed:


–Odometer Total


–Trip distance 1 TRIP 1

–Trip distance 2 TRIP 2

 Average consumption 1


 Average consumption 2


 Riding time 1


 Riding time 2


 Break 1

 Break 2

 Average speed 1

 Average speed 2

 Tire pressure


 Fuel gauge

 Range

Selecting content of driver info. status line

- Call up menu Settings, Display, Status line content.
- Turn on desired displays.
 - » It is possible to change between the selected displays in the driver info. status line. If no displays are selected, only the range is shown.

Making settings



- Select desired settings menu and confirm.
 - Turn Multi-Controller **1** down until the desired setting is marked.
 - If operating instructions are present, tilt Multi-Controller **1** to the right.
 - If no operating instructions are present, tilt Multi-Controller **1** to the left.
- » The setting is saved.

Switching Speed Limit Info on or off

Requirement


The vehicle is connected to a compatible mobile end device. The BMW Motorrad Connected app is installed on the mobile end device.

- Speed Limit Info displays the currently permitted maximum speed insofar as this information is provided by the editor of the maps in the navigation system.

- Call up menu Settings, Display.
- Switch Speed Limit Info on or off.

PURE RIDE VIEW

Tachometer



- 1** Scale
- 2** Low engine speed range
- 3** High / red engine speed range
- 4** Needle
- 5** Drag pointer
- 6** Unit for tachometer: 1000 RPM

84 TFT DISPLAY

Range



The range **1** indicates how far you can ride with the remaining fuel. This distance is calculated on the basis of average consumption and the quantity of fuel on board.

–When the motorcycle is propped on its side stand the slight angle of inclination means that the sensor cannot register the fuel level correctly. For this reason, the range is only recalculated when the side stand is folded in.

–The range is displayed together with a warning once the fuel reserve is reached.

–After refueling, the range is recalculated if the fuel quantity is greater than the fuel reserve.

–The calculated range is only an approximate figure.

Upshift recommendation



The upshift recommendation in the Pure Ride **1** view or in the status line **2** indicates the best time for an upshift from an economical perspective.

GENERAL SETTINGS

Adjusting the volume

- Connect the rider's helmet and the passenger helmet (▶▶▶ 88).
- Increase volume: turn Multi-Controller up.
- Reduce volume: turn Multi-Controller down.
- Mute: turn Multi-Controller all the way down.

Setting the date

- Switching on the ignition (▶▶▶ 50).
- Call up menu Settings, System settings, Date and time, Set date.
- Set Day, Month, and Year.
- Confirm setting.

Adjusting the date format

- Call up menu Settings, System settings, Date and time, Date format.
- Select desired setting.
- Confirm setting.

Setting the clock

- Switching on the ignition (▣▣▣▣▶ 50).
- Call up menu Settings, System settings, Date and time, Set time.
- Set Hour and Minute.

Setting the time format

- Call up menu Settings, System settings, Date and time, Time format.
- Select desired setting.
- Confirm setting.

Switch GPS synchronization on or off

–with preparation for navigation system^{OE}

- Call up menu Settings, System settings, Date and time.
- Turn GPS synchronization on or off.
- » When the corresponding option is activated in the Navigator, the time is taken from the Navigator.
- » Special functions (▣▣▣▣▶ 200)

Setting the units of measurement

- Call up menu Settings, System settings, Units.
- The following units of measurement can be set:
- Distance covered
 - Pressure
 - Temperature
 - Consumption

Setting the language

- Call up menu Settings, System settings, Language.
- The following languages can be set:
- German
 - English (UK)
 - English (US)
 - Spanish
 - French
 - Italian
 - Dutch
 - Polish
 - Portuguese
 - Turkish
 - Russian
 - Ukrainian
 - Chinese
 - Japanese
 - Korean
 - Thai

Adjusting brightness

- Call up menu Settings, Display, Brightness.
- Adjust brightness.

86 TFT DISPLAY

» The brightness of the display is dimmed to the set value if ambient brightness falls below a defined value.

Resetting all settings

- All settings in the `Settings` menu can be reset to the factory settings.
- Call up menu `Settings`.
- Select `Reset all` and confirm.

The settings of the following menus are reset:

- Vehicle settings
- System settings
- Connections
- Display
- Information

» Existing Bluetooth connections are not deleted.

BLUETOOTH

Short-range radio technology

The Bluetooth function may not be offered depending on the country of use.

Bluetooth is a short-range wireless technology. Bluetooth devices are short-range devices (transmitting with a limited range) on the license-free ISM band (Industrial, Scientific, Medical) between 2.402 GHz and 2.480 GHz. They can be operated anywhere in the

world without a license being required.

Although Bluetooth is designed for establishing robust connections over short distances, faults are possible as with any other wireless technology. Connections can be subject to interference, can be briefly interrupted or lost entirely. Especially when several devices are operated in one Bluetooth network, there is no guarantee for smooth operation in every situation.


Possible sources of interference:

- Interference fields due to transmission towers and similar.
- Devices with incorrectly implemented Bluetooth radio standard.
- By nearby Bluetooth-capable devices.

Pairing

Before two Bluetooth devices can establish a connection with each other, they must have identified each other. This process of mutual recognition is known as pairing. When two devices have paired they remember each other, so the

pairing process is conducted only once, on initial contact.

 On some mobile devices, e.g. with operating system iOS, the BMW Motorrad Connected App must be called up before using.

During the pairing process, the TFT display searches for other Bluetooth-compatible devices within its reception range. The conditions that have to be satisfied before the audio system can identify another device are as follows:

- The Bluetooth function of the device must be enabled
- The device must be "visible" to others
- The device must support the A2DP profile
- Other Bluetooth-capable devices must be switched off (e.g. mobile phones and navigation systems).

Please consult the operating instructions for your communication system.

Pairing


- Call up menu *Settings, Connections*.
- » Bluetooth connections can be established, managed, and deleted in the CONNECTIONS menu. The following Blue-

tooth connections are displayed:

- Mobile device
- Rider's helmet
- Passenger helm.

The connection status for mobile end devices is displayed.

Connecting a mobile end device

- Pairing ( 87).
 - Activate the Bluetooth function of the mobile end device (see operating instructions for the mobile end device).
 - Select *Mobile device* and confirm.
 - Select *Pair new mobile device* and confirm.
- Mobile end devices are searched for.



During the pairing, the Bluetooth symbol flashes in the lower status line.

Visible mobile end devices are displayed.


- Select the mobile end device and confirm.
- Observe the instructions for the mobile end device.
- Confirm that the codes match.
- » The connection is established and the connection status is updated.
- » If the connection cannot be established, the troubleshooting chart in the Technical data

88 TFT DISPLAY

- chapter may provide assistance. (▣▣▣ 210)
- » Depending on the mobile end device, telephone data is transferred to the vehicle automatically.
 - » Telephone data (▣▣▣ 96)
 - » If the phone book is not displayed, the troubleshooting chart in the Technical data chapter may provide assistance. (▣▣▣ 211)
 - » If the Bluetooth connection does not work as expected, the troubleshooting chart in the Technical data chapter may provide assistance. (▣▣▣ 211)

Connect the rider's helmet and the passenger helmet

- Pairing (▣▣▣ 87).
- Select *Rider's helmet* or *Passenger helm.* and confirm.
- Show the communication system of the helmet.
- Select *Pair new rider's helmet* or *Pair new passenger helmet* and confirm. Helmets are searched for.


 During the pairing, the Bluetooth symbol flashes in the lower status line.

- Visible helmets are displayed.
- Select helmet and confirm.

- » The connection is established and the connection status is updated.
- » If the connection cannot be established, the troubleshooting chart in the Technical data chapter may provide assistance. (▣▣▣ 210)
- » If the Bluetooth connection does not work as expected, the troubleshooting chart in the Technical data chapter may provide assistance. (▣▣▣ 211)

Deleting connections


- Call up menu *Settings, Connections.*
- Select *Delete connections.*
- To delete an individual connection, select the connection and confirm.
- To delete all connections, select *Delete all connections* and confirm.

MY VEHICLE**Start screen**

- 1 Check Control display (▶▶▶▶ 25)
- 2 Coolant temperature (▶▶▶▶ 35)
- 3 Range (▶▶▶▶ 84)
- 4 Total mileage
- 5 Service display (▶▶▶▶ 45)
- 6 Rear tire pressure (▶▶▶▶ 159)
- 7 Vehicle voltage (▶▶▶▶ 178)
- 8 Front tire pressure (▶▶▶▶ 159)


90 TFT DISPLAY

Operating instructions



- Operating instructions **1**: Tab that shows how far to the left or right you can leaf.
- Operating instructions **2**: Tab that shows the position of the current menu screen.


Scrolling through menu windows



- Call up the My vehicle menu.
- To scroll to the right, briefly push the Multi-Controller **1** to the right.
- To scroll to the left, briefly push the Multi-Controller **1** to the left.

The following screens are included in the My Vehicle menu:


- MY VEHICLE
- ONBOARD COMPUTER
- TRIP COMPUTER
- with tire pressure monitor (TPM) **OE**
- TIRE PRESSURE **<**
- SERVICE REQUIREMENTS
- CHECK CONTROL MESSAGE (if present)
- Further information on the tire pressure and Check Control messages can be found in the Displays (➡ 25) chapter.

 Check-Control messages are dynamically added to the menu screens in the My vehicle menu as additional tabs.

On-board computer and travel on-board computer

The ONBOARD COMPUTER and TRIP COMPUTER menu windows show the vehicle and journey data, e.g. average values.

Service display



If the time remaining until the next service is less than a month, or if the next service is due within 621 mi (1000 km), a white Check Control message is displayed.

92 TFT DISPLAY

ONBOARD COMPUTER

Calling up the on-board computer

- Call up the **My vehicle** menu.
- Scroll to the right until the **ONBOARD COMPUTER** menu panel is displayed.

On-board computer reset

- Calling up the on-board computer (▣▣▣ 92).
- Press **MENU** rocker button down.
- Select **Reset all values** or **Reset individual values** and confirm.

The following values can be reset individually:

- Break
- Journey
- Current (TRIP 1)
- Speed
- Consump.

Calling up the travel on-board computer

- Calling up the on-board computer (▣▣▣ 92).
- Scroll to the right until the **TRIP COMPUTER** menu panel is displayed.

Resetting the travel on-board computer

- Calling up the travel on-board computer (▣▣▣ 92).

- Press **MENU** rocker button down.
- Select **Automatic reset** or **Reset all values** and confirm.
 - » If **Automatic reset** is selected, the travel on-board computer is automatically reset if at least 6 hours have passed since the ignition was switched off and the date has changed.

NAVIGATION

Warnings



WARNING

Operation of a smartphone while riding or with the engine running

Accident hazard

- Observe the relevant road traffic regulations.
- Do not use while riding (except for applications without operation such as telephony via the hands-free system).



WARNING

Distraction from traffic conditions and loss of control

Risk of accident through the use of integrated information systems and communication devices during the journey

- Operate these systems or devices only if the traffic situation allows.
- If necessary, stop and operate the system or devices at a standstill.

Prerequisite

The vehicle is connected to a compatible mobile end device.

The BMW Motorrad Connected App is installed on the mobile end device.



On some mobile devices, e.g. with operating system iOS, the BMW Motorrad Connected App must be called up before using.

Enter destination address

- Connecting a mobile end device (➡ 87).
- Call up the BMW Motorrad Connected app and start the route guidance.
- Call up menu *Navigation* in the TFT display.

- » Active route guidance is displayed.
- » If the active route guidance is not displayed, the troubleshooting chart in the Technical data chapter may provide assistance. (➡ 211)

Select destination from most recent destinations

- Call up menu *Navigation*, *Recent destinations*.
- Select destination and confirm.
- Select *Start route guidance*.

Select destination from favorites

- The *FAVORITES* menu shows all destinations that have been saved as a favorite in the BMW Motorrad Connected app. It is not possible to create new favorites on the TFT display.
- Call up menu *Navigation*, *Favorites*.
- Select destination and confirm.
- Select *Start guidance*.

Entering special destinations

- Special destinations, e.g. landmarks, can be displayed on the map.

94 TFT DISPLAY

- Call up menu *Navigation*, *POIs*.

The following locations can be selected:

- At current location
- At destination
- Along the route
- Select in which location you want to search for special destinations.

E.g. the following special destination can be selected:

- Filling station
- Select special destination and confirm.
- Select *Start route guidance* and confirm.

Specifying route criteria

- Call up menu *Navigation*, *Route criteria*.

The following criteria can be selected:

- Route type
- Avoid
- Select desired *Route type*.
- Turn desired *Avoid* on or off.

The number of enabled avoidances is displayed in brackets.

Ending route guidance

- Call up menu *Navigation*, *Active route guidance*.
- Select *End route guidance* and confirm.

Switching spoken instructions on or off

- Connect the rider's helmet and the passenger helmet (▶▶▶ 88).
- The navigation can be read out by a computer voice. To do this, the *Spoken instructions* must be turned on.
- Call up menu *Navigation*, *Active route guidance*.
- Turn *Spoken instructions* on or off.

Repeating the last spoken instruction


- Call up menu *Navigation*, *Active route guidance*.
- Select *Current instruction* and confirm.


MEDIA


Prerequisite


The vehicle is connected to a compatible mobile end device and a compatible helmet.

Controlling audio playback



- Call up the **Media** menu.
-  **BMW Motorrad** recommends setting the volume for media and conversations via mobile end devices to the maximum before starting a journey.

- Adjusting the volume ( 84).
- Next title: Tilt the Multi-Controller **1** briefly to the right.
- Last title or start of current title: Tilt the Multi-Controller **1** briefly to the left.
- Fast forward: Tilt and hold the Multi-Controller **1** to the right.
- Fast rewind: Tilt and hold the Multi-Controller **1** to the left.
- Call up context menu: Press button **2** down.

 Depending on the mobile end device, the scope of the Connectivity functions may be limited.

» The following functions can be used in the context menu:

- Start playback or Pause playback.
- For search and playback, select the category **Now playing**, **All artists**, **All albums** or **All tracks**.
- Select **Playlists**.

In the submenu **Audio** options, you can adjust the following settings:


- Switch **Shuffle** on or off.
- Select **Repeat**: **Off**, **One** (current title) or **All**.

PHONE

Prerequisite

The vehicle is connected to a compatible mobile end device and a compatible helmet.

Making a phone call



- Call up the **Telephone** menu.
- Accept call: Tilt Multi-Controller **1** to the right.
- Reject call: Tilt Multi-Controller **1** to the left.

96 TFT DISPLAY

- End call: Tilt Multi-Controller **1** to the left.

Mute

The microphone in the helmet can be muted during active conversations.

Conversations with multiple users

A second telephone call can be accepted during a conversation. The first conversation will be put on hold. The number of active telephone calls is displayed in the Telephone menu. It is possible to switch between two conversations.

Telephone data

Depending on the mobile end device, telephone data is transferred to the vehicle automatically after pairing (☰➔ 86).

Phone book: List of contacts saved in the mobile end device
Call list: List of telephone calls with the mobile end device

Favorites: List of favorites saved in the mobile end device

DISPLAYING LICENSE INFORMATION

- Call up menu Settings, Information, Licenses.

DISPLAYING SOFTWARE VERSION

- Call up menu Settings, Information, Software version.

SETTING

06

MIRRORS	100
HEADLIGHT	100
WINDSHIELD	101
CLUTCH	101
BRAKE	102
SPRING PRELOAD	103
DAMPING	103

100 SETTING

MIRRORS

Adjusting mirrors



- Move mirrors into desired position by rotating.

Adjusting mirror arm



- Slide protective cap **1** up over screw connection on mirror arm.
- Loosen nut **2**.
- Turn mirror arm into desired position.
- Tighten nut to specified torque while holding mirror arm in place.



Mirror (locknut) on clamping piece

16 lb/ft (22 Nm) (Left-hand thread)

- Slide protective cap over screw connection.

HEADLIGHT

Headlight setting for right-hand/left-hand traffic


In countries where you must drive on the opposite side of the road from the country in which the vehicle was registered, the asymmetrical low-beam headlight dazzles oncoming traffic.

Have the headlights adapted to the relevant conditions by a specialist workshop, preferably by a BMW Motorrad retailer.

Headlight beam throw and spring preload

The headlight beam throw generally remains constant due to the adjustment of the spring preload to the load status.

Only with a very heavy payload can adjustment of the spring preload be insufficient. If that is the case, the headlight beam throw must be adapted to the weight.

 If there are doubts as to the correct headlight range, have the adjustment checked by a specialized workshop, preferably by an authorized BMW Motorrad retailer.

Adjusting the headlight beam throw



- Loosen the screws **1** on the left and right.
- Adjust the headlight by tilting slightly.
- Tighten the screws **1** on the left and right.

WINDSHIELD

Adjusting the windscreen Requirement

The motorcycle is stopped.



WARNING

Adjusting the windshield while driving

Accident hazard

- Only adjust the windshield when the motorcycle is stationary.

- Pull the lever **2** downward to raise the windscreen **1**.
- Push the lever **2** upward to lower the windshield **1**.

CLUTCH

Adjusting the clutch lever


WARNING

Adjusting the clutch lever while driving


Accident hazard

- Adjust the clutch lever when the motorcycle is stationary.

102 SETTING



- Turn the adjusting screw **1** clockwise to increase distance between clutch lever and handlebar grip.
- Turn the adjusting screw **1** counterclockwise to decrease distance between clutch lever and handlebar grip.

 The adjusting screw is easier to turn when the clutch lever is pressed forward.

BRAKE

Adjusting brake lever

WARNING

Modified position of the brake fluid reservoir

Air in the brake system


- Do not twist the handlebar fitting or the handlebars.

WARNING


Adjusting the brake lever while driving

Risk of accident

- Do not attempt to adjust the brake lever unless the motorcycle is at a standstill.



- Turn the adjusting screw **1** counterclockwise to increase the distance between the brake lever and handlebar grip.
- Turn the adjusting screw **1** clockwise to decrease the distance between the brake lever and handlebar grip.

 The adjustment screw is easier to turn when the brake lever is pressed forward.

SPRING PRELOAD


–without Dynamic ESA^{OE}

Setting

It is essential to set the spring preload at the rear wheel to suit the load carried by the motorcycle. Increase spring preload if the payload increases and reduce spring preload accordingly if the payload decreases.

Adjusting the spring preload on the rear wheel

- Removing seat (▶▶▶ 72).
- Remove toolkit.



WARNING

Uncoordinated settings of spring preload and spring strut damping.

Poorer handling.

- Adjust damping characteristic to changed spring preload.

- To increase spring preload, turn adjustment wheel **1** clockwise using toolkit.
- To decrease spring preload, turn adjustment wheel **1** counterclockwise using toolkit.



Basic setting of spring preload, rear

Turn adjustment wheel counterclockwise as far as possible. (One-up without load)

Turn adjuster wheel counterclockwise as far as possible, then 20 turns clockwise. (One-up with load)

Turn adjustment wheel clockwise as far as possible. (Two-up and load)

- Remount toolkit.
- Installing seat (▶▶▶ 73).

DAMPING

–without Dynamic ESA^{OE}

Setting

Damping must be adjusted to the road condition and the spring preload.

- A rough road requires softer damping than a smooth road.
- An increase in spring preload requires firmer damping, a reduction in spring preload requires softer damping.

104 SETTING

Adjusting the damping characteristic for rear wheel

- Park motorcycle on a level, firm surface.



- Adjust damping via the adjusting screw **1**.



- To increase damping, turn the adjusting screw **1** clockwise.
- To reduce damping, turn the adjusting screw **1** counter-clockwise.



Basic setting of rear wheel damping

Turn adjusting screw clockwise up to the stop, then turn back by 0.5 turns. (One-up with load)

Turn adjusting screw clockwise as far as possible, then back a quarter turn. (Two-up with load)



Basic setting of rear wheel damping

Turn adjusting screw clockwise up to the stop, then turn back by 1.5 turns. (One-up without load)

RIDING

07

SAFETY INSTRUCTIONS	108
REGULAR CHECK	111
STARTING	112
BREAKING IN	115
SHIFTING GEARS	116
OFF-ROAD USE	117
BRAKES	118
PARKING YOUR MOTORCYCLE	120
REFUELING	121
SECURING MOTORCYCLE FOR TRANSPORTATION	127

SAFETY INSTRUCTIONS

Rider's equipment

Do not ride without the correct clothing! Always wear

- Helmet
- Rider's suit
- Gloves
- Boots

This applies even to short journeys, and to every season of the year. Your authorized BMW Motorrad retailer will be happy to advise you and has the correct clothing for every purpose.



WARNING

Seizure of loose textile fabrics, luggage items or straps in open running rotating vehicle parts (wheels, prop shaft)

Risk of accident

- Make sure that no loosely worn textile fabrics can get caught in open, running and rotating vehicle parts.
- Keep luggage items as well as tension belts and lashing straps away from open, running and rotating vehicle parts.

Reduced clearance in inclined position

—with lowered^{OE}

Motorcycles with lowered chassis have a reduced ground clearance in angular position and to the ground compared to motorcycles with a standard chassis (see chapter Technical data).



WARNING

When cornering with lowered motorcycles, motorcycle parts can contact the road surface sooner than normal.

Accident hazard

- Carefully test the clearance of the motorcycle in an inclined position and adjust your riding style accordingly.

Test the clearance of your motorcycle at an angle in safe situations. Remember to take the limited ground clearance of your motorcycle into account when riding over curbs and similar obstacles.

Lowering the motorcycle reduces the spring travel. A possible reduction in the accustomed riding comfort may result. Especially in two-up mode,

the spring preload should be adjusted accordingly.

Correct loading



WARNING

Reduced riding stability caused by overloading and uneven loading

Accident hazard

- Do not exceed the gross weight limit and observe the loading information.

- Adjust the spring preload and damping for the current gross vehicle weight.

–with case^{OA}

- Ensure that case volumes on left and right are equal.
- Make sure that weight is uniformly distributed between right and left.
- Pack heavy luggage items to the bottom and center of cases.
- Observe the maximum payload and maximum speed; also see the Accessories (▶▶▶ 193) chapter.



Payload per case

max 18 lbs (max 8 kg)◀

–with topcase^{OA}

- Observe the maximum payload and maximum speed;

also see the Accessories (▶▶▶ 196) chapter.



Payload of Topcase

max 11 lbs (max 5 kg)◀

–with tank bag^{OA}

- Observe the maximum payload of the tank bag.



Payload of tank rucksack

max 11 lbs (max 5 kg)◀

–with rear bag^{OA}

- Observe maximum payload of the rear bag.



Payload of rear bag

max 3 lbs (max 1.5 kg)◀

Speed

If you ride at high speed, always bear in mind that various boundary conditions can adversely affect the handling of your motorcycle, e.g.:

- Incorrect settings of spring-strut and shock absorber system
- Unevenly distributed load
- Loose clothing
- Insufficient tire pressure
- Tire tread in poor condition
- Installed luggage systems, such as cases, topcases and tank rucksacks.

110 RIDING

Maximum speed with studded or winter tires

DANGER

Maximum speed of the motorcycle is higher than the permissible maximum rated speed of the tires.

Risk of accident due to tire damage at high speed.

- Observe the maximum permissible speed for the tires.

With studded or winter tires, the maximum permissible speed for the tires must be observed.

Attach a label specifying the maximum permissible speed in the field of view of the instrument cluster.

Risk of poisoning

Exhaust gas contains carbon monoxide, which is colorless and odorless but highly toxic.

WARNING

Harmful exhaust gas

Danger of suffocation

- Do not inhale exhaust fumes.
- Do not run the engine in closed rooms.

WARNING

Inhalation of vapors that are harmful to health

Damage to health

- Do not inhale vapors from operating fluids and plastics.
- Only use the vehicle outdoors.

Burn hazard

CAUTION

Intense heating up of engine and exhaust system while riding

Burn hazard

- After parking the motorcycle, make sure that no persons or objects come into contact with the engine and exhaust system.

Catalytic converter

If misfiring causes unburned fuel to enter the catalytic converter, there is a danger of overheating and damage. The following must be observed:

- Do not run the fuel tank dry
- Do not run the engine with the spark-plug cap removed
- Stop the engine immediately if it misfires
- Use unleaded fuel only

- Comply with all specified maintenance intervals.



ATTENTION

Unburned fuel in the catalytic converter

Damage to catalytic converter

- Note the points listed for protection of the catalytic converter.

Danger of overheating



ATTENTION

Engine idling for a lengthy period while at a standstill

Overheating due to insufficient cooling; in extreme cases vehicle fire

- Do not allow the engine to idle unnecessarily.
- After starting, ride off immediately.

Modifications



ATTENTION

Modifications to the motorcycle (e.g. engine control unit, throttle valves, clutch)

Damage to the affected parts, failure of safety-relevant functions, expiration of warranty

- Do not make any modifications.

REGULAR CHECK

Checklist

- Use the following checklist to check your motorcycle at regular intervals.

In the event of a change to the load status:

-without Dynamic ESA^{OE}

- Adjusting the spring preload on the rear wheel (▮▮▮ 103).

- Adjusting the damping characteristic for rear wheel (▮▮▮ 104).<

-with Dynamic ESA^{OE}

- Adjusting the suspension (▮▮▮ 61).<

Before every journey:

- Check operation of the brake system.
- Check operation of the lighting and signal system.

112 RIDING

- Checking clutch function (▮▮▮▮ 156).
- Checking tire tread depth (▮▮▮▮ 160).
- Checking tire pressure (▮▮▮▮ 159).
- Check secure hold of cases and luggage.

At every third refueling stop:

- Checking engine oil level (▮▮▮▮ 150).
- Checking the front brake pad thickness (▮▮▮▮ 152).
- Checking the rear brake pad thickness (▮▮▮▮ 153).
- Checking the front brake fluid level (▮▮▮▮ 154).
- Checking the rear brake fluid level (▮▮▮▮ 155).
- Checking coolant level (▮▮▮▮ 157).
- Lubricating drive chain (▮▮▮▮ 172).
- Checking chain tension (▮▮▮▮ 172).

STARTING

Starting the engine



ATTENTION

Sufficient transmission gear-box lubrication only when the engine is running.

Transmission damage


- Do not allow the motorcycle to roll for longer periods or push it over longer distances with the engine switched off.
- Switching on the ignition (▮▮▮▮ 50).
 - » Pre-Ride-Check is carried out. (▮▮▮▮ 113)
 - » ABS self-diagnosis is performed. (▮▮▮▮ 114)
 - » DTC self-diagnosis is performed. (▮▮▮▮ 114)
- Engage neutral, or pull back clutch lever if a gear is engaged.



You cannot start the motorcycle with the side stand extended and a gear engaged. The engine will switch itself off if it is started with the transmission in neutral and then a gear is engaged before retracting the side stand.



- Press starter button 1.

 The starting procedure is automatically canceled if the battery voltage is too low. Recharge the battery before you attempt to start the engine again, or use jump-starting. More detailed information can be found in the Maintenance chapter under Jump-starting.



Engine starts.

» If the engine fails to start, the troubleshooting chart in the Technical Data chapter may provide assistance. (► 210)

Pre-Ride-Check

After switching on the ignition, the instrument cluster performs a test of the indicator and warning lights – what we call the "Pre-Ride-Check". Starting the engine before the test is completed will cancel the remainder of the test.

Phase 1

All indicator and warning lights are switched on. After a longer standstill of the vehicle, an animation is displayed during the system start.

Phase 2


The general warning light switches from red to yellow.

Phase 3

All switched-on indicator and warning lights are switched off one after the other in reverse order.

If one of the indicator and warning lights has not been switched on:

- Have the malfunction corrected as soon as possible at a specialist workshop, preferably an authorized BMW Motorrad retailer.

 Depending on the riding mode or its configuration, the intervention of electronic stability control systems can be restricted. Possible restrictions are displayed as a pop-up message, e.g. Caution! ABS & DTC setting..

You can find more detailed information regarding electronic stability control systems such

114 RIDING

as ABS and DTC in the "Technology in detail" chapter.

ABS self-diagnosis

The self-diagnosis routine is determining whether BMW Motorrad ABS is ready for operation. The self-diagnosis routine launches automatically when you start the ignition.

Phase 1

» Check on system components monitored by diagnostic system while motorcycle is parked.



ABS indicator and warning light flashes.

Phase 2

» Check wheel speed sensors while starting off.



ABS indicator and warning light flashes.

ABS self-diagnosis completed

» The ABS indicator and warning light goes out.



ABS self-diagnosis not completed

ABS is not available, as the self-diagnosis routine was not completed. (The motorcycle must reach a specified minimum speed before the system can check operation of the wheel speed sensors: 3 mph (5 km/h))

If an ABS error is displayed after the ABS self-diagnosis is completed:

- You may continue riding. It must be noted that the ABS function is not available.
- Have the malfunction corrected as soon as possible at a specialist workshop, preferably an authorized BMW Motorrad retailer.

DTC self-diagnosis

The self-diagnosis routine is determining whether BMW Motorrad DTC is ready for operation. The self-diagnosis runs automatically when you switch on the ignition.

Phase 1

» Checking system components capable of diagnosis while vehicle is at a standstill.



flashes slowly.

Phase 2

» Checking system components capable of diagnosis while riding off.



flashes slowly.

DTC self-diagnosis completed

» The DTC symbol is no longer displayed.

- Check the display of all indicator and warning lights.



DTC self-diagnosis not completed

The DTC function is not available, as the self-diagnosis function has not been completed. (To check wheel speed sensors, motorcycle must reach a minimum speed with engine running: min 3 mph (min 5 km/h))

If a DTC fault is displayed after the DTC self-diagnosis is completed:

- You may continue riding. Please note that the DTC function is restricted or is not available at all.
- Have the malfunction corrected as soon as possible at a specialist workshop,

preferably an authorized BMW Motorrad retailer.

BREAKING IN

Engine

- In the period preceding the break-in service, attempt to engine load and engine speed ranges as frequently as possible, avoiding extended periods at constant rpm.
- Try to do most of your riding during this initial period on twisting, fairly hilly roads, avoiding highways if possible.
- Observe the engine run-in speeds.



Engine run-in speed

<6500 min⁻¹ (Odometer reading 0...746 miles (0...1200 km))

No full throttle (Odometer reading 0...746 miles (0...1200 km))

- Observe mileage, after which the running-in check should be performed.



Mileage until first run-in check

311...746 miles (500...1200 km)

116 RIDING

Brake pads

New brake pads must be run in before they achieve their optimum friction force. This initial reduction in braking effect can be compensated for by exerting greater pressure on the brake levers.



WARNING

New brake pads

Extension of the braking distance, accident hazard

- Brake early.

Tires

New tires have a smooth surface. They must be roughened by riding in a restrained manner at varying lean angles until the tires are run in. This running in procedure is essential if the tire tread is to achieve maximum grip.



WARNING

Loss of adhesion of new tires on wet roads and at extreme angles


Accident hazard


- Always think well ahead and avoid extreme angles.

SHIFTING GEARS

–with Gearshift Assistant Pro^{OE}

Gear Shift Assistant Pro

 Due to safety reasons, the cruise control is automatically disabled when downshifting with the Gear Shift Assistant Pro.



- Engage the gears as usual with the foot-operated gearshift lever.
- » The Gear Shift Assistant provides assistance for upshifts and downshifts, without need for the rider to actuate the clutch or throttle grip.
- This is not an automatic gearshift system.
- The rider is the most important part of the system and decides when to shift gears.
- The sensor **1** on the gearshift shaft detects the gearshift request and triggers the shift assistance.
- » When riding at a steady speed in a low gear at high

- RPM, an attempt to shift gears without clutch control can cause a strong load-change response.
- BMW Motorrad recommends clutch control for shifting gears in these driving circumstances.
 - Use of the Gear Shift Assistant Pro should be avoided at RPMs where the engine speed limiter becomes active.
 - » Shift assistance is not available in the following situations:
 - With clutch actuated.
 - Gearshift lever not in its initial position
 - When upshifting with closed throttle valve (coasting over-run) or when decelerating.
 - When downshifting with open throttle valve or when accelerating.
 - After a gearshift, you must fully release the gearshift lever before another gear shift with the Gear Shift Assistant Pro can take place. More detailed information on the Gear Shift Assistant Pro (📖 143).

OFF-ROAD USE

After riding off-road

BMW Motorrad recommends the following after riding off-road:

Tire pressure



WARNING

When driving off-road, lower tire pressure than riding on paved roads

Risk of accident due to poorer handling characteristics.

- Ensure proper tire inflation pressure.

Brakes



WARNING

Riding on unpaved or dirty roads

Delayed braking effect due to dirty brake discs and brake pads

- Brake early until the brakes are clean again.



ATTENTION

Riding on unpaved or dirty roads

Increased brake pad wear

- Check the brake pad thickness more often and replace the brake pads sooner.



ATTENTION

Dirty air filter element

Engine damage

- When driving in dusty terrain, check air filter insert for soiling at short intervals and clean or replace if necessary.

Spring preload and damping



WARNING

Modified values for spring preload and spring strut damping when riding off-road

Poorer handling characteristics on paved roads

- Set correct spring preload and correct spring strut damping before leaving off-road terrain.

Use under very dusty conditions (deserts, savannas, etc.) requires the use of air filter elements specially developed for these kinds of applications.

BRAKES

How do you achieve the shortest braking distance?

The dynamic load distribution between the front and rear wheel changes during braking. The heavier you brake, the greater the weight transfer to the front wheel. Increases in the load on an individual wheel are accompanied by a rise in the effective braking force that the wheel can provide.

To achieve the shortest possible braking distance, the front wheel brake must be applied quickly and with progressively greater levels of force. This procedure provides ideal exploitation of the extra weight transfer to the front wheel.

Rims

BMW Motorrad recommends checking the rims for possible damage after riding off-road.

Air cleaner element

The clutch should also be disengaged at the same time. With the frequently instructed "emergency braking," in which the brake pressure is generated as quickly as possible and with great force, dynamic load distribution lags behind the progressive increases in deceleration rate and the braking force cannot be completely transferred to the road. The front wheel can lock up. Locking up of the front wheel is prevented by BMW Motorrad ABS.

Descending mountain passes



WARNING

Braking should be done predominantly using the rear wheel brake when riding on downhill routes

Loss of braking effect, destruction of the brakes due to overheating

- Apply the front and rear wheel brake and use the engine brake.

Wet, soiled brakes

Moisture and dirt on the brake discs and the brake pads result in a decrease in the braking effect.

Delayed or poorer braking effect must be expected in the following situations:

- When driving in the rain and through puddles.
- After washing the motorcycle.
- When driving on roads spread with salt.
- After working on the brakes due to oil or grease residues.
- When driving on soiled roads or offroad.



WARNING

Poorer braking action due to moisture and dirt

Accident hazard

- Brake until brakes are dry or clean; clean if necessary.
- Brake early until the full braking action is available again.

120 RIDING

ABS Pro

Physical riding limits



WARNING

Braking in curves

Danger of falling despite ABS Pro

- The rider is always responsible for adapting his/her driving style.
- Do not reduce the system's extra safety margin with careless riding or unnecessary risks.

ABS Pro is available in all riding modes except for Enduro PRO.

Falling cannot be excluded

Although ABS Pro represents valuable support and an enormous safety advantage for the rider when braking in the inclined position, it by no means redefines the physical riding limits. It is still possible to exceed those limits through misjudgments or riding errors. In extreme cases this may result in a fall.

Use on public roads

ABS Pro helps make riding your motorcycle on public roads even safer. When braking due to unexpected hazards in curves, locking-up

and slipping of the wheels is prevented within the scope of the physical riding limits.



ABS Pro was not developed to increase the individual braking performance in the inclined position.

PARKING YOUR MOTORCYCLE

Side stand

- Switch off engine.



ATTENTION

Poor ground conditions in area of stand

Component damage caused by tipping over

- Always check that the ground under the stand is level and firm.



ATTENTION

Loading of the side stand with additional weight

Component damage caused by tipping over

- Do not sit on the motorcycle when it is parked on the side stands.

- Fold out side stand and park motorcycle.

- If the slope of the road permits, turn the handlebars to the left.
- On slopes point the motorcycle uphill and engage 1st gear.

Center stand

–with center stand^{OE}

- Switch off engine.



ATTENTION

Poor ground conditions in area of stand

Component damage cause by tipping over

- Always check that the ground under the stand is level and firm.



ATTENTION

Folding in the center stand in case of strong movements

Component damage cause by tipping over

- Do not sit on the vehicle while it is resting on the center stand.

- Fold down center stand and prop up motorcycle.

REFUELING

Fuel grade

Requirement

For optimal fuel consumption, the fuel should be sulfur-free or very low in sulfur content.



ATTENTION

Refueling with leaded fuel

Damage to catalytic converter

- Do not refuel with leaded gasoline or gasoline with metallic additives, e.g. manganese or iron.



ATTENTION

Use of Ethanol E85 as fuel

Damage to the engine and fuel supply

- Do not refuel with E85, i.e. fuel with an ethanol content of 85 %, or with Flex Fuel.

- Observe the maximum ethanol content of the fuel.



Fuel additives clean the fuel injection system and the combustion area. Fuel additives should be used when refueling with low-quality fuels or during longer periods of downtime. Your authorized BMW Motorrad retailer can

122 RIDING

provide you with more detailed information.



Recommended fuel quality

Regular unleaded (max. 15% ethanol, E15)
87 AKI (91 ROZ/RON)
87 AKI

Refueling procedure



WARNING

Fuel is highly flammable

Fire and explosion hazard

- Do not smoke. Never bring a naked flame near the fuel tank.



WARNING

Escaping of fuel due to expansion under exposure to heat with overfilled fuel tank

Accident hazard

- Do not overfill the fuel tank.



ATTENTION

Contact of fuel and plastic surfaces

Damage to surfaces (become unattractive or cloudy)

- Immediately clean plastic surfaces after contact with fuel.

- Put the motorcycle up on the side stand, ensuring that it is resting on a firm and level support surface.
–with center stand^{OE}



WARNING

Fuel is highly flammable

Fire and explosion hazard

- Do not smoke. Never bring a naked flame near the fuel tank.



WARNING

Escaping of fuel due to expansion under exposure to heat with overfilled fuel tank

Accident hazard

- Do not overfill the fuel tank.



ATTENTION

Contact of fuel and plastic surfaces

Damage to surfaces (become unattractive or cloudy)

- Immediately clean plastic surfaces after contact with fuel.

- Make sure the ground is level and firm and place the motorcycle on its center stand.◁



- Open the protective cover **1**.
- Unlock the fuel tank cap **2** in a clockwise direction using the ignition key and fold it up.



- Refuel up to the lower edge of the fuel filler neck, but no higher.
- i** If refueling is carried out after running on fuel reserve, the resulting filling capacity must be greater than the fuel reserve so that the new fill level is detected and the fuel reserve indicator light is switched off.

i The "usable fuel quantity" specified in the technical data is the fuel quantity, which can be refueled if the fuel tank was completely emptied, i.e., if the engine dies off due to lack of fuel.



Usable fuel quantity

Approx. 4 gal (Approx. 15 l)



Reserve fuel quantity

Approx. 3.7 quarts (Approx. 3.5 l)

- Press fuel tank cap down firmly to close it.
- Remove the ignition key and close the protective flap.

Refueling procedure

—with Keyless Ride^{OE}

Requirement

Steering lock is unlocked.



WARNING

Fuel is highly flammable

Fire and explosion hazard

- Do not smoke. Never bring a naked flame near the fuel tank.



WARNING

Escaping of fuel due to expansion under exposure to heat with overfilled fuel tank

Accident hazard

- Do not overfill the fuel tank.



ATTENTION

Contact of fuel and plastic surfaces

Damage to surfaces (become unattractive or cloudy)

- Immediately clean plastic surfaces after contact with fuel.

- Put the motorcycle up on the side stand, ensuring that it is resting on a firm and level support surface.

–with Keyless Ride^{OE}

- Switch off ignition (🔌 52).



After the ignition is switched off, the fuel filler cap can be opened within the specified run-on time even without the radio-operated key being within the reception area.



After-running period for opening the fuel filler cap

2 min

» There are **2 ways** to open the fuel filler cap:

- Within the after-run period.
- After the after-run period is over.

–with center stand^{OE}



WARNING

Fuel is highly flammable

Fire and explosion hazard

- Do not smoke. Never bring a naked flame near the fuel tank.



WARNING

Escaping of fuel due to expansion under exposure to heat with overfilled fuel tank

Accident hazard

- Do not overfill the fuel tank.



ATTENTION


Contact of fuel and plastic surfaces


Damage to surfaces (become unattractive or cloudy)

- Immediately clean plastic surfaces after contact with fuel.

- Make sure the ground is level and firm and place the motorcycle on its center stand.

- with Keyless Ride^{OE}
- Switch off ignition (▶▶▶ 52).

 After the ignition is switched off, the fuel filler cap can be opened within the specified run-on time even without the radio-operated key being within the reception area.

	After-running period for opening the fuel filler cap
2 min	

- » There are **2 ways** to open the fuel filler cap:
- Within the after-run period.
 - After the after-run period is over.◀

Version 1

–with Keyless Ride^{OE}

Requirement

Within the after-running period



- Slowly pull up tab **1** of fuel filler cap.
- » Fuel filler cap unlocked.

- Open fuel filler cap completely.

Version 2

–with Keyless Ride^{OE}


Requirement

After run-on time expires

- Bring radio-operated key into reception range.
- Slowly pull up tab **1**.
 - » The indicator light for the radio-operated key flashes as long as the radio-operated key is being searched for.
- Slowly pull up tab **1** of fuel filler cap again.
 - » Fuel filler cap unlocked.
- Open fuel filler cap completely.






- Refuel with a fuel meeting the specifications above, continuing until fuel is no higher than lower edge of filler neck.

 If refueling is carried out after running on fuel reserve, the resulting filling capacity must be greater than the

126 RIDING

fuel reserve so that the new fill level is detected and the fuel reserve indicator light is switched off.

 The "usable fuel quantity" specified in the technical data is the fuel quantity, which can be refueled if the fuel tank was completely emptied, i.e., if the engine dies off due to lack of fuel.

	Usable fuel quantity
	Approx. 4 gal (Approx. 15 l)
	Reserve fuel quantity
	Approx. 3.7 quarts (Approx. 3.5 l)


- Press fuel filler cap of fuel tank down firmly.
 - » Fuel filler cap audibly engages.
 - » Fuel filler cap automatically locks after run-on time expires.
 - » The engaged fuel filler cap locks immediately when the steering lock is locked or during starting.

Open fuel filler cap emergency release

—with Keyless Ride^{OE}

The fuel filler cap cannot be opened.

- Have the defect rectified as quickly as possible by a specialist workshop, preferably an authorized BMW Motorrad retailer.




- Remove screws **1**.
- Remove emergency release **2**.
 - » Fuel filler cap unlocked.
- Open fuel filler cap completely.
- Refueling (▣▣▣ 123).
- Close fuel filler cap emergency release (▣▣▣ 126).

Close fuel filler cap emergency release

—with Keyless Ride^{OE}

Requirement

Fuel filler cap is closed.



- Position the emergency release **2**.
- Install screws **1**.

SECURING MOTORCYCLE FOR TRANSPORTATION

- Make sure that all components that might come into contact with tensioning straps used to secure the motorcycle are adequately protected against scratching. Use adhesive tape or soft cloths, for example, for this purpose.




ATTENTION

Motorcycle tips to the side when raising

Component damage cause by tipping over

- Secure the motorcycle against tipping to the side, preferably with the assistance of a second person.
- Push the motorcycle onto the transportation flat and hold it in position; do not place it on the side stand or center stand.



ATTENTION

Pinching of components

Component damage

- Do not pinch components, e.g. brake lines or wiring harnesses.
- Fasten the front tensioning straps on both sides on the lower fork bridge and tighten them.



- Fasten the rear tensioning straps on both sides on the rear frame and tighten them.
- Tighten all tensioning straps evenly.

TECHNOLOGY IN DETAIL

08

GENERAL NOTES	132
ANTI-LOCK BRAKING SYSTEM (ABS)	132
TRACTION CONTROL (DTC)	135
DYNAMIC ENGINE BRAKE CONTROL	137
DYNAMIC ESA	137
RIDING MODE	138
DYNAMIC BRAKE CONTROL	140
TIRE PRESSURE CONTROL (RDC)	141
GEAR SHIFT ASSISTANT	143

132 TECHNOLOGY IN DETAIL

GENERAL NOTES

More information on the topic of technology is available at: bmw-motorrad.com/technology

ANTI-LOCK BRAKING SYSTEM (ABS)

How does ABS work?

The maximum braking force that can be transferred to the road is partially dependent on the coefficient of friction of the road. Gravel, ice, snow and wet roads offer a considerably poorer friction coefficient than a dry, clean asphalt surface. The poorer the coefficient of friction of the road is, the longer the braking distance will be.

If the maximum transferable braking force is exceeded when the rider increases the brake pressure, the wheels begin to lock and riding stability is lost, and a fall can result. Before this situation occurs, ABS intervenes and adjusts the brake pressure to the maximum transferable braking force. This enables the wheels to continue to turn and maintains riding stability regardless of the road condition.

What happens when rough roads are encountered?

Bumpy or rough roads can briefly lead to a loss of contact between the tires and the road surface, until the transferable braking force is reduced to zero. If the brakes are applied in this situation, the ABS must reduce the brake pressure to ensure riding stability when contact to the road is restored. At this point, the BMW Motorrad ABS must assume extremely low coefficients of friction (gravel, ice, snow) so that the running wheels turn in every imaginable case and the riding stability is ensured. After detecting the actual conditions, the system adjusts the optimum brake pressure.

Lifting off rear wheel

During extremely heavy and rapid decelerations, however, it is possible under certain circumstances that the BMW Motorrad Antilock Brake System cannot prevent the rear wheel from lifting off the ground. In these cases, the motorcycle can also flip end over end.

**WARNING****Lifting off of the rear wheel due to heavy braking**

Accident hazard

- When braking heavily, bear in mind that the ABS control cannot always be relied on to prevent the rear wheel from lifting off the ground.

What are the design characteristics of the BMW Motorrad ABS?

The BMW Motorrad ABS ensures riding stability on any surface within the limits of riding physics.

From a speed greater than 2.5 mph (4 km/h), the BMW Motorrad ABS can ensure riding stability on any surface within the limits of riding physics. At lower speeds, the BMW Motorrad ABS cannot provide optimal support on all surfaces due to system limitations.

The system is not optimized for the special conditions encountered under the extreme conditions of competitive off-road and racetrack use.

Special situations

To detect the tendency of the wheels to lock up, the speeds of the front and rear wheel are compared. If implausible values are detected over a longer period of time, the ABS function is switched off for safety reasons, and an ABS error is displayed. A self-diagnosis routine must be completed before the fault memory entry will be displayed.

Apart from problems with the BMW Motorrad ABS, unusual riding conditions can also cause a fault memory entry to be generated:

- Riding on the rear wheel (wheelie) for a longer period.
- Rear wheel spinning in place with front wheel brake engaged (burn out).
- Warm-up on the center or auxiliary stand at idle or with gear engaged.
- Rear wheel locked-up for a longer period of time by engine brake, e.g. when riding downhill on slippery surfaces.

Should a fault memory entry occur due to an unusual riding condition, the ABS function can be reactivated by switching the ignition off and then on again.

134 TECHNOLOGY IN DETAIL

How important is regular maintenance?



WARNING

Brake system not regularly serviced

Accident hazard

- To ensure that the BMW Motorrad ABS is in a properly maintained condition, it is vital that the specified service intervals are kept to.

Reserves for safety

But remember, the potentially shorter braking distances that the BMW Motorrad ABS permits must not be used as an excuse for careless riding. ABS is primarily a means of ensuring a safety margin in genuine emergencies.

Be careful in curves! When you apply the brakes on a corner, the motorcycle's weight and momentum take over and even the BMW Motorrad ABS is unable to counteract their effects.

Further development of ABS to ABS Pro

In the past, the BMW Motorrad ABS system provided for a very high level of safety while braking during straight-ahead riding. Now ABS Pro also offers increased safety even when braking in curves. ABS Pro prevents the wheels from locking up, even in the event that the brakes are applied quickly. ABS Pro reduces abrupt changes in steering forces, especially during shock braking, and therefore decreases the risk of the vehicle lifting off the ground inadvertently.

ABS control

From a technical standpoint, ABS Pro adjusts the ABS control to the angle of inclination of the motorcycle in dependence on the respective riding situation. Signals for the roll and yaw rate and the lateral acceleration are used to determine the inclination of the motorcycle.

With an increasing inclination, the brake pressure gradient is increasingly limited at the start of braking. This results in a slower pressure buildup. In addition, the pressure modu-

lation in the range of the ABS control is more uniform.

Advantages for the rider

The advantages of ABS Pro for the rider are sensitive response and high braking and riding stability with the best possible deceleration, even in curves.

TRACTION CONTROL (DTC)

How does traction control work?

The traction control compares the wheel circumferential velocities of the front and rear wheels. The slip, and with it the stability reserves at the rear wheel, are determined from the speed difference. The engine control adapts the engine torque when the slip limit is exceeded.

BMW Motorrad DTC is designed as an assistance system for the rider and for riding on public roads. The extent to which the rider affects DTC control can be considerable (weight shifts when cornering, loose luggage on the motorcycle), especially when approaching the limits imposed by the laws of physics.

The *Enduro* riding mode should be activated for off-road riding. In this mode, the

control intervention by the DTC is performed slightly later in this mode, enabling controlled drifting.

The system is not optimized for the special conditions encountered under the extreme conditions of competitive off-road and racetrack use. BMW Motorrad DTC can be switched off in such instances.



WARNING

Risky riding style

Risk of accident despite DTC

- The rider is always responsible for adapting his/her driving style.
- Do not reduce the system's extra safety margin with careless riding or unnecessary risks.

Special situations

As lean angles increase, acceleration capability is also progressively restricted by the laws of physics. This can result in reduced acceleration when coming out of very tight curves.

To detect spinning or slipping away of the rear wheel, the speeds of the front and rear wheel are compared and the

136 TECHNOLOGY IN DETAIL

angle is considered, for example.

If the values for the lean angle are detected to be implausible for a long period, a replacement value is used for the angle, or the DTC function is switched off. In these cases, a DTC error is displayed. A self-diagnosis must be completed before the fault memory entry will be displayed.

Under the following unusual riding conditions, BMW Motorrad Traction Control may be deactivated automatically.

Unusual riding conditions:

- Riding on the rear wheel (wheelie) for a longer period.
- Rear wheel spinning in place with front wheel brake engaged (burn out).
- Warming up the engine on an auxiliary stand in neutral or with gear engaged.

Switching the ignition off and on again and then riding the motorcycle at a minimum speed reactivates the DTC.



Minimum speed for DTC activation

min 3 mph (min 5 km/h)

If the front wheel loses contact with the ground under extreme acceleration, the DTC reduces the engine torque in the RAIN and ROAD riding modes until the front wheel makes contact with the ground again.

The riding modes ENDURO and ENDURO PRO are designed for off-road riding and are not suitable for road operation.

In the riding modes DYNAMIC and ENDURO, the front wheel lift-off detection permits brief wheelies.

The front wheel lift-off detection is switched off in riding mode ENDURO PRO.

BMW Motorrad recommends that you respond to the front wheel lifting off by letting off on the throttle grip somewhat to return to a stable riding state as quickly as possible. In the RAIN, ROAD, DYNAMIC, and ENDURO riding modes, the DTC setting corresponds to the riding mode.

In the ENDURO PRO riding mode, DTC can be set differently.

DYNAMIC ENGINE BRAKE CONTROL

–with riding modes Pro^{OE}

How does dynamic engine brake control work?

The purpose of the dynamic engine brake control is to safely prevent unstable riding conditions that are related to excess drag torque at the rear wheel. Depending on the road condition and riding dynamics, excess drag torque can make the slip at the rear wheel increase severely and impede riding stability. The dynamic engine brake control reduces slip at the rear wheel to a safe, setpoint slip that is dependent on the mode.

Causes of excess slip at the rear wheel:

- Riding in coasting overrun on a road with low coefficient of friction (e.g. wet leaves).
- Hopping when shifting gears down.
- Hard brake onset in sporty riding style.

Like the BMW Motorrad DTC traction control, the dynamic engine brake control compares the wheel centrifugal velocity of the front and rear wheel, which are calculated from the

wheel RPM and the tire radius. The dynamic engine brake control can determine the slip, and therefore the stability reserve, on the rear wheel using the speed difference.

If the slip exceeds the respective limit value, the engine torque is increased by slightly opening the throttle valves. The slip is reduced, and the vehicle is stabilized.

Effect of the dynamic engine brake control

–In the RAIN and ROAD riding modes: maximum stability.

–with riding modes Pro^{OE}

–In the DYNAMIC riding mode: Reduced intervention when compared to the RAIN and ROAD riding modes.

–In the ENDURO and ENDURO PRO riding modes: Maximum Performance. Stability may be impaired on poorly surfaced roads or if using unsuitable tires.

DYNAMIC ESA

–with Dynamic ESA^{OE}

138 TECHNOLOGY IN DETAIL

Dynamic ESA function

Using a ride height sensor, Dynamic ESA detects movements of the chassis and suspension and responds to them by adjusting the damper valve. As a result, the suspension is adjusted to the conditions of the ground surface.

Dynamic ESA calibrates itself at regular intervals to ensure that the system is operating correctly.

Adjustment options

Damping modes

- Road: Damping for comfortable road travel
- Dynamic: Damping for dynamic road travel
- Enduro: Damping for off-road riding

Load settings

- One-up
- One-up with luggage
- Two-up (with luggage)

RIDING MODE

Selection

In order to adjust the motorcycle to the road condition and the desired riding experience, it is possible to select one of the following riding modes:

Standard

- RAIN
- ROAD (standard mode)
- with riding modes Pro^{OE}

With Pro riding modes

- DYNAMIC
- ENDURO
- ENDURO PRO

For each of these riding modes, there is a coordinated setting for the ABS and DTC systems, the dynamic engine brake control and the throttle response.

- with Dynamic ESA^{OE}

The coordination of the Dynamic ESA also depends on the selected riding mode.

The DTC can be switched off in any riding mode. The following explanations always refer to the riding safety systems that are switched on.

Throttle response

- In the RAIN riding mode: Soft throttle response.
- In the ROAD riding mode: Optimal throttle response.
- with riding modes Pro^{OE}
- In the DYNAMIC riding mode: Direct throttle response.
- In the ENDURO riding mode: Soft throttle response.

- In the ENDURO PRO riding mode: Optimal throttle response.
- In the ENDURO PRO riding mode, the throttle response can be set differently via the SETUP (▶▶ 65).

ABS

- The rear wheel lift-off detection is active in all riding modes except ENDURO PRO.
- In the DYNAMIC and ENDURO riding modes, rear wheel lift-off detection is reduced in order to achieve a greater braking effect.
- In the RAIN, ROAD, and DYNAMIC riding modes, ABS is attuned for road use.
- In the ENDURO riding mode, ABS is attuned for off-road use with road tires.
- In riding mode ENDURO PRO, there is no ABS control on the rear wheel when the foot-brake lever is actuated. The ABS is adjusted to off-road use with cleated tires.

ABS Pro

- In the RAIN and ROAD riding modes, all ABS Pro functions are available. The stand-up tendency the motorcycle has when braking while traveling

around curves is reduced to a minimum.

- In the DYNAMIC and ENDURO riding modes, ABS Pro is available only when the traction conditions are good. The support is reduced compared to the ROAD riding mode and is instead aimed at achieving the greatest braking effect.
- In the ENDURO PRO riding mode, the ABS Pro is not available.

DTC

Tires

- In the RAIN, ROAD and DYNAMIC riding modes, the DTC is attuned for road use with road tires.
- In the ENDURO riding mode, the DTC is attuned for off-road use with road tires.
- In the ENDURO PRO riding mode, the DTC is attuned to off-road use with cleated tires.

Riding stability

- In the RAIN riding mode, the DTC intervenes early enough to ensure maximum riding stability is achieved.
- In the ROAD riding mode, the DTC intervenes at a later point than in the RAIN riding mode. Spinning of the

140 TECHNOLOGY IN DETAIL

- rear wheel without traction is avoided wherever possible.
- In the RAIN and ROAD riding modes, the front wheel is prevented from lift-off.
 - In the DYNAMIC riding mode, the DTC intervenes later than in the ROAD riding mode so that minor drifts and brief wheelies are possible at the end of curves.
 - In the ENDURO riding mode, the DTC intervenes even later and it is set to off-road use so that longer drifts and brief wheelies are possible at the end of curves.
 - In the ENDURO PRO riding mode, the control of the DTC assumes that cleated tires are being used for off-road riding. Longer wheelies as well as wheelies at small angles are permitted. The front wheel lift-off detection is switched off, which means that it is possible to flip over backwards in extreme cases!

Switchover

Riding modes can be changed when the vehicle is at a standstill with the ignition switched on. A changeover while riding is possible under the following conditions:

- No drive torque at rear wheel.
- No brake pressure in the braking system.

For a changeover while riding, the following steps must be carried out:

- Turn back throttle grip.
- Do not actuate brake lever.
- Deactivate the adaptive cruise control.

First, the desired riding mode is preselected. The switchover does not take place until the affected systems are in the required state.

The Selection menu does not disappear from the display until the riding mode has been switched over.

DYNAMIC BRAKE CONTROL

- with riding modes Pro^{OE}

Dynamic Brake Control function

The Dynamic Brake Control function helps the rider in the event of emergency braking.

Detection of emergency braking

- Emergency braking is detected when the front wheel brake is applied quickly and with force.

Behavior during emergency braking

–If emergency braking is applied at a speed of more than 10 km/h, in addition to the ABS function, the Dynamic Brake Control function will also be activated.

Behavior in the event of accidental activation of the throttle grip

- If the throttle grip is accidentally actuated during emergency braking (throttle position >5%), the intended braking effect is ensured by the Dynamic Brake Control ignoring the opening process of the throttle grip. This ensures the action of emergency braking.
- If the gas is shut off (throttle position <5%) during the intervention of the Dynamic Brake Control, the engine torque required by the ABS brake system will be restored.
- If the emergency braking is stopped and the throttle grip is still under actuation, the Dynamic Brake Control reduces the engine torque as required by the rider in a controlled manner.

TIRE PRESSURE CONTROL (RDC)

–with tire pressure monitor (TPM)^{OE}

Function

A sensor located in each tire monitors the air temperature and the pressure inside the tire and transmits this information to the control unit.

The sensors are equipped with a centrifugal controller, which does not enable the transmission of the measured values until the minimum speed is exceeded for the first time.



Minimum speed for the transmission of the RDC measured values:

min 19 mph (min 30 km/h)

Before initial reception of the tire pressure, -- is shown in the display for each tire. The sensors continue to transmit the measured readings for some time after the vehicle comes to a stop.



Transmission time of the measured values after vehicle standstill:

min 15 min

If an RDC control unit is installed but the wheels have no

142 TECHNOLOGY IN DETAIL

sensors, a fault memory entry is generated.

Tire inflation pressure ranges

The RDC control unit distinguishes between three inflation pressure ranges matched to the motorcycle:

- Tire pressure within the permissible tolerance.
- Tire pressure at the limits of the permissible tolerance.
- Tire pressure outside the permissible tolerance.

Temperature compensation

The tire pressure is temperature dependent, i.e. it increases or decreases together with the tire air temperature. The tire temperature is dependent on the outside temperature, the riding style and the length of the journey.



The tire pressures are shown in the display with temperature compensation and are always based on the following tire air temperature:

68 °F (20 °C)

Tire pressure gauges at gas stations do not make any compensation for the air temperature, the tire pressure indicated depends on the temperature of the air in the tire. As a result,

in most cases the values displayed there do not match the values shown in the display.

Tire pressure adjustment

Compare the RDC value in the display with the value on the back cover of the operating instructions. The difference between the two values must be compensated with the tire inflation pressure tester at the filling station.



Example

According to the operating instructions, the tire pressure should have the following value:

36.3 psi (2.5 bar)

The following value is indicated in the display:

33.4 psi (2.3 bar)

The shortfall is thus:

2.9 psi (0.2 bar)

The tester at the filling station shows:

34.8 psi (2.4 bar)

To produce the correct tire pressure, this must be increased to the following value:

37.7 psi (2.6 bar)

GEAR SHIFT ASSISTANT

—with riding modes Pro^{OE}

Pro gearshift assistant

Your motorcycle is equipped with a Pro gearshift assistant originally developed for racing but now specially adapted for touring use. It allows you upshift and downshift under almost any load conditions and in virtually all engine-speed ranges without operating the clutch or accelerator.

Benefits


- 70-80 % of all gear changes can be performed without using the clutch.
- Less movement between pilot and pillion due to shorter gear-change intervals.
- Throttle does not have to be closed when changing gear under acceleration.
- During deceleration and downshifts (throttle plate closed) the system blips the throttle to obtain the correct engine speed.
- Shifting times are faster than when the clutch is used to change gears.

For the system to detect the rider's intention to change gear, the gearshift lever previously not operated must be moved against the force of the spring by a certain amount of "over-travel" in the desired direction with a normal to brisk action and held in that position until the gear change is completed. A further increase of the force applied to the gearshift lever during the gear-shift operation is not necessary. After the gear change is completed, the gear lever must be fully released before the Pro gearshift assistant can execute a new gear change. The load factor (throttle grip position) should remain constant both prior to and during execution of shifts using the Pro gearshift assistant. Changing the accelerator twist-grip position during the gear-shift operation may cause the function to abort and/or the gear change to fail. The Pro gearshift assistant does not provide support when gear changes are made using the clutch.

144 TECHNOLOGY IN DETAIL


Downshifts

- Downshifts are assisted up to the speed at which the engine reaches maximum rpm in the gear to be engaged. Over-revving is thus prevented.

 Maximum engine speed
max 9000 min ⁻¹

Upshifts

- Upshifting is supported until the idling speed is reached in the target gear.
- This prevents the idling speed from being dropped below.

 Idle speed
1250 ^{±50} min ⁻¹ (Engine at operating temperature)

MAINTENANCE

09

GENERAL NOTES	148
ONBOARD VEHICLE TOOL KIT	148
SERVICE TOOL SET	149
FRONT-WHEEL STAND	149
REAR-WHEEL STAND	150
ENGINE OIL	150
BRAKE SYSTEM	152
CLUTCH	156
COOLANT	157
TIRES	159
RIMS	160
WHEELS	161
DRIVE CHAIN	172
AIR FILTER	174
LIGHT SOURCE	176
TRIM PANEL COMPONENTS	176
JUMP-STARTING	177
BATTERY	178
FUSES	182
DIAGNOSTIC SOCKET	184

148 MAINTENANCE


GENERAL NOTES

The 'Maintenance' chapter describes work involving the checking and replacement of wear parts that can be performed with a minimum of effort.

If special tightening torques are to be taken into account for installation, these are listed. An overview of all required tightening torques is contained in the chapter "Technical data". Information on additional preventive maintenance and repair procedures is provided in the repair manual for your motorcycle on DVD, which you can obtain from your authorized BMW Motorrad retailer.

Special tools and thorough specialized knowledge are required to carry out some of the work described here. If you are in doubt, consult a specialist workshop, preferably your authorized BMW Motorrad retailer.


ONBOARD VEHICLE TOOL KIT



- 1** Screwdriver handle
- 2** Reversible screwdriver insert with Phillips and slotted blade
 - Removing the battery (➡ 180).
 - Adjusting the damping characteristic for rear wheel (➡ 104).
- 3** Open-ended wrench
Key range: 14 mm
 - Adjusting mirror arm (➡ 100).
- 4** Torx wrench, T25/T30
T25 on short end, T30 on long end
 - Removing the tank cover (➡ 176).
- 5** Keys
 - Adjusting the spring preload on the rear wheel (➡ 103).

SERVICE TOOL SET

–with service tool set^{OA}



For expanded servicing (e.g. installing and removing wheels), BMW Motorrad has set up a service toolkit designed for your motorcycle. You can obtain the toolkit from your BMW Motorrad retailer.

FRONT-WHEEL STAND

Attaching front-wheel stand



ATTENTION

Use of the BMW Motorrad front wheel stand without an auxiliary stand

Component damage caused by tipping over

- Place the motorcycle on an auxiliary stand before lifting the front wheel with the BMW Motorrad front-wheel stand.

- Ensure that the motorcycle is standing securely.

- Place motorcycle on an auxiliary stand; BMW Motorrad recommends the BMW Motorrad auxiliary stand.
- Mounting the rear-wheel stand (→ 150).



- For a description of the correct installation, please refer to the instructions for the front-wheel stand.
- BMW Motorrad offers a suitable auxiliary stand for each motorcycle. Your authorized BMW Motorrad retailer will be very happy to assist you in choosing the suitable auxiliary stand.

150 MAINTENANCE

REAR-WHEEL STAND

Mounting the rear-wheel stand



- For a description of the correct installation, please refer to the instructions for the rear-wheel stand.
- BMW Motorrad offers a suitable auxiliary stand for each motorcycle. Your authorized BMW Motorrad retailer will be very happy to assist you in choosing the suitable auxiliary stand.

ENGINE OIL

Checking engine oil level



ATTENTION

Misinterpretation of the oil filling quantity, as the oil level is temperature-dependent (the higher the temperature, the higher the oil level)

Engine damage

- Only check the oil level after a longer journey or when the engine is warm.
- Clean the area around the oil filler opening.
- Allow the engine to idle in neutral until the fan starts up, then allow it to idle one minute longer.
- Switch off the engine.



ATTENTION

Lateral tipping of the vehicle


Component damage cause by tipping over

- Secure the vehicle from tipping over laterally, preferably with the support of a second person.
- Make sure the ground is level and firm and hold the motorcycle, which is at the operating temperature, upright.


BMW Motorrad recommends the use of a suitable auxiliary stand.

–with center stand^{OE}

- Make sure the surface is level and firm and place the motorcycle on its center stand at operating temperature.◀





- Wait five minutes to allow oil to drain into the oil pan.
- Remove the oil level dipstick **1**.




- Clean measuring range **2** using a dry cloth

- Place oil dipstick on oil filler opening, but do not install.
- Remove the oil level dipstick and check oil level.



 Specified level of engine oil

Between **MIN** and **MAX** mark

 Engine oil, quantity for topping up

max 0.5 quarts (max 0.5 l)
(Difference between MIN and MAX)


If the oil level is below the minimum mark:

- Topping up engine oil (▮▮▮▮▶ 152).

If the oil level is above the maximum mark:

- Have the oil level corrected at a specialist workshop, preferably an authorized BMW Motorrad retailer.
- Insert the oil level dipstick.

152 MAINTENANCE

 BMW Motorrad recommends occasionally checking the motor oil after a journey of at least 31 mi (50 km) in order to reduce the environmental impact.

Topping up engine oil

- Park motorcycle, ensuring that support surface is firm and level.
- Clean area adjacent to oil fill location.




- Remove oil dipstick **1**.

ATTENTION

Use of too little or too much engine oil

Engine damage

- Always make sure that the oil level is correct.
- Add engine oil up to specified level.
- Checking engine oil level ( 150).
- Install oil dipstick.

BRAKE SYSTEM

Checking function of brakes

- Actuate brake lever.
 - » The pressure point must be clearly perceptible.
- Press the footbrake lever.
 - » The pressure point must be clearly perceptible.

If pressure points are not clearly perceptible:

ATTENTION

Improper working on the brake system

Endangering of the operating safety of the brake system

- Have all work on the brake system carried out by experts.
- Have the brakes checked by a specialist workshop, preferably an authorized BMW Motorrad retailer.


Checking the front brake pad thickness

- Park motorcycle, ensuring that support surface is firm and level.



- Visually inspect left and right brake pads to determine their thickness. Direction of view: between wheel and front suspension toward brake caliper **1**.




 Front brake-pad wear
 limit

min 0.04 in (min 1.0 mm)
 (Only friction material without
 carrier plate. The wear mark-
 ings, i.e. the grooves, must be
 clearly visible.)

If the wear indicators are no longer clearly visible:

WARNING

Dropping below the minimum pad thickness

Reduced braking action, damage to the brake

- In order to ensure the operating reliability of the brake system, make sure that the brake pads are not worn beyond their minimum thickness.

- Have brake pads replaced at an authorized service facility, preferably an authorized BMW Motorrad retailer.

Checking the rear brake pad thickness

- Park motorcycle, ensuring that support surface is firm and level.



- Conduct a visual inspection of the brake pad thickness.

154 MAINTENANCE

Direction of view: from rear onto brake caliper **1**.



Rear brake-pad wear limit

min 0.04 in (min 1.0 mm)
(Only friction material without carrier plate.)

If brake pads are worn:



WARNING

Dropping below the minimum pad thickness

Reduced braking action, damage to the brake

- In order to ensure the operating reliability of the brake system, make sure that the brake pads are not worn beyond their minimum thickness.
- Have brake pads replaced at an authorized service facility, preferably an authorized BMW Motorrad retailer.

Checking the front brake fluid level



WARNING

Insufficient or contaminated brake fluid in the brake fluid reservoir

Considerably reduced braking power caused by air, dirt or water in the brake system


- Stop riding immediately until fault is rectified.
- Check brake fluid level regularly.
- Make sure that the lid of the brake fluid reservoir is cleaned before opening.
- Make sure that brake fluid is used from a sealed container only.

–with center stand^{OE}

- Make sure ground is level and firm and place the motorcycle on its center stand.
- Move handlebars to straight-ahead position.<
- Make sure ground is level and firm and hold motorcycle vertically.
- Move handlebars to straight-ahead position.



- Check brake fluid level at brake fluid reservoir for front wheel brake **1**.

 The brake fluid level in the brake-fluid reservoir drops due to brake pad wear.



Front brake fluid level

Brake fluid, DOT4

The brake fluid level must not fall below the MIN mark. (Brake fluid reservoir horizontal, motorcycle standing upright)

If the brake fluid level falls below the approved level:

- Have the defect rectified as quickly as possible by a specialist workshop, preferably an authorized BMW Motorrad retailer.

Checking the rear brake fluid level

WARNING


Insufficient or contaminated brake fluid in the brake fluid reservoir

Considerably reduced braking power caused by air, dirt or water in the brake system


- Stop riding immediately until fault is rectified.
- Check brake fluid level regularly.
- Make sure that the lid of the brake fluid reservoir is cleaned before opening.
- Make sure that brake fluid is used from a sealed container only.

- Hold the motorcycle upright, making sure that the ground is firm and level.
—with center stand^{OE}
- Make sure ground is level and firm and place the motorcycle on its center stand.◁


156 MAINTENANCE



- Check the brake fluid level at the brake fluid reservoir for the rear wheel brake **1**.

 The brake fluid level in the brake-fluid reservoir drops due to brake pad wear.



	Rear brake fluid level (visual inspection)
Brake fluid, DOT4	
The brake fluid level must not fall below the MIN mark.	

If the brake fluid level falls below the approved level:

- Have the defect rectified as quickly as possible by a specialist workshop, preferably an

authorized BMW Motorrad retailer.

CLUTCH


Checking clutch function

- Pull back the clutch lever.
 - » A rising force must be perceptible upon increasing operation.

If no rising force can be felt upon increasing operation:

- Have the clutch checked by a specialist workshop, preferably an authorized BMW Motorrad retailer.

Checking clutch pedal free play



- Actuate clutch lever **1** several times until it touches the handle.
- Actuate clutch lever **1** slightly until you can feel resistance while observing the free play of the clutch pedal **A**.




Clutch cable play

0.12...0.2 in (3...5 mm) (along the outside of the hand lever, handlebars in the straight-ahead position, when the engine is cold)


If clutch play is outside of tolerance:

- Adjust clutch pedal free play (►► 157).

Adjust clutch pedal free play



- Loosen lock nut **1**.
- To increase clutch pedal free play: turn adjusting screw **2** into the handlebar fitting.
- To reduce clutch pedal free play: loosen adjusting screw **2** out of the handlebar fitting.

 The distance between locknuts and nuts (measured inside) must not exceed 0.55 in (14 mm).

If the correct clutch play can only be set through further unscrewing, contact a spe-


cialist workshop, preferably a BMW Motorrad retailer.

- Checking clutch pedal free play (►► 156).
- Tighten lock nut **1**, hold down adjusting screw **2** while doing so.

COOLANT

Checking coolant level


- Park motorcycle on a level, firm surface.
- Turn the handlebars to the right.



- Read the coolant level on the expansion tank **1**. Line of sight: from the rear, through the opening and into the right side trim panel.

158 MAINTENANCE




 Required coolant level

Between the MIN - MAX marks on the expansion tank (Engine cold)


If coolant level drops below approved level:

- Add coolant.

Topping up coolant




- Loosen the radiator cowl screws **1** from the inside.




- Pull the radiator cowl **1** out of the holders **2**.



- Open the expansion tank cap **1**.
- Top up the coolant until it reaches the target level using a suitable funnel.
- Checking coolant level (→ 157).
- Close the cap **1** of the expansion tank.



- Insert the radiator cowl **1** into the holders **2**.
- » The radiator cowl will audibly engage.



- Tighten the radiator cowl screws **1** from the inside.

TIRES

Checking tire pressure

WARNING

Incorrect tire inflation pressure

Poorer handling characteristic of motorcycle, reduction of tire service life

- Ensure proper tire inflation pressure.

WARNING

Automatic opening of vertically installed valve inserts at high speeds

Sudden loss of tire inflation pressure

- Use valve caps with rubber sealing ring and screw on firmly.

- Park motorcycle. Ensure that the ground is firm and level.
- Check tire pressure against data below.



Front tire pressure

31.9 psi (2.2 bar) (One-up, with cold tires)

36.3 psi (2.5 bar) (Driver with passenger and/or load, with cold tire)

160 MAINTENANCE



Rear tire pressure

36.3 psi (2.5 bar) (One-up, with cold tires)

42.1 psi (2.9 bar) (Driver with passenger and/or load, with cold tire)

If tire pressure is too low:

- Correct tire pressure.

Checking tire tread depth



WARNING

Riding with heavily worn tyres

Risk of accident due to poorer rideability

- If necessary, replace the tyres before the legally specified minimum tread depth is reached.

- Park motorcycle. Ensure that the ground is firm and level.
- Measure tire tread depth in main tread grooves with wear marks.



Tread wear marks are integrated into the main grooves on every tire. If the tire tread has worn down to the level of the marks, the tire is completely worn. The locations of the marks are indicated on the edge of the tire, e.g. by the letters TI, TWI or by an arrow.

When the minimum tread depth is reached:

- Replace the worn tire.

RIMS

Checking wheel rims

- Park motorcycle. Ensure that the ground is firm and level.
- Visually inspect rims for defects.
- Have damaged rims checked and, if necessary, renewed by a specialist workshop, preferably an authorized BMW Motorrad retailer.

Checking spokes

- Park motorcycle, ensuring that support surface is firm and level.
- Using the handle of a screwdriver or similar object, run it over the spokes and listen to the sound pattern.

If the sound pattern is uneven:

- Have spokes checked by a specialist workshop, preferably by an authorized BMW Motorrad Retailer.

WHEELS

Tire recommendation

For every tire size, BMW Motorrad has tested and approved certain tire brands as roadworthy. BMW Motorrad cannot evaluate the suitability of any other tires, and can therefore take no responsibility for their riding safety.

BMW Motorrad recommends only using the tires tested and approved by BMW Motorrad. Detailed information can be obtained from your authorized BMW Motorrad Retailer or on-line at

bmw-motorrad.com/service

Effect of wheel sizes on suspension control systems


The wheel sizes play an important role with suspension control systems. The diameter and width of the wheels stored in the control unit have particular significance as the basis for all necessary calculations. A change in these sizes resulting from conversion to wheels not installed as standard equipment can seriously affect the control efficiency of these systems. The sensor rings required for wheel speed detection must

also match the installed control systems and may not be replaced.

If you want to convert your motorcycle to different wheels, please contact a specialist workshop, preferably a BMW Motorrad retailer. In some cases, the data stored in the control units can be adapted for the new wheel sizes.


Removing the front wheel

- Park the motorcycle, making sure that the ground is firm and level.



- Remove screws **1**.
- Carefully swing the lower part of the front wheel cover **2** in the arrow direction.


162 MAINTENANCE



- Remove screw **1** and remove wheel speed sensor from the drilled hole.



- Push the brake pads **3** apart slightly by turning the brake caliper **4** against the brake disc **5**.



- Detach wheel speed sensor cable from holding clips **2** and **3**.
- Remove the mounting bolts **4** of the left and right brake caliper.



ATTENTION

Using hard or sharp-edged objects near the component


Component damage

- Do not scratch components, if necessary tape off or cover.
- Mask off areas of the wheel rim that could be scratched in the process of removing the brake calipers.

**ATTENTION****Unintentional pressing together of brake pads**

Component damage when mounting the brake caliper or when pressing the brake pads apart

- Do not actuate the brakes with the brake caliper removed.
- Carefully pull the brake calipers back and outward to remove them from brake discs.
- Place motorcycle on a suitable auxiliary stand.
- Mounting the rear-wheel stand (▣▣▣▶ 150).
—with center stand^{OE}
- Make sure the ground is level and firm and place the motorcycle on its center stand.◁
- Raise front of motorcycle until the front wheel can turn freely. BMW Motorrad recommends using the BMW Motorrad front wheel stand for propping up the motorcycle.
- Attaching front-wheel stand (▣▣▣▶ 149).



- Remove axle screw **2**.
- Loosen left-side axle clamping screws **3**.




- Loosen right-side axle clamping screws **1**.



- Remove axle **4** while supporting wheel.
- Do not remove grease on axle.

164 MAINTENANCE

- Roll front wheel forward to remove it.



- Remove spacer bushing **5** on left side from wheel hub.

Installing the front wheel

WARNING

Use of a wheel which does not comply with series specifications

Malfunctions during control interventions by ABS and DTC

- Please see the information on the effect of wheel sizes on the ABS and DTC chassis control systems at the beginning of this chapter.

ATTENTION

Tightening of screwed connections with incorrect tightening torque

Damage or loosening of screwed connections

- Always have the tightening torques checked by a specialized workshop, preferably an authorized BMW Motorrad retailer.



- Lubricate the contact surface on the spacer bush **5**.



Lubricant

Unirex N3


- Insert the spacer bushing **5** into the wheel hub on the left side with the seat facing outwards.

ATTENTION

Front wheel installation opposite the running direction

Accident hazard

- Observe running direction arrows on tire or rim.
- Roll the front wheel into the front suspension.



- Lubricate the quick-release axle **4**.





Lubricant

Unirex N3


WARNING

Improper installation of quick-release axle

Loosening of the front wheel



- After the brake caliper is fastened and the spring fork is relaxed, tighten the quick-release axle and axle clamping with the specified torque.
 - Raise the front wheel and insert the quick-release axle **4** as far as possible.
 - Remove front wheel stand and firmly compress front forks. Do not actuate hand-brake lever at the same time.
 - Attaching front-wheel stand ( 149).
- 
- Install the axle screw **2** to the specified torque. Brace quick-release axle on the right side at the same time.


166 MAINTENANCE

 Axle screw in front quick-release axle

37 lb/ft (50 Nm)

- Tighten the left-side axle clamping screws **3** to the specified torque.



 Pinch bolt on quick-release axle

Tightening sequence: Tighten the screws 6 times, alternating between one and the other each time

14 lb/ft (19 Nm)

 Pinch bolt on quick-release axle


Tightening sequence: Tighten the screws 6 times, alternating between one and the other each time

14 lb/ft (19 Nm)


- Position the brake calipers onto the left-hand and right-hand side of the brake discs.



- Tighten the right-side axle clamping screws **1** to the specified torque.



- Tighten the mounting bolts **4** of the left and right brake caliper using an appropriate torque.

 Brake caliper on telescopic forks

28 lb/ft (38 Nm)

- Remove adhesive tape from wheel rim.

 **WARNING**


Brake pads do not contact the brake disc

Risk of accident due to delayed braking effect.

- Before driving off, check that the braking effect kicks in without any delay.
- Engage the brake repeatedly, continuing until the brake pads are against the rotors.
- Insert the wheel speed sensor cable into the holding clips **2** and **3**.




- Insert the wheel speed sensor into the bore and tighten the screw **1** using an appropriate torque.


 Wheel speed sensor at front on fork

Thread-locking compound: micro-encapsulated

6 lb/ft (8 Nm)



- Move the lower part of the front wheel cover **2** into position.
- Install screws **1**.

 Front wheel cover on telescopic forks

Thread-locking compound: micro-encapsulated


2 lb/ft (3 Nm)

- Remove the front-wheel stand.
- without center stand^{OE}
- Remove the auxiliary stand.
- Place motorcycle on its side stand.◁

168 MAINTENANCE

Removing the rear wheel


- Make sure the ground is level and firm and prop the motorcycle up on a suitable auxiliary stand.
- Mounting the rear-wheel stand (▣▶ 150).
–with center stand^{OE}
- Make sure the ground is level and firm and place the motorcycle on its center stand.◁
- Support the rear wheel, e.g. with a wooden block, so that it cannot fall down after the quick-release axle is removed.




- Press the brake caliper **1** against the brake disk **2**.
» Brake pistons are pressed back.




- Remove the screw **3** and remove the wheel speed sensor from the drilled hole.




- Remove the axle nut **4** and washer **5**.
- Remove chain tensioner **6** and push axle in as far as possible.



- Remove the quick-release axle **7** and remove the chain tensioner **8**.




- Roll the rear wheel as far forward as possible and disengage the drive chain **9** from the chain sprocket.



- Roll rear wheel toward rear out of swinging arm

while pulling brake caliper carrier **10** toward rear until rear-wheel rim can be guided past it.

 The camshaft sprocket and the spacing bushings on the left and right are loosely inserted in the wheel. During removal, make sure that the parts are not damaged or lost.

Installing the rear wheel

WARNING

Use of a wheel which does not comply with series specifications

Malfunctions during control interventions by ABS and DTC

- Please see the information on the effect of wheel sizes on the ABS and DTC chassis control systems at the beginning of this chapter.

170 MAINTENANCE

ATTENTION


Tightening of screwed connections with incorrect tightening torque

Damage or loosening of screwed connections


- Always have the tightening torques checked by a specialized workshop, preferably an authorized BMW Motorrad retailer.
- Roll the rear wheel on the support into the swinging arm until the brake-caliper support can be installed.




- Mount brake caliper carrier **1** in guide **2**.



- Roll rear wheel further into swinging arm while simultaneously pushing brake caliper carrier **1** toward front.



- Roll the rear wheel as far forward as possible and place the drive chain **7** on the chain sprocket.




- Insert the right-hand chain tensioner **6** into the swinging arm.
- Lubricate the quick-release axle **5** and install it in the brake caliper carrier **4** and rear wheel.



Lubricant

Unirex N3

- Make sure that the axle fits into the recess of the chain tensioner.



- Insert chain tensioner, left **4**.
- Install washer **3** and axle nut **2**, but do not tighten yet.

—without center stand^{OE}

- Remove the auxiliary stand.◁



- Insert the wheel speed sensor into the bore and tighten the screw **1** using an appropriate torque.



Rear wheel speed sensor on the brake caliper carrier

Thread-locking compound: micro-encapsulated

6 lb/ft (8 Nm)

WARNING

Brake pads do not contact the brake disc

Risk of accident due to delayed braking effect.

- Before driving off, check that the braking effect kicks in without any delay.
- After this work is complete, engage the brake repeatedly, continuing until the brake pads seat against the discs.

172 MAINTENANCE

- Checking chain tension (▶▶▶ 172).
- Adjusting chain tension (▶▶▶ 173).

DRIVE CHAIN

Lubricating drive chain



ATTENTION

Insufficient cleaning and lubrication of the drive chain

Increased wear

- Clean and lubricate the drive chain regularly.
- Lubricate the drive chain every third fuel stop.
- Perform lubrication at shorter intervals after riding in wet conditions, or after riding in dusty or dirty conditions.
- Switch off ignition and engage Neutral.
- Clean drive chain with suitable cleaning agent, dry and apply chain lubricant.
- To extend and maximize the chain's service life BMW Motorrad recommends using BMW Motorrad chain lubricant or:




Lubricant

Chain spray, O-ring compatible

- Wipe off excess lubricant.

Checking chain tension

- Park the motorcycle, making sure that the ground is firm and level.
- Turn the rear wheel until the position with the lowest chain sag is reached.



- Using a screwdriver, push the drive chain in the middle between the pinion and chain sprocket and measure the difference **A**.



Chain sag

1.6...2 in (40...50 mm) (Motorcycle unloaded on side stand)

–with lowered^{OE}
–with seat, low^{OE}


1.4...1.8 in (35...45 mm) (Motorcycle unloaded on side stand)◀

If the measured value is outside the approved tolerance:

- Adjusting chain tension (▶▶ 173).

Adjusting chain tension

- Park the motorcycle, making sure that the ground is firm and level.



- Loosen axle nut **1**.
- Adjust the chain tension with the adjusting screws **3** on the left and right.
- Checking chain tension (▶▶ 172).
- Make sure that the same scale value **2** is set on the left and right.
- Tighten the quick-release axle nut **1** to the tightening torque.



Rear-wheel quick-release axle in swinging arm

Thread-locking compound: mechanical

74 lb/ft (100 Nm)




- Check whether washer **4** is in full contact with screw head **3** and correct if necessary.

Checking chain wear

Requirement

The chain tension is correctly adjusted.

- Park the motorcycle, making sure that the ground is firm and level.



- Check whether the third marker line **1** is fully visible. If the third marker line **1** is fully visible, check the chain length:
 - Engage 1st gear.
 - Rotate the rear wheel toward the front of the motorcycle

174 MAINTENANCE

until the drive chain is tensioned.

- Determine the chain length below the rear wheel swinging arm across the center of 10 rivets.
- Turn the rear wheel in the direction of travel and calculate the chain length at 3 different spots.




Permissible chain length

max 5.7 in (max 144 mm)
(measured over the **center** of
10 rivets, drive chain under
tension)

If the drive chain has reached the maximum approved length:

- Contact a specialist workshop, preferably an authorized BMW Motorrad retailer.



- Check to see whether a rivet head **1** has rotated.

Rivet heads should be parallel to the centerline of the drive chain **2**.

- Riveting is OK.


If one or more rivet heads has rotated:

- Contact a specialist workshop, preferably an authorized BMW Motorrad retailer.


AIR FILTER

Removing air cleaner


- Removing the tank cover (▶▶ 176).




- Unclip hose **1** from retaining lugs **2**.



- To unlock it, press and hold button **3** (arrow **1**).
- Remove frame **4** from the bracket (arrow **2**).




- Make sure that the air filter **5** is attached to the lugs **6** on the frame **4** correctly.




- Remove frame **4**.
- Remove air filter element **5**.


Installing the air filter



- Install the air filter **5** in the frame **4**.



- Install frame **4**.



- Clip hose **1** into retaining lugs **2**.

LIGHT SOURCE

Replacing the LED light source



WARNING

Overlooking the vehicle in traffic due to a defective light source on the vehicle

Safety risk


- Replace defective light sources as quickly as possible. For details please contact a specialist service facility, preferably an authorized BMW Motorrad Retailer.

All light sources on the vehicle except the license plate illumination are LED light sources. The service life of the LED light sources is longer than the assumed service life of the vehicle. If an LED light source is faulty, please contact a specialist workshop, preferably an authorized BMW Motorrad retailer.

TRIM PANEL COMPONENTS


Removing the tank cover

- Removing seat (▶▶▶ 72).



- Remove screws **1**.
- Remove screws **2**.
- Remove the tank cover **3**; when doing so, pay attention to fastening clips and retaining lugs.

Refitting fuel tank cover



- Ensure that the six holders **2** in the retaining collar **3** and the four sockets **5** in the mounting brackets **4** lock into place.
- Refitting fuel tank cover **1**.



- Install screws **2**.
- Install screws **1**.
- Installing seat (➡ 73).

JUMP-STARTING

CAUTION

Touching live parts of the ignition system when the engine is running

Electrocution

- Do not touch parts of the ignition system when the engine is running.

ATTENTION

Current too high when jump-starting the motorcycle

Cable fire or damage to the motorcycle electronics

- Do not jump-start the motorcycle using the power socket, only via the battery terminal.

ATTENTION

Contact between crocodile clips of jump leads and motorcycle

Danger of short circuit

- Use jump leads fitted with fully insulated crocodile clips at both ends.


ATTENTION

Jump-starting with a voltage higher than 12 V

Damage to the motorcycle's electronics

- The battery of the donor motorcycle must have a voltage of 12 V.


- Removing seat (➡ 72).
- Do not disconnect the battery from the electrical system for external starting.



- Push in the locking mechanism and open the positive terminal cover **1**.

178 MAINTENANCE

- First connect the positive terminal of the drained battery to the positive terminal on the donor battery using the red jumper cable (positive terminal on this vehicle: position **2**).
- Connect the black jumper cable to the negative terminal of the donor battery and then to the negative terminal of the drained battery (negative terminal on this vehicle: position **3**).

 As an alternative to the negative battery terminal, the spring strut bolt can also be used.

- Run the engine of the donor vehicle during jump-starting.
- Start the engine of the vehicle with the drained battery in the usual way; if the engine does not start, wait a few minutes before repeating the attempt to protect the starter motor and the donor battery.
- Allow both engines to idle for a few minutes before disconnecting the jumper cable.
- Disconnect the jumper cable from the negative terminals first, then disconnect the second cable from the positive terminals.



To start the engine, do not use start sprays or similar items.

- Installing seat (▶▶▶ 73).

BATTERY

Maintenance instructions

Correct battery maintenance combined with proper charging and storage procedures extends the battery's service life, and is also required for warranty claims.

Compliance with the points below is important in order to maximize battery life:

- Keep the surface of the battery clean and dry.
- Do not open the battery.
- Do not top up with water.
- Be sure to read and comply with the instructions for charging the battery on the following pages.
- Do not turn the battery upside down.

**ATTENTION****Discharging of the connected battery by the vehicle electronics (e.g. clock)**

Total discharge of battery leading to a rejection of warranty claims

- During riding breaks of more than 4 weeks, connect a trickle-charger to the battery.



BMW Motorrad has developed a trickle-charger specially designed for compatibility with the electronics of your motorcycle. Using this charger, you can keep the battery charged during long periods when the motorcycle is not being used without having to disconnect the battery from the motorcycle's onboard systems. Additional information is available at your authorized BMW Motorrad retailer.

Charging connected battery

- Remove devices connected to onboard power sockets.

**ATTENTION****Charging the battery connected to the vehicle using the battery terminals**

Damage to the motorcycle's electronics

- Disconnect the battery before charging on the battery terminals.

**ATTENTION****Unsuitable chargers connected to the power socket**

Damage to charger and vehicle electronics

- Use suitable BMW chargers. The correct charger is available through your authorized BMW Motorrad retailer.



ATTENTION

A fully discharged battery must be charged via a power socket or extra socket.

Damage to vehicle electronics

- A fully discharged battery (battery voltage less than 12 V, indicator lights and multifunction display remain off when ignition is switched on) must always be charged directly at the poles of the **disconnected** battery.

- Charge disconnected battery via onboard socket.



The motorcycle's onboard electronics know when the battery is fully charged. The onboard socket is switched off when this happens.

- Comply with operating instructions of charger.



If you are unable to charge the battery via the onboard socket, you may be using a charger that is not compatible with your motorcycle's electronics. In this case, charge the battery directly from the terminals of the battery disconnected from the vehicle.

Charging disconnected battery

- Charge battery using a suitable charger.
- Comply with operating instructions of charger.
- After charging, remove the terminal clips of the charger from the battery poles.



In the case of longer periods when the motorcycle is not being used, the battery must be recharged regularly. See the instructions for caring for your battery. Always fully recharge the battery before returning it to use.

Removing the battery

- Park the motorcycle, making sure that the ground is firm and level.
- Removing seat (▶▶▶ 72).
–with anti-theft alarm system (DWA)^{OE}
- Switch off the anti-theft alarm if necessary.◀
- Switch off the ignition.

**ATTENTION****Incorrect battery disconnection**

Danger of short circuit

- Follow the disconnection sequence.


- First, remove the negative battery cable **3**.
- Push in the lock and open the positive terminal cover **1**.
- Then, remove the positive battery cable **2**.
- Remove screws **4** and take off battery carrier **5** forward from the battery.
- Lift the battery up and out, using tilting movements if the movement is stiff.

Installing the battery

If the vehicle has been disconnected from the battery for a long time, the current date must be entered in the instrument cluster to

make sure the service display is working properly.

- Switch off the ignition.
- Insert the battery into the battery compartment with positive terminal on the right in the direction of travel.


**ATTENTION****Incorrect battery connection**

Danger of short circuit

- Follow the installation sequence.

- Install positive battery cable **2**.
- Close positive terminal cover **1**.

182 MAINTENANCE



- Install the negative battery cable in alignment with **6**, making sure there is a sufficient distance between the negative battery cable and the seat locking lever.

–with anti-theft alarm system (DWA)^{OE}

- Switch on the anti-theft alarm system if necessary. <
- Installing seat (➡ 73).
- Setting the clock (➡ 85).
- Setting the date (➡ 84).

FUSES

Replace main fuse



ATTENTION

Bypassing defective fuses


Risk of short circuit and fire

- Do not bypass defective fuses.
 - Replace defective fuses with new fuses.
-
- Switch off the ignition.

- Place the motorcycle on its stand on firm, even ground.
- Removing seat (➡ 72).



- Replace faulty fuse **1**.

 If the fuses blow frequently, have the electrical system checked by an authorized specialized workshop, preferably an authorized BMW Motorrad retailer.




Main fuse

40 A (Voltage regulator)

- Installing seat (➡ 73).

Replacing fuses



- Switch off the ignition.
- Removing seat (► 72).
- Pull off the fuse box **1**.



ATTENTION

Bypassing defective fuses

Risk of short circuit and fire

- Do not bypass defective fuses.
- Replace defective fuses with new fuses.

- Replace the faulty fuse **1** or **2** replace fuses according to their assignment.



If the fuses blow frequently, have the electrical system checked by an authorized specialized workshop, preferably an authorized BMW Motorrad retailer.



Fuse box

10 A (Slot 1: instrument cluster, anti-theft alarm system (DWA), ignition lock, diagnostic socket, coil main relay)

7.5 A (Slot 2: left multifunction switch, Tire Pressure Control (TPC/RDC))

- Insert the fuse box.
- Installing seat (► 73).

DIAGNOSTIC SOCKET

Removing the diagnostic connector



CAUTION

Incorrect procedure followed when disconnecting the data link connector for the On-Board Diagnostics.

Motorcycle experiences malfunctions

- Only have the data link connector disconnected by a specialist workshop or other authorized persons during your next BMW Service appointment.
- Have the work performed by appropriately trained staff.
- Refer to the vehicle manufacturer specifications.

- Removing seat (➡ 72).




- Press the locking mechanisms **1** on both sides.

- Unplug the data link connector **2** from the bracket **3**.
 - » The diagnosis and information system interface can be connected at the data link connector **2**.

Secure the data link connector

- Disconnect the diagnosis and information system interface.



- Plug the seat data link connector **2** into the holder **3**.
 - » The locks **1** engage.
- Installing seat (➡ 73).

ACCESSORIES

10

GENERAL NOTES	188
ONBOARD POWER SOCKETS	188
USB CHARGING SOCKET	189
CASES	190
TOPCASE	193
NAVIGATION SYSTEM	196

GENERAL NOTES



CAUTION

Use of products from other manufacturers

Safety risk

- BMW Motorrad cannot examine or test each product of outside origin to ensure that it can be used on or in connection with BMW motorcycles without constituting a safety hazard. Nor is this guarantee provided when the official approval of a specific country has been granted. Tests conducted by these instances cannot make provision for all operating conditions experienced by BMW motorcycles and, consequently, they are not sufficient in some circumstances.
- Use only parts and accessories approved by BMW for your motorcycle.

The safety, operation and suitability of the parts and accessory products have been thoroughly tested by BMW. Therefore, BMW assumes responsibility for these products. BMW shall not be held liable for un-

approved parts and accessory products of any kind.

Comply with legal requirements for any modifications.

The motorcycle shall not violate the regulations governing motorcycle approval for highway use applicable in your own country.

Your BMW Motorrad retailer offers you expert advice when choosing genuine BMW parts, accessories and other products. More information on the topic of accessories is available at: bmw-motorrad.com/equipment

ONBOARD POWER SOCKETS

Notes on using onboard power sockets:

Automatic shut-off

Power outlets are switched off automatically in the following circumstances:

- If the battery voltage is too low to retain the starting capability of the vehicle.
- If the maximum load specified in the technical data is exceeded.
- During the starting mode.

Operating electrical accessories

The ignition must be switched on before any accessories connected to the power sockets can be operated. If the ignition is then switched off, the accessory remains in operation. The sockets are switched off approx. 15 minutes after switching off the ignition to reduce the strain on the onboard electrical system.

Accessories with low power consumption are possibly not detected by the vehicle electronics. In these cases, onboard sockets are already switched off shortly after the ignition is switched off.

Cable routing

Observe the following when routing cable from power sockets to additional devices:

- Cables must not impede the rider.
- Cables must not restrict the steering angle and driving characteristics.
- Cables must not become trapped.

USB CHARGING SOCKET

Notes about use:

Charge current

This is a 5 V USB charging socket providing a maximum charge current of 2.4 A.

Automatic shut-off

The USB charging sockets are automatically switched off under the following conditions:

- To retain the starting capability if the battery voltage is too low.
- If the maximum load capacity specified in the technical data is exceeded.
- During the starting procedure.

Connection of electrical devices

The ignition must be switched on before electrical devices connected to USB charging sockets can be operated. To reduce loads on the electrical system, these are switched off no more than 15 minutes after the ignition is switched off. To protect the connected device, the device should be unplugged when riding in rain. When no device is connected, the cover should be closed to prevent soiling.

190 ACCESSORIES

Cable routing

Observe the following when routing cables from USB charging sockets to additional devices:

- Cables must not impede the rider.
- Cables must not restrict the steering angle and handling characteristics.
- Cables must not become trapped.



- Press yellow button down **1** and open case cover at the same time.

CASES

Open case

-with case^{OA}



- Turn key **1** clockwise.
- Press and hold yellow locking mechanism **2** and open handle **3**.

Adjusting case volume

-with case^{OA}

- Open case and empty it.



- Engage swivel arm **1** into its upper end position to obtain the smallest volume.
- Engage swivel arm **1** into its lower end position to obtain the largest volume.
- Close case.



Case volume, left

6.6...9.2 gal (25...35 l)




Case volume, right

4...6.1 gal (15...23 l)

Close case

–with case^{OA}

- Turn key in case lock transversely to the direction of travel.
- Close case lid.
- » The lid clicks audibly into place.



ATTENTION

Folding down the carrying handle when the case is locked

Damage to the locking tab


- Before folding down the carrying handle, make sure that the slot of the case lock is perpendicular to the direction of travel.

- Shut carrying handle **1**.


- Turn key **2** counterclockwise and remove.

Remove case

–with case^{OA}



- Turn the ignition key **1** clockwise.
- Press and hold yellow locking mechanism **2** and open carrying handle **3**.



- Pull up red release lever **1**.
- » Locking mechanism **2** springs open.
- Fully open locking mechanism.
- Remove case on the carrying handle from the bracket.


192 ACCESSORIES

Attaching a case


—with case^{OA}




- Pull the red release lever **1** upwards.
 - » Locking mechanism **2** springs open.
- Fully fold-out locking mechanism.



- Push locking mechanism **1** down until you feel resistance.
- Then push down locking mechanism and red release lever **2** at the same time.
 - » Locking mechanism engages.



- Insert case from above into brackets **1** and **2**.



ATTENTION

Folding down the carrying handle when the case is locked

Damage to the locking tab

- Before folding down the carrying handle, make sure that the slot of the case lock is perpendicular to the direction of travel.

- Shut carrying handle **1**.
- Turn key **2** counterclockwise and remove.

Maximum payload and maximum speed

Observe maximum payload and maximum speed.



Maximum speed for riding with case

max 99 mph (max 160 km/h)



Payload per case

max 18 lbs (max 8 kg)

TOPCASE

Open topcase

–with topcase^{OA}



- Turn key **1** clockwise.
- Press and hold yellow locking mechanism **2** and open handle **3**.



- Push forward yellow button **1** and open topcase cover at the same time.

Adjust topcase volumes

–with topcase^{OA}

- Open topcase and empty it.




- Lock swivel arm **1** into its most forward position to obtain the largest volume.
- Lock swivel arm **1** as far back as it goes to obtain the smallest volume.
- Close topcase.

194 ACCESSORIES

Close topcase

—with topcase^{OA}

- Close topcase cover forcefully.



ATTENTION


Folding down the carrying handle when the case is locked

Damage to the locking tab

- Before folding down the carrying handle, make sure that the slot of the topcase lock is vertical.
- Shut carrying handle **1**.
 - » Carrying handle audibly engages.
- Turn key **2** counterclockwise and remove.

Remove topcase

—with topcase^{OA}




- Turn key **1** clockwise.
- Press and hold yellow locking mechanism **2** and open handle **3**.




- Pull back red lever **1**.
 - » Locking mechanism **2** springs open.
- Fully open locking mechanism.
- Remove topcase on the carrying handle from the bracket.

Mount topcase

—with topcase^{OA}




- Pull back red lever **1**.
» Locking mechanism **2** springs open.
- Fully open locking mechanism.



- Mount topcase onto the front brackets **1** of the topcase mounting plate.
- Push topcase back on the topcase mounting plate.



- Push locking mechanism **1** forward until you feel resistance.
- Then push forward locking mechanism and red release lever **2** at the same time.
» Locking mechanism engages.



ATTENTION

Folding down the carrying handle when the case is locked

Damage to the locking tab

- Before folding down the carrying handle, make sure that the slot of the topcase lock is vertical.

196 ACCESSORIES

- Shut carrying handle **1**.
» Carrying handle audibly engages.
- Turn key **2** counterclockwise and remove.

Maximum payload and maximum speed

Observe maximum payload and maximum speed.




Maximum speed when riding with a loaded topcase

max 99 mph (max 160 km/h)



Payload of Topcase

max 11 lbs (max 5 kg)





- Turn the ignition key **1** counterclockwise.
- Pull the shut-off lock **2** to the **left**.
- Press in the locking mechanism **3**.
» The Mount Cradle is unlocked and the cover **4** can be removed with a rotational movement toward the front.


NAVIGATION SYSTEM

–with preparation for navigation system^{OE}

Securely fastening navigation device

 The navigation preparation is suitable as from the BMW Motorrad Navigator IV.

 The locking system of the Mount Cradle offers no protection against theft. Remove the navigation system and store in a safe place after every drive.



- Mount the navigation device **1** in the lower area and swing backward with a rotational movement.
» Navigation device audibly engages.
- Slide the shut-off lock **2** completely to the **right**.

- » The locking mechanism **3** is locked.
- Turn the ignition key **4** clockwise.
- » Navigation device is locked and ignition key can be removed.

Removing the navigation device and installing the cover panel




ATTENTION

Dust and dirt on the contacts of the Mount Cradle


Damage to the contacts

- Reinstall the cover after end of each drive.



- Turn the ignition key **1** counterclockwise.
- Pull the shut-off lock **2** completely to the **left**.
- » The locking mechanism **3** is unlocked.
- Slide the locking mechanism **3** completely to the **left**.

- » Navigation device **4** is unlocked.
- Remove navigation device **4** downward with a tilting movement.




- Mount the cover **1** in the lower area and swing upward with a rotational movement.
- » Cover audibly engages.
- Slide the shut-off lock **2** to the **right**.
- Turn the ignition key **3** clockwise.
- » The cover **1** is locked and ignition key can be removed.

Operating the navigation system




The following description refers to the BMW Motorrad Navigator V and the BMW Motorrad Navigator VI. The BMW Motorrad Navigator IV does not offer all options described.

198 ACCESSORIES

 Only the latest version of the BMW Motorrad communication system is supported. A software update may be required for the BMW Motorrad communication system. In this case, please contact your authorized BMW Motorrad retailer.

If the BMW Motorrad Navigator is installed and the operating focus is switched to the Navigator (➡ 81), some of its functions can be operated directly from the handlebars.



The navigation system is operated using the Multi-Controller **1** and the rocker button **MENU 2**.

Turning the Multi-Controller 1 up and down

On the compass and Mediaplayer page: Increase or decrease the volume of a BMW Motorrad communication

system connected via Bluetooth.

On the BMW special menu: Select menu items.


Briefly tilt the Multi-Controller 1 to the left and to the right


Switch between the main pages of the Navigator:

- Map view
- Compass
- Mediaplayer
- BMW special menu
- My motorcycle page

Tilt and hold the Multi-Controller 1 to the left and to the right

Activate specific functions on the Navigator display. These functions are marked with a right arrow or a left arrow above the corresponding touch field.

 The function is triggered by long actuation to the right.

 The function is triggered by long actuation to the left.

Press the bottom of the rocker button MENU 2

Switch the operating focus to the Pure Ride view.

In detail, the following functions can be operated:

Map view

- Turn upward: zooms into map section (Zoom in).
- Turn downward: zooms out of map section (Zoom out).

BMW special menu

- Speak: Repeat last navigation announcement.
- Waypoint: Save current location as a favorite.
- Navigate home: Starts navigation to the home address (is grayed-out if no home address is set).
- Mute: Switch automatic navigation announcements off or on (off: the top line in the display shows a crossed-out lip icon). Navigation announcements can still be output via "Speak". All other sound outputs remain switched on.
- Switching off display: Switch off display.
- Call home: Calls the phone number stored in the navigator (only displayed when a phone is connected).

- Detour: Activates the detour function (only displayed if a route is active).
- Skip: Skips the next waypoint (only displayed if route is provided with waypoints).

My Motorcycle

- Turn: Changes the number of the displayed data.
- Tapping a data field on the display opens a menu for selecting the data.
- The values available for selection depend on the optional equipment that is installed.



The MediaPlayer function is only available when using a Bluetooth device as per A2DP standard, e.g., a BMW Motorrad communication system.

MediaPlayer


- Long press to the left: Play previous title.
- Long press to the right: Play next title.
- Turning increases or reduces the volume of a BMW Motorrad communication system connected via Bluetooth.

200 ACCESSORIES

Warning and status messages




Warning and status messages of the motorcycle are indicated with a corresponding symbol **1** at the upper left on the map view.

 If a BMW Motorrad communication system is connected, an acoustic signal is also sounds in case of a warning.

If several warning messages are active, the number of messages is indicated below the warning triangle.

A list of all warning messages is opened by pressing on the warning triangle with more than one message. Additional information is display when a message is selected.

 Detailed information cannot be displayed for all warnings.

Special functions

Due to integration of the BMW Motorrad Navigator, there are differences from the descriptions in the Operating Instructions for the Navigator.

Reserve fuel level warning

The settings for the fuel gauge are not available because the low-fuel warning light is transmitted from the vehicle to the Navigator. If the message is active, the nearest gas stations are shown when you press on the message.

Time and date display

The Navigator transmits the time and date to the motorcycle. In order to adopt the time in the TFT display, in the menu **Settings, System settings, Date and time** the function **GPS synchronization** also needs to be activated.

Security settings

The BMW Motorrad Navigator V and the BMW Motorrad Navigator VI can be secured against unauthorized use with a four-digit PIN (Garmin Lock). If this function is activated, while the Navigator is cradled on the motorcycle and the ignition is switched on you are prompted

to add the motorcycle to the list of secured vehicles. If you confirm this question by answering "yes", then the Navigator will save the vehicle identification number of this vehicle. A maximum of five VINs can be saved in this way.

A PIN entry will no longer be required when this Navigator is activated by turning on the ignition switch in any of these vehicles.

Removing the Navigator from the motorcycle while it is switched on will launch a new PIN request as a security measure.

Screen brightness

Screen brightness is adjusted by the motorcycle while the unit is cradled. There is no need for manual input.

If desired, automatic setting can be switched off in the Navigator via the display settings.

CARE

11

CARE PRODUCTS	204
WASHING YOUR MOTORCYCLE	204
CLEANING SENSITIVE MOTORCYCLE PARTS	205
CARE OF PAINTWORK	206
PAINT PRESERVATION	207
STORING THE MOTORCYCLE	207
PUTTING THE MOTORCYCLE INTO OPERATION	207

CARE PRODUCTS

BMW Motorrad recommends that you use cleaning and care products available at your authorized BMW Motorrad retailer. BMW Care Products have been materials tested, laboratory tested, and field tested and provide optimum care and protection for the materials used in your motorcycle.



ATTENTION

Use of unsuitable cleaning and care agents

Damage to motorcycle parts

- Do not use any solvents such as nitro thinners, cold cleaners, fuel or similar, and do not use cleaning agents that contain alcohol.



ATTENTION

Use of highly acidic or alkaline cleaning agents

Damage to motorcycle parts

- Observe the dilution ratio on the packaging of the cleaning agents.
- Do not use highly acidic or alkaline cleaning agents.

WASHING YOUR MOTORCYCLE

BMW Motorrad recommends that you use BMW Insect Remover to soften and wash off insects and stubborn dirt from painted parts before washing the motorcycle.

To prevent stains, do not wash the vehicle immediately after it has been exposed to bright sunlight and do not wash it in the sun.

Regularly clean the fork tubes of soiling.

Make sure that the motorcycle is washed frequently, especially during the winter months.

To remove road salt, clean the motorcycle with cold water immediately after every trip.



WARNING

Damp brake disks and brake pads after washing the motorcycle, after riding through water or in the rain

Poorer braking action, accident hazard

- Brake early until the brake rotors and brake pads are dry.

**ATTENTION****Increased effect of salt caused by warm water**

Corrosion

- Only use cold water to remove road salt.

**ATTENTION****Damage caused by high water pressure from high-pressure cleaners or steam-jet devices**

Corrosion or short circuit, damage to labels, to seals, to hydraulic brake system, to the electrical system and the seat

- Exercise caution when using high-pressure or steam-jet devices.

CLEANING SENSITIVE MOTORCYCLE PARTS**Plastics****ATTENTION****Use of unsuitable cleaning agents**

Damage to plastic surfaces

- Do not use abrasive cleaners or cleaners containing alcohol or solvents.
- Do not use insect sponges or sponges with a hard surface.

Trim panel components

Clean trim panel components with water and BMW Motorrad cleaning agent.

Windshields and turn indicator glass are manufactured of plastic

Clean off dirt and insects with a soft sponge and plenty of water.



Soften stubborn dirt and dead insects by covering the affected areas with a wet cloth.

206 CARE

TFT display

Clean the TFT display with warm water and detergent. Then dry with a clean cloth, e.g. a paper towel.

Chrome

Carefully clean chrome parts with plenty of water and BMW Motorrad Care Products motorcycle cleaner. This is required in particular for removing road salt. Use BMW Motorrad metal polish for additional treatment.

Radiator

Clean the radiator regularly to prevent overheating of the engine due to inadequate cooling. For example, use a garden hose with low water pressure.



ATTENTION

Bending of radiator fins

Damage to radiator fins

- When cleaning, ensure that the cooler fins are not bent.

Rubber

Treat rubber components with water or BMW rubber care product.



ATTENTION

Use of silicone sprays for care of rubber seals

Damage to rubber seals

- Do not use silicone sprays or care products that contain silicone.

CARE OF PAINTWORK

Washing the motorcycle regularly will help counteract the long-term effects of substances that damage the paint, especially if your motorcycle is ridden in areas with high air pollution or natural sources of dirt, such as tree resin or pollen. However, remove particularly aggressive substances immediately; otherwise changes in the paint or discoloration may occur. These include spilled fuel, oil, grease and brake fluid as well as bird droppings. It is recommended to use BMW Motorrad solvent cleaner and then apply BMW Motorrad high gloss polish to preserve the paint. Contaminants on the paint surface are particularly easy to see after washing the vehicle. Remove this type of dirt immediately with cleaning benzene

or ethyl alcohol on a clean cloth or cotton ball. BMW Motorrad recommends removing tar stains with BMW tar remover. Then add a protective wax coating to the paint at these locations.


PAINT PRESERVATION

Apply a preservative when water fails to bead up on the painted surface.

BMW Motorrad recommends BMW Motorrad high gloss polish or agents that contain carnauba or synthetic wax for paint preservation.

STORING THE MOTORCYCLE

- Completely fill the motorcycle's fuel tank.

 Fuel additives clean the fuel injection system and the combustion area. Fuel additives should be used when refueling with low-quality fuels or during longer periods of downtime. Your authorized BMW Motorrad retailer can provide you with more detailed information.

- Clean the motorcycle.
- Remove battery.
- Spray brake lever and clutch lever as well as side stand pivots with a suitable lubricant.

- Coat bare metal and chrome plated parts with an acid-free grease (petroleum jelly).
- Park motorcycle in a dry room, raising it to relieve weight from both wheels (preferably using the front-wheel and rear-wheel stands offered by BMW Motorrad).

PUTTING THE MOTORCYCLE INTO OPERATION

- Remove the protective wax coating.
- Clean the motorcycle.
- Install the battery.
- Checklist (▶▶▶ 111).

TECHNICAL DATA

12

TROUBLESHOOTING CHART	210
SCREW CONNECTIONS	212
FUEL	214
ENGINE OIL	214
ENGINE	215
CLUTCH	216
TRANSMISSION	216
REAR-WHEEL DRIVE	216
FRAME	217
CHASSIS	217
BRAKES	218
WHEELS AND TIRES	218
ELECTRICAL SYSTEM	219
DIMENSIONS	221
WEIGHTS	222
PERFORMANCE DATA	222

210 TECHNICAL DATA

TROUBLESHOOTING CHART

Engine does not start:

Possible cause	Remedy
Side stand extended and gear engaged	Engage neutral or fold in side stand.
Gear engaged and clutch not disengaged	Shift transmission to neutral or disengage clutch.
No fuel in tank	Refueling.
Battery drained	Charge the connected battery.
Overheating protection for starter motor has triggered. Starter motor can only be actuated for a limited period.	Leave the starter motor to cool down for around 1 minute until it becomes available again.

Bluetooth connection is not established.

Possible cause	Remedy
Necessary pairing steps were not performed.	Refer to the operating instructions of the communication system for the necessary steps for pairing.
The communication system is not connected automatically despite successful pairing.	Switch off the communication system of the helmet and connect again after one to two minutes.
Too many Bluetooth devices are stored in the helmet.	Delete all pairing entries in the helmet (see the operating instructions of the communication system).
There are additional vehicles with Bluetooth-capable devices nearby.	Avoid simultaneous pairing with multiple vehicles.

212 TECHNICAL DATA

SCREW CONNECTIONS

Front wheel	Value	Valid
Wheel speed sensor at front on fork		
M6 x 16, Renew bolt micro-encapsulated	6 lb/ft (8 Nm)	
Front wheel cover on telescopic forks		
M6 x 16, Renew bolt micro-encapsulated	2 lb/ft (3 Nm)	
Brake caliper on telescopic forks		
M10 x 45	28 lb/ft (38 Nm)	
Pinch bolt on quick-release axle		
M8 x 35	Tightening sequence: Tighten the screws 6 times, alternating between one and the other each time	
	14 lb/ft (19 Nm)	
Axle screw in front quick-release axle		
M20 x 1.5	37 lb/ft (50 Nm)	
Rear wheel	Value	Valid
Rear wheel speed sensor on the brake caliper carrier		
M6 x 16, Renew bolt micro-encapsulated	6 lb/ft (8 Nm)	

Rear wheel	Value	Valid
Rear-wheel quick-release axle in swinging arm		
M24 x 1.5 mechanical	74 lb/ft (100 Nm)	
Mirror arm	Value	Valid
Mirror (locknut) on clamping piece		
M10 x 1.25	Left-hand thread, 16 lb/ft (22 Nm)	
Adapter to clamping block		
M10 x 14 - 4.8	18 lb/ft (25 Nm)	

214 TECHNICAL DATA

FUEL

Recommended fuel quality	Regular unleaded (max. 15% ethanol, E15) 87 AKI (91 ROZ/RON) 87 AKI
Usable fuel quantity	Approx. 4 gal (Approx. 15 l)
Reserve fuel quantity	Approx. 3.7 quarts (Approx. 3.5 l)
Fuel consumption	57 mpg (4.1 l/100 km), according to WMTC
CO2 emissions	98 g/km, according to WMTC
Emission standard	TIER 2

ENGINE OIL

Engine oil, capacity	Approx. 3.2 quarts (Approx. 3.0 l), with filter replacement
Specification	SAE 5W-40, API SL/ JASO MA2, Additives (for instance, molybdenum-based substances) are prohibited, because they would attack the coatings on engine components, BMW Motorrad recommends BMW Motorrad ADVANTEC Ultimate oil.

BMW recommends **ADVANTEC**
ORIGINAL BMW ENGINE OIL

Oil additives	BMW Motorrad does not recommend the use of oil additives, as these can adversely affect the operation of the clutch. Ask your BMW Motorrad retailer for engine oils suitable for your motorcycle.
Engine oil, quantity for topping up	max 0.5 quarts (max 0.5 l), Difference between MIN and MAX

BMW recommends  **ADVANTEC**
ORIGINAL BMW ENGINE OIL

ENGINE

Engine number location	Upper right crankcase
Engine type	A24A08B
Engine design	Water-cooled 2-cylinder four-stroke engine with four valves (operated via rocker arms) per cylinder, two overhead camshafts and dry-sump lubrication
Displacement	853 cc (853 cm ³)
Cylinder bore	3.3 in (84 mm)
Piston stroke	3 in (77 mm)
Compression ratio	13.1:1
Nominal capacity	89 hp (66 kW), at RPM: 8000 min ⁻¹
Torque	63 lb/ft (86 Nm), at RPM: 6250 min ⁻¹
Maximum engine speed	max 9000 min ⁻¹
Idle speed	1250 ^{±50} min ⁻¹ , Engine at operating temperature

216 TECHNICAL DATA

CLUTCH

Clutch design	Multiple-disc oil bath (anti-hopping)
---------------	---------------------------------------

TRANSMISSION

Transmission design	Claw-shifted 6-speed manual gearbox integrated in engine housing
Transmission gear ratios	1.821, Primary gear ratio 1:2.833, 1st gear 1:2.067, 2nd gear 1:1.600, 3rd gear 1:1.308, 4th gear 1:1.103, 5th gear 1:0.968, 6th gear

REAR-WHEEL DRIVE

Type of final drive	Chain drive
Chain sag	1.6...2 in (40...50 mm), Motorcycle unloaded on side stand
-with lowered ^{OE} -with seat, low ^{OE}	1.4...1.8 in (35...45 mm), Motorcycle unloaded on side stand
Permissible chain length	max 5.7 in (max 144 mm), measured over the center of 10 rivets, drive chain under tension
Number of teeth of rear-wheel drive (Pinion/sprocket)	17/44
Secondary gear ratio	2.588

FRAME

Frame design	Steel weigh-bridge frame in shell construction
Location of type plate	Frame at front left on steering head
Location of the vehicle identification number	Frame at front right next to steering head

CHASSIS**Front wheel**

Type of front suspension	Upside-down telescopic forks
Spring travel, front	9.1 in (230 mm), on front wheel
–with lowered ^{OE}	8.3 in (210 mm), on front wheel

Rear wheel

Type of rear-wheel guide	Two-arm aluminum swinging arm
Design of rear-wheel suspension	Central spring strut with coil spring, adjustable rebound-stage damping and spring preload
Spring travel on the rear wheel	8.5 in (215 mm), on rear wheel
–with lowered ^{OE}	7.7 in (195 mm), on rear wheel

218 TECHNICAL DATA

BRAKES

Front wheel

Type of front wheel brake	Hydraulically operated twin disc brake with 2-piston floating calipers and floating brake discs
Front brake pad material	Sintered metal
Front brake disc thickness	0.18 in (4.5 mm), New min 0.16 in (min 4.0 mm), Wear limit
Free travel of brake actuation (Front wheel brake)	0.03...0.07 in (0.7...1.7 mm), measured at the piston

Rear wheel

Type of rear wheel brake	Hydraulically operated disc brake with 1-piston floating caliper and fixed brake disk
Rear brake pad material	Organic
Rear brake disc thickness	0.2 in (5.0 mm), New min 0.18 in (min 4.5 mm), Wear limit
Blow-by clearance of foot-brake lever	0.07...0.08 in (1.9...2.1 mm), At the end stop of the foot brake lever on the footrest plate.

WHEELS AND TIRES

Recommended tire combinations	An overview of the current tire approvals is available from your authorized BMW Motorrad retailer or on the Internet at bmw-motorrad.com .
Speed category of front/rear tires	V, minimum requirement: 149 mph (240 km/h)

Front wheel

Front wheel design	Cross spoke wheel
Front-wheel rim size	2.15" x 21" MTH2
Front tire designation	90/90-21
Load index for front tire	54
Permissible front-wheel imbalance	max 0.2 oz (max 5 g)

Rear wheel

Rear wheel design	Cross spoke wheel
Rear-wheel rim size	4.25" x 17" MTH2
Rear tire designation	150/70 R 17
Load index for rear tire	69
Permissible rear-wheel imbalance	max 0.2 oz (max 5 g)

Tire pressure

Front tire pressure	31.9 psi (2.2 bar), One-up, with cold tires 36.3 psi (2.5 bar), Driver with passenger and/or load, with cold tire
Rear tire pressure	36.3 psi (2.5 bar), One-up, with cold tires 42.1 psi (2.9 bar), Driver with passenger and/or load, with cold tire

ELECTRICAL SYSTEM

Main fuse	40 A, Voltage regulator
-----------	-------------------------

220 TECHNICAL DATA

Fuse box	10 A, Slot 1: instrument cluster, anti-theft alarm system (DWA), ignition lock, diagnostic socket, coil main relay 7.5 A, Slot 2: left multifunction switch, Tire Pressure Control (TPC/RDC)
Fuses	All electrical circuits are electronically protected. If an electric circuit was switched off by the electronic fuse and if the fault that caused this has been rectified, the electric circuit will be active again after switching on the ignition.
Electrical rating of onboard sockets	5 A (in total)
Battery	
Battery design	AGM battery (Absorbent Glass Mat)
Battery voltage	12 V
Battery capacity	10 Ah
Battery type (For Keyless Ride radio-operated key)	
–with Keyless Ride ^{OE}	CR 2032
Spark plugs	
Spark plugs, manufacturer and designation	NGK LMAR9J-9E

Light source	
Bulb for high-beam headlight	LED
Bulbs for low-beam headlight	LED
Bulb for parking light	LED
Bulb for taillight/brake light	LED
Light source for license plate light	W5W 12 V 5 W
Bulbs for flashing turn indicators	LED

DIMENSIONS

Motorcycle length	90.7 in (2305 mm), over license-plate carrier
–with lowered ^{OE}	90.4 in (2295 mm), over license-plate carrier
Motorcycle height	53.4...55.6 in (1356...1411 mm), over windshield, at DIN unloaded vehicle weight
–with lowered ^{OE}	52.4...54.5 in (1330...1385 mm), over windshield, at DIN unloaded vehicle weight
Motorcycle width	34.5 in (877 mm), without mounted parts 38.9 in (988 mm), with case
Front-seat height	33.9 in (860 mm), without rider, at DIN unloaded vehicle weight
–with seat, low ^{OE}	32.9 in (835 mm), without rider, at DIN unloaded vehicle weight
–with comfort seat ^{OE}	34.4 in (875 mm), without rider, at DIN unloaded vehicle weight

222 TECHNICAL DATA

-with lowered ^{OE}	32.1 in (815 mm), without rider, at DIN unloaded vehicle weight
Rider's inside-leg arc, heel to heel	75.2 in (1910 mm), without rider, at DIN unloaded vehicle weight
-with seat, low ^{OE}	73.6 in (1870 mm), without rider, at DIN unloaded vehicle weight
-with comfort seat ^{OE}	76.8 in (1950 mm), without rider, at DIN unloaded vehicle weight
-with lowered ^{OE}	72 in (1830 mm), without rider, at DIN unloaded vehicle weight

WEIGHTS

Unloaded vehicle weight	514 lbs (233 kg), DIN unloaded vehicle weight, ready for road, 90% full tank of gas, without OE
Gross vehicle weight	981 lbs (445 kg)
Maximum payload	467 lbs (212 kg)

PERFORMANCE DATA

Maximum speed	>124 mph (>200 km/h)
-with case ^{OA}	99 mph (160 km/h)
-with topcase ^{OA}	99 mph (160 km/h)

SERVICE

13

REPORTING SAFETY DEFECTS	226
BMW MOTORRAD SERVICE	227
BMW MOTORRAD ELECTRONIC SERVICE HISTORY (ESH)	227
BMW MOTORRAD MOBILITY SERVICES	228
MAINTENANCE PROCEDURES	228
MAINTENANCE SCHEDULE	230
MAINTENANCE CONFIRMATIONS	231
SERVICE CONFIRMATIONS	245

REPORTING SAFETY DEFECTS

If you think that your motorcycle has a fault which may cause an accident, injury or death, you must inform the NHTSA (National Highway Traffic Safety Administration) immediately and BMW of North America, LLC.

If the NHTSA receives other similar complaints, it may open an investigation. If it finds that a safety defect exists in a group of vehicles, the NHTSA may order the manufacturer to perform a recall and remedy campaign. However, the NHTSA cannot become involved in individual problems between you, your authorized BMW Motorrad retailer, or BMW of North America, LLC. You can contact the NHTSA by calling the Vehicle Safety Hotline on 1-888-327-4236 (Teletypewriter TTY for the hearing impaired: 1-800-424-9153) for free, by visiting the website at [http:// www.safercar.gov](http://www.safercar.gov) or by writing to Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590. Further information on vehicle safety is available at [http:// www.safercar.gov](http://www.safercar.gov). Canadian customers who wish to report a safetyrelated defect to Transport Canada, Defect Investigations and Recalls, may call the toll-free hotline 1-800-333-0510. You can also obtain other information about motor vehicle safety from [http:// www.tc.gc.ca/roadsafety](http://www.tc.gc.ca/roadsafety).

BMW MOTORRAD SERVICE

With its worldwide retailer network, BMW Motorrad can attend to you and your motorcycle in over 100 countries around the globe. Authorized BMW Motorrad retailers have the technical information and expertise needed to reliably conduct all preventive maintenance and repair tasks on your BMW.

You will find the nearest authorized BMW Motorrad retailer to you at our website:
bmw-motorrad.com



WARNING

Improperly performed maintenance and repair work

Accident hazard caused by subsequent damage

- BMW Motorrad recommends having corresponding work on the motorcycle carried out by a specialized workshop, preferably by an authorized BMW Motorrad retailer.

To ensure that your BMW is always in optimal condition, BMW Motorrad advises that you observe the recommended

service intervals for your motorcycle.

Have all maintenance and repair tasks confirmed in the Service chapter in this manual. Documented proof of scheduled preventive maintenance is essential for generous treatment of claims submitted after the warranty period has expired (goodwill).

You can obtain information on the contents of the BMW Services from your BMW Motorrad retailer.

BMW MOTORRAD ELECTRONIC SERVICE HISTORY (ESH)

Entries

Maintenance work that has been performed is recorded in the diagnostics and information system. Like a Service Booklet, these entries provide proof of regular maintenance.

If an entry is made in the vehicle's eSH, service-related data is stored on the central IT systems of BMW AG in Munich, Germany.

When there is a change in vehicle owner, the data entered in the eSH can also be viewed by the new vehicle owner. A BMW Motorrad retailer or spe-

cialist workshop can view the data entered in the electronic Service Manual.

Objection

At the BMW Motorrad retailer or specialist workshop, the vehicle owner can object to the entry of data in the electronic Service Manual with the related storage of data in the vehicle and the transfer of data to the vehicle manufacturer during his time as the vehicle owner. In this case, no entry is made in the vehicle's electronic Service Manual.

BMW MOTORRAD MOBILITY SERVICES

The BMW Motorrad Mobility Services furnish you and your new BMW motorcycle with extra security by offering a wide array of assistance services in the event of a breakdown (mobile service, breakdown assistance, vehicle recovery and retrieval, etc.).

Contact your authorized BMW Motorrad retailer for additional information on available mobility services.

MAINTENANCE PROCEDURES

BMW pre-delivery check

The BMW pre-delivery check is carried out by your authorized BMW Motorrad retailer before it turns the motorcycle over to you.

BMW Running-in check

The BMW running-in check must be carried out between 300 mi (500 km) and 750 mi (1200 km).

BMW Service

BMW Service is carried out once a year. The scope of the services performed may be dependent on the age of the motorcycle and the mileage ridden. Your BMW Motorrad retailer confirms that the service has been performed and enters the date for the next service. For riders with high annual mileage, it may be necessary to come in for service before the entered date. In this case a corresponding maximum odometer reading will also be entered in the confirmation of service. If this odometer reading is reached before the next service appointment, service must be performed sooner.

The service interval indicator in the display reminds you of the next service appointment approx. one month or 621 mi (1000 km) before the entered values.

More information on the topic of service is available at:

[bmw-motorrad.com/service](https://www.bmw-motorrad.com/service)

The required scope of maintenance work for your motorcycle can be found in the following maintenance schedule:

230 SERVICE

MAINTENANCE SCHEDULE

	50 000 km 300 - 750 mls	10 000 km 6 000 mls	20 000 km 12 000 mls	30 000 km 18 000 mls	40 000 km 24 000 mls	50 000 km 30 000 mls	60 000 km 36 000 mls	70 000 km 42 000 mls	80 000 km 48 000 mls	90 000 km 54 000 mls	100 000 km 60 000 mls	12 months	24 months
①	X												
②												X	
③		X	X	X	X	X	X	X	X	X	X	X ^a	
④			X		X		X		X		X		
⑤			X		X		X		X		X		
⑥			X		X		X		X		X		
⑦		X ^b	X ^b	X ^b	X ^b	X ^b	X ^b	X ^b	X ^b	X ^b	X ^b	X ^b	
⑧				X			X			X			
⑨												X ^c	X ^c

- 1 BMW running-in check
 - 2 BMW standard scope of service
 - 3 Engine oil change with filter
 - 4 Check valve clearance
 - 5 Replace all spark plugs
 - 6 Replace air filter insert
 - 7 Check or replace air filter insert
 - 8 Oil change in the telescopic forks
 - 9 Change brake fluid in entire system
- ^a annually or every 6000 mi (10000 km) (whichever comes first)

- ^b when used off-road, annually or every 6000 mi (10000 km) (whichever comes first)
- ^c at first after one year, then every two years

MAINTENANCE CONFIRMATIONS

BMW Service standard scope

The repair procedures belonging to the BMW Service standard package are listed below. The actual maintenance work applicable for your vehicle may differ.

- Performing the vehicle test using the BMW Motorrad diagnostic system
- Checking coolant level
- Checking/adjusting clutch play
- Checking the front brake pads and brake discs for wear
- Checking the rear brake pads and brake disc for wear
- Checking the front and rear brake fluid level
- Visual inspection of the brake lines, brake hoses, and connections
- Checking the tire pressure and tread depth
- Check the tension of the spokes and tighten as needed
- Checking and lubricating the chain drive
- Check side stand for ease of movement
- Checking center stand for ease of movement
- Checking steering-head bearing
- Checking the lighting and signal system
- Functional check for engine starting suppression
- Final inspection and road safety check
- Set the service date and remaining distance using the BMW Motorrad diagnostic system
- Checking charging state of battery
- Confirm the BMW service in the vehicle literature

232 SERVICE

BMW pre-delivery check
performed

on _____

Stamp, signature

BMW Running-in Check
performed

on _____

Odometer reading _____

Next service

latest

on _____

or, if reached earlier

Odometer reading _____

Stamp, signature

BMW Service

performed

on _____

Odometer reading _____

Next service

latest

on _____

or, if reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	<input type="checkbox"/>	<input type="checkbox"/>
Engine oil change with filter	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Replacing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Replacing air cleaner element	<input type="checkbox"/>	<input type="checkbox"/>
Checking or replacing air cleaner element (maintenance)	<input type="checkbox"/>	<input type="checkbox"/>
Oil change - telescopic fork	<input type="checkbox"/>	<input type="checkbox"/>
Changing brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Information

Stamp, signature

234 SERVICE

BMW Service

performed

on _____

Odometer reading _____

Next service

latest

on _____

or, if reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	<input type="checkbox"/>	<input type="checkbox"/>
Engine oil change with filter	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Replacing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Replacing air cleaner element	<input type="checkbox"/>	<input type="checkbox"/>
Checking or replacing air cleaner element (maintenance)	<input type="checkbox"/>	<input type="checkbox"/>
Oil change - telescopic fork	<input type="checkbox"/>	<input type="checkbox"/>
Changing brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Information

Stamp, signature

BMW Service

performed

on _____

Odometer reading _____

Next service

latest

on _____

or, if reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	<input type="checkbox"/>	<input type="checkbox"/>
Engine oil change with filter	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Replacing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Replacing air cleaner element	<input type="checkbox"/>	<input type="checkbox"/>
Checking or replacing air cleaner element (maintenance)	<input type="checkbox"/>	<input type="checkbox"/>
Oil change - telescopic fork	<input type="checkbox"/>	<input type="checkbox"/>
Changing brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Information

Stamp, signature

236 SERVICE

BMW Service

performed

on _____

Odometer reading _____

Next service

latest

on _____

or, if reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	<input type="checkbox"/>	<input type="checkbox"/>
Engine oil change with filter	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Replacing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Replacing air cleaner element	<input type="checkbox"/>	<input type="checkbox"/>
Checking or replacing air cleaner element (maintenance)	<input type="checkbox"/>	<input type="checkbox"/>
Oil change - telescopic fork	<input type="checkbox"/>	<input type="checkbox"/>
Changing brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Information

Stamp, signature

BMW Service

performed

on _____

Odometer reading _____

Next service

latest

on _____

or, if reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	<input type="checkbox"/>	<input type="checkbox"/>
Engine oil change with filter	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Replacing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Replacing air cleaner element	<input type="checkbox"/>	<input type="checkbox"/>
Checking or replacing air cleaner element (maintenance)	<input type="checkbox"/>	<input type="checkbox"/>
Oil change - telescopic fork	<input type="checkbox"/>	<input type="checkbox"/>
Changing brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Information

Stamp, signature

238 SERVICE

BMW Service

performed

on _____

Odometer reading _____

Next service

latest

on _____

or, if reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	<input type="checkbox"/>	<input type="checkbox"/>
Engine oil change with filter	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Replacing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Replacing air cleaner element	<input type="checkbox"/>	<input type="checkbox"/>
Checking or replacing air cleaner element (maintenance)	<input type="checkbox"/>	<input type="checkbox"/>
Oil change - telescopic fork	<input type="checkbox"/>	<input type="checkbox"/>
Changing brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Information

Stamp, signature

BMW Service

performed

on _____

Odometer reading _____

Next service

latest

on _____

or, if reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	<input type="checkbox"/>	<input type="checkbox"/>
Engine oil change with filter	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Replacing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Replacing air cleaner element	<input type="checkbox"/>	<input type="checkbox"/>
Checking or replacing air cleaner element (maintenance)	<input type="checkbox"/>	<input type="checkbox"/>
Oil change - telescopic fork	<input type="checkbox"/>	<input type="checkbox"/>
Changing brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Information

Stamp, signature

240 SERVICE

BMW Service

performed

on _____

Odometer reading _____

Next service

latest

on _____

or, if reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	<input type="checkbox"/>	<input type="checkbox"/>
Engine oil change with filter	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Replacing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Replacing air cleaner element	<input type="checkbox"/>	<input type="checkbox"/>
Checking or replacing air cleaner element (maintenance)	<input type="checkbox"/>	<input type="checkbox"/>
Oil change - telescopic fork	<input type="checkbox"/>	<input type="checkbox"/>
Changing brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Information

Stamp, signature

BMW Service

performed

on _____

Odometer reading _____

Next service

latest

on _____

or, if reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	<input type="checkbox"/>	<input type="checkbox"/>
Engine oil change with filter	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Replacing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Replacing air cleaner element	<input type="checkbox"/>	<input type="checkbox"/>
Checking or replacing air cleaner element (maintenance)	<input type="checkbox"/>	<input type="checkbox"/>
Oil change - telescopic fork	<input type="checkbox"/>	<input type="checkbox"/>
Changing brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Information

Stamp, signature

242 SERVICE

BMW Service

performed

on _____

Odometer reading _____

Next service

latest

on _____

or, if reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	<input type="checkbox"/>	<input type="checkbox"/>
Engine oil change with filter	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Replacing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Replacing air cleaner element	<input type="checkbox"/>	<input type="checkbox"/>
Checking or replacing air cleaner element (maintenance)	<input type="checkbox"/>	<input type="checkbox"/>
Oil change - telescopic fork	<input type="checkbox"/>	<input type="checkbox"/>
Changing brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Information

Stamp, signature

BMW Service

performed

on _____

Odometer reading _____

Next service

latest

on _____

or, if reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	<input type="checkbox"/>	<input type="checkbox"/>
Engine oil change with filter	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Replacing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Replacing air cleaner element	<input type="checkbox"/>	<input type="checkbox"/>
Checking or replacing air cleaner element (maintenance)	<input type="checkbox"/>	<input type="checkbox"/>
Oil change - telescopic fork	<input type="checkbox"/>	<input type="checkbox"/>
Changing brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Information

Stamp, signature

244 SERVICE

BMW Service

performed

on _____

Odometer reading _____

Next service

latest

on _____

or, if reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	<input type="checkbox"/>	<input type="checkbox"/>
Engine oil change with filter	<input type="checkbox"/>	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>	<input type="checkbox"/>
Replacing all spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
Replacing air cleaner element	<input type="checkbox"/>	<input type="checkbox"/>
Checking or replacing air cleaner element (maintenance)	<input type="checkbox"/>	<input type="checkbox"/>
Oil change - telescopic fork	<input type="checkbox"/>	<input type="checkbox"/>
Changing brake fluid in entire system	<input type="checkbox"/>	<input type="checkbox"/>

Information

Stamp, signature

CERTIFICATE FOR ELECTRONIC IMMOBILIZER	249
CERTIFICATE FOR KEYLESS RIDE	251
DECLARATION OF CONFORMITY FOR TIRE PRESSURE CONTROL	255
CERTIFICATE FOR TIRE PRESSURE CONTROL	261
CERTIFICATE FOR TFT INSTRUMENT CLUSTER	262
DECLARATION OF CONFORMITY FOR ANTI-THEFT ALARM	265

FCC Approval


Ring aerial in the ignition switch



To verify the authorization of the ignition key, the electronic immobilizer exchanges information with the ignition key via the ring aerial.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

 Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. ◀

Approbation de la FCC

Antenne annulaire présente dans le commutateur d'allumage



Pour vérifier l'autorisation de la clé de contact, le système d'immobilisation électronique échange des informations avec la clé de contact via l'antenne annulaire.

Le présent dispositif est conforme à la partie 15 des règles de la FCC. Son utilisation est soumise aux deux conditions suivantes :

- (1) Le dispositif ne doit pas produire d'interférences nuisibles, et
- (2) le dispositif doit pouvoir accepter toutes les interférences extérieures, y compris celles qui pourraient provoquer une activation inopportune.



Toute modification qui n'aurait qui n'aurait pas été approuvée expressément par l'organisme responsable de l'homologation peut annuler l'autorisation accordée à l'utilisateur pour utiliser le dispositif. ◀

Certifications

BMW Keyless Ride ID Device



USA, Canada:

Product name: BMW Keyless Ride ID
Device FCC ID: YGOHUF5750
IC: 4008C-HUF5750



Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Canada:

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

USA:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Argentina:

CNC COMISIÓN NACIONAL
DE COMUNICACIONES

H-17115

Declaration Of Conformity

We declare under our responsibility that the product

BMW Keyless Ride ID Device (Model: HUF5750)


complies with the appropriate essential requirements of the article 3 of the R&TIE and the other relevant provisions, when used for its intended purpose. Applied Standards:

1. Health and safety requirements contained in article 3 (1) a)
 - EN 60950-1:2006+A11:2009+A1:2010+A12:2011; Information technology equipment-Safety
2. Protection requirements with respect to electromagnetic compatibility article 3 (1) b)
 - EN 301 489-1 (V1 .9.2, 09/2011), Electromagnetic compatibility and radio spectrum matters (ERM); Electromagnetic compatibility (EMC) standard for radio equipment and services; Part 1: Common technical requirements
 - EN 301 489-3 (V1.4.1, 08/2002) Electromagnetic compatibility and radio spectrum matters (ERM); Electromagnetic compatibility (EMC) standard for radio equipment and services; Part 3: Specific conditions for short range devices (SRD) operating on frequencies between 9 kHz and 40 GHz
3. Means of the efficient use of the radio frequency spectrum article 3 (2)
 - EN 300 220-1 & -2 (V2.4.1, 05/2012), electromagnetic compatibility and radio spectrum matters (ERM); Short range devices (SRD); Radio equipment to be used in the 25 MHz to 1000 MHz frequency range with power levels ranging up to 500 mW; Part 1: Technical characteristics and test methods. Part 2: Harmonized EN covering essential requirements under article 3.2 of the R&TIE directive

The product is labeled with the CE marking:

CE

Velbert, October 15th, 2013



Benjamin A. Müller

Product Development Systems
Car Access and Immobilization -
Electronics Huf Hülsbeck & Fürst
GmbH & Co. KG
Steeger Straße 17, D-42551
Velbert

Declaration of Conformity

Radio equipment tyre pressure control (RDC)

Simplified EU Declaration of Conformity acc. Radio Equipment Directive 2014/53/EU after 12.06.2016 and during transition period



Technical information

Frequency Band: 433.895 -

433.945 MHz

Output Power: <10 mW e.r.p.

Manufacturer and Address

Manufacturer: Schrader Electronics Ltd.

Address: Technology Park, Antrim,
N. Ireland BT41 1QS,
United Kingdom

Austria

Hiermit erklärt Schrader Electronics Ltd., dass der Funkanlagentyp BC5A4 der Richtlinie

2014/53/EU entspricht.

Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar:

http://www.tpmseuroshop.com/documents/declaration_conformities

Belgium

Le soussigné, Schrader Electronics Ltd., déclare que l'équipement radioélectrique du type BC5A4 est conforme à la directive 2014/53/UE.

Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante:

http://www.tpmseuroshop.com/documents/declaration_conformities

Cyprus

Με την παρούσα ο/η Schrader Electronics Ltd., δηλώνει ότι ο ραδιοεξοπλισμός BC5A4 πληροί την οδηγία 2014/53/ΕΕ.

Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο:

http://www.tpmseuroshop.com/documents/declaration_conformities

Czech Republic

Tímto Schrader Electronics Ltd. prohlašuje, že typ rádiového zařízení BC5A4 je v souladu se směrnicí 2014/53/EU.

Úplné znění EU prohlášení o shodě je k dispozici na této internetové adrese:

http://www.tpmseuroshop.com/documents/declaration_conformities

Germany

Hiermit erklärt Schrader Electronics Ltd., dass der Funkanlagentyp BC5A4 der Richtlinie

2014/53/EU entspricht.

Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar:

http://www.tpmseuroshop.com/documents/declaration_conformities

Denmark

Hermed erklærer Schrader Electronics Ltd., at radioudstyrstypen BC5A4 er i overensstemmelse med direktiv 2014/53/EU.

EU-overensstemmelseserklæringens fulde tekst kan findes på følgende internetadresse:

http://www.tpmseuroshop.com/documents/declaration_conformities

Estonia

Käesolevaga deklareerib Schrader Electronics Ltd., et käesolev raadioseadme tüüp BC5A4 vastab direktiivi 2014/53/EL nõuetele.

ELi vastavusdeklaratsiooni täielik tekst on kättesaadav järgmisel internetiaadressil:

http://www.tpmseuroshop.com/documents/declaration_conformities

Spain

Por la presente, Schrader Electronics Ltd. declara que el tipo de equipo radioeléctrico BC5A4 es conforme con la Directiva 2014/53/UE.

El texto completo de la declaración UE de conformidad está disponible en la dirección Internet siguiente:

http://www.tpmseuroshop.com/documents/declaration_conformities

Finland

Schrader Electronics Ltd.
vakuuttaa, että radiolaitetyyppi
BC5A4 on direktiivin 2014/53/EU
mukainen.

EU-
vaatimustenmukaisuusvakuutukse
n täysimittainen teksti on saatavilla
seuraavassa internetosoitteessa:
[http://www.tpmseuroshop.com/
documents/
declaration_conformities](http://www.tpmseuroshop.com/documents/declaration_conformities)

France

Le soussigné, Schrader
Electronics Ltd., déclare que
l'équipement radioélectrique du
type BC5A4 est conforme à la
directive 2014/53/UE.
Le texte complet de la déclaration
UE de conformité est disponible à
l'adresse internet suivante:
[http://www.tpmseuroshop.com/
documents/
declaration_conformities](http://www.tpmseuroshop.com/documents/declaration_conformities)

United Kingdom

Hereby, Schrader Electronics Ltd.
declares that the radio equipment
type BC5A4 is in compliance with
Directive 2014/53/EU.
The full text of the EU declaration
of conformity is available at the
following internet address: [http://
www.tpmseuroshop.com/
documents/
declaration_conformities](http://www.tpmseuroshop.com/documents/declaration_conformities)

Greece

Με την παρούσα ο/η Schrader
Electronics Ltd., δηλώνει ότι ο
ραδιοεξοπλισμός BC5A4 πληροί
την οδηγία 2014/53/ΕΕ.
Το πλήρες κείμενο της δήλωσης
συμμόρφωσης ΕΕ διατίθεται στην
ακόλουθη ιστοσελίδα στο
διαδίκτυο:
[http://www.tpmseuroshop.com/
documents/
declaration_conformities](http://www.tpmseuroshop.com/documents/declaration_conformities)

Croatia

Schrader Electronics Ltd. ovime
izjavljuje da je radijska oprema
tipa BC5A4 u skladu s Direktivom
2014/53/EU.
Cjeloviti tekst EU izjave o
sukladnosti dostupan je na
sljedećoj internetskoj adresi:
[http://www.tpmseuroshop.com/
documents/
declaration_conformities](http://www.tpmseuroshop.com/documents/declaration_conformities)

Hungary

Schrader Electronics Ltd. igazolja,
hogy a BC5A4 típusú
rádióberendezés megfelel a
2014/53/EU irányelvnek.
Az EU-megfelelőségi nyilatkozat
teljes szövege elérhető a
következő internetes címen:
[http://www.tpmseuroshop.com/
documents/
declaration_conformities](http://www.tpmseuroshop.com/documents/declaration_conformities)

Ireland

Hereby, Schrader Electronics Ltd. declares that the radio equipment type BC5A4 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: http://www.tpmseuroshop.com/documents/declaration_conformities

Italy

Il fabbricante, Schrader Electronics Ltd., dichiara che il tipo di apparecchiatura radio BC5A4 è conforme alla direttiva 2014/53/UE.

Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: http://www.tpmseuroshop.com/documents/declaration_conformities

Lithuania

Aš, Schrader Electronics Ltd., patvirtinu, kad radijo įrenginių tipas BC5A4 atitinka Direktyvą 2014/53/ES.

Visas ES atitiktis deklaracijos tekstas prieinamas šiuo interneto adresu: http://www.tpmseuroshop.com/documents/declaration_conformities

Luxembourg

Le soussigné, Schrader Electronics Ltd., déclare que l'équipement radioélectrique du type BC5A4 est conforme à la directive 2014/53/UE.

Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: http://www.tpmseuroshop.com/documents/declaration_conformities

Latvia

Ar šo Schrader Electronics Ltd. deklarē, ka radioiekārta BC5A4 atbilst Direktīvai 2014/53/ES. Pilns ES atbilstības deklarācijas teksts ir pieejams šādā interneta vietnē:

http://www.tpmseuroshop.com/documents/declaration_conformities

Malta

B'dan, Schrader Electronics Ltd., niddikjara li dan it-tip ta' tagħmir tar-radju BC5A4 huwa konformi mad-Direttiva 2014/53/UE.

It-test kollu tad-dikjarazzjoni ta' konformità tal-UE huwa disponibbli f'dan l-indirizz tal-Internet li ġej: http://www.tpmseuroshop.com/documents/declaration_conformities

Netherlands

Hierbij verklaar ik, Schrader Electronics Ltd., dat het type radioapparatuur BC5A4 conform is met Richtlijn 2014/53/EU. De volledige tekst van de EU-conformiteitsverklaring kan worden geraadpleegd op het volgende internetadres: http://www.tpmseuroshop.com/documents/declaration_conformities

Poland

Schrader Electronics Ltd. niniejszym oświadcza, że typ urządzenia radiowego BC5A4 jest zgodny z dyrektywą 2014/53/EU. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: http://www.tpmseuroshop.com/documents/declaration_conformities

Portugal

O(a) abaixo assinado(a) Schrader Electronics Ltd. declara que o presente tipo de equipamento de rádio BC5A4 está em conformidade com a Diretiva 2014/53/EU. O texto integral da declaração de conformidade está disponível no seguinte endereço de Internet: http://www.tpmseuroshop.com/documents/declaration_conformities

Romania

Prin prezenta, Schrader Electronics Ltd. declară că tipul de echipamente radio BC5A4 este în conformitate cu Directiva 2014/53/UE. Textul integral al declarației UE de conformitate este disponibil la următoarea adresă internet: http://www.tpmseuroshop.com/documents/declaration_conformities

Sweden

Härmed försäkrar Schrader Electronics Ltd. att denna typ av radioutrustning BC5A4 överensstämmer med direktiv 2014/53/EU. Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande webbadress: http://www.tpmseuroshop.com/documents/declaration_conformities

Slovenia

Schrader Electronics Ltd. potrjuje, da je tip radijske opreme BC5A4 skladen z Direktivo 2014/53/EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: http://www.tpmseuroshop.com/documents/declaration_conformities

Slovakia

Schrader Electronics Ltd. týmto vyhlasuje, že rádiové zariadenie typu BC5A4 je v súlade so smernicou 2014/53/EÚ.

Úplné EÚ vyhlásenie o zhode je k dispozícii na tejto internetovej adrese:

[http://www.tpmseuroshop.com/
documents/
declaration_conformities](http://www.tpmseuroshop.com/documents/declaration_conformities)

Bulgaria

С настоящото Schrader Electronics Ltd. декларира, че този тип радиосъоръжение BC5A4 е в съответствие с Директива 2014/53/ЕС.

Цялостният текст на ЕС декларацията за съответствие може да се намери на следния интернет адрес:

[http://www.tpmseuroshop.com/
documents/
declaration_conformities](http://www.tpmseuroshop.com/documents/declaration_conformities)

Certification Tire Pressure Control (TPC)

FCC ID: MRXBC54MA4
IC: 2546A-BC54MA4

FCC ID: MRXBC5A4
IC: 2546A-BC5A4

This device complies with Part 15 of the FCC Rules and with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

Declaration of Conformity

Radio equipment TFT instrument cluster

For all Countries without EU

Technical information

BT operating frq. Range:

2402 – 2480 MHz

BT version: 4.2 (no BTLE)

BT output power: < 4 dBm

WLAN operating frq. Range:

2412 – 2462 MHz

WLAN standards:

IEEE 802.11 b/g/n

WLAN output power: < 20 dBm

Manufacturer and Address

Manufacturer:

Robert Bosch Car Multimedia GmbH

Address: Robert Bosch Str. 200,
31139 Hildesheim, GERMANY

Turkey

Robert Bosch Car Multimedia

GmbH, ICC6.5in tipi telsiz

sisteminin 2014/53/EU

nolu yönetmeliğe uygun olduğunu

beyan eder. AB Uygunluk

Beyanı'nın tam metni, aşağıdaki

internet adresinden görülebilir:

[http://cert.bosch-](http://cert.bosch-carmultimedia.net)

[carmultimedia.net](http://cert.bosch-carmultimedia.net)

Brazil

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário.

Canada

This device complies with Industry Canada's licence-exempt RSSs and part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Korea

적합성평가에 관한 고시
R-CMM-RBR-ICC65IN
상호 : Robert Bosch Car
Multimedia GmbH모델명 :
ICC6.5in
기자재명칭 : 특정소출력 무선기
기
(무선데이터통신시스템용 무선기
기)
제조사 및 제조국가 : Robert
Bosch Car Multimedia GmbH /
포르투갈
제조년월 : 제조년월로 표기
이 기기는 업무용 환경에서 사용
할 목적으로 적합성평가를 받은
기기로서 가정용 환경에
서 사용하는 경우 전파간섭의 우
려가 있습니
다.

Mexico

La operación de este equipo está sujeta a las siguientes dos condiciones:

- (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y
- (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

Taiwan, Republic of

根據 NCC 低功率電波輻射性電機
管理辦法 規定: 第十二條
經型式認證合格之低功率射頻電
機, 非經許可, 公司、商號或使用
者均不得擅自變更頻率、加大功率
或變更原設計之特性及功能。
第十四條
低功率射頻電機之使用不得影響飛
航安全及干擾合法通信; 經發現有
干擾現象時, 應立即停用, 並改善
至無干擾時方得繼續使用。
前項合法通信,
指依電信法規定作業之無線電通
信。
低功率射頻電機須忍受合法通信或
工業、科學及醫療用電波輻射性電
機設備之干擾。

Thailand

เครื่องโทรคมนาคมและอุปกรณ์ นี้

มีความสอดคล้องตามข้อกำหนดของ กทช.

(This telecommunication equipments is in compliance with NTC requirements)

United States (USA)

This device complies with Industry Canada's licence-exempt RSSs and part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Declaration of Conformity

Radio equipment anti-theft alarm (DWA)

Simplified EU Declaration of Conformity acc. Radio Equipment Directive 2014/53/EU after 12.06.2016 and during transition period



Technical information

Frequency Band:
433.05-434.79 MHz
Output Power: 10 mW e.r.p.

Manufacturer and Address

Manufacturer: Meta System S.p.A.
Address: Via Galimberti 5 42124
Reggio Emilia - Italy

Austria

Hiermit erklärt Meta System S.p.A., dass der Funkanlagentyp TXBMWMR der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: <https://docs.metasystem.it/>

Belgium

Le soussigné, Meta System S.p.A., déclare que l'équipement radioélectrique du type TXBMWMR est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: <https://docs.metasystem.it/>

Bulgaria

С настоящото Meta System S.p.A. декларира, че този тип радиосъоръжение TXBMWMR е в съответствие с Директива 2014/53/ЕС. Цялостният текст на ЕС декларацията за съответствие може да се намери на следния интернет адрес: <https://docs.metasystem.it/>

Cyprus

Με την παρούσα ο/η Meta System S.p.A., δηλώνει ότι ο ραδιοεξοπλισμός TXBMWMR πληροί την οδηγία 2014/53/ΕΕ. Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: <https://docs.metasystem.it/>

Czech Republic

Tímto Meta System S.p.A. prohlašuje, že typ rádiového zařízení TXBMWMMR je v souladu se směrnicí 2014/53/EU. Úplné znění EU prohlášení o shodě je k dispozici na této internetové adrese:
<https://docs.metasystem.it/>

Germany

Hiermit erklärt Meta System S.p.A., dass der Funkanlagentyp TXBMWMMR der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar:
<https://docs.metasystem.it/>

Denmark

Hermed erklærer Meta System S.p.A., at radioudstyrstypen TXBMWMMR er i overensstemmelse med direktiv 2014/53/EU. EU-overensstemmelseserklæringens fulde tekst kan findes på følgende internetadresse:
<https://docs.metasystem.it/>

Estonia

Käesolevaga deklareerib Meta System S.p.A., et käesolev raadioseadme tüüp TXBMWMMR vastab direktiivi 2014/53/EL nõuetele. ELi vastavusdeklaratsiooni täielik tekst on kättesaadav järgmisel internetiaadressil: <https://docs.metasystem.it/>

Spain

Por la presente, Meta System S.p.A. declara que el tipo de equipo radioeléctrico TXBMWMMR es conforme con la Directiva 2014/53/UE. El texto completo de la declaración UE de conformidad está disponible en la dirección Internet siguiente: <https://docs.metasystem.it/>

Finland

Meta System S.p.A. vakuuttaa, että radiolaitetyyppi TXBMWMMR on direktiivin 2014/53/EU mukainen. EU-vaatimustenmukaisuusvakuutuksen täysimittainen teksti on saatavilla seuraavassa internetosoitteessa: <https://docs.metasystem.it/>

France

Le soussigné, Meta System S.p.A., déclare que l'équipement radioélectrique du type TXBMWMMR est conforme à la directive 2014/53/UE

Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante : <https://docs.metasystem.it/>

United Kingdom

Hereby, Meta System S.p.A. declares that the radio equipment type TXBMWMMR is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://docs.metasystem.it/>

Greece

Με την παρούσα ο/η Meta System S.p.A., δηλώνει ότι ο ραδιοεξοπλισμός TXBMWMMR πληροί την οδηγία 2014/53/ΕΕ. Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: <https://docs.metasystem.it/>

Croatia

Meta System S.p.A. ovime izjavljuje da je radijska oprema tipa TXBMWMMR u skladu s Direktivom 2014/53/EU. Cjeloviti tekst EU izjave o sukladnosti dostupan je na sljedećoj internetskoj adresi: <https://docs.metasystem.it/>

Hungary

Meta System S.p.A. igazolja, hogy a TXBMWMMR típusú rádióberendezés megfelel a 2014/53/EU irányelvnek. Az EU-megfelelőségi nyilatkozat teljes szövege elérhető a következő internetes címen: <https://docs.metasystem.it/>

Ireland

Hereby, Meta System S.p.A. declares that the radio equipment type TXBMWMMR is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://docs.metasystem.it/>

Italy

Il fabbricante, Meta System S.p.A., dichiara che il tipo di apparecchiatura radio TXBMWMMR è conforme alla direttiva 2014/53/UE. Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: <https://docs.metasystem.it/>

Lithuania

Aš, Meta System S.p.A., patvirtinu, kad radijo įrenginių tipas TXBMWMMR atitinka Direktyvą 2014/53/ES.

Visas ES atitikties deklaracijos tekstas prieinamas šiuo interneto adresu: <https://docs.metasystem.it/>

Luxembourg

Le soussigné, Meta System S.p.A., déclare que l'équipement radioélectrique du type TXBMWMMR est conforme à la directive 2014/53/UE.

Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: <https://docs.metasystem.it/>

Latvia

Ar šo Meta System S.p.A. deklarē, ka radioiekārta TXBMWMMR atbilst Direktīvai 2014/53/ES.

Pilns ES atbilstības deklarācijas teksts ir pieejams šādā interneta vietnē: <https://docs.metasystem.it/>

Malta

B'dan, Meta System S.p.A., niddikjara li dan it-tip ta' tagħmir tar-radju TXBMWMMR huwa konformi mad-Direttiva 2014/53/UE.

It-test kollu tad-dikjarazzjoni ta' konformità tal-UE huwa disponibbli f'dan l-indirizz tal-Internet li ġej: <https://docs.metasystem.it/>

Netherlands

Hierbij verklaar ik, Meta System S.p.A., dat het type radioapparatuur TXBMWMMR conform is met Richtlijn 2014/53/EU.

De volledige tekst van de EU-conformiteitsverklaring kan worden geraadpleegd op het volgende internetadres: <https://docs.metasystem.it/>

Poland

Meta System S.p.A. niniejszym oświadcza, że typ urządzenia radiowego TXBMWMMR jest zgodny z dyrektywą 2014/53/UE. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: <https://docs.metasystem.it/>

Portugal

O(a) abaixo assinado(a) Meta System S.p.A. declara que o presente tipo de equipamento de rádio TXBMWMMR está em conformidade com a Diretiva 2014/53/UE.

O texto integral da declaração de conformidade está disponível no seguinte endereço de Internet: <https://docs.metasystem.it/>

Romania

Prin prezenta, Meta System S.p.A. declară că tipul de echipamente radio TXBMWMR este în conformitate cu Directiva 2014/53/UE. Textul integral al declarației UE de conformitate este disponibil la următoarea adresă internet: <https://docs.metasystem.it/>

Sweden

Härmed försäkrar Meta System S.p.A. att denna typ av radioutrustning TXBMWMR överensstämmer med direktiv 2014/53/EU. Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande webbadress: <https://docs.metasystem.it/>

Slovenia

Meta System S.p.A. potrjuje, da je tip radijske opreme TXBMWMR skladen z Direktivo 2014/53/EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: <https://docs.metasystem.it/>

Slovakia

Meta System S.p.A. týmto vyhlasuje, že rádiové zariadenie typu TXBMWMR je v súlade so smernicou 2014/53/EÚ. Úplné EÚ vyhlásenie o zhode je k dispozícii na tejto internetovej adrese: <https://docs.metasystem.it/>

270 INDEX

- A**
 - Abbreviations and symbols, 4
 - ABS
 - Displays, 41
 - Self-diagnosis, 114
 - Technology in detail, 132
 - Accessories
 - General notes, 188
 - Ambient temperature
 - Outside temperature warning, 31
 - Anti-theft alarm system
 - Indicator light, 19, 35
- B**
 - Battery
 - Charging connected battery, 179
 - Charging disconnected battery, 180
 - Indicator light for vehicle voltage, 32, 33
 - Installing, 181
 - Maintenance instructions, 178
 - Removing, 180
 - Technical data, 220
 - Bluetooth, 86
 - Pairing, 86
 - Brake fluid
 - Checking the front fluid level, 154
 - Checking the rear fluid level, 155
 - Front expansion tank, 15
 - Rear expansion tank, 15
 - Brake pads
 - Breaking-in, 116
 - Check rear, 153
 - Checking the front, 152
 - Brakes
 - ABS Pro in detail, 134
 - ABS Pro dependent on riding mode, 120
 - Adjusting the brake lever, 102
 - Checking function, 152
 - Safety instructions, 118
 - Technical data, 218
 - Break-in, 115
- C**
 - Care
 - Chrome, 206
 - Paint preservation, 207
 - Case, 190
 - Chain
 - Chain sag adjust, 173
 - Checking sag, 172
 - Checking wear, 173
 - Lubricating, 172
 - Chassis
 - Technical data, 217
 - Check Control
 - Dialog, 25
 - Display, 25
 - Checklist, 111
 - Clock
 - Adjusting, 85
 - Clutch
 - Adjust play, 157
 - Adjusting the clutch lever, 101
 - Checking function, 156
 - Checking play, 156
 - Technical data, 216
 - Coolant
 - Check fill level, 157
 - Fill level indicator, 15
 - Indicator light for excess temperature, 35
 - Topping up, 158

D

- Damping
 - Adjusting element, 14
- Diagnostic socket
 - fasten, 184
 - Loosen, 184
 - Position on the vehicle, 16
- Dimensions
 - Technical data, 221
- Drive malfunction warning light, 35
- DTC
 - Indicator and warning light , 43
 - Operation, 58
 - Self-diagnosis, 114
 - Switching off, 58
 - Switching on, 59
 - Technology in detail, 135
- Dynamic Brake Control, 140
 - Technology in detail, 140
- Dynamic engine brake control, 137
- Dynamic ESA
 - Operating element, 17
 - Operation, 60

E

- Electrical system
 - Technical data, 219
- Emergency-off switch
 - Operating, 55
 - Operating element, 18

Engine, 36

- Drive malfunction warning light, 35
 - Indicator light for engine control, 37
 - Indicator light for engine electronics, 36
 - Starting, 112
 - Technical data, 215
- Engine oil**
- Checking fill level, 150
 - Oil filler opening, 14
 - Oil level dipstick, 14
 - Technical data, 214
 - Topping up, 152
- Equipment, 5**

F

- Factory settings, 71
- Fairing
 - Refitting fuel tank cover, 176
 - Removing the tank cover, 176
- Frame
 - Technical data, 217
- Front wheel stand
 - Mounting, 149
- Fuel
 - Fuel grade, 121
 - Refueling, 122
 - refueling with Keyless Ride, 123, 125
 - Technical data, 214
- Fuel filler cap emergency release, 126
- Fuel reserve
 - Indicator light, 44
 - Range, 84
- Fuses
 - Position on the vehicle, 16
 - Replacing, 182

272 INDEX

- G**
Gearshift assistant
 Gear not taught in, 45
 Riding, 116
 Technology in detail, 143
- H**
Hazard warning flasher
 Operating element, 17
 Operation, 57
Headlight
 Adjusting the headlight beam throw, 101
 Headlight beam throw, 100
 Right-hand/left-hand drive, 100
Headlight courtesy delay feature, 56
Heated grips
 Operating element, 18
 Operation, 71
Horn, 17
- I**
Ignition
 Switching off, 51
 Switching on, 50
Immobilizer
 Spare key, 54
Indicator lights, 19, 36
 ABS, 41
 Anti-theft alarm system, 35
 Bulb faulty, 33
 Coolant temperature, 35
 Drive malfunction warning light, 35
 DTC, 43
 Engine control, 37
 Engine electronics, 36
 Fuel reserve, 44
 Gear not taught in, 45
 Layout, 25
 My Vehicle, 89
 Outside temperature warning, 31
 Overview, 22
 RDC, 38
 Vehicle voltage, 32, 33
Instrument cluster
 Ambient light sensor, 19
 Overview, 19
- J**
Jump-starting, 177
- K**
Keyless Ride
 Battery of the radio-operated key is drained or the radio-operated key is lost, 53
 Indicator light, 31, 32
 Locking handlebars, 52
 Switch off ignition, 52
 Switching on the ignition, 52
 Unlocking fuel cap, 123
 Unlocking fuel filler cap, 125
Keys, 50, 51
- L**
Light sources
 Replacing the LED light source, 176
 Technical data, 221
 Warning for defective bulb, 33
Lights
 Headlight courtesy delay feature, 56
 Low beams, 56
 Operating element, 17

- Operating headlight
flasher, 56
- Operating high beams, 56
- Operating the parking
lights, 57
- Parking lights, 56
- Lowered suspension
Limitations, 108
- Luggage
Loading information, 109

M

- Maintenance
Maintenance schedule, 230
- Maintenance confirma-
tions, 231
- Maintenance intervals, 228
- Media
Operation, 94
- Menu
Calling up, 80
- Mirrors
Adjusting, 100
- Mobility Services, 228
- Motorcycle
Care, 202
Cleaning, 202
Lashing down, 127
Parking, 120
Putting into operation, 207
Storage, 207
- Multifunction switch
Overview, left, 17
Overview, right, 18

N

- Navigation
Operation, 92
- Notice concerning current
status, 6

O

- Off-road mode
Adjusting, 62
Technology in detail, 138
- Offroad riding, 117
- Onboard computer, 92
- Onboard vehicle toolkit
Position on the vehicle, 16
- Operating focus
change, 81
- Outside temperature
Display, 31
- Overview of warning
indicators, 27
- Overviews
Indicator and warning
lights, 22
Instrument cluster, 19
Left side of vehicle, 14
Left-side multifunction
switch, 17
Multifunction switch, right, 18
My Vehicle, 89
Right side of vehicle, 15
TFT display, 23, 24
Underneath the seat, 16

P

- Pairing, 86
- Parking light, 57
- Performance data
Technical data, 222
- Phone
Operation, 95
- Pre-Ride-Check, 113
- Pure Ride
Overview, 23

274 INDEX

R

- RDC
 - Indicator lights, 38
 - Technology in detail, 141
 - Rear-wheel drive
 - Technical data, 216
 - Rear-wheel stand
 - Mounting, 150
 - Refueling, 122
 - Fuel grade, 121
 - with Keyless Ride, 123, 125
 - Remote control
 - Replacing the battery, 54
 - Rider info status line
 - Adjusting, 81, 82
 - Riding mode, 62
 - Setting the PRO riding mode, 64
 - Riding mode preselection, 63
 - configure, 63
 - Road sign detection
 - Switching on or off, 83
- ### S
- Safety information
 - On braking, 118
 - On riding, 108
 - Screw connections, 212
 - Seat
 - Installing, 72
 - Lock, 14
 - Removing, 72
 - Service, 227
 - Electronic service history, 227
 - Reporting safety defects, 226
 - Service display, 45
 - Shifting gears
 - Upshift recommendation, 84
 - Socket
 - Information on use, 188
 - Position on the vehicle, 14

- Spark plugs
 - Technical data, 220
- Speed control
 - Operation, 66
- Speedometer, 19
- Spring preload
 - Adjusting, 103
 - Adjusting element, 15
- Start, 112
 - Operating element, 18
- Steering lock
 - Locking, 50
- Switching off, 120

T

- Tachometer, 19
 - Tachometer, 83
- Technical data
 - Battery, 220
 - Brakes, 218
 - Chassis, 217
 - Clutch, 216
 - Dimensions, 221
 - Electrical system, 219
 - Engine, 215
 - Engine oil, 214
 - Frame, 217
 - Fuel, 214
 - General notes, 5
 - Light source, 221
 - Performance data, 222
 - Rear-wheel drive, 216
 - Spark plugs, 220
 - Standards, 5
 - Transmission, 216
 - Weights, 222
 - Wheels and tires, 218

- TFT display, 19
 - Operating element, 17
 - Operation, 80, 81
 - Overview, 23, 24
 - Selecting the display, 77
 - Tire Pressure Control TPC/RDC Display, 37
 - Tires
 - Breaking-in, 116
 - Checking tire pressure, 159
 - Checking tread depth, 159, 160
 - Recommendation, 161
 - Technical data, 218
 - Tire pressures, 219
 - Top speed, 110
 - Topcase
 - Operation, 193
 - Torques, 212
 - Traction Control, 135
 - DTC, 135
 - Transmission
 - Technical data, 216
 - Troubleshooting chart, 210
 - Turn signals
 - Operating element, 17
 - Operation, 57
 - Type plate
 - Position on the vehicle, 15
- U**
- USB charging interface
 - Position on the vehicle, 14
- V**
- Values
 - Display, 25
 - Vehicle identification number
 - Position on the vehicle, 15
 - Vehicle voltage
 - Indicator light, 32, 33

W

- Warning lights, 19
 - Overview, 22
- Weights
 - Payload table, 16
 - Technical data, 222
- Wheels
 - Checking spokes, 160
 - Checking wheel rims, 160
 - Installing the front wheel, 164
 - Installing the rear wheel, 169
 - Removing the front wheel, 161
 - Removing the rear wheel, 168
 - Size change, 161
 - Technical data, 218
- Windshield
 - Adjusting, 101

The descriptions and illustrations in this manual may vary from your own motorcycle's actual equipment, depending upon its equipment level and accessories as well as your specific national version. No claims will be entertained as a result of such discrepancies. Dimensions, weights, fuel consumption and performance data are quoted to the customary tolerances. The right to modify designs, equipment and accessories is reserved. Errors and omissions excepted.

© 2020 Bayerische Motoren Werke Aktiengesellschaft
80788 Munich, Germany
Reprinting, in whole or in part, is only permitted with the written permission of BMW Motorrad, Aftersales. Original Rider's Manual, printed in Germany.



WARNING

Harmful substances

Operating, servicing and maintaining a passenger vehicle or off-road vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates and lead, which are known to the State of California to be carcinogenic or detrimental to childbirth or reproduction.

- To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle.
- For more information visit: www.P65Warnings.ca.gov/passenger-vehicle

Important data for refueling:

Fuel

Recommended fuel quality	Regular unleaded (max. 15% ethanol, E15) 87 AKI (91 ROZ/RON) 87 AKI
Usable fuel quantity	Approx. 4 gal (Approx. 15 l)
Reserve fuel quantity	Approx. 3.7 quarts (Approx. 3.5 l)

Tire pressure

Front tire pressure	31.9 psi (2.2 bar), One-up, with cold tires 36.3 psi (2.5 bar), Driver with passenger and/or load, with cold tire
Rear tire pressure	36.3 psi (2.5 bar), One-up, with cold tires 42.1 psi (2.9 bar), Driver with passenger and/or load, with cold tire

You can find further information on all aspects of your vehicle at: bmw-motorrad.com

BMW recommends **ADVANTEC**
ORIGINAL BMW ENGINE OIL

Order No.: 01 40 9 830 467
04.2020, 4th edition, 07



Huomioi seuraavat seikat käyttöohjeen lisäksi.

VAROITUS

Auton avaimessa on nappiparisto. Paristot tai nappiparistot voivat joutua nieluun ja johtaa kahden tunnin sisällä vakaviin tai hengenvaarallisiin vammoihin, esim. sisäisiin palovammoihin tai syöpymävammoihin. Tämä aiheuttaa loukkaantumis- ja hengenvaaran. Säilytä auton avainta ja paristoja lasten ulottumattomissa. Jos epäilet, että paristo tai nappiparisto on nieltä tai se on joutunut kehon sisälle, käänny välittömästi lääkärin puoleen.

HUOMAUTUS

Auton avaimen asetetut epäsoivat paristot voivat vaurioittaa auton avainta. Tämä aiheuttaa aineellisten vahinkojen vaaran. Vaihda tyhjän pariston tilalle vain jännitearvoltaan, kooltaan ja ominaisuuksiltaan vastaava paristo.

Oltre al libretto Uso e manutenzione, osservare quanto segue.

AVVERTENZA

La chiave della vettura contiene come batteria una batteria a bottone. Le batterie o le batterie a bottone possono essere ingerite ed entro due ore causare lesioni gravi o mortali, ad es. dovute a ustioni o corrosioni interne. Sussiste il pericolo di lesioni o conseguenze letali. Tenere la chiave della vettura e le batterie fuori dalla portata dei bambini. Nel dubbio che una batteria o una batteria a bottone sia stata ingerita o si trovi in una parte del corpo, chiedere immediatamente aiuto medico.

AVVISO

Batterie non adatte nella chiave della vettura possono danneggiare la chiave della vettura stessa. Sussiste il pericolo di danni materiali. Sostituire una batteria scarica soltanto con una batteria con la stessa tensione, la stessa dimensione e la stessa specifica.

Vær også oppmerksom på bruksanvisningen.

ADVARSEL

Batteriet i bilnøkkelen er en knappecelle. Batterier eller knappceller kan svelges og forårsake alvorlig personskade eller død innen to timer, f.eks. som følge av indre forbrenninger eller etseskader. Fare for personskader eller livsfare. Oppbevar bilnøkklene og batteriene utilgjengelig for barn. Hvis du mistenker at et batteri eller en knappecelle er svelget eller befinner seg i noen del av kroppen, må du ringe lege straks.

MERKNAD

Feil batterier i bilnøkkelen kan skade bilnøkkelen. Det er fare for materielle skader. Bytt ut utladet batteri kun med et batteri med samme spenning, størrelse og spesifikasjon.

Opórcz instrukcji obsługi przestrzegaj następujących zaleceń.

OSTRZEŻENIE

W kluczu do pojazdu znajduje się bateria guzikowa. Baterie zwykłe i guzikowe mogą zostać połknięte i w przeciągu dwóch godzin doprowadzić do ciężkich lub śmiertelnych obrażeń, np. w wyniku wewnętrznych oparzeń lub oparzeń chemicznych. Istnieje niebezpieczeństwo odniesienia obrażeń oraz zagrożenie dla życia. Klucz do pojazdu i baterie trzymać poza zasięgiem dzieci. W przypadku podejrzenia, że bateria zwykła lub guzikowa została połknięta lub znajduje się w innej części ciała, bezwzględnie udać się po pomoc medyczną.

WSKAZÓWKA

Niewłaściwa bateria może doprowadzić do uszkodzenia klucza do pojazdu. Istnieje niebezpieczeństwo strat materialnych. Rozładowaną baterię należy wymienić na baterię o takim samym napięciu, o tej samej wielkości i z taką samą specyfikacją.

Naast de handleiding ook het volgende in acht nemen.

WAARSCHUWING

De voertuigsluutel heeft een knoopcel als accu. Accu's of knoopcellen kunnen worden ingeslikt en binnen twee uur tot ernstige of dodelijke letsels leiden, bijv. door verbrandingen. Er bestaat kans op letsel of levensgevaar. Voertuigsluutels en accu's buiten het bereik van kinderen bewaren. Onmiddellijk medische hulp inroepen bij een vermoeden dat een accu of knoopcel werd ingeslikt of zich in een lichaamsdeel bevindt.

OPMERKING

Ongeschikte accu's in de voertuigsluutel kunnen de voertuigsluutel beschadigen. Er bestaat gevaar voor schade. De ontladen accu alleen door een accu met dezelfde spanning, dezelfde grootte en dezelfde specificaties vervangen.

Suplimentar față de manualul de utilizare, respectați următoarele.

⚠️ AVERTIZARE

Cheia autovehiculului conține o baterie sub forma unui element tip buton. Bateriile sau elementele tip buton pot fi înghițite și pot produce vătămări grave sau mortale în interval de două ore, de ex. prin provocarea de arsuri interne sau arsuri caustice. Există pericol de vătămare sau chiar pericol de moarte. Păstrați cheia autovehiculului și bateriile în locuri inaccesibile copiilor. Dacă aveți suspiciunea că o baterie sau un element tip buton a fost înghițit sau se află într-o parte a corpului, apelați imediat medicul.

⚠️ INDICAȚIE

Dacă în cheia autovehiculului se află baterii inadecvate, cheia autovehiculului poate suferi deteriorări. Există pericolul daunelor materiale. Înlocuiți bateria descărcată numai cu o baterie de aceeași tensiune, aceeași mărime și specificație identică.

Επιπρόσθετα στο εγχειρίδιο οδηγών προσέξτε τα παρακάτω.

⚠️ ΠΡΟΕΙΔΟΠΟΙΗΣΗ

Το κλειδί οχήματος περιέχει μια κομβίοδοχημης μπαταρία. Οι μπαταρίες ή οι κομβίοδοχημης μπαταρίες υπάρχουν κίνδυνος να καταποθούν και εντός δύο ωρών να οδηγήσουν σε σοβαρούς ή θανάσιμους τραυματισμούς, π.χ. εξαιτίας εσωτερικών εγκαυμάτων ή χημικών εγκαυμάτων. Υπάρχει κίνδυνος τραυματισμού ή θανάτου. Φυλάτε το κλειδί οχήματος και τις μπαταρίες μακριά από παιδιά. Αν υπάρχει υποψία κατάποσης μιας κομβίοδοχημης μπαταρίας ή μιας μπαταρίας ή ότι αυτή βρισκείται μέσα σε κάποιο μέρος του σώματος, αναζητήστε άμεσα ιατρική βοήθεια.

⚠️ Υπόδειξη

Ακατάλληλες μπαταρίες μέσα στο κλειδί οχήματος μπορούν να προκαλέσουν ζημιά στο κλειδί οχήματος. Υπάρχει κίνδυνος υλικών ζημιών. Αντικαθιστάτε την αποφορτισμένη μπαταρία μόνο με μια μπαταρία ίδιας τάσης, ίδιου μεγέθους και ίδιων προδιαγραφών.

Kromě návodu k obsluze věnujte pozornost následujícímu.

⚠️ VAROVÁNÍ

Klíč vozidla obsahuje knoflíkový článěk jako baterii. Baterie nebo knoflíkové články lze spolknout a během dvou hodin může dojít k těžkému nebo smrtelnému zranění, např. v důsledku vnitřních popálenin nebo poleptání. Hrozí nebezpečí poranění nebo smrtelného úrazu. Klíč vozidla a baterie uchovávejte mimo dosah dětí. Při podezření na spolknutí baterie nebo knoflíkového článku nebo na jejich přítomnost v těle ihned zavolejte lékařskou pomoc.

⚠️ UPOZORNĚNÍ

Nevhodné baterie v klíči vozidla mohou klíč vozidla poškodit. Hrozí nebezpečí hmotných škod. Vybítenou baterii vyměňte pouze za baterii se stejným napětím, stejnými rozměry a stejnou specifikací.

Para além do manual do condutor, respeitar o seguinte.

⚠️ ATENÇÃO

Como bateria, a chave do veículo contém uma pilha tipo botão. As baterias ou as pilhas tipo botão podem ser engolidas e, dentro de duas horas, causar ferimentos graves ou até a morte devido a, por ex., queimaduras químicas internas. Existe risco de lesão ou risco de vida. Guardar a chave do veículo fora do alcance das crianças. Se suspeitar que uma bateria ou pilha tipo botão tenha sido engolida ou se encontra numa parte do corpo, entrar imediatamente em contacto com a assistência médica.

⚠️ AVISO

Baterias inadequadas na chave do veículo podem danificar a chave do veículo. Existe perigo de danos materiais. Substituir a bateria descarregada por uma bateria com a mesma tensão, do mesmo tamanho e da mesma especificação.

Beakta även följande om instruktionsboken.

⚠️ VARNING

Fordonsnyckeln innehåller en knappcell som batteri. Batterier eller knappceller kan sväljas och leda till allvarliga eller dödliga skador inom två timmar, t.ex. genom inre brännskador eller frätskador. Risk för personskador eller livsfara. Förvara fordonsnyckeln och batterierna utom räckhåll för barn. Om du misstänker att någon person har svält ett batteri eller en knappcell eller att den finns i en kroppsdelen måste du omedelbart söka medicinsk hjälp.

⚠️ ANVISNING

Olämpliga batterier i fordonsnyckeln kan skada fordonsnyckeln. Risk för materiella skador. Ett urladat batteri får bara bytas ut mot ett batteri med samma spänning, storlek och specifikation.

A kezelési útmutató mellett vegye figyelembe a következőket.

FIGYELMEZTETÉS

A járműkulcs egy gombelemmel működik. Az elemek, illetve a gombelemek lenyelhetők, és két órán belül súlyos vagy halálos sérüléseket okozhatnak, például belső gyulladások vagy felmaródások okozásával. Sérülésveszély vagy életveszély áll fenn. A járműkulcsot és az elemeket gyermekektől távol kell tartani. Egy elem, illetve egy gombelem lenyelésének gyanúja esetén, vagy ha az egy testrészebe kerülne, azonnal kérjen orvosi segítséget.

MEGJEGYZÉS

Csak megfelelő gombelemekkel használja a járműkulcsot, különben a járműkulcs károsodhat. Anyagi kár veszélye áll fenn. A lemerült elemet csak azonos feszültségű, azonos méretű és azonos jellemzőkkel rendelkező elemmel helyettesítse.

Vær opmærksom på følgende ud over instruktionsbogen.

ADVARSEL

Bilnøglen inderholder et knapbatteri som batteri. Batterier eller knapbatterier kan sluges og i løbet af to timer føre til alvorlige eller dødelige kvæstelser, f.eks. indre forbrændinger eller ætsninger. Der er risiko for kvæstelse eller livsfare. Bilnøgler og batterier skal opbevares utilgængeligt for børn. Hvis der er mistanke om, at et batteri eller et knapbatteri er blevet slugt eller befinder sig i en kropsdel, skal lægen kontaktes omgående.

BEMÆRK

Uegnede batterier i bilnøglen kan beskadige bilnøglen. Der er risiko for materiel skade. Det afladede batteri må kun udskiftes med et batteri med samme spænding, størrelse og specifikationer.

Poleg navodil za uporabo upoštevajte še naslednje.

OPOZORILO

Avtomobilski ključ ima gumbasto celico kot baterijo. V primeru, če pride do zaužitja baterije ali gumbaste celice, lahko to v dveh urah povzroči resne telesne poškodbe ali smrt, npr. zaradi notranjih kemičnih opeklin. Obstaja nevarnost telesnih poškodb ali smrtna nevarnost. Avtomobilski ključ in baterije hranite zunaj dosega otrok. Če obstaja sum, da je prišlo do zaužitja baterije ali gumbaste celice ali da je v katerem koli delu telesa, takoj pokličite zdravniško pomoč.

OPOMBA

Neprimerno baterije v avtomobilskem ključu ga lahko poškodujejo. Obstaja nevarnost materialne škode. Izpraznjeno baterijo lahko zamenjate samo z baterijo enake napetosti, enake velikosti in istih tehničnih specifikacij.

Okrem návod na obsluhu rešpektujte aj nasledujúce pokyny.

VAROVANIE

Kľúč od vozidla obsahuje gombikovú batériu. Hrozí prehltnutie batérie alebo gombikových batérií a v priebehu dvoch hodín vznik vážnych alebo smrteľných poranení, napr. vnútorné popáleniny alebo poleptania. Hrozí nebezpečenstvo zranenia alebo ohrozenia života. Kľúč od vozidla a batérie uchovávajte mimo dosahu detí. Pri podozrení na prehltnutie batérie alebo gombikovej batérie alebo na ich prítomnosť v niektorej časti tela okamžite vyhľadajte lekársku pomoc.

UPOZORNENIE

Nevhodné batérie v kľúči od vozidla ho môžu poškodiť. Hrozí nebezpečenstvo večných škôd. Vybíť batériu nahraďte batériou s rovnakým napätím, rovnakou veľkosťou a rovnakou špecifikáciou.

Please note the following in addition to the information provided in the Owner's Handbook.

⚠ WARNING

The battery inside the vehicle key is a button cell. Batteries or button cells can be swallowed, causing serious or even fatal injuries within two hours, e.g. due to internal burns or cauterisations. There is a danger of injury or danger to life. Keep vehicle keys and batteries out of the reach of children. Seek medical assistance immediately if you suspect that a battery or button cell has been swallowed or has got into a part of the body.

⚠ NOTE

Using unsuitable batteries in a vehicle key can damage the vehicle key. There is a risk of material damage. Discharged batteries should only ever be replaced with batteries of the same voltage, same size and same specification.

Respecter les consignes suivantes en plus de la notice d'utilisation

⚠ AVERTISSEMENT

La clé du véhicule contient une pile bouton. Les batteries ou piles boutons peuvent être avalées et provoquer des blessures graves voire mortelles dans les deux heures, par exemple par des brûlures internes ou des brûlures chimiques. Risque de blessures ou danger de mort. Tenir la clé du véhicule et les batteries hors de la portée des enfants. En cas de suspicion d'ingestion d'une batterie ou d'une pile bouton ou d'introduction dans une partie du corps, contacter immédiatement un médecin.

⚠ REMARQUE

L'insertion de batteries non conformes dans la clé du véhicule peut endommager cette dernière. Risque de dommages matériels. Remplacer la batterie déchargée uniquement par une batterie de tension, de taille et de spécification identiques.

Zusätzlich zur Betriebsanleitung folgendes beachten.

⚠ WARNUNG

Der Fahrzeugschlüssel enthält als Batterie eine Knopfzelle. Batterien oder Knopfzellen können verschluckt werden und innerhalb von zwei Stunden zu schweren oder tödlichen Verletzungen führen, z. B. durch innere Verbrennungen oder Verätzungen. Es besteht Verletzungsgefahr oder Lebensgefahr. Fahrzeugschlüssel und Batterien außerhalb der Reichweite von Kindern aufbewahren. Bei Verdacht, dass eine Batterie oder Knopfzelle verschluckt wurde oder sich in einem Körperteil befindet, sofort medizinische Hilfe rufen.

⚠ HINWEIS

Ungeeignete Batterien im Fahrzeugschlüssel können den Fahrzeugschlüssel beschädigen. Es besteht die Gefahr von Sachschäden. Die entladene Batterie nur durch eine Batterie mit gleicher Spannung, gleicher Größe und gleicher Spezifikation ersetzen.

Observar lo siguiente adicionalmente al manual de instrucciones.

⚠ AVISO

La llave del vehículo contiene una pila de botón a modo de batería. Las pilas o las pilas de botón pueden ser ingeridas y, en el plazo de dos horas, causar lesiones graves o mortales como, p. ej., por quemaduras o abrasiones internas. Existe peligro de lesionarse o peligro de muerte. Mantener la llave del vehículo y las pilas fuera del alcance de los niños. Si sospecha que se ha ingerido una pila o una pila de botón, o que se encuentra en una parte del cuerpo, busque asistencia médica de inmediato.

⚠ INDICACIÓN

Las pilas no adecuadas para la llave del vehículo pueden dañar la misma. Existe peligro de daños materiales. La pila descargada únicamente debe ser sustituida por una pila con la misma tensión, el mismo tamaño y las mismas especificaciones.

© 2020 Bayerische Motoren Werke

Aktiengesellschaft

Munich, Germany

Not to be reproduced, wholly or in part, without written permission from BMW AG, Munich.

Order No.: 01 40 9 831 840

12.2020

Printed on environmentally friendly paper, bleached without chlorine, suitable for recycling.

