

Rider's Manual (US Model)

K 1600 GTL



BMW Motorrad



The Ultimate
Riding Machine

Motorcycle/Retailer Data

Motorcycle data

Model

Vehicle Identification Number

Color number

First registration

Registration number

Retailer Data

Contact in Service

Ms./Mr.

Phone number

Retailer's address/phone number (company stamp)

Welcome to BMW

We congratulate you on your choice of a motorcycle from BMW and welcome you to the community of BMW riders.

Familiarize yourself with your new motorcycle so that you can ride it safely and confidently in all traffic situations.

Please read this Rider's Manual carefully before starting to use your new BMW motorcycle. It contains important information on how to operate the controls and how to make the best possible use of all your BMW's technical features.

In addition, it contains information on maintenance and care to help you maintain your vehicle's reliability and safety, as well as its value.

If you have any questions concerning your motorcycle, your authorized BMW Motorrad retailer

is always happy to provide advice and assistance.

We wish you many miles of safe and enjoyable riding

BMW Motorrad.

01 41 8 543 207



Table of Contents

You can also consult the index at the end of this Rider's Manual if you want to find a particular topic or item of information.

1 General instructions 5

Overview	6
Abbreviations and symbols	6
Equipment	7
Technical data	7
Currentness of this manual	7

2 Overviews 9

General view, left side	11
General view, right side	13
Multifunction switch, left	14
Multifunction switch, right	16
Underneath seat	17
Instrument cluster	18

3 Status indicators 19

Multifunction display	20
Meaning of symbols.....	21
Range	22
Ambient temperature.....	22
Tire inflation pressures	22
Oil level indicator	23
Service display	23
Warning and indicator lights	25
Warning indicators	26

4 Operation..... 41

Steering and ignition lock	42
EWS Electronic immobilizer	43
Multifunction display	44
Onboard computer	48
Odometer	50
Lights	50
Turn indicators	52
Hazard warning flashers	53
Emergency ON/OFF switch	53

Heated handlebar grips	54
Seat heating	54
Dynamic Traction Control (DTC)	56
Riding mode	57
Seat	58
Windshield	59
Wind deflection wing	59
Cruise control	60
Storage compartments.....	62
Clutch	62
Brakes	63
Shifting.....	63
Mirrors	64
Spring preload	64
Damping	65
ESA Electronic Suspension Adjustment.....	66
Central locking	67
Anti-theft alarm (DWA)	71
Tires	74

5 Riding.....	77	Case	102	Returning motorcycle to	
Safety instructions	78	Topcase.....	104	use	138
Checklist	79	8 Maintenance	109	10 Technical data	139
Starting.....	80	General instructions	110	Troubleshooting chart.....	140
Breaking in	82	Standard tool kit.....	110	Threaded fasteners	141
Brakes	83	Engine oil	110	Engine	142
Parking your motorcycle	84	Brake system	112	Fuel	143
Refueling	84	Coolant.....	116	Engine oil	143
Securing motorcycle for		Clutch	117	Clutch	144
transport	86	Rims and tires.....	117	Transmission.....	144
6 Technology in		Wheels	118	Rear-wheel drive	145
detail	87	Front wheel stand	124	Running gear.....	145
Riding mode	88	Jump-starting	126	Brakes	146
Brake system with BMW		Lamps.....	126	Wheels and tires	147
Motorrad Integral ABS	89	Battery	129	Electrical system	148
Engine management with		Fuses	132	Anti-theft alarm system ...	150
BMW Motorrad DTC	92	9 Care	135	Frame	151
Tire Pressure Control TPC/		Care products	136	Dimensions	151
RDC.....	93	Washing your motorcy-		Weights	152
ESA II Electronic Suspension		cle.....	136	Riding specifications	152
Adjustment.....	94	Cleaning sensitive vehicle			
7 Accessories	97	parts	136		
General instructions	98	Paint care	137		
Onboard sockets	98	Protective wax coating	138		
Navigation device	99	Storing motorcycle	138		

11 Service 153

Reporting safety

defects 154

BMW Motorrad Service ... 155

BMW Motorrad Mobility

Services 155

Maintenance work 155

Confirmation of mainte-

nance work 157

Confirmation of service 162

12 Appendix 165

Certificates 166

13 Index 171

General instructions

Overview	6
Abbreviations and symbols	6
Equipment	7
Technical data	7
Currentness of this manual	7

Overview

Chapter 2 of this Rider's Manual will provide you with an initial overview of your motorcycle. All maintenance and repair work carried out on your motorcycle will be documented in Chapter 11. Proof of the maintenance work performed is a prerequisite for generous treatment of claims. When the time comes to sell your BMW, please remember to hand over this Rider's Manual; it is an important part of the motorcycle.

Abbreviations and symbols



Indicates warnings that you must comply with for reasons of your safety and the safety of others, and to protect your motorcycle against damage.



Special information on operating and inspecting your motorcycle as well as maintenance and adjustment procedures.



Indicates the end of an item of information.



Instruction.



Result of an activity.



Reference to a page with more detailed information.



Indicates the end of accessory or equipment-dependent information.



Tightening torque.



Technical data.

OE	Optional equipment The motorcycles are assembled complete with all the BMW optional extras originally ordered.
OA	Optional accessory BMW optional accessories can be purchased and installed at your authorized BMW Motorrad retailer.
EWS	Electronic immobilizer.
DWA	Anti-theft alarm.
ABS	Anti-Lock Brake System.
DTC	Dynamic Traction Control.
ESA	Electronic Suspension Adjustment.
TPC/ RDC	Tire Pressure Control (TPC).

Equipment

When you ordered your BMW motorcycle, you chose various items of custom equipment. This Rider's Manual describes optional equipment (OE) offered by BMW and selected optional accessories (OA). This explains why the manual may also contain descriptions of equipment which you have not ordered. Please note, too, that your motorcycle might not be exactly as illustrated in this manual on account of country-specific differences.

If your BMW is equipped with options or accessories not described in this Rider's Manual, then this equipment is described in separate operating instructions.

Technical data


All dimensions, weights and outputs in the Rider's Manual refer to the Deutsches Institut für Normung e. V. (DIN) and comply with its tolerance regulations. Versions for individual countries may differ.

Currentness of this manual

The high safety and quality standards of BMW motorcycles are maintained by constant development work on designs, equipment and accessories. Because of this, your motorcycle may differ from the information supplied in the Rider's Manual. In addition, BMW Motorrad cannot guarantee the total absence of errors. We hope you will appreciate that no claims can be entertained on the basis of the data, illustrations or descriptions in this manual.


Overviews

General view, left side.....	11
General view, right side	13
Multifunction switch, left	14
Multifunction switch, right.....	16
Underneath seat	17
Instrument cluster	18



General view, left side

- 1** Clutch fluid reservoir
( 117)
- 2** Fuel filler opening ( 84)
- 3** Operating panel for the audio system (see separate user guide)
- 4** Seat lock ( 58)
- 5** Control for rear-seat heating (on the seat) ( 55)
- 6** Payload table
Tire inflation pressure table
- 7** Adjusting spring preload
( 64)
- 8** Adjusting damping ( 65)
- 9** Storage compartment
( 62)
- 10** Adjustable shift lever
( 63)
- 11** Wind deflection wing
( 59)




General view, right side

- 1** Vehicle Identification Number (above engine oil filler neck)
- 2** Onboard socket (▮▮▮▮ 98)
- 3** Brake-fluid reservoir, front (▮▮▮▮ 114)
- 4** Coolant level indicator (behind side panel) (▮▮▮▮ 116)
- 5** Type plate (on front suspension)
- 6** Wind deflection wing (▮▮▮▮ 59)
- 7** Engine oil fill location and oil dipstick (▮▮▮▮ 110)
- 8** Stowage compartment of the audio system (▮▮▮▮ 62)
- 9** Brake-fluid reservoir, rear (▮▮▮▮ 115)

Multifunction switch, left

- 1 Headlight high beam and flasher (➡ 50)
- 2 – with LED auxiliary headlights^{OE}
Operating additional headlights (➡ 51)
- 3 Cruise control (➡ 60)
- 4 Hazard warning flashers (➡ 53)
- 5 Windshield (➡ 59)
- 6 Turn signals (➡ 52)
- 7 Horn




- 8** Multi-controller and MENU button
Operating the multifunction display (▣▣▣▣➡ 44)
Operation of the audio system (see the appropriate instructions for use)
– with Dynamic Traction Control (DTC) ^{OE}
Using DTC (▣▣▣▣➡ 56)
– with Electronic Suspension Adjustment (ESA) ^{OE}
ESA control (▣▣▣▣➡ 66)
- 9** Selecting favorite menu (▣▣▣▣➡ 47).

Multifunction switch, right

- 1 – with central locking^{OE}
Operation of the central locking system (➡ 67)
- 2 Selection of the ride mode (➡ 57)
- 3 Emergency ON/OFF switch (➡ 53)
- 4 Starting the engine (➡ 80)






Underneath seat

- 1 Rider's Manual (US Model)
- 2 Fuses (➡ 132)
- 3 Battery (➡ 129)
- 4 Standard tool kit (➡ 110)

Instrument cluster

- 1 Speedometer
- 2 Release for navigation slot
- 3 Warning and indicator lights (►► 25)
- 4 – with navigation system^{OA}
Navigation device (►► 99)
- 5 Ambient brightness sensor
(for brightness adjustment
of instrument lighting)
- 6 Tachometer
- 7 Control for tripmeters
(►► 50)
- 8 Multifunction display
(►► 20)

 The brightness of the warning lights and telltale lights, the display and the instrument needle and gauge lighting is adapted automatically to suit ambient brightness.◀




Status indicators


Multifunction display	20
Meaning of symbols	21
Range	22
Ambient temperature	22
Tire inflation pressures.....	22
Oil level indicator.....	23
Service display	23
Warning and indicator lights.....	25
Warning indicators	26

Multifunction display

- 1 Riding mode (➡ 57)
- 2 Coolant temperature
- 3 Area for warnings (➡ 26)
- 4 Menu area (➡ 44)
Area for messages relating to the audio system
- 5 Onboard computer display area (➡ 48)
– with Tire Pressure Control (TPC/RDC)^{OE}
RDC readings
- 6 Status indicators for seat heating (➡ 54)
Status indicators for handlebar grip heating (➡ 54)
– with Electronic Suspension Adjustment (ESA)^{OE}
ESA settings
- 7 Trip distance (➡ 50)
- 8 Total distance covered
- 9 Clock (➡ 47)
- 10 Fuel level
- 11 Gear indicator, "N" is shown for Neutral



Meaning of symbols



Meanings of the symbols at position **1**:



Average consumption
1 and 2 since last reset
(49)



Range with fuel now on
board (22)



Average speed since last
reset (49)



Ambient temperature
(22)



Tire inflation pressures
(22)



Stopwatch (49)



Travel times (49)



Date (display mode de-
pends on the time format
selected) (47)



Oil level (23)




2 Rear-seat heating ON

3 Handlebar grip heating ON

4 Front-seat heating ON

- with Electronic Suspension Adjustment (ESA)^{OE}



- 5 Damping
- 6 Vehicle load◀

Range



The range indicates the travel distance available with the remaining fuel. The average consumption employed to calculate the remaining travel range does not appear in the display and may vary from the indicated average consumption. You must put at least five liters of fuel into the fuel tank for the new

level to be registered correctly. If the sensor cannot register the new level the range display cannot be updated.

If the motorcycle is standing on its side stand, the motorcycle's inclined position will prevent the fuel level from being registered accurately. For this reason travel range is only calculated with the side stand retracted.



The determined range is an approximate reading. BMW Motorrad therefore recommends that you do not try to use the full range before refueling.◀

Ambient temperature



Engine heat can lead to spurious readings of ambient temperature when the motorcycle is stationary. When the effects of engine heat on the monitored temperature become excessive the display responds

by temporarily reverting to -- as the display reading.



If the ambient temperature drops below 37 °F (3 °C), this warning of possible icing-up appears. The display automatically switches from any other mode to the temperature reading when the temperature drops below this threshold for the first time.

Tire inflation pressures

- with Tire Pressure Control (TPC/RDC)^{OE}



The displayed tire inflation pressures refer to a tire temperature of 68 °F (20 °C). The left-hand value **1** indicates the air pressure of the front wheel, and the right-hand value **2** the inflation pressure of the rear wheel. Immediately after switching on the ignition, "-- --" is displayed, as the transfer of the inflation pressure values does not begin until a speed of 19 mph (30 km/h) is exceeded for the first time.

If the pressure in a tire drops to a critical level the corresponding status indicator shows red.



The tire warning symbol also appears on the display.



The general warning light flashes red.

Additional information on BMW Motorrad TPC/RDC is provided from page (93).

Oil level indicator



The oil-level indicator gives you an indication of the engine oil level.

The conditions for the oil level indicator are as follows:

- Engine at operating temperature.

- Engine idling for at least ten seconds.
- Side-stand retracted.
- Motorcycle is vertical.

The readings mean:

OK: Oil level is correct

CHECK !: Check oil level during next refueling stop.

- – -: No measurement possible (above-mentioned conditions not met).

Service display



If a service is due, for a brief period after the pre-ride check the service symbol appears on the display and the service-due date shows instead of the odometer reading.



If the service is overdue the General warning light briefly

shows yellow and the service symbol lights up continuously.




If the countdown to the next service is less than one month, service-due date **1** appears on the display.



If the motorcycle is driven long distances annually, it is possible that earlier service will be required. If the countdown distance to the early service is less than 621 mls (1000 km), countdown distance **2** appears on the display.



If the service display appears more than a month before the service date, the stored date must be adjusted in the instrument cluster. This situation can occur if the battery was disconnected.◀



Warning and indicator lights


- 1 ABS warning light (►► 34)
- 2 – with Dynamic Traction Control (DTC) OE
DTC warning light (►► 35)
- 3 Telltale light of the left turn indicators
- 4 Warning light for fuel down to reserve (►► 31)
- 5 Neutral indicator light
- 6 High-beam headlight indicator light
- 7 Telltale light of the right turn indicators
- 8 Warning light for engine electronics
- 9 – with anti-theft alarm^{OE}
Anti-theft alarm telltale light (►► 71)
- 10 – with LED auxiliary headlights^{OE}
Telltale light for the auxiliary headlights (►► 51)

- 11** Indicator light of cruise-control system (➡ 60)
- 12** General warning light, in conjunction with warning indicators in display (➡ 26)

Warning indicators

Display

Warnings are displayed with the corresponding warning light.



Warnings for which there is no dedicated warning light are indicated by 'General' warning light **1** showing in combination with a warning symbol such as, for example, **2** appearing in the multifunction display. The 'General' warning light shows red or yellow, depending on the urgency of the warning.

Up to four warning symbols can be displayed at any given time.

The general warning light is shown in accordance with the most urgent warning.

The possible warnings are listed on the following pages.

Overview of warning indicators

Warning light	Displays	Meaning
 Lights up yellow	 appears on the display	Electronic immobilizer is active (▮▮▮ 31)
 Lights up	Fuel-level reading turns yellow	Fuel down to reserve (▮▮▮ 31)
 Lights up red	Temperature reading turns red	Coolant temperature too high (▮▮▮ 31)
 Lights up		Engine fault (▮▮▮ 32)
 Flashes		Severe engine fault (▮▮▮ 32)
	 appears on the display	Engine-oil level too low (▮▮▮ 32)
 Lights up red	 appears on the display	Battery charge current insufficient (▮▮▮ 32)
	 appears on the display	Onboard system voltage low (▮▮▮ 33)

Warning light	Displays	Meaning
 Lights up yellow	 appears on the display	Onboard system voltage critical (➡ 33)
 Lights up yellow	 appears on the display	Rear light failure (➡ 33)
 Lights up yellow	 appears on the display	Front light failure (➡ 34)
 Lights up yellow	 appears on the display	Light failure (➡ 34)
	 appears on the display	Ice warning (➡ 34)
 Flashes		ABS self-diagnosis not completed (➡ 34)
 Lights up		ABS error (➡ 35)
 Flashes rapidly		DTC intervention (➡ 35)
 Flashes slowly		DTC self-diagnosis not completed (➡ 35)

Warning light

Displays

Meaning



Lights up

DTC deactivated (→ 35)



Lights up

DTC error (→ 36)



Flashes red



+ tire pressure in red

Tire inflation pressure is outside approved range (→ 36)



+ "--" or "--" is indicated

Transmission error (→ 36)



Lights up yellow



+ "--" or "--" is indicated

Sensor defective or system fault (→ 37)



Lights up yellow



appears on the display

Battery of tire-inflation pressure sensor weak (→ 37)



Lights up red



appears on the display

Light direction of the low-beam headlight not known (→ 38)



Flashes yellow



appears on the display

Beam-throw adjustment of the low-beam headlight restricted (→ 38)



appears on the display

Headlight aiming changed (→ 38)

Warning light

Displays

Meaning

		appears on the display	Anti-theft alarm battery low charge (▢▢▢▢➡ 38)
 Lights up yellow		appears on the display	Anti-theft alarm battery drained (▢▢▢▢➡ 39)
		appears on the display	Central locking locked (▢▢▢▢➡ 39)
 briefly shows yellow		appears on the display	Service overdue (▢▢▢▢➡ 39)

Electronic immobilizer is active



General warning light shows yellow.



Key appears on the display.

Possible cause:

The key being used is not authorized for starting, or communication between the key and engine electronics is disrupted.

- Remove other ignition keys located on the ignition key.
- Use the reserve key.
- Have the defective key replaced, preferably by an authorized BMW Motorrad retailer.

Fuel down to reserve



Reserve-fuel symbol lights up

Fuel-level reading turns yellow.




A fuel shortage can lead to misfiring and to the engine dying unexpectedly. Misfiring can damage the catalytic converter, and the engine dying unexpected can lead to accidents.

Do not drive to the extent that the fuel tank is completely empty.◀

Possible cause:

At the most, the fuel tank still contains the reserve fuel quantity.



- Refueling (►► 84).

Coolant temperature too high



General warning light shows red.

The temperature reading turns red.



Continued driving with an overheated engine can result in engine damage. Be sure to observe the measures listed below.◀

Possible cause:

The coolant temperature is too high.

- If possible, continue driving in the part-load range to cool down the engine.
- In traffic jams, switch off the engine, but keep the ignition switched on so that the radiator fan continues to operate.
- Should the coolant temperature frequently be too high, have the fault rectified as quickly as possible by a specialized workshop, preferably an authorized BMW Motorrad retailer.

Engine fault



The engine symbol lights up.

Possible cause:

The engine control unit has diagnosed a fault.



The engine is in the emergency operating mode. Unusual engine response is a possibility.

Adapt your style of riding accordingly. Avoid accelerating sharply and overtaking.◀

- If you continue to ride be prepared for unusual engine behavior (low power, poor throttle response, abrupt stalling, etc.)
- Have the malfunction corrected as soon as possible by a specialized workshop, preferably an authorized BMW Motorrad retailer.

Severe engine fault



The engine symbol flashes.

Possible cause:

The engine control unit has diagnosed a severe fault.



An engine fault that can lead to severe consequential damage has been detected. Adapt your style of riding accordingly. Ride slowly, avoid accelerating and overtaking. If possible, have the motorcycle picked up.◀

- If you continue to ride be prepared for unusual engine behavior (low power, poor throttle response, abrupt stalling, etc.)
- Have the malfunction corrected as soon as possible by a specialized workshop, preferably an authorized BMW Motorrad retailer.

Engine-oil level too low



The oil can symbol is displayed.

Possible cause:

The electronic oil level sensor has detected a low engine oil level. Check the engine-oil level with the dipstick the next time you stop to refuel:

- Checking engine oil level (➡ 110).

If oil level is too low:

- Topping up engine oil (➡ 112).

Battery charge current insufficient



General warning light shows red.



The battery symbol is displayed.



A discharged battery leads to the failure of various motorcycle systems, e.g. lighting,

engine or ABS. This can result in dangerous driving situations. If possible, do not continue driving.◀

The battery is not being charged. If you continue driving, the vehicle electronics will discharge the battery.

Possible cause:

Alternator or alternator drive defective

- Have the malfunction corrected as soon as possible by a specialized workshop, preferably an authorized BMW Motorrad retailer.

Onboard system voltage low



The split battery symbol appears on the display.

Generator power is only just sufficient to supply all consumers and charge the battery.

Possible cause:

Too many consumers switched on. On-board system voltage tends to drop particularly at low engine rpm and when the engine is idling.

- When riding at low engine rpm switch off consumers that are not necessary for road safety (e.g. heated body warmer or auxiliary headlights).

Onboard system voltage critical



General warning light shows yellow.



The split battery symbol appears on the display.

Generator power is no longer sufficient to supply all consumers and charge the battery. In order to ensure that the engine can be started and the motorcycle ridden, the onboard electronics switch off the electricity supply

to the onboard sockets and the auxiliary headlights. In extreme cases the seat heating and the grip heating might also be shut down.

Possible cause:

Too many consumers switched on. On-board system voltage tends to drop particularly at low engine rpm and when the engine is idling.

- When riding at low engine rpm switch off consumers that are not necessary for road safety (e.g. heated body warmer or auxiliary headlights).

Rear light failure



General warning light shows yellow.



Bulb symbol with arrow pointing to the rear appears on the display.

Possible cause:

Rear light, brake light or rear flashing turn indicator defective.

- The diode tail light must be replaced. Please contact a specialized workshop, preferably an authorized BMW Motorrad retailer.

Front light failure



General warning light shows yellow.



Bulb symbol with arrow pointing to the front appears on the display.

Possible cause:

Low-beam headlight, high-beam headlight, parking light or front flashing turn indicator defective.

- Consult a specialist workshop, preferably an authorized BMW Motorrad dealer, if the low-beam headlight or an LED turn indicator requires replacement.

- Replacing high-beam bulb (126).

Light failure



General warning light shows yellow.



Bulb symbol with two arrows appears on the display.

Possible cause:

A combination of light failures has occurred.

- Please contact a specialized workshop, preferably an authorized BMW Motorrad retailer.

Ice warning



The ice crystal symbol is displayed.

Possible cause:

The ambient temperature measured at the motorcycle is lower than 37 °F (3 °C).



The ice warning does not mean that there is no risk of black ice forming at measured temperatures above 37 °F (3 °C). At low outside temperatures, black ice must especially be expected on bridges and in shady road areas. ◀

- Think well ahead when driving.

ABS self-diagnosis not completed



ABS warning light flashes.

Possible cause:

The self-diagnosis routine was not completed; the ABS function is not available. The motorcycle must reach a speed of at least 3.1 mph (5 km/h) before the ABS self-diagnosis routine can be completed.

- Ride off slowly. It must be noted that the ABS function

is not available until the self-diagnosis has been completed.

ABS error



ABS warning light lights up.

Possible cause:

The ABS control unit has detected an error. The ABS function is not available.

- Continued driving is possible while taking the failed ABS function into account. Observe additional information on situations which can lead to an ABS error (► 91).
- Have the malfunction corrected as soon as possible by a specialized workshop, preferably an authorized BMW Motorrad retailer.

DTC intervention

– with Dynamic Traction Control (DTC) ^{OE}



DTC warning light flashes rapidly.

The DTC has detected instability at the rear wheel and has reduced the torque. The warning light flashes longer than the DTC intervention lasts. This feature continues to furnish the rider with optical feedback confirming that the system has initiated active closed-loop intervention even after the critical situation has passed.

DTC self-diagnosis not completed

– with Dynamic Traction Control (DTC) ^{OE}



DTC warning light flashes slowly.

Possible cause:

The self-diagnosis was not completed; the ASC function is not available. So that the ASC self-diagnosis can be completed, the engine must be running and the motorcycle must be moved at a speed of at least 3.1 mph (5 km/h).

- Ride off slowly. It must be noted that the ASC function is not available until the self-diagnosis has been completed.

DTC deactivated

– with Dynamic Traction Control (DTC) ^{OE}



DTC warning light lights up.

Possible cause:

The DTC system has been deactivated by the driver.

- Switch on DTC.

DTC error

- with Dynamic Traction Control (DTC) ^{OE}



DTC warning light lights up.

Possible cause:

The DTC control unit has detected an error. The DTC function is not available.

- Continued driving is possible. It must be noted that the DTC function is not available. Observe additional information on situations which can lead to a DTC error (► 92).
- Have the malfunction corrected as soon as possible by a specialized workshop, preferably an authorized BMW Motorrad retailer.

Tire inflation pressure is outside approved range

- with Tire Pressure Control (TPC/RDC) ^{OE}



General warning light flashes red.



+ the critical tire pressure shows red.

Possible cause:

The measured tire inflation pressure is outside the permissible tolerance.

- Check tire for damage and drivability.

Is it still possible to drive with tire:



Incorrect tire inflation pressure result in poorer handling of the motorcycle.

Always adapt your driving style to the incorrect tire inflation pressure. ◀

- Correct tire inflation pressure at next opportunity.



Before adjusting the tire inflation pressure, observe the information on temperature compensation and on inflation pressure adjustment in the chapter "Technology in detail". ◀

- Have the tire checked for damage by a specialized workshop, preferably an authorized BMW Motorrad retailer.

If you are unsure about the drivability of the tire:

- Do not continue driving.
- Inform roadside service.

Transmission error

- with Tire Pressure Control (TPC/RDC) ^{OE}



+ "—" or "— —" is indicated.

Possible cause:

There is a fault in the radio connection to the RDC sensors.

Possible causes are radio systems in the surrounding area, which interfere with the connection between the RDC control unit and the sensors.

- Watch the RDC display in another environment. A permanent fault has not occurred until the general warning light also lights up. In this case:
- Have fault eliminated by a specialized workshop, preferably an authorized BMW Motorrad retailer.

Sensor defective or system fault

– with Tire Pressure Control (TPC/RDC)^{OE}



General warning light shows yellow.



+ "--" or "-- --" is indicated.

Possible cause:

Wheels without installed RDC sensors are mounted.

- Retrofit wheel set with RDC sensors.

Possible cause:

One or two RDC sensors have failed.

- Have fault eliminated by a specialized workshop, preferably an authorized BMW Motorrad retailer.

Possible cause:

A system fault has occurred.

- Have fault eliminated by a specialized workshop, preferably an authorized BMW Motorrad retailer.

Battery of tire-inflation pressure sensor weak

– with Tire Pressure Control (TPC/RDC)^{OE}



General warning light shows yellow.



The RDC battery symbol appears on the display.



This error message is only displayed for a short time following the pre-ride check. ◀

Possible cause:

The battery of the tire inflation pressure sensor no longer has its full capacity. The operation of the tire inflation pressure control is only ensured for a limited time.

- Contact a specialized workshop, preferably an authorized BMW Motorrad retailer.

Light direction of the low-beam headlight not known



General warning light shows red.



Headlight with question mark appears on the display.

Illumination of the road ahead is no longer optimum; there is a possibility of dazzling oncoming traffic.

Possible cause:

Light direction and range of the low-beam headlight are unknown, adjustment is no longer possible.

- If it is dark leave the motorcycle where it is or have it picked up, if possible.
- Have the defect rectified as quickly as possible by a specialist workshop, preferably an authorized BMW Motorrad dealer.

Beam-throw adjustment of the low-beam headlight restricted



General warning light flashes yellow.



Headlight with zero appears on the display.

Illumination of the road ahead is no longer optimum.

Possible cause:

Only restricted adjustment of light direction and range of the low-beam headlight possible.

- Have the defect rectified by a specialist workshop, preferably an authorized BMW Motorrad dealer.

Headlight aiming changed

– with Adaptive Headlight ^{OE}



appears on the display. Cornering light control for the low-beam headlight is switched off.

Possible cause:

Headlight alignment has been changed from the as-delivered condition.

- Adjusting for traffic driving on right or driving on left (→ 51).

Anti-theft alarm battery low charge

– with anti-theft alarm ^{OE}



The anti-theft alarm battery symbol appears on the display.



This error message is only displayed for a short time following the pre-ride check. ◀

Possible cause:

The anti-theft alarm battery no longer has its full capacity. The operation of the anti-theft alarm is only ensured for a limited time with the motorcycle battery disconnected.

- Contact a specialized workshop, preferably an authorized BMW Motorrad retailer.

Anti-theft alarm battery drained

– with anti-theft alarm^{OE}



General warning light shows yellow.



The anti-theft alarm battery symbol appears on the display.



This error message is only displayed for a short time following the pre-ride check. ◀

Possible cause:

The anti-theft alarm battery has no capacity. The operation of the anti-theft alarm is no longer ensured with the motorcycle battery disconnected.

- Contact a specialized workshop, preferably an authorized BMW Motorrad retailer.

Central locking locked

– with central locking^{OE}



The locked symbol appears on the display.

All locks in the central locking system are locked.

Service overdue



appears on the display.



General warning light briefly shows yellow after the pre-ride check.

Possible cause:

A necessary service has not been carried out.

- Have servicing carried out as quickly as possible by a specialist workshop, preferably an authorized BMW-Motorrad dealer.

Operation

Steering and ignition lock	42	Wind deflection wing.....	59
EWS Electronic immobilizer.....	43	Cruise control.....	60
Multifunction display	44	Storage compartments	62
Onboard computer	48	Clutch	62
Odometer	50	Brakes	63
Lights.....	50	Shifting	63
Turn indicators.....	52	Mirrors	64
Hazard warning flashers.....	53	Spring preload	64
Emergency ON/OFF switch.....	53	Damping.....	65
Heated handlebar grips	54	ESA Electronic Suspension Adjust- ment.....	66
Seat heating	54	Central locking.....	67
Dynamic Traction Control (DTC)....	56	Anti-theft alarm (DWA).....	71
Riding mode	57	Tires.....	74
Seat	58		
Windshield.....	59		

Steering and ignition lock


Keys

Two main keys and one emergency key are provided with the vehicle. The emergency key features a light, compact design, allowing it to be carried in a wallet, etc. This key is intended for use when no main key is immediately available, and is not suitable for continuous use.

If a key is lost, please note the information on the electronic immobilizer (EWS) (► 43).

Ignition switch/steering lock, tank filler cap lock, stowage compartments, seat lock and cases are all operated with the same key.

Switching on ignition



- Turn key to position **1**.
 - » Parking lights and all function circuits switched on.
 - » Engine can be started.
 - » Pre-ride check is performed. (► 80)
 - » ABS self-diagnosis in progress. (► 81)
- with Dynamic Traction Control (DTC) ^{OE}
 - » DTC self-diagnosis is performed. (► 81)

Switching off ignition



- Turn key to position **2**.
 - » Light switched off.
 - » Handlebars not locked.
 - » Key can be removed.
 - » The windscreen automatically moves to the bottom limit position.

Locking handlebars



If the motorcycle is on the side stand, the surface of the ground will determine whether it is better to turn the handlebars to the left or right. However, the motorcycle is more

stable on a level surface with the handlebars turned to the left than with the handlebars turned to the right.

On level ground, always turn the handlebars to the left to set the steering lock. ◀

- Turn handlebars to full left or right lock position.



- Turn key to position **3** while moving handlebars slightly.
 - » Ignition, lights and all function circuits switched off.
 - » Handlebars locked.
 - » Key can be removed.

EWS Electronic immobilizer

The motorcycle's electronic circuitry monitors the data stored in the key through a ring antenna incorporated in the ignition lock. The engine management system does not enable engine starting until the key has been recognized as "authorized" for your motorcycle.

▶ A spare key attached to the same ring as the ignition key used to start the engine could "irritate" the electronics, in which case the enabling signal for starting is not issued. The EWS warning is shown in the multifunction display.

Always store the spare key separately from the ignition key. ◀

If you lose a key, you can have it disabled by your BMW Motorrad partner. When having a key disabled you should also bring all of the motorcycle's remaining keys with you.

The engine can no longer be started using a disabled key; however, a disabled key can be enabled again.

Replacement and spare keys are only available through an authorized BMW Motorrad retailer.

The keys are part of an integrated security system, so the retailer is under an obligation to check the legitimacy of all applications for replacement/extra keys.

Multifunction display


Selecting menu



Press button **2** to step through the sequence of menus, starting with the **Info** menu. Each time you press button **2** you call up the next menu in the sequence; the number of menus depends on the options fitted to the motorcycle.

You also have the option of pressing button **3** for direct access to a favorite menu of your choice.

With the exception of the **Audio** area, the **Settings** menu can only be called with the motorcycle at a standstill.



The type of menu shows at position **1**; cursor **2** indicates the current selection. Each line **3** indicates a menu that can be selected. The line representing the menu you are currently viewing is grayed to show you where you are in the sequence of menus.




See the separate Quick Reference Guide for an overview of all menus.◀


Selecting menu item



Move the cursor within the menu using the Multi-Controller **1**.




Setting parameters



Direct selection:

If you move the cursor to a menu item that requires no other settings, your selection goes active right away.



Resetting values:

You can reset average values marked with an arrow **1** by long-pressing the Multi-Controller to the right.


An arrow **1** on the upper or lower edge of the display indicates that by turning the Multi-Controller in the corresponding direction, you can access additional menu items. If the arrow **2** is shown on the cursor, then you can call up a submenu by pressing the Multi-Controller to the right (different meaning for average values and list selection, see (▮ 45)).



Selecting from a list:


A circle **2** beside each selectable item means that the items are part of a selection list. A circle with a dot indicates the item that is currently selected.

If you want to change the selection, move the cursor to another item in the list and press the Multi-Controller to the right to either activate or deactivate the parameter you selected.



Setting numerical values:


If there are one or more numerical values between the arrows **3**, you can increase the values by turning the Multi-Controller up or reduce the values by turning it down. By pressing the Multi-Controller to the right or left, you can change between the values.



Setting relative values:

A bar indicator enables you to set a value in a range between two limits. Turning the Multi-Controller up increases or turning it down decreases the value to be set.

Exiting menu



Arrow **3** appears when you are in a submenu.



By pressing the Multi-Controller **1** to the left, you jump back to the next-higher menu; by pressing the MENU button **2**, you jump back to the main menu.

To hide the menus, press the Multi-Controller **1** to the left in a main menu.

Selecting favorite menu

- Select the main menu of your choice.



- Hold down button **3**.

 The diamond appears to the right of the menu designation.

» The menu you have selected will subsequently be called up whenever you press button **3**.

Adapting mode of presentation

- Switch on ignition.
- Call up the Settings menu and select User.

The settings you can choose are as follows:

- Language: Display language (German, English, Spanish, Italian, French, Dutch, Portuguese)
- Time format - 12 h / 24 h: Clock in 12-hour format (12 h) or in 24-hour format (24 h)
- Time format - Date format: Date in day . month . year format (dd . mm . yy) or in month / day / year format (mm / dd / yy)
- Time format - GPS time: Accept GPS time and GPS date from the built-in navigation system (On), (Off)
- Brightness: Brightness of the display and the instruments
- Start logo: Show start logo after the ignition is switched on (On), (Off)
- Background: Indicator on the display when the radio is switched off: Empty: no indicator, Logo: 6 cylinder logo, Speedo: digital speed indicator
- Fact. settings: Restore factory defaults (when Reset ! appears on the display, press the Multi-Controller to the right and hold it in this position)
 - Using the Multi-Controller, make the desired adjustments.

Onboard computer

Selecting display readings

- Call up the Info menu and select the item of information of your choice.



The following items of information can be displayed in panel **3**:

- ØConsump. 1: Average consumption 1
- ØConsump. 2: Average consumption 2
- Range: Range with fuel remaining in fuel tank
- ØSpeed: Average speed
- Temperature: Ambient temperature
- Tire pressure: Tire pressures
- Stopwatch: Stopwatch

- Travel times: Travel times
- Date: Current date
- Oil level: Engine-oil level
- Off: No reading

Resetting average data

- Call up the Info menu and select the average value you want to reset.
- Push the Multi-Controller to the right and hold it in this position until the average value is reset.

Operating stopwatch

- Call up the Info menu and select Stopwatch.



- With the stopwatch stopped, push the Multi-Controller **1** to the right to start the stopwatch.
 - » The stopwatch continues timing even if you select some other reading or switch off the ignition.
- With the stopwatch running, push Multi-Controller **1** to the right to stop the stopwatch.
- Push Multi-Controller **1** to the right and hold it in this position to reset the stopwatch.

Measuring travel times

- Call up the Info menu and select Travel times.



- Push the Multi-Controller **1** to the right and hold it in this position to reset the travel time.
 - » Timing continues even if you select some other reading or switch off the ignition.


 Time during which the motorcycle was on the move since the last reset.

 Time during which the motorcycle was at a standstill since the last reset.

Odometer

Selecting odometer

- Switch on ignition.




- Press button **1** to select trip-meter **2** of your choice.

The following counters can be displayed:

- Tripmeter 1 (Trip 1)
- Tripmeter 2 (Trip 2)
- Automatic trip meter (Trip A, resets automatically eight hours after ignition OFF)

Resetting trip odometer

- Switch on ignition.
- Select desired trip odometer.



- Press and hold down button **1** until the tripmeter reading is reset.

Lights

Parking lights

The parking lights come on automatically when the ignition is switched on.



The parking lights are a strain on the battery. Do not leave the ignition switched on longer than absolutely necessary. ◀

Headlight low beam

The headlights automatically come on in their low-beam mode as soon as you start the engine.

Headlight high beam and flasher




- Press switch **1** toward front to switch on high beams.
- Pull switch **1** rearward to operate headlight flasher.

 The high-beam headlight can also be switched on when the engine is not running. ◀

Parking light

- Switch off ignition.



- Immediately after switching off the ignition push the button **1** to the left and maintain pressure until the parking lights come on.
- Switch ignition on and then off again to switch off parking lights.

Adjusting for traffic driving on right or driving on left

- with Adaptive Headlight ^{OE}
- Switch on ignition.
- Call up the Settings menu and select Vehicle - Headlight.



- R-hand traffic: for countries in which the traffic drives on the right-hand side of the road.

- L-hand traffic: for countries in which the traffic drives on the left-hand side of the road.

- Select the appropriate setting.



- ◻ appears on the display.


- » The cornering light function is not active for as long as the setting is changed.

Headlight range

The xenon headlight has continuous beam throw control that keeps beam throw constant regardless of how the motorcycle is ridden and the load it carries.

Operating auxiliary driving light

- with LED auxiliary headlights ^{OE}



- Press button **1** to switch on the auxiliary headlights.



The telltale light shows.




If this warning symbol appears it tells you that the on-board system voltage is low. If applicable, the auxiliary headlights might have been temporarily switched off.

- Press button **1** again to switch off the auxiliary headlights.

Operating ground lighting

– with ground lighting^{OA}

- Switch on ignition.
- Call up the Settings menu and select Vehicle - Ground light.



- On: Ground lighting comes on for a brief period after the ignition is switched off.
- Off: Ground lighting does not come on after the ignition is switched off.

– with central locking^{OE}

» If the function is switched off as described above, the ground lighting switches on nonetheless when you unlock the central locking system.


Turn indicators

Operating turn indicator

- Switch on ignition.



After driving for approx. ten seconds or after covering a distance of approx. 300 m, the turn indicators are automatically switched off.◀



- Press button **1** toward left to switch on left-hand turn indicator.
- Press button **1** toward right to switch on right-hand turn indicator.
- Press button **1** into center position to switch off turn indicators.


Hazard warning flashers

Operating hazard warning flashers

- Switch on ignition.

▶ The hazard warning flashers place a strain on the battery. Do not use the hazard warning flashers for longer than absolutely necessary.◀

▶ If a turn indicator button is pressed with the ignition switched on, the flashing function replaces the emergency flashing function as long as the button is pressed. If the turn indicator button is released, the emergency flasher function becomes active again.◀



- Press button **1** to switch on hazard warning flashers.

» Ignition can be switched off. To switch off the hazard warning flashers:

- Switch on the ignition and press button **1**.

Emergency ON/OFF switch



- 1** Emergency ON/OFF switch

⚠ Operating the emergency ON/OFF switch when riding can cause the rear wheel to lock and thus cause a fall.

Do not operate the emergency ON/OFF switch when riding.◀

The engine can be switched off easily and quickly using the emergency ON/OFF switch.



- a** Engine switched off
b Operating position


Heated handlebar grips

Operating heated handlebar grips

- Start engine.


 The heated hand grips option can only be activated when the engine is running.◀

- Call up the Handle heat. menu.



The grips have five-stage heating. Stage five is for heating the grips quickly: it is advisable to switch back to a lower stage as soon as the grips are warm.

- Select the heating stage you want.



Symbol **1** appears on the display, indicating that the handlebar grip heating is ON.

 If this warning symbol appears it tells you that the on-board system voltage is low. If applicable, the handlebar grip heating might have been temporarily switched off.


Seat heating

Driver's seat heater

- Start engine.


▶ Seat heating can be activated only when the engine is running.◀

- Call up the Seat heating menu.



The front seat has five-stage heating. Stage five is for heating the seat quickly: it is advisable to switch back to a lower stage as soon as the seat is warm.

- Select the heating stage you want.



Symbol **1** appears on the display, indicating that the seat heating is ON.



If this warning symbol appears it tells you that the on-board system voltage is low. If applicable, the seat heating might have been temporarily switched off.

Passenger seat heater

- Start engine.



Seat heating can be activated only when the engine is running.◀



- Select desired heating level with switch **1**.



The passenger seat can be heated at two levels. The second level is used for fast heat-up of the seat; then the switch should

be switched back to the first level.

- **2** Switch in middle position: Heating off.
- **3** Switch in one-dot position: 50 % heating output.
- **4** Switch in two-dot position: 100 % heating output.



Symbol **5** appears on the display, indicating that the rear seat heating is ON.



If this warning symbol appears it tells you that the on-board system voltage is low. If applicable, the seat heating

might have been temporarily switched off.

Dynamic Traction Control (DTC)


- with Dynamic Traction Control (DTC) ^{OE}

Switching DTC off and on

- Switch on ignition.
- Call up the Settings menu and select DTC.



This menu cannot be called up while the motorcycle is on the move. ◀



- Select **Off (once)** to switch DTC off once, in other words until the ignition is next switched on.



The DTC warning light shows to indicate that DTC has been switched off.

- Select **On** to switch on DTC. Alternatively: Switch the ignition off and then on.



The DTC warning light goes out; if self-diagnosis has not completed the DTC warning light starts flashing.

Riding mode

Setting driving mode

- Switch on ignition.



- Press button **1**.

 Details on the selectable driving modes are provided in the chapter "Technology in Detail". ◀



The current setting is shown at position **2**; each time the button is pressed one of the possible riding modes is shown at position **3**.

- Repeatedly press the button until the reading shows the riding mode you want.
 - » With the motorcycle at a standstill, the mode you select is activated after a brief delay.
 - » The new driving mode is activated while driving under the following conditions:
 - Brake not actuated


- Throttle turned all the way back
- Clutch actuated
 - » Once the new riding mode has been activated, the selection display disappears.
 - » The mode selected in this way is retained with the engine-characteristic and DTC adaptation settings even after the ignition has been switched off.

Seat

Remove seat




- Use the ignition key to unlock seat lock **1** and lift the rear of the seat.




- Disconnect plug **2** of the seat heating and remove the seat.
- Place the seat, upholstered side down, on a clean surface.

Installing seat



- Connect plug **2** of the seat heating.



- Position the seat with mounts **3** in rubber buffers **4** on left and right.

- Lower the rear of the seat and engage the seat in the latching mechanism.

Windshield

Adjusting windshield

- Switch on ignition.
- » When you pull away the windscreen automatically returns to the position it was in before the ignition was switched off.



- Press button **1** at top to raise windshield.
- Press button **1** at bottom to lower windshield.

- Switch off ignition.
- » The windscreen automatically moves to the bottom limit position.
- » If the windscreen encounters resistance before it reaches its limit position the pressure-sensitive finger guard system goes active. The windscreen is stopped and raised slightly. After a delay of a few seconds the windscreen again attempts to move to the bottom limit position.

There is no guarantee that the pressure-sensitive finger guard system will function correctly if a windscreen that does not have BMW approval is installed.

- Under these circumstances: Before switching off the ignition always check that there is nothing to obstruct movement of the windscreen.

Wind deflection wing

Adjusting slipstream deflectors



 Attempting to adjust the slipstream deflectors while the motorcycle is being ridden can lead to accidents. Do not attempt to adjust the slipstream deflectors unless the motorcycle is at a standstill. ◀

- Turn slipstream deflector **1** in or out to adjust the airflow for the rider. In this process, note the outer limit stop.

Cruise control

Switching on cruise control



- Push switch **1** to right.
- » Button **2** is operational.

Setting road speed



- Briefly press button **2** forward.

 The cruise control can be set within a speed range from 19 mph (30 km/h) to 136 mph (220 km/h).◀

SET Indicator light for cruise-control system lights up.

- » The motorcycle maintains your current cruising speed and the setting is saved.

Acceleration



- Briefly press button **2** forward.
- » Speed is increased by 0.6 mph (1 km/h) each time button is pressed.
- Press button **2** forward and hold.
- » The motorcycle accelerates steplessly.
- » If the button **2** is no longer pressed, the speed achieved is maintained and saved.

Decreasing speed



- Briefly press button **2** backward.
 - » Speed is decreased by 0.6 mph (1 km/h) each time button is pressed.
- Press button **2** back and hold.
 - » The motorcycle decelerates steplessly.
 - » If the button **2** is no longer pressed, the speed achieved is maintained and saved.

Deactivating cruise control

- Actuate brakes or clutch or throttle grip (take back throttle beyond back position) to deactivate cruise-control system.
 - » Cruise control indicator light goes out.

Resuming former cruising speed



- Briefly push button **2** back to return to the speed saved beforehand.

 Opening the throttle does not deactivate the cruise-control system. If you release the twistgrip the motorcycle will decelerate only to the cruising speed saved in memory, even though you might have intended slowing to a lower speed.◀

SET Indicator light for cruise-control system lights up.

Switching off cruise control



- Push switch **1** to left.
 - » The system is deactivated.
 - » Button **2** is locked.

Storage compartments

Use the stowage compartments



- Use the ignition key to open or close lock **1** of the left stowage compartment or lock **2** of the right stowage compartment.
- To open the lid, push the unlocked lock barrel down.

! Temperatures inside the stowage compartments can be high, particularly in summer, and it is important to remember that high temperatures might damage objects stowed in the compartments. This applies in

particular to electronic devices such as mobile phones and MP3 players.

Refer to the operating instructions of your electronic devices for possible usage restrictions.◀

- In summer, do not place heat-sensitive objects in the stowage compartments.

Clutch

Adjusting clutch lever



Changing the position of the clutch-fluid reservoir can allow air to penetrate the clutch system.

Do not turn the handlebar fitting on the handlebar.◀



Adjusting the clutch lever while driving can lead to accidents.

Only adjust the clutch lever when the motorcycle is stationary.◀



- Turn adjusting screw **1** clockwise to increase distance between clutch lever and handlebar grip.
- Turn adjusting screw **1** counterclockwise to decrease distance between clutch lever and handlebar grip.



The adjusting screw can be turned more easily if you press the clutch lever forward when doing so.◀



The anti-hopping function of the clutch can cause the clutch lever to pulsate briefly in

some situations (e.g. variation of load).◀

Brakes

Adjusting handbrake lever



Changing the position of the brake-fluid reservoir can allow air to penetrate the brake system.

Do not turn the handlebar fitting on the handlebar.◀



Adjusting the handbrake lever while driving can lead to accidents.

Only adjust the handbrake lever when the motorcycle is stationary.◀



- Turn adjusting screw **1** clockwise to increase distance between brake lever and handlebar grip.
- Turn adjusting screw **1** counterclockwise to decrease distance between brake lever and handlebar grip.



The adjusting screw can be turned more easily if you press the handbrake lever forward when doing so.◀

Shifting

Adjusting shift lever



- Slacken screw **1**.
- Turn foot piece **2** into desired position.



A foot piece adjusted too high or too low can cause problems when shifting. In case of shifting problems, check the adjustment of the foot piece.◀

- Tighten screw **1** to appropriate torque.



Eccentric, peg to shift lever

– 6 lb/ft (8 Nm)

Mirrors

Adjusting mirrors



- Move mirror into desired position by applying light pressure at edge.

Spring preload Setting

It is essential to set spring preload of the rear suspension to suit the load carried by the motorcycle. Increase spring preload when the motorcycle is heavily loaded and reduce spring preload accordingly when the motorcycle is lightly loaded.

Adjusting spring preload for rear wheel

- Make sure ground is level and firm and park motorcycle.



Adjusting the spring preload while the motorcycle is being ridden can lead to accidents. Adjust the spring preload only when the motorcycle is stationary.◀

- Pull knob **1** out for better accessibility.



Your motorcycle's handling will suffer if you do not match the spring-preload and damping-characteristic settings. Adjust the damping characteristic to suit the spring preload.◀

- To increase spring preload, turn handwheel in direction of arrow HIGH.
- To decrease spring preload, turn handwheel in direction of arrow LOW.



Basic setting of spring preload, rear

- without Electronic Suspension Adjustment (ESA)^{OE}
 - Knob turned as far as it will go in the direction indicated by the LOW arrow (Full tank of gas, with rider 187 lbs (85 kg))<
- Push the knob back in to its original position.

Damping Setting

The damping must be adjusted to the road conditions and the spring preload.

- A rough road surface requires softer damping than a smooth road surface.
- An increase in spring preload requires firmer damping, a reduction in spring preload requires softer damping.

Adjusting damping on rear wheel

- Make sure ground is level and firm and park motorcycle.



- If you want a harder damping characteristic, use the tool from the on-board toolkit to turn adjusting screw **1** in the direction indicated by the H arrow.
- If you want a softer damping characteristic, use the tool from the on-board toolkit to turn adjusting screw **1** in the direction indicated by the S arrow.



Basic setting of rear wheel rear-wheel damping

- without Electronic Suspension Adjustment (ESA)^{OE}



Basic setting of rear wheel rear-wheel damping

- Turn the adjusting screw as far as it will go in the direction indicated by the H arrow and then turn it back one and a half turns in the direction indicated by the S arrow (Full tank of gas, with rider 187 lbs (85 kg))◀


ESA Electronic Suspension Adjustment

- with Electronic Suspension Adjustment (ESA)^{OE}

Settings

Using the electronic suspension adjustment ESA you can conveniently adjust your motorcycle to its loading and the ground. This

entails selecting the load variant and the damping characteristic. You have a choice of three load variants with any of three damping characteristics selectable for each one.



The current setting appears in display field **1**.

Additional information on the electronic suspension adjustment ESA II is provided on page (▶▶ 94).

Adjusting the suspension

- Start engine.



The damping can be adjusted while the motorcycle is being ridden.◀

- Call up the ESA menu.



The possible settings for the damping characteristic appear on the display.

- **Comfort**: comfort mode
- **Normal**: normal mode
- **Sport**: sport mode
- Select the damping characteristic you want or move the

cursor down to set the vehicle load.

 The load cannot be set while the motorcycle is in motion. ◀



The possible settings for vehicle load appear on the display.



One-up



One-up with luggage



Two-up (with luggage)

- Select the vehicle load variant you want.
 - » The suspension adjusts to suit the new setting and the ESA reading changes accordingly. The symbols for vehicle load and damping characteristic are grayed while adjustment is in progress.

Central locking

– with central locking^{OE}

Lock



- Switch on the ignition and press button **3**.

- Alternatively: Press button **1** on the remote control.
 - » The two stowage compartments in the side panels, the cases and the topcase are locked.
 - » These locks cannot subsequently be unlocked manually.
-  The locked symbol appears on the display.
 - with anti-theft alarm^{OE}
 - » The functions of the remote control for the anti-theft alarm are described in the corresponding section.

Unlocking



- Switch on the ignition and press button **3**.
- Alternatively: Press button **2** on the remote control.
 - » The two stowage compartments in the side panels, the cases and the topcase are unlocked.
 - » Once a lock has been locked manually it subsequently has to be unlocked manually as well.
 - with anti-theft alarm^{OE}
 - » The functions of the remote control for the anti-theft alarm

are described in the corresponding section.

- with ground lighting^{OA}
- » The ground lighting is switched on for a brief period.

Emergency unlocking

If the central locking system refuses to unlock, you can open the cases, topcase and stowage compartments manually. The procedure is as follows:

- Removing case (➡ 103).
- Opening case (➡ 102).



- First turn the key in the topcase lock 45° past the LOCK

position, then turn it to the dot position and press in the lock barrel.

- » The release lever pops open.




- Turn the key in the stowage-compartment lock 45° out past the vertical position and press in the lock barrel.
 - » The stowage-compartment lid pops open.

Logon of remote controls

If a remote control has been mislaid and a replacement acquired or if you are going to use an additional remote control, you must

invariably log on all the remote controls in the set.


- Enable logon of the remote controls as follows:
- Switch on ignition.



- Press button **2** on the remote control three times.
 - » One acoustic signal sounds.
- Within ten seconds, switch off the ignition.
- Press button **2** on the remote control three times.
 - » One acoustic signal sounds.
- Within ten seconds, switch on the ignition.

You can now proceed to log on all the remote controls.

- Step through the following procedure with each remote control in turn:



- Press and hold down buttons **1** and **2** until LED **3** stops flashing.
 - » LED **3** flashes for about ten seconds.
- Release buttons **1** and **2**.
 - » LED **3** is illuminated.
- Press button **1** or button **2**.
 - » One acoustic signal sounds, LED **3** goes out.

To complete logon:


- Switch off ignition.
 - » Three acoustic signals sound.
 - » Logon is also ended when
 - four remote controls have been logged on.
 - if you have logged on the first remote control and then do not press a button within approximately 30 seconds.

Synchronize the remote controls

If the central locking system stops responding to the signals from a remote control, the unit in question has to be synchronized. This can happen, for example, if the buttons on the remote control were pressed too frequently while the remote control was out of range of the anti-theft alarm.

- The procedure for synchronizing the remote controls is as follows:

- Switch on ignition.




- Press and hold down buttons **1** and **2** until LED **3** stops flashing.
» LED **3** flashes for about ten seconds.
- Release buttons **1** and **2**.
» LED **3** is illuminated.
- Press button **1** or button **2**.
» LED **3** goes out.

Replacing battery of remote control

If you press a button on the remote control and the LED does not show or lights up only briefly:

- Replace the battery of the remote control.



- Open lid of battery compartment **1**.
- Dispose of the old battery in accordance with legal regulations. Do not dispose of the battery in the household waste.



Using batteries of the wrong type or inserting batteries with reversed polarity can destroy the device.

Use a battery compliant with the manufacturer's specifications. When inserting the battery, make sure that the polarity is correct.◀


- Insert the new battery with the positive terminal up.



Battery design and nominal voltage

- CR 1632 lithium
- 3 V

- » The LED on the remote control lights up; the remote control has to be synchronized.




- Press button **1** twice.
 - » LED **3** flashes for a few seconds.
 - » The remote control is ready to operate again.

Anti-theft alarm (DWA) Activation without remote control

– with anti-theft alarm^{OE}

- If applicable, switch on automatic activation of the anti-theft alarm after ignition OFF.
- Customizing anti-theft alarm settings (▮▮▮▮▶ 74).

- Switch off ignition.
 - » Activation takes approximately 30 seconds to complete.
 - » Turn signals are illuminated twice.
 - » Confirmation tone sounds twice (if programmed).
 - » Anti-theft alarm is activated.
- To deactivate the motion sensor (for example if you are about to transport the motorcycle on a train and the swaying movement of the moving train could trip the alarm), call up the Settings menu before switching off the ignition.
- Select Vehicle - Alarm syst. - Sensor.



- Select Off (once) to switch off the motion sensor this once.
- Switch off ignition.
 - » Activation takes 30 seconds to complete.
 - » Turn signals are illuminated three times.
 - » Confirmation tone sounds three times (if programmed).
 - » The anti-theft alarm is active, the motion sensor is deactivated.

Activation with remote control

- with anti-theft alarm^{OE}
- with central locking^{OE}
- Switch off ignition.



- Press button **1** on the remote control twice.



See also the other functions of the remote control for the central locking system.◀

- » Activation takes approximately 30 seconds to complete.
- » Turn signals are illuminated twice.

- » Confirmation tone sounds twice (if programmed).
- » Anti-theft alarm is activated.



- To deactivate the motion sensor (for example if you are about to transport the motorcycle on a train and the swaying movement of the moving train could trip the alarm), press button **1** on the remote control again during the activation phase.
- » Turn signals are illuminated three times.
- » Confirmation tone sounds three times (if programmed).

- » Motion sensor is deactivated.

Alarm

- with anti-theft alarm^{OE}


The alarm can be triggered by

- the motion sensor
- an attempt to use an unauthorized key to switch on the ignition
- disconnecting the alarm system from the motorcycle battery (alarm system battery takes over the power supply - alarm sound only, no illumination of the turn signals)

All functions are sustained even if the internal battery of the anti-theft alarm system is flat; the only difference is that an alarm cannot be triggered if the system is disconnected from the motorcycle's battery.

An alarm lasts for approximately 26 seconds. During the alarm, an alarm tone sounds and the turn signals flash. The type of alarm sound can be programmed.

– with central locking^{OE}



You can cancel an alarm at any time without deactivating the anti-theft alarm by pressing button **2** on the remote control.◀

If an alarm was triggered while the motorcycle was unattended, the rider is notified accordingly by an alarm tone sounding once when the ignition is switched on.

The anti-theft alarm telltale light then signals the reason for the alarm for one minute.

The meanings of the flash codes are as follows:

- Flashes 1x: Motion sensor 1
- Flashes 2x: Motion sensor 2
- Flashes 3x: Ignition switched on with unauthorized key
- Flashes 4x: Alarm system is disconnected from the motorcycle battery
- Flashes 5x: Motion sensor 3


Deactivation without remote control

– with anti-theft alarm^{OE}

- Safety cutout switch in operating position (run).
- Switch on ignition.
 - » Turn signals are illuminated once.
 - » Confirmation tone sounds once (if programmed).
 - » Anti-theft alarm is deactivated.

Deactivation with remote control

- with anti-theft alarm^{OE}
- with central locking^{OE}



- Press button **2** on the remote control once.

▶ See also the other functions of the remote control for the central locking system.◀

▶ If the alarm function is deactivated with the remote control, and if the ignition is not switched on subsequently, then the alarm function automatically becomes active again after 30


seconds when "Activation after ignition off" is programmed.◀

- » Turn signals are illuminated once.
- » Confirmation tone sounds once (if programmed).
- » Anti-theft alarm is deactivated.

Customizing anti-theft alarm settings

– with anti-theft alarm^{OE}

- Call up the Settings menu and select Vehicle - Alarm syst..



The following settings are available:

- Automatic - On: Anti-theft alarm is activated automatically when the ignition is switched off.
- Automatic - Off: Anti-theft alarm has to be activated with the remote control when the ignition is switched off.
- Alarm tone: Type of alarm tone.
- Operat. tone - On: Turn indicators flash and one tone sounds as confirmation

when the alarm is switched on or off.

- Operat. tone - Off: Turn indicators flash as only confirmation when anti-theft alarm is switched on or off.
- Make the desired adjustment using the Multi-Controller.

Tires

Checking tire pressure



Incorrect tire inflation pressure results in poorer handling characteristics of the motorcycle and reduces the life of the tires.

Ensure proper tire inflation pressure.◀

- Make sure ground is level and firm and park motorcycle.
- Check tire pressures against data below.



Tire pressure, front

– 42.1 psi (2.9 bar) (With tire cold)



Tire pressure, rear

– 42.1 psi (2.9 bar) (With tire cold)

If tire pressure is too low:

- Correct tire pressure.

Riding

Safety instructions	78
Checklist.....	79
Starting	80
Breaking in.....	82
Brakes	83
Parking your motorcycle	84
Refueling	84
Securing motorcycle for transport	86

Safety instructions

Rider's equipment

Do not ride without the correct clothing. Always wear:

- Helmet
- Rider's suit
- Gloves
- Boots

This applies even to short journeys, and to every season of the year. Your authorized BMW Motorrad retailer will be happy to advise you and has the correct clothing for every purpose.

Correct loading



Overloading and uneven loading can diminish the riding stability of the motorcycle. Do not exceed the gross weight limit and observe the loading information. ◀

- Adjust spring preload, suspension damping rate settings and

tire inflation pressures for the current gross vehicle weight.

- Make sure that weight is uniformly distributed between right and left.
- Pack heavy luggage and cargo as low and as close to the center of the motorcycle as possible.
- Observe maximum payload and top speed as indicated on label in case.
- Observe maximum payload and top speed as indicated on label in Topcase.

Speed

If you ride at high speed, always bear in mind that various boundary conditions can adversely affect the handling of your motorcycle:

- Settings of spring-strut and shock absorber system
- Imbalanced load
- Loose clothing

- Insufficient tire inflation pressure
- Poor tire tread
- Etc.

Risk of poisoning

Exhaust fumes contain carbon monoxide, which is colorless and odorless but highly toxic.



Inhaling exhaust fumes therefore represents a health hazard and can even cause loss of consciousness with fatal consequences.

Do not inhale exhaust fumes.

Do not run the engine in closed rooms. ◀

Risk of burn injury



Engine and exhaust system become very hot when the motorcycle is in use. There is a risk of burn injuries by contact with hot surfaces, particularly at the silencer.

When you park the motorcycle

make sure that no-one comes into contact with the engine and exhaust system.◀

Catalytic converter

If misfiring causes unburned fuel to enter the catalytic converter, there is a danger of overheating and damage.

For this reason, observe the following points:

- Do not run the fuel tank dry
- Do not run the engine with the spark-plug cap removed
- Stop the engine immediately if it misfires
- Use unleaded fuel only
- Comply with all specified maintenance intervals.



Unburned fuel will destroy the catalytic converter.

Note the points listed for protection of the catalytic converter.◀

Danger of overheating



Cooling would be inadequate if the engine were allowed to idle for a lengthy period with the motorcycle at a standstill: overheating would result. In extreme cases, the motorcycle could catch fire.

Do not allow the engine to idle unnecessarily. After starting, ride off immediately.◀

Manipulation



Modifications of the motorcycle (e.g. engine management system, throttle valves, clutch) can cause damage to the affected components and failure of safety-related functions.

Damage caused in this way is not covered by the warranty. Do not make any modifications.◀

Checklist

Use the following checklist to check important functions, settings and wear limits before you ride off:

- Brakes
- Front and rear brake fluid levels
- Clutch
- Clutch fluid level
- Shock absorber setting and spring preload
- Tread depth and tire inflation pressure
- Firm seating of cases and luggage

At regular intervals:

- Engine oil level (every time you refuel)
- Brake pad wear (during every third stop for refueling)

Starting

Starting the engine

- Switch on ignition.
 - » Pre-ride check is performed. (➡ 80)
 - » ABS self-diagnosis in progress. (➡ 81)
 - with Dynamic Traction Control (DTC) ^{OE}
 - » DTC self-diagnosis is performed. (➡ 81)
- Engage neutral, or pull back clutch lever if a gear is engaged.

 You cannot start the motorcycle with the side stand extended and a gear engaged. The engine will switch itself off if it is started with the transmission in neutral and then a gear is engaged before retracting the side stand.◀

- For cold starts and at low ambient temperatures: pull the lever to disengage the clutch

and twist the throttle grip slightly.



- Press starter button **1**.

 The start attempt is automatically interrupted if battery voltage is too low. Recharge the battery before you start the engine, or use jump leads and a donor battery to start.◀

- » Engine starts.
- » Consult the troubleshooting chart if the engine refuses to start. (➡ 140)

Pre-ride check

The instrument cluster runs a test of the 'General' warning light when the ignition is switched on: this is the "Pre-Ride-Check". The test is aborted if you start the engine before it completes.

Phase 1



General warning light shows red.

– CHECK ! is indicated.

Phase 2



General warning light shows yellow.

– CHECK ! is indicated.



The SET light comes on.

If the 'General' warning light does not show:



Some malfunctions cannot be indicated if the 'Gener-

al' warning light cannot be displayed.

Check that the 'General' warning light comes on, and that it shows red and yellow.◀

- Have the malfunction corrected as soon as possible by a specialized workshop, preferably an authorized BMW Motorrad retailer.

ABS self-diagnosis

The self-diagnosis routine is determining whether the BMW Motorrad Integral ABS is ready for operation. The self-diagnosis routine launches automatically when you switch on the ignition.

Phase 1

- » Check on system components monitored by diagnostic system while vehicle is parked.



ABS warning light flashes.

Phase 2

- » Checking wheel sensors while starting off. The motorcycle must reach a speed of at least 3 mph (5 km/h) before the ABS self-diagnosis routine can be completed.



ABS warning light flashes.

ABS self-diagnosis completed

- » The ABS warning lamp goes out.

If an ABS error is indicated following completion of the ABS self-diagnosis routine:

- It remains possible to continue riding. Bear in mind that neither the ABS function nor the integral braking function is available.
- Have the malfunction corrected as soon as possible at a specialist service facility, preferably

an authorized BMW Motorrad retailer.

DTC self-diagnosis

- with Dynamic Traction Control (DTC) ^{OE}

The readiness for operation of the BMW Motorrad DTC is checked by the self-diagnosis. Self-diagnosis is performed automatically when you switch on the ignition.

Phase 1

- » Checking the diagnosable system components while stopped.



DTC warning light flashes slowly.

Phase 2

- » Checking the diagnosable system components while driving. The engine must be running and the motorcycle must reach a speed of at

least 3 mph (5 km/h) in order for DTC self-diagnosis to complete.



DTC warning light flashes slowly.

DTC self-diagnosis completed

» The DTC symbol is no longer displayed.

If a DTC error is indicated after the DTC self-diagnosis is completed:

- Continued driving is possible. It must be noted that the DTC function is not available.
- Have the malfunction corrected as soon as possible by a specialized workshop, preferably an authorized BMW Motorrad retailer.

Breaking in Engine

- While running in the motorcycle, vary the throttle opening and engine-speed range frequently; avoid driving for long periods at a constant speed.
- Try to do most of your riding during this initial period on twisting, fairly hilly roads, avoiding highways if possible.
- Observe the engine run-in speeds.



Engine run-in speed

- <5000 min⁻¹ (Odometer reading 0...186 miles (0...300 km))
- <6000 min⁻¹ (Odometer reading 186...621 miles (300...1000 km))



Engine run-in speed

- no full throttle (Odometer reading 0...621 miles (0...1000 km))

- Have the first inspection carried out after 300 - 750 mls (500 - 1,200 km).

Brake pads

New brake pads must be run in before they achieve their optimum friction force. This initial reduction in braking efficiency can be compensated for by exerting greater pressure on the brake levers.



New brake pads can extend stopping distance by a significant margin.

Brake early. ◀

Tires

New tires have a smooth surface. This must be roughened by riding in a restrained manner at various heel angles until the tires are run in. This running in procedure is essential if the tires are to achieve maximum grip.



New tires have not achieved their full adhesion yet. There is a danger of accidents when driving at extreme angles.

Avoid extreme angles.◀

Brakes

How do you achieve the shortest stopping distances?

The dynamic load distribution between the front and rear wheel changes during braking. The heavier you brake, the greater the weight transfer to the front wheel. Increases in the load at

an individual wheel are accompanied by a rise in the effective braking force that the wheel can provide.

To achieve the shortest possible braking distance, the front brake must be applied quickly and with increasing force. This procedure provides ideal exploitation of the extra weight transfer to the front wheel. The clutch should also be disengaged at the same time.

With the "forced braking" often practiced in which the brake pressure is generated as quickly as possible and with great force, the dynamic load distribution cannot follow the increased deceleration and the braking force cannot be completely transferred to the road surface.

BMW Motorrad Integral ABS prevents the front wheel from locking.

Descending mountain passes



There is a danger of the brakes fading if you use only the rear brakes when descending mountain passes. Under extreme conditions, the brakes could overheat and suffer severe damage.

The BMW integrated braking function ensures that the rear wheel brake is also applied when the handbrake lever is actuated, thus providing protection against overheating. Simply apply the front wheel brake and use the engine brake.◀

Wet, soiled brakes

Moisture and dirt on the brake disks and the brake pads result in a decrease in the braking action. Delayed or poorer braking action must be expected in the following situations:

- When driving in the rain and through puddles.
- After washing the motorcycle.
- When driving on roads spread with salt.
- After working on the brakes due to oil or grease residues.
- When driving on soiled roads or offroad.



Poor braking action due to moisture and dirt.

Brake until brakes are dry or clean; clean if necessary. Brake early until the full braking action is available again.◀

Parking your motorcycle

Side stand

- Switch off engine.



If the ground is soft or uneven, there is no guarantee that the motorcycle will rest firmly on the stand.

Always check that the ground under the stand is level and firm.◀

- Fold out side stand and park motorcycle.



The side stand is designed to support only the weight of the motorcycle.

Do not lean or sit on the motorcycle with the side stand extended.◀

- If the slope of the road permits, turn the handlebars to the left.
- On a grade, the motorcycle should always face uphill; select 1st gear.

Center stand

- Switch off engine.



If the ground is soft or uneven, there is no guarantee that the motorcycle will rest firmly on the stand.

Always check that the ground

under the stand is level and firm.◀



Excessive movements could result in the center stand retracting, and the motorcycle would topple as a result.

Do not sit on the motorcycle while it is resting on the center stand.◀

- Fold out center stand and jack up motorcycle.

Refueling



Fuel is highly flammable. Fire at the fuel tank can result in fire and explosion.


Do not smoke. Never bring a naked flame near the fuel tank.◀



Fuel attacks plastic surfaces, making them cloudy or unattractive.

Wipe off any fuel that gets onto plastic parts immediately.◀

- Make sure ground is level and firm and park motorcycle.
- Open protective cap.



- Unlock cap of fuel tank with ignition key and fold up.



! Fuel expands when exposed to heat. When the tank is overfilled, fuel can escape and get onto the road. This results in a danger of falling. Do not overfill the fuel tank.◀

! Leaded fuel will destroy the catalytic converter. Use only unleaded fuel.◀

- Refuel with quality listed below at most until lower edge of filler neck is reached.

▶ When refueling after running on reserve, make sure that you top up the tank to a level above reserve, as other-

wise the sensor will not be able to register the new level and the fuel warning lamp will not be switched off.◀

 Recommended fuel quality

- Super unleaded (E10)
- 89 AKI (95 ROZ/RON)
- 89 AKI

 Usable fuel quantity

- Approx. 7 gal (Approx. 26.5 l)

 Reserve fuel quantity

- Approx. 1.1 gal (Approx. 4 l)

- Press fuel tank cap down firmly to close.
- Remove key and close protective cap.

Securing motorcycle for transport

- Protect all component surfaces against which straps are routed against scratching. For example, use adhesive tape or soft cloths.



The motorcycle can tip away to the side and fall over.

Secure the motorcycle against tipping away to the side.◀

- Push motorcycle onto transport surface, and do not place on side stand or center stand.



The ball joint and the brake lines can suffer damage.

Take care not to damage components.◀

- Pass the straps on left and right through the suspension and strap the motorcycle down.



- Secure straps at rear on both sides on rear frame and tension.
- Do not pull the straps over the footrests.
- Uniformly tighten all the straps.

Technology in detail

Riding mode	88
Brake system with BMW Motorrad Integral ABS	89
Engine management with BMW Motorrad DTC	92
Tire Pressure Control TPC/RDC	93
ESA II Electronic Suspension Adjust- ment	94

Riding mode

Selection

Three riding modes enable the motorcycle's characteristics to adapt to the prevailing weather conditions, the road and traffic, and the rider's style of riding:

- RAIN
- ROAD
- DYNAMIC

Each driving mode affects the behavior of the motorcycle in a different way. DTC can be switched off in each mode; the explanations below invariably refer to conditions with the system switched ON. The last selected driving mode is reactivated automatically after the ignition is switched off and on again.

The following always applies: The sportier the selected mode, the more directly the engine output can be utilized. At the same time, the level of rider assistance

that the DTC system offers decreases accordingly.

Therefore, consider the following when selecting the driving mode: The sportier the setting, the more demanding the requirements for the driving skill of the rider are!

RAIN

The engine output is only partially available. Power increase when you open the throttle is reserved, engine response is correspondingly soft.

The DTC system intervenes early enough to prevent the rear wheel from spinning. On road surfaces with high to medium grip (dry and wet asphalt to dry cobblestones) the motorcycle remains very stable; movements of the tail are clearly perceptible only on slippery road surfaces (wet bitumen or wet cobblestones).

ROAD

In this mode the full engine output is available. Power increase when you open the throttle is more direct than in RAIN mode, the engine responds more rapidly.

DTC system intervention is later than in RAIN mode. On road surfaces with high to medium grip (dry and wet asphalt to dry cobblestones) the motorcycle remains stable. Slight rear-wheel drift is perceptible. Movements of the tail are clearly perceptible on slippery road surfaces (wet bitumen or wet cobblestones).

DYNAMIC

The DYNAMIC mode is the sportiest mode. Power increase and engine response are the same as in ROAD mode. However, the driver's request is implemented much more directly.

DTC system intervention is even later, which means that even on dry asphalt drifting is possible under sharp acceleration when cornering.

Switchover

A mode change involving functions in the engine management system and the DTC system is possible only when drive torque is not applied to the rear wheel.

To obtain this state,

- the motorcycle must be stopped with the ignition switched on,
- or
- the throttle must be turned back,
- the clutch must be actuated.

First the desired driving mode is preselected. The switchover does not take place until the

affected systems are in the required state.

The selection menu does not disappear in the display until the driving mode has been switched over.

Brake system with BMW Motorrad Integral ABS

Partially integral brake

Your motorcycle is equipped with a partially integral brake configuration. Both front and rear brakes are applied simultaneously when you pull the handbrake lever.

The footbrake lever acts only on the rear brake.

The BMW Motorrad Integral ABS adapts the braking force distribution between the front and rear wheel brake to the loading of the motorcycle during braking.



Spinning of the rear wheel with the front brake pulled (burn out) is made considerably more difficult by the integral function. The result may be damage to the rear wheel brake and the clutch.

Avoid burn-outs.◀

How does ABS work?

The maximum braking force that can be transferred to the road surface is partially dependent on the friction coefficient of the road surface. Gravel, ice, snow and wet roads offer a considerably poorer friction coefficient than a dry, clean asphalt surface. The poorer the friction coefficient of the road surface is, the longer the braking distance will be. If the maximum transferrable braking force is exceeded when the driver increases the brake pressure, the wheels begin to lock and driving stability is lost,

and a fall can result. Before this situation occurs, ABS intervenes and adjusts the brake pressure to the maximum transferrable braking force. This enables the wheels to continue to turn and maintains driving stability regardless of the road surface condition.

What happens when rough roads are encountered?

Bumpy or rough roads can briefly lead to a loss of contact between the tires and the road surface, until the transferrable braking force is reduced to zero. If braking is carried out in this situation, ABS must reduce the brake pressure to ensure driving stability when restoring contact to the road. At this point in time, the BMW Motorrad Integral ABS must assume extremely low friction coefficients (gravel, ice,

snow) so that the running wheels turn in every imaginable case and the driving stability is ensured. After detecting the actual conditions, the system adjusts the optimum brake pressure.

How is the BMW Motorrad Integral ABS noticeable to the rider?

If the ABS system must reduce the braking forces due to the conditions described above, then vibrations can be felt at the handbrake lever.

If the handbrake lever is pulled, then braking pressure is built up at the rear wheel with the integral function. If the footbrake pedal is first actuated after this, the brake pressure already built up can be felt earlier than the counter-pressure, than when the footbrake pedal is actuated before or together with the handbrake lever.

Lifting off rear wheel

Even during severe braking, a high level of tire grip can mean that the front wheel does not lock up until very late, if at all. Consequently, ABS does not intervene until very late, if at all. Under these circumstances the rear wheel can lift off the ground, and the outcome can be a high-siding situation in which the motorcycle can flip over.



Heavy braking can lead to the rear wheel lifting off the ground.

When braking, bear in mind that the ABS control cannot be relied on in all circumstances to prevent the rear wheel from lifting off the ground.◀

What are the design characteristics of the BMW Motorrad Integral ABS?

The BMW Motorrad Integral ABS ensures driving stability on any surface within the limits of driving physics. The system is not optimized for special requirements resulting under extreme weather conditions offroad or on the race-track.

Special situations

To detect the tendency of the wheels to lock up, the speeds of the front and rear wheel are compared. If implausible values are detected over a longer period of time, the ABS function is deactivated for safety reasons and an ABS fault is indicated. The condition for a fault message is the completed self-diagnosis. In addition to problems on the BMW Motorrad Integral ABS,

unusual driving conditions can also lead to a fault message.

Unusual driving conditions:

- Heating up on the main or auxiliary stand at idle or with gear engaged.
- Rear wheel locked by the engine brake for a lengthy period, for example while descending on a loose surface.

Should a fault message result due to one of the driving conditions described above, the ABS function can be reactivated by switching the ignition off and then on again.

How important is regular maintenance?



Any technical system is always only as good as its maintenance condition.

To ensure that the BMW Motorrad Integral ABS is in an optimally maintained condition, it is

vital that the specified inspection intervals be complied with. ◀

Reserves for safety

But remember: the potentially shorter braking distances which BMW Motorrad Integral ABS permits must not be used as an excuse for careless riding. ABS is primarily a means of ensuring a safety margin in genuine emergencies.

Take care when cornering. When you apply the brakes on a corner, the motorcycle's weight and momentum take over and even BMW Motorrad Integral ABS is unable to counteract their effects.

Engine management with BMW Motorrad DTC

- with Dynamic Traction Control (DTC) ^{OE}

How does DTC work?

The BMW Motorrad DTC compares the wheel speeds of the front and rear wheel. From the speed difference the slip, and with it the stability reserves on the rear wheel are determined. When a slip limit is exceeded, the engine torque is adapted by the engine management system.



Even with DTC, the laws of physics cannot be overridden. The driver is always responsible for adapting his/her driving style.

Do not reduce the additional safety provided with risky driving.◀

What is the design baseline for BMW Motorrad DTC?

BMW Motorrad DTC is designed as an assistant system for the rider and for use on public roads. The extent to which the rider affects DTC control can be considerable (weight shifts when cornering, items of luggage loose on the motorcycle), especially when style of riding takes rider and machine close to the limits imposed by physics.

The system is not optimized for special requirements resulting under extreme weather conditions offroad or on the racetrack. You have the option of deactivating the BMW Motorrad DTC system for these circumstances.



Even with DTC, the laws of physics cannot be overridden. The driver is always respon-

sible for adapting his/her driving style.

Do not reduce the additional safety provided with risky driving.◀

Special situations

At an increasing angle, the acceleration performance is increasingly limited in accordance with physical laws. This can result in reduced acceleration when coming out of very tight curves.

To detect spinning or slipping away of the rear wheel, the speeds of the front and rear wheel are compared and the angle is considered, for example. If these values are detected to be implausible for a long period, a replacement value is used for the angle and the DTC function is deactivated. In these cases, a DTC error is displayed. The

condition for a fault message is the completed self-diagnosis. The BMW Motorrad DTC can issue an error message under the exceptional riding conditions outlined below.

Unusual driving conditions:

- Driving on the rear wheel (wheelie) for a longer period with DTC deactivated.
- Rear wheel spinning in place with front brake pulled (burn out).
- Heating up on an auxiliary stand at idle or with gear engaged.

If the front wheel loses contact to the ground during extreme acceleration, the DTC reduces the engine torque until the front wheel touches the ground again. In this case, BMW Motorrad recommends turning back the throttle twist grip somewhat to

achieve a stable driving state again as quickly as possible.

On a slippery surface, the throttle grip should never be suddenly turned back completely without pull the clutch at the same time. The engine braking torque can cause the rear wheel to slip, resulting in an unstable driving state. This case cannot be controlled by the BMW Motorrad DTC.

Tire Pressure Control TPC/RDC

- with Tire Pressure Control (TPC/RDC)^{OE}

Function

A sensor is located in each tire, which measures the air temperature and the inflation pressure inside the tire and sends these values to the control unit.

The sensors are equipped with a switch, which does not enable the transmission of the measured values until a speed of approx. 19 mph (30 km/h) is reached. The display shows "--" for each tire until the tire-pressure signal is received for the first time. The sensors continue to transmit the measured values for approx. 15 minutes after the motorcycle comes to a stop. If a TPC/RDC control unit is installed, however the wheels have no sensors, then an error message is output.

Temperature compensation

The tire inflation pressure is temperature dependent, i.e. it increases or decreases together with the tire temperature. The tire temperature is dependent on the ambient temperature and on the driving style and duration.

The tire inflation pressures are shown temperature-compensated in the multifunction display; they refer to a tire temperature of 68 °F (20 °C). No temperature compensation takes place in the inflation pressure testers at filling stations, i.e. the measured tire inflation pressure is dependent on the tire temperature. As a result, the values displayed there do not match the values shown in the multifunction display in most cases. The warmer the tire, the higher the gauge reading by comparison with the reading shown on the display.

Adjusting inflation pressure

Compare the TPC/RDC value in the multifunction display with the value on the back cover of the Rider's Manual. The difference between the two values must be

compensated with the air pressure tester at the filling station.

Example: According to the Rider's Manual, the tire inflation pressure is to be 42 psi (2.9 bar), however 39 psi (2.7 bar) is shown in the multifunction display. The tester at the filling station indicates 36 psi (2.5 bar). This value must be increased by 3 psi (0.2 bar) to 39 psi (2.7 bar) in order to produce the correct tire inflation pressure.

ESA II Electronic Suspension Adjustment

– with Electronic Suspension Adjustment (ESA)^{OE}

Chassis adjustments

The proper loading state must first be selected when the motorcycle is stationary according to the motorcycle's load. Depending on the riding mode selected, the damping levels are set on both spring struts and the spring base and spring rate are set on the rear spring strut. If the selected riding mode is changed, the spring rate on the rear spring strut is also adjusted in addition to the damping of both spring struts. This enables very precise adjustment of the chassis to all riding conditions, including while riding.

- The combination of spring base, damping and spring rate ensures the chassis geometry is always appropriate.
- The static normal position is virtually maintained while riding.
- The different riding and loading conditions are offset so that

the handling of the motorcycle remains constant.

It is possible to electrically change the spring rate through the combination of a conventional coil spring with a plastic element (Elastogran), the lateral expansion of which can be electrohydraulically limited using a displaceable sleeve. The more the sleeve surrounds the plastic element, the more its expansion is limited and the spring rate increases. The highest spring rate is achieved when the sleeve completely encloses the plastic element and sits on the steel spring. Accordingly, the spring rate is lower, the less the sleeve limits the expansion of the plastic element.

Accessories

General instructions.....	98
Onboard sockets	98
Navigation device	99
Case	102
Topcase	104

General instructions

BMW Motorrad recommends the use of parts and accessories for your motorcycle that are approved by BMW for this purpose. Your authorized BMW Motorrad retailer is the right place to go for genuine BMW parts and accessories, other BMW approved products, and expert advice on their installation and use.

These parts and products have been tested by BMW for safety, function and suitability. BMW accepts product liability for these products.

Conversely, BMW is unable to accept any liability whatsoever for parts and accessories which it has not approved.

Observe the information on the importance of tire sizes for chassis control systems (► 118).



BMW Motorrad cannot examine or test each product of outside origin to ensure that it can be used on or in connection with BMW motorcycles without constituting a safety hazard. Nor is this guarantee provided when the official approval of a specific country has been granted. Tests conducted by these instances cannot make provision for all operating conditions experienced by BMW motorcycles and, consequently, they are not sufficient in some circumstances.

Use only parts and accessories approved by BMW for your motorcycle. ◀

Whenever you are planning modifications, comply with all the legal requirements. The motorcycle must not infringe on national road-vehicle construction and use regulations of your country.

Onboard sockets

Information on using onboard sockets:

automatic switch-off



If this warning symbol appears it tells you that the on-board system voltage is low. The on-board sockets might be temporarily switched off.

The on-board sockets are also switched off when the engine is being cranked by the starter and if maximum load capability as stated in the technical data is exceeded.

If several onboard sockets are being operated, the total current may not exceed the maximum loadability.

Operating electrical accessories

You can start using electrical accessories connected to an on-board socket only when the ignition is switched on. If you subsequently switch off the ignition the sockets are also switched off if the power drain caused by their electrical consumers is high. If the power drain is low the sockets remain operational for a certain period of time before being switched off.

Cable routing

The cables from the onboard sockets to the auxiliary devices must be routed in such a way that they:

- Do not impede the rider
- Do not restrict the steering angle and the driving characteristics
- Cannot be trapped

Navigation device

– with navigation system^{OA}

Installing navigation device


- Switch on ignition.



- Press button **1** to open the slot for the navigation device.
 - » Slot cover pops open, wind-screen moves to top limit position.
- Pull slot cover up as far as it will go.
- From behind, push out cap **2**.



- Operate latch **3** and remove cover **4**.




- Initially insert the navigation device into mount **5**, then press it into latching mechanism **6**.

- Check that the navigation device is secure in the cradle.
- Press cover **7** to push cradle with navigation device into the slot until it snaps into position.

Removing navigation device

- Switch on ignition.



- Press button **1** to open the slot for the navigation device.
- » Slot cover pops open, wind-screen moves to top limit position.

- Pull slot cover up as far as it will go.



- Operate latch **3**, pull the navigation device forward out of holder **6** and lift it up and out.




- Install cover **4**.
- Press cover **7** to push the cradle into the slot until it snaps into position.



- Insert cap **2**.

Operating navigation device

- If applicable, switch on the navigation device.
- Call up the **Navigation** menu.



The options for using the navigation device appear on the display.

- **Page:** You can page from view to view; the choices are main menu, map and on-board computer.
- **Zoom +:** Performs functions marked with a plus sign + in the navigation system. In the

map view, for instance, the view zooms in on the map detail.

- **Zoom -:** Performs functions marked with a minus sign - in the navigation system. In the map view, for instance, the view zooms out from the map detail.
- **Speak:** The last navigation announcement is spoken again. The announcement is spoken again even if automatic spoken announcements have been switched off in the settings of the navigation system.
- **Mute:** Automatic spoken announcements are toggled off and on.
- **Display Off:** The display of the navigation device is toggled off and on.
- Select the function you want and implement the function by pushing the Multi-Controller to the right.

Special functions

Integration of the BMW Motorrad Navigator IV into the K 1600 GT/L series has produced a number of deviations from the descriptions in the user guide for the Navigator.

Traffic channel (TMC)

If the motorcycle is fitted with an audio system, the audio system sends the traffic announcements to the Navigator. The symbol described in the user guide for the Navigator appears on the display. It is not possible to receive traffic announcements from subscription services via the BMW Motorrad audio system.

Reserve fuel level warning

The settings for the fuel gauge enable you to define a distance that is covered per tankful of fuel. The motorcycle sends the figure for residual range possible

with the fuel remaining in the fuel tank to the Navigator, so it is no longer necessary to enter this value.

Time and date

The Navigator sends time and date to the motorcycle. Acceptance of these data for the readings on the instrument panel has to be activated in the user settings for the motorcycle.

Security settings

The BMW Motorrad Navigator IV can be secured against unauthorized use with a four-digit PIN (Garmin Lock). If this function is activated, while the Navigator is cradled on the motorcycle and the ignition is switched on you are prompted to add the motorcycle to the list of secured vehicles. If you answer "Yes" at this prompt the Navigator saves the

VIN of this vehicle in its internal memory.

A maximum of five VINs can be saved in this way.

Subsequently, the PIN does not have to be entered when the Navigator is switched on by ignition ON while cradled in any of these vehicles.

If the Navigator is removed from the vehicle while switched on, a security prompt asking for the PIN to be entered is issued.

Screen brightness

Screen brightness is adjusted by the motorcycle while the unit is cradled. There is no provision for manual input.


Case

Opening case

- with central locking^{OE}
- If applicable, open the central locking.<



- Turn the key to the in the case lock to the position indicated by the dot.



- Press lock barrel **1** downward.
» Unlocking lever **2** pops up.

- Pull the release lever all the way up and open the lid of the case.

Close case



- Pull release lever **2** all the way up.
- Close case lid and press down. Ensure that no luggage is trapped between lid and case.

▶ The case can also be closed when the lock is in the LOCK position. In this case, it should be ensured that the ignition key is not in the case.◀

- Push release lever **2** down, continuing until it engages.
- Turn key in case lock into LOCK position and remove.

Removing case



- Turn key in case lock to RELEASE position.
 - » Handle pops out.



- Pull carry handle **3** up as far as it will go.
 - » Case is released and can be removed.

Mounting case

- Pull up handle as far as possible.



- Insert case in brackets **4**.



- Press handle **3** down until it engages.
- Turn key in case lock into LOCK position and remove.


Topcase

Opening the Topcase

- with central locking^{OE}
- If applicable, open the central locking.<



- Turn the key to the in the topcase lock to the position indicated by the dot.



- Press lock barrel **1** forward.
» Release lever **2** pops up.
- Pull the release lever all the way up and open the lid of the topcase.

Closing the Topcase




- Pull release lever **2** all the way up.
- Close Topcase lid and hold it down. Ensure that no luggage is trapped between lid and case.
- Push release lever **2** down, continuing until it engages.
- Turn key in Topcase lock into LOCK position then extract it.

Removing Topcase



- Use the ignition key to unlock seat lock **1** and lift the rear of the seat.




- Disconnect plug **2** of the seat heating and remove the seat.

- Place the seat, upholstered side down, on a clean surface.
- Switch off ignition.



- Disconnect plug connection **1**.
- Work the topcase-end plug through to the rear.
- Opening the Topcase (➡ 104).
- If applicable, empty the topcase and lift out the bottom mat.



- Push slide latch **2** toward the outside and hold it in this position.
- Turn rotary latch **3** clockwise as far as it will go.
 - » Release warning **4** is visible.
- Closing the Topcase (➡ 105).




- Lift off Topcase at rear and pull off luggage rack.

Mounting Topcase

- If applicable, empty the topcase and lift out the bottom mat.



- Set the topcase on the luggage carrier.
- Opening the Topcase (➡ 104).




- Turn rotary latch **3** counter-clockwise as far as it will go,

while pressing down on the back edge of the topcase.


» Release warning **4** is no longer visible.

If the release warning is still visible the topcase is not correctly secured.


- Do not attempt to set the motorcycle in motion. Make sure that the topcase is correctly seated on the luggage carrier.




- Route the connecting cable forward in cable guide **5**.



- Work the cable into position at positions **6**.
- Close plug connection **1**.



- Connect plug **2** of the seat heating.



- Position the seat with mounts **3** in rubber buffers **4** on left and right.
- Lower the rear of the seat and engage the seat in the latching mechanism.

Maintenance

General instructions.....	110
Standard tool kit	110
Engine oil	110
Brake system	112
Coolant	116
Clutch	117
Rims and tires	117
Wheels	118
Front wheel stand	124
Jump-starting.....	126
Lamps	126
Battery.....	129
Fuses	132


General instructions

The 'Maintenance' chapter describes work involving the checking and replacement of wear parts that can be performed with a minimum of effort.

If special tightening torques are to be taken into account for assembly, these are listed. An overview of all required tightening torques is contained in the chapter "Technical Data". Information on additional maintenance and repair work is provided in the Repair Manual for your motorcycle on DVD, which you can obtain from your authorized BMW Motorrad retailer.

Special tools and thorough specialized knowledge are required to carry out some of the work described here. If you are in doubt, consult a certified workshop, preferably your authorized BMW Motorrad retailer.

Standard tool kit



- 1 Screwdriver handle
- 2 Reversible screwdriver insert with Phillips and Torx T25 blade
 - Adjusting damping on rear wheel (➡ 65).

- 3 Torx wrench, T25/T30
 - T25 on short end, T30 on long end
 - Replacing high-beam bulb (➡ 126).
 - Adjusting shift lever (➡ 63).
 - Removing license-plate carrier.

Engine oil

Checking engine oil level

 The engine can seize if the oil level is low, and this can lead to accidents. Always make sure that the oil level is correct. ◀

 The oil level varies with the temperature of the oil. The higher the temperature, the higher the level of oil in the sump. Checking the oil level with the engine cold or after a short trip leads to misinterpretations


and therefore to incorrect oil fill quantities.

To ensure that the display of the engine oil level is correct, only check the oil level after a longer trip.◀

- Make sure ground is level and firm and place motorcycle at operating temperature on its center stand.
- Allow engine to idle until fan starts up, then allow to continue running for an additional minute.
- Switch off the engine and wait for about one minute to allow the oil to drain into the sump.
- Wipe area around oil fill location clean.



- Remove oil dipstick **1** and wipe it with a clean, dry cloth.
- Position oil dipstick on oil fill location, but do not screw in.
- Remove oil dipstick and read off oil level.



Specified level of engine oil

– between MIN and MAX marking (Engine at operating temperature)

If oil level is below MIN mark:

- Topping up engine oil (➡ 112).

If oil level is above MAX mark:

- Have oil level corrected by a specialized workshop, preferably an authorized BMW Motorrad retailer.
- Install oil dipstick.

Topping up engine oil

- Make sure ground is level and firm and park motorcycle.
- Wipe area around fill location clean.



- Remove oil dipstick **1**.



Both too little and too much engine oil can lead to engine damage. Always make sure that the oil level is correct.◀

- Add engine oil up to specified level.
- Checking engine oil level (▶▶▶ 110).

- Install oil dipstick.

Brake system

Checking brake operation

- Pull handbrake lever.
 - » Pressure point must be clearly perceptible.
- Press footbrake lever.
 - » Pressure point must be clearly perceptible.

If no clear pressure points are perceptible:



Incorrect working practices endanger the reliability of the brakes.

Have all work on the brake system carried out by specialists.◀


- Have the brakes checked by a certified workshop, preferably an authorized BMW Motorrad retailer.

Checking front brake pad thickness

- Make sure ground is level and firm and park motorcycle.



- Visually inspect left and right brake pads to ascertain their thickness. Viewing direction: between wheel and front suspension toward brake pads **1**.



Front brake-pad wear limit


- min 0.04 in (min 1.0 mm)
(Only friction material without carrier plate. Wear markings (grooves) must be clearly visible.)

In order to ensure the operating reliability of the brake system, make sure that the brake pads are not worn beyond their minimum thickness. ◀

- Have the brake pads replaced by a specialized workshop, preferably an authorized BMW Motorrad retailer.

Checking rear brake pad thickness

- Make sure ground is level and firm and park motorcycle.




- Check the brake pad thickness with visual inspection. Viewing direction: from below toward brake pads **1**.

If the wear indicating marks are no longer clearly visible:



Dropping below the minimum pad thickness leads to reduced braking performance and may result in damage to the brakes.



Rear brake-pad wear limit

- min 0.04 in (min 1.0 mm)
(Only friction material without carrier plate. Do not permit wear to progress to the point at which the wear indicators (grooves) are reached.)

If the wear indicating mark is no longer visible:



Dropping below the minimum pad thickness leads to reduced braking performance

and may result in damage to the brakes.

In order to ensure the operating reliability of the brake system, make sure that the brake pads are not worn beyond their minimum thickness. ◀

- Have the brake pads replaced by a specialized workshop, preferably an authorized BMW Motorrad retailer.

Checking front brake fluid level



A low fluid level in the brake reservoir can allow air to penetrate the brake system. This significantly reduces braking efficiency.

Check brake fluid level regularly. ◀

- Make sure ground is level and firm and place motorcycle on its center stand.



- Read off brake fluid level at front brake-fluid reservoir **1**.



The brake fluid level in the brake-fluid reservoir drops due to brake pad wear. The decreasing fluid level is compensated with an easy-to-see black rubber bellows. ◀



Front brake fluid level

– Brake fluid, DOT4

- The brake fluid level must not fall below the MIN mark. (Brake fluid reservoir horizontal, motorcycle standing upright and handlebars straight ahead)

If brake fluid level drops below permissible level:

- Have the defect corrected as soon as possible by a specialized workshop, preferably an

authorized BMW Motorrad retailer.

If the lower edge of the black bellows in the brake-fluid reservoir is below the MAX marking:

- Checking front brake pad thickness (➡ 112).

Checking rear brake fluid level



A low fluid level in the brake reservoir can allow air to penetrate the brake system. This significantly reduces braking efficiency.

Check brake fluid level regularly.◀

- Make sure ground is level and firm and place motorcycle on its center stand.



- Read off brake fluid level at rear brake-fluid reservoir **1**.



The brake fluid level in the brake-fluid reservoir drops due to brake pad wear.◀



Rear brake fluid level

- Brake fluid, DOT4
- The brake fluid level must not fall below the MIN mark. (Brake-fluid reservoir horizontal, motorcycle standing upright)

If brake fluid level drops below permissible level:


- Have the defect corrected as soon as possible by a specialized workshop, preferably an

authorized BMW Motorrad retailer.


Coolant

Checking coolant level

- Make sure ground is level and firm and park motorcycle.
- Allow the engine to cool down.



- Read off coolant level on expansion tank **1**.



Coolant, specified level

- between MIN and MAX marks on the expansion tank (With cold engine)

If coolant level drops below permissible level:

- Have the defect corrected as soon as possible by a specialized workshop, preferably an authorized BMW Motorrad retailer.

Clutch

Checking clutch operation

- Pull the clutch lever.
- » Pressure point must be clearly perceptible.

If no clear pressure point can be felt:

- Have the clutch checked by a specialized workshop, preferably an authorized BMW Motorrad retailer.


Checking clutch fluid level

- Make sure ground is level and firm and place motorcycle on its center stand.
- Move handlebars into straight-ahead position.



- Read off clutch fluid level at reservoir **1**.

 The fluid level in the clutch fluid reservoir rises due to clutch wear.◀



If clutch fluid level drops:

 Unsuitable hydraulic fluids could cause damage to the clutch system.

No fluids may be poured in.◀

- Have the defect corrected as soon as possible by a specialized workshop, preferably an authorized BMW Motorrad retailer.

Rims and tires

Checking rims

- Make sure ground is level and firm and park motorcycle.
- Visually inspect rims for defects.
- Have damaged rims checked and, if necessary, replaced by a specialized workshop, preferably an authorized BMW Motorrad retailer.

Checking tire tread depth

 The handling of your motorcycle can already change for the worse before the legally prescribed minimum tread depth is reached.

Have tires replaced even be-

fore the minimum tread depth is reached.◀

- Make sure ground is level and firm and park motorcycle.
- Measure tire tread depth in main tread grooves with wear indicating marks.

 Tires have wear indicators integrated into the main tread grooves. If the tire tread has worn down to the level of the marks, the tire is completely worn. The locations of the marks are indicated on the edge of the tire, e.g. by the letters TI, TWI or by an arrow.◀

When the minimum tread depth is reached:

- Replace tires concerned.

Wheels

Tire recommendation

For every size of tire, BMW Motorrad has tested and approved certain makes as roadworthy. BMW Motorrad cannot evaluate the suitability of other tires, and can therefore take no responsibility for their driving safety.

BMW Motorrad recommends only using the tires tested and approved by BMW Motorrad. Extensive information is available at your authorized BMW Motorrad retailer or on the Internet at www.bmw-motorrad.com.

Affect of wheel sizes on chassis control systems

The wheel sizes play a major role in the chassis control systems ABS and DTC. Especially the diameter and width of the wheels are stored in the control unit as

the basis for all necessary calculations. A change in these sizes due to conversion to others than the wheels installed as standard equipment can seriously affect the control comfort of these systems.

The sensor wheels required for wheel speed detection must also match the control systems installed and may not be replaced. If you want to equip your motorcycle with different wheels, please speak to a specialized workshop, and preferably a BMW Motorrad retailer. In some cases the data stored in the control units can be adapted to the new wheel sizes.

TPC/RDC sticker

- with Tire Pressure Control (TPC/RDC)^{OE}



BMW Motorrad retailer or the specialized workshop of the TPC/RDC sensor.

Removing front wheel

- Make sure ground is level and firm and place motorcycle on its center stand.



- Remove screws **1** on left and right.
- Pull out front wheel cover toward front.



- Unclip retaining clip **1** holding the sensor cable to the brake line.
- Remove cable tie **2**.
- Mask off area of wheel rim that could be scratched in process of removing brake calipers.

 The TPC/RDC sensors can be damaged in case of improper tire mounting. Inform the authorized BMW Motorrad retailer or the specialized workshop on the fact that the wheel is equipped with a TPC/RDC sensor.◀


On motorcycles equipped with TPC/RDC, a corresponding sticker is located on the wheel rim at the position of the TPC/RDC sensor. During a tire change it must be ensured that the TPC/RDC sensor is not damaged. Inform the




Once the calipers have been removed, there is a risk of the brake pads being pressed together to the extent that they cannot be slipped back over the brake disk on reassembly.

Do not operate the handbrake lever when the brake calipers have been removed. ◀


- Remove screws **3** of brake calipers on left and right.



- Push brake pads **4** apart slightly by rocking brake caliper **5** back and forth against brake disk **6**.
- Carefully pull brake calipers back and out until clear of brake disks.



- Remove screw **1** and take ABS sensor out of hole.
- Raise front of motorcycle until the front wheel can turn freely. BMW Motorrad recommends the BMW Motorrad front-wheel stand for lifting the motorcycle.
- Mounting front wheel stand (▮ 124).



 The left axle clamping screw fixes the threaded bush in place in the front suspension. A poorly aligned threaded bush results in incorrect spacing between the ABS sensor ring and the ABS sensor, and therefore to ABS malfunctions or destruction of the ABS sensor. To ensure the proper alignment of the threaded bush, do not loosen or remove the left axle clamping screw. ◀

- Remove right-hand axle clamping screw **2**.

- Remove quick-release axle **3** while supporting wheel.
- Roll front wheel forward to remove.

Installing front wheel


 Malfunctions may occur during control interventions by ABS and DTC if a wheel other than the standard wheel is installed.

Please see the information on the effect of wheel sizes on the chassis control systems ABS and DTC at the beginning of this chapter. ◀

 Threaded fasteners not tightened to the specified torque can work loose or their threads can suffer damage. Always have the tightening torques checked by a specialized workshop, preferably an authorized BMW Motorrad retailer. ◀

 The front wheel must be installed right way round to rotate in the correct direction. Observe the direction of rotation arrows on the tires or on the rim. ◀

- Roll front wheel into front wheel guide.



- Lift front wheel and install quick-release axle **3** with torque.

 Quick-release axle in threaded bush (wheel carrier)


– 37 lb/ft (50 Nm)

- Tighten the right-hand axle clamping screw **2** with the specified torque.

 Clamping screw for quick-release axle to wheel carrier

– 14 lb/ft (19 Nm)

- Remove front wheel stand.



- Insert ABS sensor into hole and install screw **1**.
- Ease brake calipers onto brake disks.



- Install securing screws **3** on left and right with specified torque.

 Front brake caliper on wheel carrier

– 22 lb/ft (30 Nm)




- Clip on retaining clip **1** holding the sensor cable to the brake line.
- Secure new cable tie **2**.
- Remove adhesive tape from wheel rim.
- Press handbrake lever firmly a number of times until resistance point is noticeable.



- Install front wheel cover and fit screws **1** on right and left.

Removing rear wheel

- Make sure ground is level and firm and place motorcycle on center stand.
- Remove case if necessary.



- Remove screws **1** on left and right.
- Remove the license-plate carrier.
- Shift into first gear.



⚠ Danger of burns from the hot exhaust system. Do not touch the exhaust system. If necessary, do not continue work until the exhaust system has cooled down. ◀

- Remove five screws **1** on rear wheel, holding wheel as you do so.
- Lower rear wheel to the ground and roll out toward rear.

Installing rear wheel

⚠ Malfunctions may occur during control interventions by ABS and DTC if a wheel other

than the standard wheel is installed.

Please see the information on the effect of wheel sizes on the chassis control systems ABS and DTC at the beginning of this chapter.◀



Threaded fasteners not tightened to the specified torque can work loose or their threads can suffer damage. Always have the tightening torques checked by a specialized workshop, preferably an authorized BMW Motorrad retailer.◀

- Roll and mount rear wheel onto rear wheel support.




- Fit five screws **1** and tighten diagonally with specified torque.



Tighten rear wheel on wheel flange

- Tightening sequence: diagonally
- 44 lb/ft (60 Nm)



- Hold the license-plate carrier in position.
- Install screws **1** on left and right.

Front wheel stand


Mounting front wheel stand



The BMW Motorrad front wheel stand is not designed for holding motorcycles without a center or other auxiliary stands. A motorcycle standing on the front wheel stand and the rear wheel alone can fall over. Place the motorcycle on the cen-


ter stand or an auxiliary stand before lifting it with the BMW Motorrad front wheel stand.◀

- Use basic stand with part number (83 30 0 402 241) in combination with front-wheel adapter (83 30 0 402 243).
- Make sure ground is level and firm and place motorcycle on its center stand.



- Loosen adjusting screws **1**.
- Push two mounting pins **2** far enough apart that front suspension fits between them.

- Use locating pins **3** to set front wheel stand to desired height.
- Center front wheel stand relative to front wheel and push it against front axle.



 The sensor ring of the BMW Motorrad Integral ABS can be damaged. Only push the left mounting pin so far inward that it does not touch the sensor ring.◀

- Push two mounting pins **2** through triangles of brake caliper support toward inside

so that front wheel can still be rolled through.

- Tighten adjusting screws **1**.



 If the motorcycle is resting on the center stand: The motorcycle is raised too far at the front, the center stand lifts off the ground and the motorcycle can tip over to the side.

When raising the motorcycle, make sure that the center stand remains on the ground.◀

- Apply uniform pressure to push front wheel stand down and raise motorcycle.

Jump-starting



The wires leading to the power socket do not have a load-capacity rating adequate for jump-starting the engine. Excessively high current can lead to a cable fire or damage to the motorcycle electronics.

Do not use the onboard socket to jump-start the engine of the motorcycle. ◀



Touching live parts of the ignition system with the engine running can cause electric shock.

Do not touch parts of the ignition system when the engine is running. ◀



A short-circuit can result if the crocodile clips of the jump leads are accidentally brought into contact with the motorcycle.

Use only jump leads fitted with

fully insulated crocodile clips at both ends. ◀



Jump-starting with a donor-battery voltage higher than 12 V can damage the motorcycle electronics.

The battery of the donor vehicle must have a voltage of 12 V. ◀

- When jump-starting the engine, do not disconnect the battery from the onboard electrical system.
- Remove seat (►► 105).
- Run engine of donor vehicle during jump-starting.
- Begin by connecting one end of red jump lead to positive terminal of discharged battery and other end to positive terminal of donor battery.
- Then connect one end of black jumper lead to negative terminal of donor battery, and other end to negative terminal of discharged battery.


- Start engine of the vehicle with discharged battery in usual way; if engine does not start, wait a few minutes before repeating attempt in order to protect starter motor and donor battery.
- Allow both engines to idle for a few minutes before disconnecting jump leads.
- Disconnect jump lead from negative terminals first, then disconnect second lead from positive terminals.
- Installing seat (►► 107).

Lamps


Replacing high-beam bulb



The description below steps you through the procedure for replacing the left high-beam headlight bulb. Proceed by analogy to replace the right high-beam headlight bulb. ◀




- Turn slipstream deflector **1** out.
- Remove screw **2** and work side cover **3** to the rear and remove.




- Remove screw **1**.


- Switch on the ignition and raise the windscreen to its highest position.
- Remove screw **2** and work hand protector **3** to the side to remove.
- Switch off the ignition and wait until the windscreen has moved to its lowest position.



- Remove screws **1**.
- Work speaker unit **2** to the rear to remove.



- Disconnect connector **3**.



- Turn covers **1** counterclockwise to remove.



- Disconnect plug **2**.



- Release spring clip **3** at left and right and swing it up.
- Remove bulb **4**.

- Replace defective bulb.




Bulb for high-beam
headlight

– H7 / 12 V / 55 W


- To avoid contamination on the bulb's glass surface, never touch or hold the bulb anywhere other than on its metal socket base.




- Install bulb **4** while ensuring correct position of lug **5**.
- Insert spring clip **3**.




- Attach plug **2**.



- Turn covers **1** clockwise to install.




- Close plug connection **3**.



- Seat the speaker unit in mount **4**.




- Install screws **1**.
- Switch on the ignition and raise the windscreen to its highest position.



- Hold hand protector **3** in position and install screw **2**.

- Switch off the ignition and wait until the windscreen has moved to its lowest position.
- Install screw **1**.



- Hold side cover **3** in position and install screw **2**.
- Align slipstream deflector **1**.

Battery

Maintenance instructions

Correct upkeep, recharging and storage will prolong the life of the battery and are essential if warranty claims are to be considered.

Compliance with the points below is important in order to maximize battery life:

- Keep the surface of the battery clean and dry
- Do not open the battery
- Do not top up with water
- Be sure to read and comply with the instructions for charging the battery on the following pages
- Do not turn the battery upside down



If the battery is not disconnected, the onboard electronics (clock etc.) will drain the battery. This can cause the battery to run flat. If this happens, warranty claims will not be accepted.

During driving breaks of more than four weeks, a trickle-charger should be connected to the battery.◀



BMW Motorrad has developed a trickle-charger specially designed for compatibility with the electronics of your motorcycle. Using this charger, you can keep the battery charged during long periods when the motorcycle is not being used without having to disconnect the battery from the motorcycle's onboard systems. Additional information is available at your authorized BMW Motorrad retailer.◀

Charging connected battery



Charging the connected battery directly at the battery terminals can damage the motorcycle electronics. To charge the battery via the battery terminals, disconnect the battery first.◀



If you switch on the ignition and the multifunction display and indicator lights fail to light up, the battery is completely flat (battery voltage below 9 V). Attempting to charge a completely flat battery via the onboard socket can cause damage to the motorcycle's electronics. Always charge a completely drained battery directly at the terminals of the disconnected battery.◀



Charging the battery via the onboard socket is only possible with suitable chargers. Unsuitable chargers can result in damage to the motorcycle electronics.

Use BMW chargers with part numbers 77 02 7 722 470 (230 V), 77 02 7 729 048 (230 V), or 77 02 7 722 471 (110 V). If in doubt, charge the disconnected battery directly at the terminals.◀

- Charge disconnected battery via onboard socket.

▶ The motorcycle's onboard electronics know when the battery is fully charged. The onboard socket is switched off when this happens.◀

- Comply with operating instructions of charger.

▶ If you are unable to charge the battery via the onboard socket, you may be using a charger that is not compatible with your motorcycle's electronics. In this case, please charge the battery directly at the terminals of the disconnected battery.◀

Charging disconnected battery

- Charge battery using a suitable charger.
- Comply with operating instructions of charger.

- Once the battery is fully charged, disconnect the charger's terminal clips from the battery terminals.

▶ In the case of longer periods when the motorcycle is not being used, the battery must be recharged regularly. See the instructions for caring for your battery. Always fully recharge the battery before returning it to use.◀

Removing battery

- Remove seat (105).
– with anti-theft alarm ^{OE}
- Switch off anti-theft alarm if necessary.◀
- Switch off ignition.



⚠ An incorrect disconnection sequence increase the risk of short-circuiting.

Always observe the proper sequence.◀

- Remove negative cable **1** first.
- Then open the cover and disconnect positive lead **2**.
- Remove screws **3** and remove the retainer.
- Lift battery upwards; if it is difficult to move, moving it back and forth will help.

Installing battery

- Place battery in battery compartment, positive terminal on right in direction of travel.



- Install the retainer and install screws **3**.

! An incorrect installation sequence increases the risk of short-circuiting. Always observe the proper sequence.◀

- Connect battery positive lead **2** first and close the cover.
- Then install negative battery cable **1**.

- Installing seat (▶▶▶ 107).
- Switch on ignition.
- Set the time in Settings - Time and set the date in Settings - Date.

Fuses

Replacing fuses

- Switch off ignition.
- Remove seat (▶▶▶ 105).

! If defective fuses are bridged, this results in a danger of short-circuit and thus a danger of fire. Replace defective fuses with new fuses.◀

- Consult the fuse assignment diagram and replace the defective fuse.

▶ If the fuses blow frequently, have the electrical system checked by an authorized specialized workshop, preferably a BMW Motorrad retailer.◀

- Installing seat (▶▶▶ 107).

Fuse assignment



- | | |
|-----------|--|
| 1 | 40 A
Motorcycle electronics |
| 2 | 40 A
Motorcycle electronics
– with Electronic Suspension Adjustment (ESA) ^{OE}
ESA |
| 3 | 30 A
Engine electronics |
| 4 | Fuse box
Numbering of the fuses as per label on lid of fuse box: |
| -1 | not in use |

- 2** not in use
- 3** not in use
- 4** 4 A
Left handlebar fitting, top-case lighting
 - with Tire Pressure Control (TPC/RDC)^{OE}
 TPC/RDC
- 5** 7,5
Audio system
- 6** 4 A
Beam throw adjustment
 - with Adaptive Headlight ^{OE}
 Adaptive cornering lights
- 7** 4 A
Main relay, instrument panel, ignition switch
- 8** not in use
 - with anti-theft alarm^{OE}
 7.5 A
Anti-theft alarm

Care

Care products	136
Washing your motorcycle	136
Cleaning sensitive vehicle parts	136
Paint care	137
Protective wax coating	138
Storing motorcycle.....	138
Returning motorcycle to use	138

Care products

BMW Motorrad recommends that you use cleaning and care products available at your authorized BMW Motorrad retailer. BMW CareProducts have been materials tested, laboratory tested, and field tested and provide optimum care and protection for the materials used in your motorcycle.



The use of unsuitable cleaning and care products can damage motorcycle components.

For cleaning, do not use any solvents such as nitro-thinners, cold cleaning agents, fuel or similar, and do not use cleaning agents that contain alcohol.◀

Washing your motorcycle

BMW Motorrad recommends that you use BMW Insect Remover to soften and wash off insects and stubborn dirt from painted parts before washing the motorcycle.

To prevent stains, do not wash the motorcycle immediately after it has been exposed to bright sunlight and do not wash it in the sun.

Make sure that the motorcycle is washed frequently, especially during the winter months.

To remove road salt, clean the motorcycle with cold water immediately after every trip.



After washing the motorcycle, after driving through water or in the rain, braking can be delayed due to damp brake disks and brake pads.

Brake early until the brake disks

and pads are dry or braked until dry.◀



Warm water intensifies the effect of salt.

Only use cold water to remove road salt.◀



The high water pressure of high-pressure cleaners (steam cleaners) can damage seals, the hydraulic brake system, the electrical system and the seat.

Do not use a steam jet or high-pressure cleaning equipment.◀

Cleaning sensitive vehicle parts

Plastics



If plastic parts are cleaned using unsuitable cleaning agents, the surfaces can be damaged.

Do not use cleaning agents that

contain alcohol, solvents or abrasives to clean plastic parts. 'Fly sponges' or sponges with hard surfaces can also lead to scratches.◀

Fairings

Clean body panels with water and BMW plastic care emulsion.

Windscreens and headlight lenses made of plastic

Clean off dirt and insects with a soft sponge and plenty of water.



Soften stubborn dirt and dead insects by covering the affected areas with a wet cloth.◀

Chrome

Especially in the case of road salt, carefully clean chrome parts with plenty of water and BMW auto shampoo. Use chrome polish for additional treatment.

Radiator

Clean the radiator regularly to prevent overheating of the engine due to inadequate cooling. For example, use a garden hose with low water pressure.



Cooling fins can be bent easily.

When cleaning the radiator, ensure that the fins are not bent.◀

Rubber

Treat rubber components with water or BMW rubber protection coating agent.



Using silicone sprays for the care of rubber seals can cause damage.

Do not use silicon sprays or other care products that contain silicon.◀

Paint care

Washing the motorcycle regularly will help counteract the long-term effects of substances that damage the paint, especially if your motorcycle is ridden in areas with high air pollution or natural sources of dirt, e.g. tree resin or pollen.

However, remove particularly aggressive materials immediately; otherwise changes in the paint or discoloration can occur. These include spilled fuel, oil, grease, brake fluid as well as bird droppings. BMW Car Polish or BMW Paint Cleaner are recommended for this.

Contamination of the paint finish is particularly easy to see after the motorcycle has been washed. Remove this type of soiling with cleaning naphtha or spirit on a clean cloth or cotton ball. BMW Motorrad recommends removing tar spots with BMW Tar Re-

mover. Then add a protective wax coating to the paint at these locations.

Protective wax coating

To preserve the finish of your motorcycle, BMW Motorrad recommends using BMW Car Wax or agents that contain carnauba or synthetic waxes.

A sure sign that the paint must be protected, is the fact that water no longer pearls up on it.

Storing motorcycle

- Clean the motorcycle.
- Removing battery (🔌➡ 131).
- Spray brake and clutch lever, and main and side stand pivots with a suitable lubricant.
- Coat bare metal and chrome-plated parts with an acid-free grease (e.g., Vaseline).

- Park motorcycle in a dry room, raising it to remove weight from both wheels.

Returning motorcycle to use

- Remove the protective wax coating.
- Cleaning the motorcycle.
- Install a charged battery.
- Before starting: Observe checklist.

Technical data

Troubleshooting chart	140
Threaded fasteners	141
Engine	142
Fuel.....	143
Engine oil	143
Clutch	144
Transmission	144
Rear-wheel drive.....	145
Running gear	145
Brakes	146
Wheels and tires	147
Electrical system.....	148
Anti-theft alarm system	150
Frame	151
Dimensions	151

Weights.....	152
Riding specifications	152

Troubleshooting chart

Engine does not start at all or is very difficult to start

Possible cause	Remedy
Side stand is extended	Retract side stand.
Gear engaged and clutch not disengaged	Place transmission in neutral or disengage clutch.
No fuel in tank	Refueling (▮ 84).
Battery drained	Charge battery.

Threaded fasteners

Front wheel	Value	Valid
Front brake caliper on wheel carrier		
M8 x 30 - 10.9	22 lb/ft (30 Nm)	
Clamping screw for quick-release axle to wheel carrier		
M8 x 30	14 lb/ft (19 Nm)	
Quick-release axle in threaded bush (wheel carrier)		
M24 x 1,5	37 lb/ft (50 Nm)	
Rear wheel	Value	Valid
Tighten rear wheel on wheel flange		
M10 x 1.25 x 40	diagonally	
	44 lb/ft (60 Nm)	
Shifting	Value	Valid
Eccentric, peg to shift lever		
M6 x 20	6 lb/ft (8 Nm)	

Engine

Engine design	transverse straight-six four-stroke engine with four valves per cylinder and two overhead camshafts; liquid cooling, electronic fuel injection, integral six-speed cassette gearbox, dry-sump lubrication.
Displacement	1649 cc (1649 cm ³)
Cylinder bore	2.8 in (72 mm)
Piston stroke	2.7 in (67.5 mm)
Compression ratio	12,2:1
Rated output	160 hp (118 kW), at engine speed: 7750 min ⁻¹
– with power reduction ^{OE}	107 hp (79 kW), at engine speed: 7750 min ⁻¹
Torque	129 lb/ft (175 Nm), at engine speed: 5250 min ⁻¹
– with power reduction ^{OE}	111 lb/ft (150 Nm), at engine speed: 4750 min ⁻¹
Maximum engine speed	max 8500 min ⁻¹
Idle speed	900 ^{±50} min ⁻¹ , Engine at operating temperature

Fuel

Recommended fuel quality	Super unleaded (max. 10 % of ethanol) (E10) 89 AKI (95 ROZ/RON) 89 AKI
Usable fuel quantity	Approx. 7 gal (Approx. 26.5 l)
Reserve fuel quantity	Approx. 1.1 gal (Approx. 4 l)

BMW recommends BP fuel



Engine oil

Engine oil, capacity	1.2 gal (4.5 l), with filter change
Products recommended by BMW Motorrad	
Castrol Power 1 Racing	SAE 5W-40, API SL / JASO MA2

BMW recommends 

Clutch

Clutch design	Multi-disk oil-bath clutch
---------------	----------------------------

Transmission

Transmission design	Claw-shifted 6-speed transmission integrated in engine housing
Transmission gear ratios	1,617, Primary gear ratio 1,941 (33:17 teeth), 1st gear 1,429 (30:21 teeth), 2nd gear 1,148 (31:27 teeth), 3rd gear 0,958 (23:24 teeth), 4th gear 0,806 (25:31 teeth), 5th gear 0,686 (24:35 teeth), 6th gear 0,913 (21:23 teeth), Angle drive 1,258 (39:31 teeth), Countershaft

Rear-wheel drive

Type of final drive	Shaft drive with bevel gears
Type of rear suspension	Cast-aluminum single swing arm with BMW Motorrad Paralever
Number of teeth in bevel gears (gear ratio)	2,75 (33:12)

Running gear

Front wheel

Type of front suspension	BMW Motorrad Duolever
Design of front suspension strut	Central suspension strut
– with Electronic Suspension Adjustment (ESA) ^{OE}	Central suspension strut with electrically adjustable damping.
Spring travel, front	4.9 in (125 mm), On wheel

Rear wheel

Type of rear suspension	Cast-aluminum single swing arm with BMW Motorrad Paralever
Type of rear suspension	central suspension strut pivoted to lever system. Spring preload and rebound-stage damping steplessly adjustable.
– with Electronic Suspension Adjustment (ESA) ^{OE}	central suspension strut pivoted to lever system. Electrically adjustable damping and spring preload/spring rate.
Spring travel, rear	5.3 in (135 mm), On wheel

Brakes

Type of front brake	Hydraulically operated twin disk brake with 4-piston fixed calipers and floating brake disks
Brake-pad material, front	Sintered metal
Type of rear brake	Hydraulic disk brake with 2-piston floating caliper and fixed brake disk
Brake-pad material, rear	Organic

Wheels and tires

Recommended tire combinations	You can obtain an overview of the current tire approvals from your authorized BMW Motorrad retailer or on the Internet at www.bmw-motorrad.com .
Front wheel	
Front wheel design	Cast aluminum, MT H2
Front-wheel rim size	3.50" x 17"
Front tire designation	120 / 70 ZR 17
Rear wheel	
Rear wheel design	Cast aluminum, MT H2
Rear-wheel rim size	6.00" x 17"
Rear tire designation	190 / 55 ZR 17
Tire inflation pressure	
Tire pressure, front	42.1 psi (2.9 bar), With tire cold
Tire pressure, rear	42.1 psi (2.9 bar), With tire cold

Electrical system

Electrical rating of onboard sockets	max 10 A, all onboard sockets together
Battery	
Battery design	Gel battery
Battery voltage	12 V
Battery capacity	19 Ah
Spark plugs	
Spark plugs, manufacturer and designation	NGK LMAR8AI-8
Electrode gap of spark plug	0.03 in (0.8 mm), New 0.04 in (1.0 mm), Wear limit
Bulbs	
Bulb for high-beam headlight	H7 / 12 V / 55 W
Bulbs for low-beam headlight	D1S / 35 W
Bulb for parking light	Lighting rings, integrated into headlight
Bulb for taillight/brake light	LED
Bulbs for flashing turn indicators, front	LED
Bulbs for flashing turn indicators, rear	LED

Fuses

Fuse carrier 1	30 A, Engine electronics
Fuse carrier 2	40 A, Slot left: Vehicle electronics 40 A, Slot right: Vehicle electronics, ESA
Fuse box	not in use, Slot 1 not in use, Slot 2 not in use, Slot 3 4 A, Slot 4: Left handlebar fitting, tire pressure monitoring (RDC), topcase interior light 7.5 A, Slot 5: Audio system 4 A, Slot 6: Beam throw control, Adaptive Headlight 4 A, Slot 7: Main relay, instrument cluster, ignition switch 7.5 A, Slot 8: Anti-theft alarm (DWA), central locking

Anti-theft alarm system

– with anti-theft alarm^{OE}

Anti-theft alarm

Activation time during commissioning	30 s
Alarm duration	26 s
Activation time between two alarms	10 s
Battery type	CR 123 A

Remote control

Range of remote control	32.8 ft (10 m)
Signal frequency	25 kHz, Broadband
Transmission frequency	433.92 MHz
Battery design and nominal voltage	CR 1632 lithium 3 V

Frame

Frame design	Cast light alloy - welded design with screwed-on light alloy rear frame
Location of type plate	Wheel carrier, front right
Location of vehicle identification number	Frame side section, front right (beside engine-oil filler neck)

Dimensions

Motorcycle length	98 in (2489 mm), over topcase
Motorcycle height	57.7 in (1465 mm), Across windshield at DIN unladen weight
Motorcycle width	39.4 in (1000 mm), Across mirrors 38.6 in (980 mm), without mirrors
Driver's seat height	29.5 in (750 mm), Without driver
– with high dual seat ^{OE}	30.7 in (780 mm), Without driver
Rider's inside-leg arc, heel to heel	67.7 in (1720 mm), Without driver
– with high dual seat ^{OE}	69.7 in (1770 mm), Without driver

Weights

Unladen weight	767 lbs (348 kg), DIN unladen weight, with cases and topcase, ready for road, 90 % load of fuel, without optional extras
Permissible gross weight	1235 lbs (560 kg)
Maximum payload	467 lbs (212 kg)

Riding specifications

Top speed	>124 mph (>200 km/h)
-----------	----------------------

Service

Reporting safety defects	154
BMW Motorrad Service	155
BMW Motorrad Mobility Services	155
Maintenance work	155
Confirmation of maintenance work	157
Confirmation of service	162

Reporting safety defects

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying BMW of North America, LLC.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or BMW of North America, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to <http://www.safercar.gov>; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590. You can also obtain other information about motor vehicle safety from <http://www.safercar.gov>.

BMW Motorrad Service

With its worldwide service network, BMW Motorrad can attend to you and your motorcycle in over 100 countries around the globe. BMW Motorrad retailers have the technical information and expertise needed to conduct reliable service and repairs covering every aspect of your BMW. You can find the nearest BMW Motorrad retailer by visiting our Internet site at "www.bmw-motorrad.com".



If this maintenance and repair work is performed inexpertly, there is a danger of damage and associated safety risks. BMW Motorrad recommends having corresponding work on your motorcycle carried out by a specialized workshop, preferably by an authorized BMW Motorrad retailer. ◀

To ensure that your BMW consistently remains in optimal condition BMW Motorrad urges you to observe the recommended service intervals.

Have all maintenance and repair work confirmed in the "Service" chapter in this manual. For generous treatment of claims submitted after the warranty period has expired (goodwill), evidence of regular maintenance is essential.

You can obtain information on the contents of the BMW Services from your BMW Motorrad retailer.

BMW Motorrad Mobility Services

The BMW Motorrad Mobility Services furnish you and your new BMW motorcycle with extra security by offering a wide array of assistance services in the event

of a breakdown (Mobile Service, breakdown assistance, vehicle recovery and retrieval, etc.).

Contact your authorized BMW Motorrad retailer for additional information on available mobility-maintenance services.

Maintenance work

BMW Pre-Delivery Check

The BMW pre-delivery check is carried out by your authorized BMW Motorrad retailer before it turns over the motorcycle to you.

BMW Running-in Check

The BMW running-in check must be carried out between 300 mls (500 km) and 750 mls (1200 km).

BMW Service

BMW Service is carried out once a year. The scope of the services performed may be dependent on the vehicle owner and the mileage driven. Your BMW Motorrad retailer confirms that the service has been performed and enters the date for the next service.

For drivers who drive long distances annually, it may be necessary to come in for service before the entered date. In this case a corresponding maximum odometer reading will also be entered in the confirmation of service. If this odometer reading is reached before the next service date, service must be performed sooner.

The service display in the multi-function display reminds you of the next service date approx. one month or 621 miles (1000 km) before the entered values.

Confirmation of maintenance work

BMW Pre-Delivery Check

Conducted

on _____

Stamp, Signature

BMW Running-in Check

Conducted

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if reached sooner,

Odometer reading _____

Stamp, Signature

BMW Service

Conducted

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if reached sooner,

Odometer reading _____

Stamp, Signature**BMW Service**

Conducted

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if reached sooner,

Odometer reading _____

Stamp, Signature**BMW Service**

Conducted

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if reached sooner,

Odometer reading _____

Stamp, Signature

BMW Service

Conducted

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if reached sooner,

Odometer reading _____

Stamp, Signature**BMW Service**

Conducted

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if reached sooner,

Odometer reading _____

Stamp, Signature**BMW Service**

Conducted

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if reached sooner,

Odometer reading _____

Stamp, Signature

BMW Service

Conducted

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if reached sooner,

Odometer reading _____

Stamp, Signature**BMW Service**

Conducted

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if reached sooner,

Odometer reading _____

Stamp, Signature**BMW Service**

Conducted

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if reached sooner,

Odometer reading _____

Stamp, Signature

BMW Service

Conducted

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if reached sooner,

Odometer reading _____

Stamp, Signature**BMW Service**

Conducted

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if reached sooner,

Odometer reading _____

Stamp, Signature**BMW Service**

Conducted

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if reached sooner,

Odometer reading _____

Stamp, Signature

The table is intended as proof of maintenance and repair work, the installed optional accessories and any special campaign (recall) work carried out.

The table is intended as proof of maintenance and repair work, the installed optional accessories and any special campaign (recall) work carried out.

[illegible]

Work carried out	Odometer reading	Date

Appendix

Certificates	166
--------------------	-----

Certifications

Remote Control for central locking system



Česky

Meta System S.p.A. tímto prohlašuje, že tento PF240009 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Dansk

Undertegnede Meta System S.p.A. erklærer herved, at følgende udstyr PF240009 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Deutsch

Hiermit erklärt Meta System S.p.A., dass sich das Gerät PF240009 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

Eesti

Käesolevaga kinnitab Meta System S.p.A. seadme PF240009 vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

English

Hereby, Meta System S.p.A., declares that this PF240009 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Español

Por medio de la presente Meta System S.p.A. declara que el PF240009 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Certifications

Ελληνική

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Meta System S.p.A. ΔΗΛΩΝΕΙ ΟΤΙ PF240009 ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/EK.

Français

Par la présente Meta System S.p.A. déclare que l'appareil PF240009 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Italiano

Con la presente Meta System S.p.A. dichiara che questo PF240009 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Latviski

Ar šo Meta System S.p.A. deklarē, ka PF240009 atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Lietuvių

Šiuo Meta System S.p.A. deklaruoja, kad šis PF240009 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Nederlands

Hierbij verklaart Meta System S.p.A. dat het toestel PF240009 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Malti

Hawnhekk, Meta System S.p.A., jiddikjara li dan PF240009 jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Magyar

Alulírott, Meta System S.p.A. nyilatkozom, hogy a PF240009 megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Polski

Niniejszym Meta System S.p.A. oświadcza, że PF240009 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Português

Meta System S.p.A. declara que este PF240009 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Certifications

Slovensko

Meta System S.p.A. izjavlja, da je ta PF240009 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Slovensky

Meta System S.p.A. týmto vyhlasuje, že PF240009 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Suomi

Meta System S.p.A. vakuuttaa täten että PF240009 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Svenska

Härmed intygar Meta System S.p.A. att denna PF240009 står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Íslenska

Hér með lýsir Meta System S.p.A. yfir því að PF240009 er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

Norsk

Meta System S.p.A. erklærer herved at utstyret PF240009 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

USA, Canada

Product name: TX BMW MR
FCC ID: P3O98400
IC:4429A - TXBMWMR

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.



Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Declaration Of Conformity

R&TTE Declaration Of Conformity (DoC)

CE0470

We:

Meta System S.p.A.

with the address:

Via Majakovskij 10 b/c/d/e
42124 Reggio Emilia -Italy

Declare

Under own responsibility that the product:

TX BMW MR

To which this declaration relates is in conformity with the essential requirements and other relevant requirements of the R&TTE Directive (1999/5/EC).

This product is in conformity with the following standards:

Health & Safety (art.3.1)

EN 60950-1

EMC (art.3.2)

ETSI EN 301 489-1/-3

Spectrum

ETSI EN 300 220 - 2

Human exposure

EN 62311

According to Directive 1999/5/CE

Reggio Emilia , 14/07/2010

Technical Director
Lasagni Cesare



Certifications

Tire Pressure Control TPC

FCC ID: MRXBC54MA4

IC: 2546A-BC54MA4

This device complies with Part 15 of the FCC Rules and with RSS-210 of Industry Canada.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

A

Abbreviations and symbols, 6

ABS

- Self-diagnosis, 81
- Technology in detail, 89
- Warning indicators, 34

Accessories

- General instructions, 98

Additional headlight

- Operating, 51

Ambient temperature

- Display, 22
- Ice warning, 34

Anti-theft alarm

- Indicator light, 18
- Operating, 71
- Warning indicator, 38

Average values

- Resetting, 49

B**Battery**

- Charging connected battery, 130
- Charging disconnected battery, 131

Installing, 132

Maintenance instructions, 129

Position on motorcycle, 17

Removing, 131

Technical data, 148

Warning for battery charge current, 32

Warning for battery voltage low, 33

Brake fluid

- Checking fill level at front, 114
- Checking fill level at rear, 115
- Front reservoir, 13
- Rear reservoir, 13

Brake pads

- Check front, 112
- Check rear, 113
- Running in, 82

Brakes

- Adjusting handlebar lever, 63
- Checking operation, 112
- Safety instructions, 83
- Technical data, 146

C**Case**

- Operating, 102

Central locking

- Operating, 67
- Warning indicator for central locking, 39

Checklist, 79**Clock**

- Adjusting, 47

Clutch

- Adjusting handlebar lever, 62
- Checking fluid level, 117
- Checking operation, 117
- Fluid reservoir, 11
- Technical data, 144

Confirmation of maintenance work, 157

Coolant

- Checking fill level, 116
- Fill level indicator, 13
- Overtemperature warning indicator, 31

Cruise control
Control, 14
Operating, 60
Currentness of this manual, 7

D

Damping
Adjusting, 65
Rear adjuster, 11
Date
Adjusting, 47
Dimensions
Technical data, 151
Driving mode
Adjusting, 57
Technology in detail, 88
DTC
Control, 14
Operating, 56
Self-diagnosis, 81
Technology in detail, 92
Warning indicator, 35

E

Electrical system
Technical data, 148

Emergency ON/OFF switch, 16
Operating, 53
Engine
Starting, 80
Technical data, 142
Warning for engine
electronics, 32
Engine oil
Checking fill level, 110
Fill location, 13
Oil dipstick, 13
Oil level indicator, 23
Technical data, 143
Topping up, 112
Warning for engine oil level, 32
Equipment, 7
ESA
Control, 14
Operating, 66
Technology in detail, 94

F

Frame
Technical data, 151

Front wheel stand
Mounting, 124
Fuel
Fill location, 11
Refueling, 84
Technical data, 143
Fuel reserve
Range, 22
Warning indicator, 31
Fuses
Position on motorcycle, 17
Replacing, 132
Technical data, 148

G

Ground lighting
Operating, 52

H

Hazard warning flashers
Control, 14
Operating, 53

H

- Headlight
 - Adjusting for traffic driving on right/driving on left, 51
 - Headlight range adjustment, 11
 - Warning indicator for LHD/RHD traffic, 38
 - Warning indicator for unknown position, 38
- Heated handlebar grips
 - Operating, 54
- Horn, 14

I

- Ignition
 - Switching off, 42
 - Switching on, 42
- Immobilizer
 - Spare key, 43
 - Warning indicator, 31
- Indicator lights, 18
 - Overview, 25
- Instrument cluster
 - Ambient brightness sensor, 18
 - Overview, 18

J

- Jump-starting, 126

K

- Keys, 42

L

- Lamps
 - Replacing high-beam bulb, 126
 - Technical data, 148
 - Warning for bulb failure, 33
- Lights
 - Control, 14
 - Headlight low beam, 50
 - Operating headlight flasher, 50
 - Operating headlight high beams, 50
 - Operating parking light, 51
 - Parking lights, 50
- Luggage
 - Loading information, 78

M

- Maintenance
 - General instructions, 110
- Maintenance intervals, 155

M

- Mirrors
 - Adjusting, 64
- Mobility Services, 155
- Motorcycle
 - Care, 135
 - Cleaning, 135
 - Parking, 84
 - Returning to use, 138
 - Securing with straps, 86
 - Storage, 138
- Multifunction display, 18
 - Control, 14
 - Meaning of symbols, 21
 - Operating, 44
 - Overview, 20
 - Settings, 47
- Multifunction switch
 - General view, left, 14
 - General view, right, 16

N

- Navigation devices
 - Installing, 99
 - Operating, 101
 - Removing, 100

O

- Odometer and tripmeters
 - Operating, 50
- Onboard computer
 - Operating, 48
- Onboard socket
 - Information on use, 98
 - Position on motorcycle, 13
- Onboard toolkit
 - Contents, 110
 - Position on motorcycle, 17
- Overview of warning indicators, 27
- Overviews
 - Instrument cluster, 18
 - Left side of motorcycle, 11
 - Left-hand multifunction switch, 14
 - Multifunction display, 20
 - Right side of motorcycle, 13
 - Right-hand multifunction switch, 16
 - Underneath seat, 17
 - Warning and indicator lights, 25

P

- Pre-ride check, 80

R

- Rear-wheel drive
 - Technical data, 145
- Refueling, 84
- Remote control
 - logon, 68
 - Replacing battery, 70
 - synchronize, 69
- Rider's Manual (US Model)
 - Position on motorcycle, 17
- Running gear
 - Technical data, 145
- Running in, 82

S

- Safety instructions
 - On braking, 83
 - On riding, 78
- Seat
 - Installing, 58
 - Locking mechanism, 11
 - Removing, 58

- Seat heating
 - Control, 11
 - Operating, 54
- Service, 155
 - Reporting safety defects, 154
 - Warning indicator, 39
- Service display, 23
- Shift lever
 - Adjusting, 63
- Spark plugs
 - Technical data, 148
- Speedometer, 18
- Spring preload
 - Adjusting, 64
 - Rear adjuster, 11
- Starting, 80
 - Control, 16
- Steering lock
 - Locking, 42
- Storage compartment
 - Operating, 62
 - Position on motorcycle, 11, 13
- Switching off, 84
- Symbols
 - Meaning, 21

T

- Tachometer, 18
- Technical data
 - Battery, 148
 - Brakes, 146
 - Bulbs, 148
 - Clutch, 144
 - Dimensions, 151
 - Electrical system, 148
 - Engine, 142
 - Engine oil, 143
 - Frame, 151
 - Fuel, 143
 - Rear-wheel drive, 145
 - Running gear, 145
 - Spark plugs, 148
 - Standards, 7
 - Transmission, 144
 - Weights, 152
 - Wheels and tires, 147
- Tire Pressure Control TPC/RDC
 - Display, 22
 - Rim sticker, 118
 - Technology in detail, 93
 - Warning indicators, 36

Tires

- Checking tire inflation pressure, 74
- Checking tread depth, 117
- Inflation pressure table, 17
- Inflation pressures, 147
- Recommendation, 118
- Running in, 83
- Technical data, 147
- Topcase
 - Operating, 104
- Torques, 141
- Transmission
 - Technical data, 144
- Troubleshooting chart, 140
- Turn indicators
 - Control, 14
 - Operating, 52
- Type plate
 - Position on motorcycle, 13

V

- Vehicle Identification Number
 - Position on motorcycle, 13

W

- Warning indicators
 - ABS, 34
 - Anti-theft alarm, 38
 - Battery charge current, 32
 - Bulb defective, 33
 - Central locking, 39
 - Coolant temperature, 31
 - Display, 26
 - DTC, 35
 - Engine electronics, 32
 - Engine oil level, 32
 - Fuel reserve, 31
 - Headlight for LHD/RHD traffic, 38
 - Headlight in unknown position, 38
 - Ice warning, 34
 - Immobilizer, 31
 - Service, 39
 - Tire Pressure Monitor, 36
 - Undervoltage, 33
- Warning lamps, 18
 - Overview, 25

Weights

- Payload table, 17

- Technical data, 152

Wheels

- Checking rims, 117

- Installing front wheel, 121

- Installing rear wheel, 123

- Removing front wheel, 119

- Removing rear wheel, 123

- Size change, 118

- Technical data, 147

Wind deflection wing, 59

Windshield

- Adjusting, 59

- Control, 14

Details described or illustrated in this booklet may differ from the motorcycle's actual specification as purchased, the accessories fitted or the national-market specification. No claims will be entertained as a result of such discrepancies.

Dimensions, weights, fuel consumption and performance data are quoted to the customary tolerances.

The right to modify designs, equipment and accessories is reserved.

Errors and omissions excepted.

© 2012 BMW Motorrad

Not to be reproduced either wholly or in part without written permission from BMW Motorrad, After Sales.

Printed in Germany.

The most important data for a filling station stop can be found in the following chart.

Fuel	
Recommended fuel quality	Super unleaded (max. 10 % of ethanol) (E10) 89 AKI (95 ROZ/RON) 89 AKI
Usable fuel quantity	Approx. 7 gal (Approx. 26.5 l)
Reserve fuel quantity	Approx. 1.1 gal (Approx. 4 l)
Tire inflation pressure	
Tire pressure, front	42.1 psi (2.9 bar), With tire cold
Tire pressure, rear	42.1 psi (2.9 bar), With tire cold



Certification Tire Pressure Control (TPC)

FCC ID: MRXBC54MA4
IC: 2546A-BC54MA4

FCC ID: MRXBC5A4
IC: 2546A-BC5A4

This device complies with Part 15 of the FCC Rules and with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.