

Rider's Manual

R 1200 RT



BMW Motorrad



The Ultimate Riding
Machine

Motorcycle data/dealership details

Motorcycle data

Model

Vehicle identification number

Colour code

Date of first registration

Registration number

Dealership details

Person to contact in Service department

Ms/Mr

Phone number

Dealership address/phone number
(company stamp)

Welcome to BMW

We congratulate you on your choice of a motorcycle from BMW and welcome you to the community of BMW riders. Familiarise yourself with your new motorcycle so that you can ride it safely and confidently in all traffic situations. Please read this Rider's Manual carefully before starting to use your new BMW motorcycle. It contains important information on how to operate the controls and how to make the best possible use of all your BMW's technical features. In addition, it contains information on maintenance and care to help you maintain your motorcycle's reliability and safety, as well as its value. If you have questions concerning your motorcycle, your

authorised BMW Motorrad dealer will gladly provide advice and assistance.

We hope that you will enjoy riding your BMW and that all your journeys will be pleasant and safe.

BMW Motorrad.

Table of Contents

You can also consult the index at the end of this Rider's Manual if you want to find a particular topic or item of information.

1 General instructions ...	5	3 Status indicators	21	Multifunction display	48
Overview	6	Multifunction display	22	Clock	49
Abbreviations and symbols	6	Warning and telltale lights	24	Tyre pressure control RDC ^{OE}	49
Equipment	7	ABS warning light	24	Residual range	50
Technical data	7	Telltale light, cruise control ^{OE}	24	On-board computer ^{OE} ...	50
Currency	7	Function indicators	24	Cruise-control system ^{OE}	54
2 General views	9	Warnings, general	25	Emergency off switch (kill switch)	57
General view, left side ...	11	Warnings issued by the tyre pressure monitoring system (RDC) ^{OE}	32	Grip heating ^{OE}	57
General view, right side	13	ABS warnings	37	Seat heating ^{OE}	58
Underneath the seat	15	ASC warnings ^{OE}	39	Clutch	60
Handlebar fitting, left	16	4 Operation	43	Brakes	60
Handlebar fitting, right ...	17	Ignition switch and steering lock	44	Lights	61
Instrument cluster	18	Electronic immobiliser (EWS)	45	Headlight	62
Headlight	19	Hazard warning flashers	46	Turn indicators	63
		Odometer and tripmeters	47	Stowage compartment ...	64
				Automatic Stability Control ASC ^{OE}	65
				Front and rear seats	66
				Helmet holder	69
				Mirrors	70
				Windscreen	70

Spring preload	70	Case.....	98	Protective wax coating	140
Shock absorbers	71	Topcase ^{OA}	100	Laying up the motorcycle	140
Electronic Suspension Adjustment ESA ^{OE}	73	7 Maintenance	103	Restoring motorcycle to use	141
Tyres	74	General instructions	104	9 Technical data	143
5 Riding	77	Toolkit	104	Troubleshooting chart	144
Safety instructions	78	Engine oil	105	Threaded fasteners	145
Checklist	80	Brake system, general	107	Engine	146
Starting	80	Brake pads	108	Riding specifications	148
Running in	83	Brake fluid	109	Clutch	149
Parking your motorcycle	84	Clutch	111	Transmission	149
Refuelling	86	Tyres	112	Final drive	150
Tyre pressure control RDC ^{OE}	87	Rims	112	Running gear	150
Brake system, general	88	Wheels	112	Brakes	151
Brake system with BMW Motorrad Integral ABS	89	Front-wheel stand	119	Wheels and tyres	151
Electronic engine management with BMW Motorrad ASC ^{OE}	92	Bulbs	120	Electrics	152
6 Accessories	95	Jump starting	130	Frame	154
General instructions	96	Battery	132	Dimensions	154
Power socket	96	8 Care	137	Weights	155
Luggage	97	Care products	138		
		Washing the motorcycle	138		
		Cleaning easily damaged components	139		
		Paint care	140		

10 Service	157
BMW Motorrad	
service	158
BMW Motorrad service	
quality	158
BMW Motorrad Service	
Card: on-the-spot	
breakdown	
assistance	159
BMW Motorrad service	
network	159
Maintenance work	159
Maintenance	
schedules	160
Confirmation of	
maintenance work	161
Confirmation of	
service	166

General instructions

Overview	6
Abbreviations and symbols	6
Equipment	7
Technical data	7
Currency	7

Overview

Chapter 2 of this Rider's Manual will provide you with an initial overview of your motorcycle. All maintenance and servicing work on the motorcycle is documented in Chapter 10. This record of the maintenance work you have had performed on your motorcycle is a precondition for generous treatment of goodwill claims.

When the time comes to sell your BMW, please remember to hand over this Rider's Manual; it is an important part of the motorcycle.

Abbreviations and symbols

 Indicates warnings that you must comply with for reasons of your safety and the safety of others, and to pro-

tect your motorcycle against damage.

 Specific instructions on how to operate, control, adjust or look after items of equipment on the motorcycle.

◀ Indicates the end of an item of information.

• Instruction.

» Result of an activity.

 Reference to a page with more detailed information.

◁ Indicates the end of a passage relating to specific accessories or items of equipment.

 Tightening torque.



Item of technical data.

OE Optional extra
Your motorcycle was assembled complete with all the BMW optional extras you ordered.

OA Optional accessory
You can obtain optional accessories through your authorised BMW Motorrad dealer; optional accessories have to be retrofitted to the motorcycle.

EWS Electronic immobiliser (Elektronische Wegfahrsicherung).

DWA Anti-theft alarm (Diebstahlwarnanlage)

- ABS Anti-lock brake system
- ESA Electronic Suspension Adjustment
Electronic Suspension Adjustment.
- RDC Tyre pressure control
(ReifenDruck-Control)
- ASC Automatic Stability Control.

Equipment

When you ordered your BMW motorcycle, you chose various items of custom equipment. This Rider's Manual describes optional extras (OE) offered by BMW and selected optional accessories (OA). This explains why the manual may also contain descriptions of equipment which you have not ordered. Please note, too, that your motorcycle might

not be exactly as illustrated in this manual on account of country-specific differences. If your BMW was supplied with equipment not described in this Rider's Manual, you will find these features described in separate manuals.

Technical data

All dimensions, weights and power ratings stated in the Rider's Manual are quoted to the standards and comply with the tolerance requirements of the Deutsche Institut für Normung e.V. Versions for individual countries may differ.

Currency

The high safety and quality standards of BMW motorcycles are maintained by constant development work on designs, equipment and accessories. Because of this,

your motorcycle may differ from the information supplied in the Rider's Manual. Nor can BMW Motorrad entirely rule out errors and omissions. We hope you will appreciate that no claims can be entertained on the basis of the data, illustrations or descriptions in this manual.

General views

General view, left side	11
General view, right side	13
Underneath the seat	15
Handlebar fitting, left	16
Handlebar fitting, right	17
Instrument cluster	18
Headlight	19




General view, left side

- 1 Adjuster for headlight beam throw underneath the instrument cluster (➡ 63)
- 2 Brake-fluid reservoir (➡ 109)
- 3 Radio operating panel (OE), see instructions for use for radio
- 4 Power socket (➡ 96)
- 5 On-board socket (OE)
- 6 Adjuster, rear shock absorber (➡ 72)
- 7 Oil sight glass (➡ 105)
- 8 Filler neck, engine oil (➡ 106)



General view, right side

- 1 Seat lock (⇒ 66)
- 2 Switch, rear-seat heating, underneath the rear seat^{OE} (⇒ 59)
- 3 Mount for tank rucksack (OA)
- 4 Filler neck, fuel tank (⇒ 86)
- 5 Clutch-fluid reservoir
- 6 Electrically adjustable windscreen (⇒ 70)
- 7 Stowage compartment or radio compartment (⇒ 64)





Underneath the seat

- 1 Height adjuster, front seat (➡ 67)
- 2 Battery (➡ 132)
- 3 Brake-fluid reservoir, rear (➡ 110)
- 4 Adjuster, spring preload, rear (➡ 70)
- 5 Toolkit (➡ 104)
- 6 Type plate
- 7 Helmet holder (➡ 69)
- 8 Table of tyre pressures
- 9 Label, payload

Handlebar fitting, left

- 1 Switch, cruise-control system^{OE} (➔ 54)
- 2 Pushbutton, ASC^{OE} (➔ 65)
- 3 Radio operating unit (OE)
- 4 Pushbutton, ESA^{OE} (➔ 73)
- 5 Pushbutton, windscreen (➔ 70)
- 6 Pushbutton, horn
- 7 Pushbutton, left flashing turn indicators (➔ 63), Pushbutton, hazard warning flashers (➔ 46)
- 8 Switch, high-beam headlight and headlight flasher (➔ 61)






Handlebar fitting, right


- 1 Pushbutton, on-board computer^{OE} (➔ 50)
- 2 Emergency off switch (kill switch) (➔ 57)
- 3 Pushbutton, starter
- 4 Grip heating switch^{OE} (➔ 57)
- 5 Pushbutton, right flashing turn indicators (➔ 63), Pushbutton, hazard warning flashers (➔ 46)
- 6 Cancel button, flashing turn indicators (➔ 64), Pushbutton, cancel hazard warning flashers (➔ 47)
- 7 Front-seat heating switch^{OE} (➔ 58)

Instrument cluster

- 1 Speedometer
- 2 Warning and telltale lights (⇒ 24)
- 3 Multifunction display
- 4 Rev. counter
- 5 Telltale light, anti-theft alarm (OE)
- 6 Adjuster, clock (⇒ 49), Display dimmer (⇒ 48)
- 7 Control, odometer (⇒ 47)
- 8 Sensor for instrument cluster lighting

▶ The instrument-cluster lighting has automatic day and night switchover. ◀





Headlight


- 1 High-beam headlight
- 2 Low-beam headlight
- 3 Side lights

Status indicators

Multifunction display	22
Warning and telltale lights	24
ABS warning light	24
Telltale light, cruise control ^{OE}	24
Function indicators	24
Warnings, general	25
Warnings issued by the tyre pressure monitoring system (RDC) ^{OE}	32
ABS warnings	37
ASC warnings ^{OE}	39

Multifunction display

- 1 Fuel gauge (➔ 24)
- 2 Panel for radio (see instructions for use for radio)
- 3 Panel for warnings (➔ 25)
- 4 Gear indicator (➔ 24)
- 5 Engine temperature readout (➔ 24)
- 6 Display, on-board computer^{OE} (➔ 50), Tripmeter (motorcycles without on-board computer) (➔ 47), RDC display (motorcycles without on-board computer)^{OE} (➔ 49)
- 7 Clock (➔ 49), Panel for seat heating^{OE} (➔ 58), Panel for display dimmer (➔ 48), Panel for ESA^{OE} (➔ 73)



- 8** Odometer (motorcycles with on-board computer)
( 47)

Warning and telltale lights




- 1 Telltale light, left turn indicator
- 2 Telltale light, high-beam headlight
- 3 Telltale light, neutral
- 4 ABS warning light
- 5 Telltale light, right turn indicator
- 6 ASC warning light (OE)
- 7 Warning light, general

ABS warning light

The way in which the ABS warning light indicates status can differ in some countries.

brake failure Alternative for the ABS warning light.

Telltale light, cruise control^{OE}



- 1 Telltale light, cruise control

Function indicators

Fuel capacity

 The column below the fuel-pump symbol indicates the remaining quantity of fuel.

Gear

N Shows which gear is engaged.

If no gear is engaged, the gear indicator shows N and the 'neutral' telltale light also lights up.

Engine temperature

 The column below the temperature symbol indicates the engine temperature.

ASC intervention (OE)

 ASC warning light quick-flashes.

The ASC has detected a de-

gree of instability at the rear wheel and has intervened to reduce torque. The warning light flashes for one second longer than ASC intervention lasts. This affords the rider visual feedback on control intervention even after the critical situation has been dealt with.

Warnings, general

Mode of presentation

General warnings are displayed by means of plain-text messages and symbols in the multifunction display. In some cases, they are accompanied by the 'General' warning light showing red or yellow. If two or more warnings occur at the same time, all the appropriate warning lights and warning symbols appear.

Warnings, overview

Mode of presentation

Meaning

	Lights up yellow		The EWS ! warning appears on the display.	Electronic immobiliser active (⇒ 28)
	Lights up yellow		Flashes	Fuel down to reserve (⇒ 28)
	Lights up yellow		Appears on the display	Engine electronics (⇒ 28)
	Flashes red		Appears on the display	Insufficient engine oil pressure (⇒ 29)
			Shows accompanied by the Oil warning	Engine-oil level too low (⇒ 29)
	Lights up red		Appears on the display	Insufficient battery charge current (⇒ 30)
	Lights up yellow		Appears on the display	Rear light bulb defective (⇒ 30)
			Appears on the display	Front light bulb defective (⇒ 31)
	Lights up yellow		Appears on the display	Bulbs defective (⇒ 31)

Mode of presentation

Meaning

		Flashes with temperature reading	Ice warning (➡ 31)
		Appears on the display, accompanied by the letters DWA.	Battery of anti-theft alarm (OE) weak (➡ 32)
 Lights up yellow		Appears on the display, accompanied by the letters DWA.	Anti-theft alarm battery flat (OE) (➡ 32)

Electronic immobiliser active

 General warning light lights up yellow.

The EWS ! warning appears on the display.

The key being used is not authorised for starting, or communication between key and engine electronics is disrupted.

- Remove all other vehicle keys from the same ring as the ignition key.
- Use the reserve key.
- Have the defective key replaced, preferably by an authorised BMW Motorrad dealer.

Fuel down to reserve


 General warning light lights up yellow.

 Symbol for fuel down to reserve flashes.

 Lack of fuel can result in the engine misfiring and cutting out unexpectedly. Misfiring can damage the catalytic converter; a hazardous situation can result if the engine cuts out unexpectedly. Do not run the fuel tank dry. ◀

 The estimated residual range appears on the display. ◀

The fuel tank contains no more than the reserve quantity of fuel.



- Refuelling (➔ 86)

Engine electronics

 General warning light lights up yellow.

 Engine electronics symbol appears on the display.

 The engine is running in emergency operating mode. Engine power might be reduced and this can cause hazardous situations, particularly if you attempt to overtake other road users. Engine power level might be lower than normal: adapt your style of riding accordingly. ◀

The engine electronics control unit has diagnosed a fault. In exceptional cases, the engine stops and refuses to start. Otherwise, the engine runs in emergency operating mode.

- You can continue to ride, but bear in mind that the

usual engine power might not be available.

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Insufficient engine oil pressure



General warning light flashes red.



Engine oil pressure symbol appears on the display.

The oil pressure in the lube-oil system is too low. Stop immediately and switch off the engine if the warning light shows.



The insufficient oil pressure warning does not fulfil the function of an oil gauge. The only way of checking whether the oil level

is correct is to check the oil sight glass. ◀

A low oil level is one reason why a warning indicating insufficient oil pressure is issued.

- Checking the engine oil level (➡ 105)

If the oil level is too low:

- Top up the engine oil.

If the warning indicating insufficient engine oil level is issued and a check indicates that the engine oil level is correct:



Other engine problems besides a low oil level can cause the insufficient engine oil pressure warning to be issued. Continuing to ride in these cases can cause engine damage.

If this warning is issued even though the engine oil level is

correct: do not continue to ride. ◀

- Do not continue your journey.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Engine-oil level too low



Shows accompanied by the Oil warning

The electronic oil-level sensor has registered an excessively low oil level.

The only exact way of checking whether the oil level is correct is to check the oil sight glass. The next time you stop for fuel:

- Checking the engine oil level (➡ 105)

If the oil level is too low:

- Topping up the engine oil (➔ 106)

The oil sensor might be defective if the "Check oil level" message appears even though a check at the oil sight glass reveals that the oil level is correct.

- Checking the engine oil level (➔ 105)

If the oil level is too low:

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.

Insufficient battery charge current

 General warning light lights up red.

 Battery charge current symbol is displayed.

 A discharged battery can cause the engine to die suddenly, and this could result in a dangerous situation in traffic.

Have faults rectified as soon as possible.◀

 If the battery is not charging, continuing to ride can cause it to discharge completely, in which case it will suffer irreparable damage. If possible, do not continue your journey.◀

Battery is not being charged.

- You can continue to ride until the battery is discharged. Bear in mind, however, that the engine could cut out suddenly and that the battery could discharge until completely flat, in which case it might have suffered irreparable damage.

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Rear light bulb defective

 General warning light lights up yellow.

 Defective bulb symbol with arrow pointing to the rear appears on the display.

 A defective bulb places your safety at risk because it is easier for other users to oversee you and your motorcycle.

Replace defective bulbs as soon as possible; always carry a complete set of spare bulbs if possible.◀

Rear light or brake light bulb defective.

- Replacing brake-light, rear light and rear-indicator bulbs (⇒ 127)

Front light bulb defective

 Defective bulb symbol with arrow pointing to the front appears on the display.

 A defective bulb places your safety at risk because it is easier for other users to oversee you and your motorcycle.

Replace defective bulbs as soon as possible; always carry a complete set of spare bulbs if possible. ◀

Low-beam headlight, high-beam headlight, side-light or turn-indicator bulb defective.

- Replacing high-beam headlight bulb (⇒ 121)

- Replacing left low-beam headlight bulb (⇒ 122)
- Replacing right low-beam headlight bulb (⇒ 122)
- Replacing parking-light bulb (⇒ 125)
- Replacing front turn indicator bulb (⇒ 129)

Bulbs defective

 General warning light lights up yellow.

 Defective bulb symbol with two arrows appears on the display.

 A defective bulb places your safety at risk because it is easier for other users to oversee you and your motorcycle.

Replace defective bulbs as soon as possible; always carry a complete set of spare bulbs if possible. ◀

A combination of the bulb defects described above has occurred.

- See the fault descriptions above.

Ice warning

 Ice warning symbol flashes with the temperature reading.

The air temperature measured at the motorcycle is lower than 3 °C.

 The ice warning does not mean that there is no risk of black ice forming at measured temperatures above 3 °C.

Always take extra care and think well ahead when temperatures are low; remember that the danger of black ice is particularly high on bridges and where the road is in the shade. ◀

- Ride carefully and think well ahead.

Battery of anti-theft alarm (OE) weak

 Battery symbol appears on the display, accompanied by the letters DWA.

 This error message appears only briefly after the pre-ride check completes. ◀

The integral battery in the anti-theft alarm has lost a significant proportion of its original capacity. There is no assurance of how long the anti-theft alarm can remain operational if the motorcycle's battery is disconnected.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.

Anti-theft alarm battery flat (OE)

 General warning light lights up yellow.

 Battery symbol appears on the display, accompanied by the letters DWA.

 This error message appears only briefly after the pre-ride check completes. ◀

The integral battery in the anti-theft alarm has lost its entire original capacity. There is no assurance that the anti-theft alarm will be operational if the motorcycle's battery is disconnected.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.

Warnings issued by the tyre pressure monitoring system (RDC)^{OE}

Display mode for RDC warnings



The tyre pressure for the front wheel **3** and the tyre pressure for the rear wheel **2** appear in the top line of the display, accompanied by warning symbol **1**. The critical tyre pressure flashes.

If the critical value is close to the limit of the permissible tol-

erance range, the reading is accompanied by the 'General' warning light showing yellow. If the tyre pressure registered by the sensor is outside the permissible tolerance range, the 'General' warning light flashes red.

 If the motorcycle does not have an on-board computer this reading appears where the odometer reading is normally displayed. ◀

Warnings, overview

Mode of presentation

Meaning

	Lights up yellow		The critical tyre pressure flashes	Tyre pressure close to limit of permitted tolerance (➡ 35)
	Flashes red		The critical tyre pressure flashes	Tyre pressure outside permitted tolerance (➡ 35)
			"--" or "-- --" appears on the display	Signal transmission disrupted (➡ 36)
	Lights up yellow		Indicated by "--" or "-- --"	Sensor defective or system error (➡ 36)
	Lights up yellow		Indicated by the letters RDC appearing on the display.	Tyre-pressure sensor battery weak (➡ 37)

Tyre pressure close to limit of permitted tolerance



General warning light lights up yellow.



The critical tyre pressure flashes.

Measured tyre pressure is close to the limit of permitted tolerance.

- Correct the tyre pressure as stated on the inside cover of the Rider's Manual.



The tyre-pressures listed on the inside cover are temperature-compensated; the reference tyre temperature for these readings is always 20 °C. The procedure for correctly tyre pressures when the tyres are not at this reference temperature is as follows:

Calculate the difference between the specified value stated in the Rider's Manual

and the reading shown by the RDC system. Use the public air line at a petrol station or motorway service area to adjust the tyre pressure by this amount.◀

Tyre pressure outside permitted tolerance



General warning light flashes red.



The critical tyre pressure flashes.

Measured tyre pressure is outside permitted tolerance.

- Check the tyre for damage and to ascertain whether the motorcycle can be ridden with the tyre in its present condition.

If the motorcycle can be ridden with the tyre in its present condition:



Incorrect tyre pressures impair the motorcycle's handling characteristics. If tyre pressure is incorrect it is essential to adapt your style of riding accordingly.◀

- Correct the tyre pressure at the earliest possible opportunity.
- Have the tyre checked for damage by a specialist workshop, preferably an authorised BMW Motorrad dealer.

If you are unsure whether the motorcycle can be ridden with the tyre in its present condition:

- Do not continue your journey.
- Notify the breakdown service.
- Have the tyre checked for damage by a specialist workshop, preferably an

authorised BMW Motorrad dealer.

Signal transmission disrupted

"--" or "-- --" appears on the display.

The motorcycle has not yet accelerated past the threshold of approximately 30 km/h. The RDC sensors do not start transmitting signals until the motorcycle reaches a speed above this threshold (➔ 87).

- Increase speed above this threshold observe the RDC readings. Assume that a permanent fault has not occurred unless the 'General' warning light comes on to accompany the symptoms. Under these circumstances:
- Have the fault rectified by a specialist workshop, prefer-

ably an authorised BMW Motorrad dealer.

Wireless communication with the RDC sensors has been disrupted. Possible causes include radio-communication systems operating in the vicinity and interfering with the link between the RDC control unit and the sensors.

- Move to another location and observe the RDC readings. Assume that a permanent fault has not occurred unless the 'General' warning light comes on to accompany the symptoms. Under these circumstances:
- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Sensor defective or system error



General warning light lights up yellow.



Indicated by "--" or "-- --".

Motorcycle is fitted with tyres not equipped with RDC sensors.

- Fit wheels and tyres equipped with RDC sensors.
- One or two RDC sensors have failed.
- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.

A system error has occurred.

- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Tyre-pressure sensor battery weak



General warning light lights up yellow.



Indicated by the letters RDC appearing on the display.



This error message appears only briefly after the pre-ride check completes. ◀

The integral battery in the tyre-pressure sensor has lost a significant proportion of its original capacity. There is no assurance of how long the tyre pressure control system can remain operational.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.

ABS warnings

Mode of presentation

ABS warnings are indicated by a combination of the general warning light and the ABS warning light. Both warning lights can light up continuously or flash at a rate of one or four flashes per second. There are two country-dependent versions of the ABS warning light:



Version 1.



Version 2.

Version 1 is used as the basis for the description of the warnings in this section.

Warnings, overview

Mode of presentation

Meaning



Flashes

Self-diagnosis not completed
(➡ 39)



Lights up

ABS fault (➡ 39)

Self-diagnosis not completed



ABS warning light flashes.

The ABS function is not available, because self-diagnosis did not complete. The motorcycle has to move forward a few metres for the wheel sensors to be tested.

- Pull away slowly. Bear in mind that the ABS function is not available until self-diagnosis has completed.

ABS fault



ABS warning light ON.

The ABS control unit has detected a fault. The ABS function is not available.

- You can continue to ride. Bear in mind that the ABS function is not available. Bear in mind the more de-

tailed information on situations that can lead to an ABS fault (➡ 91).

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

ASC warnings^{OE}

Mode of presentation



ASC warnings are indicated by the ASC warning light. The ASC warning light can show continuously or flash.

Warnings, overview

Mode of presentation

Meaning

	Slow-flashes	Self-diagnosis not completed (➡ 41)
	Lights up	ASC fault (➡ 41)
	Lights up	ASC switched off (➡ 41)

Self-diagnosis not completed



ASC warning light slow-flashes.

Self-diagnosis did not complete, so the ASC function is not available. The engine must be running and the motorcycle must reach a speed of at least 5 km/h in order for ASC self-diagnosis to complete.

- Pull away slowly. Bear in mind that the ASC function is not available until self-diagnosis has completed.

ASC fault



ASC warning light shows.

The ASC control unit has detected a fault. The ASC function is not available.

- You can continue to ride. Bear in mind that the ASC

function is not available. Bear in mind the more detailed information on situations that can lead to an ASC fault (➡ 93).

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

ASC switched off



ASC warning light shows.

The rider has switched off the ASC system. with OE Automatic Stability Control (ASC):

- Activate the ASC function (➡ 65)

Operation

Ignition switch and steering lock.....	44	Brakes	60
Electronic immobiliser (EWS) ...	45	Lights	61
Hazard warning flashers	46	Headlight	62
Odometer and tripmeters	47	Turn indicators	63
Multifunction display	48	Stowage compartment	64
Clock	49	Automatic Stability Control ASC ^{OE}	65
Tyre pressure control RDC ^{OE} ..	49	Front and rear seats	66
Residual range	50	Helmet holder	69
On-board computer ^{OE}	50	Mirrors	70
Cruise-control system ^{OE}	54	Windscreen	70
Emergency off switch (kill switch)	57	Spring preload	70
Grip heating ^{OE}	57	Shock absorbers	71
Seat heating ^{OE}	58	Electronic Suspension Adjustment ESA ^{OE}	73
Clutch	60	Tyres	74

Ignition switch and steering lock

Keys

You receive one master key and one spare key. Please consult the information on the electronic immobiliser (EWS) if a key is lost or mislaid (➡ 45).

▶ Ignition switch and steering lock, tank filler cap lock and the seat and case locks are all operated with the same key. On request, the topcase available as an optional accessory can be arranged to lock with the same key. ◀

Switching on ignition




- Turn the key to position **1**.
 - » Side lights and all function circuits switched on.
 - » Engine can be started.
 - » Pre-ride check is performed. (➡ 81)
 - » ABS self-diagnosis is performed. (➡ 82)

with OE Automatic Stability Control (ASC):

- Turn the key to position **1**.
 - » ASC self-diagnosis is performed in addition to

the checks outlined above. (➡ 82) ◀

Switching off ignition




⚠ Brake servo assistance is not available when the ignition is off. Do not switch off the ignition when riding. ◀

- Turn the key to position **2**.
 - » Lights switched off.
 - » Handlebars not locked.
 - » Key can be removed.
 - » Electrically powered accessories remain opera-

tional for a limited period of time.

- » The battery can be recharged via the on-board socket.

Locking handlebars



! If the motorcycle is on the side stand, the surface of the ground will determine whether it is better to turn the handlebars to the left or right. However, the motorcycle is more stable on a level surface with the handlebars turned to the left than

with the handlebars turned to the right.

On level ground, always turn the handlebars to the left to set the steering lock. ◀

- Turn the handlebars to the full left or right lock position.
- Turn the key to position **3**, while moving the handlebars slightly.
 - » Ignition, lights and all function circuits switched off.
 - » Handlebars locked.
 - » Key can be removed.

Electronic immobiliser (EWS)

Protection against theft

The electronic immobiliser helps protect your BMW motorcycle from theft, and this enhanced security is at your disposal without any need for you to set parameters or activate additional systems. The

engine of a motorcycle fitted with this electronic immobiliser can be started only with the keys that belong to the vehicle. You can also have your authorised BMW Motorrad dealer bar individual keys, for example if a particular key goes missing. The engine cannot be started with a key that has been barred.

In-key electronics

An electronic component is integrated into each of your keys. The motorcycle's electronics exchange certain continuously changing signals with the electronics in the key; these signals are specific to your motorcycle and they are transmitted via the ring aerial in the ignition lock. The ignition is not enabled for starting until the key has been

recognised as "authorised" for your motorcycle.

▶ A spare key attached to the same ring as the ignition key used to start the engine could "irritate" the electronics, in which case the enabling signal for starting is not issued. The EWS warning appears in the multifunction display.

Always keep the spare key separately from the ignition key. ◀

Replacement and extra keys


You can obtain replacement/extra keys only through an authorised BMW Motorrad dealer. The keys are part of an integrated security system, so the dealer is under an obligation to check the legitimacy of all applications for replacement/extra keys. If

you want to have a lost key barred, you have to bring with you all the other keys that belong to the motorcycle. A key that has been barred can subsequently be cleared and reactivated for use.

Hazard warning flashers

Switching on hazard warning flashers

- Switch on the ignition.



- Simultaneously press button **1** for left turn indicators

and button **2** for right turn indicators.


▶ The hazard warning flashers place a strain on the battery. Do not use the hazard warning flashers for longer than absolutely necessary. ◀

▶ If you press a turn-indicator button with the ignition switched on, the turn-indicator function is activated instead of the hazard warning flashers, and remains active until you release the button. The hazard warning flashers recommence flashing as soon as the button is released. ◀

- » Hazard warning flashers in operation.
- » Left/right turn indicator tell-tale lights flash.
- Switch off the ignition.
- » The hazard warning flashers continue to operate.

- » Left/right turn indicator tell-tale lights off.

Switching off hazard warning flashers



- Press cancel button **1**.
- » Hazard warning flashers switched off.

Odometer and tripmeters

Odometer




The odometer reading appears in display field **1**.

Selecting tripmeter

- Switch on the ignition.

▶ When you switch on the ignition, the tripmeter reading shown when the ignition was switched off always reappears on the multifunction display. ◀



- Briefly press tripmeter button **1** once to proceed to each subsequent step in the cycle.



If the motorcycle has an on-board computer these read-

ings alternate in the panel for the odometer:

- Tripmeter 1 (Trip I)
- Tripmeter 2 (Trip II)
- Total distance covered




If the motorcycle does not have an on-board computer these readings alternate in the panel for the tripmeter:

- Tripmeter 1 (Trip I)
- Tripmeter 2 (Trip II)
- Residual range once fuel level is down to reserve

- Tyre pressures (OE) for motorcycles without on-board computer

Resetting tripmeter

- Switch on the ignition.
- Select the desired tripmeter.



- Press and hold down tripmeter button **1** until the reading changes.
- » The tripmeter is reset to zero.

Multifunction display

Adjusting dimmer



 Attempting to adjust the dimmer while riding the motorcycle can lead to accidents.

Do not attempt to adjust the dimmer unless the motorcycle is at a standstill. ◀

- Press button **1**.
- » The level of dimming appears in display field **2**.
- Press button **1** again.
- » The brightness of the display increases one level

each time you press the button. Each time you press the button after maximum brightness is reached, brightness is reduced by one level.

Clock


Setting clock



Attempting to set the clock while riding the motorcycle can lead to accidents.

Set the clock only when the motorcycle is stationary. ◀

- Switch on the ignition.



- Press and hold down button **1** until the reading changes.
 - » Hours reading **3** starts to flash.
- Press button **1**.
 - » The hour increments by one each time you press the button.
- Press and hold down button **1** until the reading changes.
 - » Minutes reading **2** starts to flash.
- Press button **1**.

» The minute increments by one each time you press the button.

- Press and hold down button **1** until the reading changes.
 - » The reading stops flashing.
 - » The time is now set.

Tyre pressure control RDC^{OE}

Viewing tyre-pressure readings

- Switch on the ignition.



- Repeatedly press BC button **1** until the tyre pressures appear in the display.



The tyre pressures are displayed as an additional set of readings by the on-board computer. The front tyre

pressure is on the left; the reading on the right is the rear tyre pressure. If your motorcycle is not fitted with an on-board computer, the tyre-pressure readings and the odometer readings alternate.

Residual range



The residual-range readout **1** indicates how far you can ride with the fuel remaining in the tank. On a motorcycle not equipped with an on-board computer, this reading is not displayed until fuel level has


dropped to reserve. This distance is calculated on the basis of fuel level and average consumption.

When you refuel, the increase in fuel level is not registered unless several litres are added to the fuel already in the tank.

▶ The residual range is only an approximate reading. Consequently, BMW Motorrad recommends that you should not try to use the full residual range before refuelling.◀

On-board computer^{OE} Selecting readings

- Switch on the ignition.



- Press BC button **1** once.



The on-board computer's display field starts with the current value and cycles through the following sequence:

- Ambient temperature

- Range
- Average speed
- Average consumption
- Oil level
- Tyre pressures (OE)

Ambient temperature



Ambient-temperature display **1** is active only when the engine is running; at other times the display shows --.

 An ice warning appears if the ambient-temperature reading drops below 3 °C. The display automatically switches

from any other mode to the temperature reading when the temperature drops below this threshold for the first time. The reading flashes until you select some other display mode.

Range



The description of the residual-range function (→ 50) also covers the residual-range readout. You can also view range **1** before the fuel level drops to reserve. A special average-consumption figure

is used to calculate range; this figure is not necessarily the same as the value you can call up for viewing on the display.


▶ The calculated range is only an approximate reading. Consequently, BMW Motorrad recommends that you should not try to use the full range before refuelling.◀

Calculating average speed



Average speed **1** is calculated on basis of the time elapsed since the last RESET. Times during which the engine was stopped are excluded from the calculation.

Resetting average speed




- Repeatedly press BC button **1** until the average speed appears in the display.
- Press and hold down the BC button until the reading changes (RESET).
 - » The display shows "--- km/h".

Calculating average consumption



Average consumption **1** is calculated by dividing the distance covered since the last RESET by the corresponding amount of fuel used.

Resetting average consumption



- Repeatedly press BC button **1** until the average fuel consumption appears in the display.
- Press and hold down the BC button until the reading changes (RESET).
- » The display shows "--.- l/100 km".

Oil level



The "Oil" reading gives you an indication of the engine oil level. You can call up this reading only when the motorcycle is at a standstill.

The preconditions for automatic registration of the oil level are as follows:

- Engine idling for at least 30 seconds.
- Engine at operating temperature.
- Make sure the motorcycle is upright.

The readings mean:



Oil level is correct



Check the oil level with the dipstick the next time you stop for fuel. If you call up another reading on the on-board computer, this symbol remains visible beside the BC line.



Oil level cannot be measured (conditions as stated above not satisfied).

The most recently measured level is displayed for 5 seconds when you next switch on the ignition.




The oil sensor might be defective if the "Check oil level" message reappears even though the oil level in the oil sight glass is correct. In this case, consult your

authorised BMW Motorrad dealer. ◀


Cruise-control system^{OE}

Switching on cruise control




- Move switch **1** to ON.
- » Telltale light **2** in the switch lights up red.

Setting road speed




- Briefly push button **3** in the SET direction
- SET** Cruise control telltale light shows.
- » The motorcycle maintains your current cruising speed and the setting is saved.

Step-by-step acceleration




- Briefly push button **3** in the SET direction
- » Speed is increased by approx. 2 km/h each time you push the button, and the new setting is saved.

Stepless acceleration




- Push button **3** in the SET direction and hold it in this position.
- » The motorcycle accelerates steplessly.
- Release button **3**.
- » The motorcycle maintains your current cruising speed and the setting is saved.

Step-by-step deceleration



- Briefly push button **3** in the RES direction
- » Speed is decreased by approx. 2 km/h each time you push the button, and the new setting is saved.
- Release button **3**.
- » The motorcycle maintains your current cruising speed and the setting is saved.

Stepless deceleration




- Push button **3** in the RES direction and hold it in this position.
- » The motorcycle decelerates steplessly.
- Release button **3**.
- » The motorcycle maintains your current cruising speed and the setting is saved.

Deactivating cruise control

- Apply the brakes or pull the clutch or close the throttle

- (turn the throttle twistgrip back past the idle position).
- » The cruise-control system is deactivated.
 - » The cruise control telltale light goes out.
 - » The telltale light in the switch remains on.

Resuming former cruising speed



- Push button **3** in the RES direction.


 Opening the throttle does not deactivate the cruise-control system. If

you release the twistgrip the motorcycle will decelerate only to the cruising speed saved in memory, even though you might have intended slowing to a lower speed. ◀

 Cruise control telltale light shows.

- » The motorcycle resumes the previous cruising speed.


Switching off cruise control



- Move switch **1** to OFF.

- » The system is deactivated.
- » Button **3** is locked.


Emergency off switch (kill switch)



1 Emergency off switch (kill switch)

 Operating the kill switch when riding can cause the rear wheel to lock and thus cause a fall. Do not operate the kill switch when riding. ◀

The emergency off switch is a kill switch for switching off the engine quickly and easily.




- A** Normal operating position (run)
- B** Engine switched off.

 You cannot start the engine unless the kill switch is in the run position. ◀

 If you move the kill switch away from the RUN position while the ignition is switched on, the BMW Motorrad Integral ABS remains operational. ◀


Grip heating^{OE}



1 Grip heating switch

The handlebar grips have two-stage heating. Grip heating can be activated only when the engine is running.

 The increase in power consumption caused by the grip heating can drain the battery if you are riding at low engine speeds. If the charge level is low, grip heating is switched off to ensure the battery's starting capability. ◀



- 2 Heating off.
- 3 50 % heat output (one dot visible).
- 4 100 % heat output (three dots visible)

Seat heating^{OE}

Dependency on battery charge state


Seat heating can be activated only when the engine is running. If the charge level is low, the heating is switched off to ensure the battery's starting capability.

Seat heating, front seat




- 1 Switch for seat heating, front seat

The front seat has two-stage heating.




- 2 Heating off.
- 3 50% heating power
- 4 100% heating power

Seat heating, rear seat



- 1** Switch for seat heating, rear seat

The rear seat has two-stage heating.



- 2** Switch centred: Heating off.
3 Switch pushed back: 50% heating power.
4 Switch pushed forward: 100% heating power.

Indicator in multifunction display

- Switch on the front-seat or rear-seat heating.



The symbols shown below appear on the display to indicate which heating stage has been selected:

-  Front seat, 50 % heating power
-  Front seat, 100 % heating power
-  Rear seat, 50 % heating power
-  Rear seat, 100 % heating power

Clutch

Adjusting clutch lever

The distance between handlebar grip and clutch lever can be adjusted to any of three positions.


Adjusting clutch lever

! If the position of the clutch fluid reservoir is changed, air can enter the clutch system.

Do not twist the handlebar fitting or the handlebars. ◀

! Attempting to adjust the clutch lever while riding the motorcycle can lead to accidents.

Do not attempt to adjust the clutch lever unless the motorcycle is at a standstill. ◀



- Turn adjuster **A** to position **1**:
 - » smallest span.
- Turn adjuster **A** to position **3**:
 - » largest span.

Brakes

Adjusting handbrake lever

The distance between handlebar grip and handlebar lever can be adjusted to any of four positions.


Adjusting handbrake lever

! Changing the position of the brake-fluid reservoir can allow air to penetrate the brake system.

Do not twist the handlebar fitting or the handlebars. ◀

! Attempting to adjust the brake lever while riding the motorcycle can lead to accidents.

Do not attempt to adjust the brake lever unless the motorcycle is at a standstill. ◀



▶ The side lights place a strain on the battery. Do not switch the ignition on for longer than absolutely necessary. ◀

Switching on the low-beam headlight

The low-beam headlight switches on automatically when you start the engine.

▶ When the engine is not running you can switch on the lights by switching on the ignition and either switching on the high-beam headlight or operating the headlight flasher. ◀

- Turn adjuster **A** to position **1**:
 - » smallest span.
- Turn adjuster **A** to position **4**:
 - » largest span.

Lights

Switching on the side lights

The side lights switch on automatically when the ignition is switched on.

Switching on high-beam headlight



- Press the top section of switch **1** for the high-beam headlight.
 - » High-beam headlight switched on.
- Move switch **1** for the high-beam headlight to the centre position.
 - » High-beam headlight switched off.
- Press the bottom section of switch **1** for the high-beam headlight.

» The high-beam headlight is switched on until you release the button (headlight flasher).

Switching on parking lights

- Switch off the ignition.

 You can switch on the parking lights only immediately after switching off the ignition. ◀



- Press and hold down button **1** for the left turn indic-

ators until the parking lights are ON.

Switching off parking lights

- Switch on the ignition.
- » Parking lights switched off.

Headlight

Adjusting headlight for driving on left/driving on right

If the motorcycle is ridden in a country where the opposite rule of the road applies, its asymmetric low-beam headlight will tend to dazzle oncoming traffic.

Have the headlight set accordingly by a specialist workshop, preferably an authorised BMW Motorrad dealer.



Commercially available adhesive tape will damage the plastic lens of the light.

Consult a specialist workshop, preferably an authorised BMW Motorrad dealer, in order to avoid damaging the plastic lens of the light. ◀

Headlight beam throw and spring preload

Headlight beam throw is generally kept constant when spring preload is adjusted to suit load.

Spring preload adjustment might not suffice only if the motorcycle is very heavily loaded. Under these circumstances, headlight beam throw has to be adjusted to suit the weight carried by the motorcycle.


▶ Consult a specialist workshop, preferably an authorised BMW Motorrad dealer, if you are unsure whether the headlight basic setting is correct. ◀

Headlight beam-throw adjustment



1 Headlight beam-throw adjustment

Moving the pivot lever adjusts headlight beam throw so as not to dazzle oncoming traffic.



- A Position for heavy load
- B Normal position

Turn indicators

Switching on left flashing turn indicators

- Switch on the ignition.



- Press left-hand turn indicator or button 1.

▶ The turn indicators are cancelled automatically after you have ridden for approximately 10 seconds, or covered a distance of about 200 m. ◀

- » Left-hand turn indicators switched on.
- » Telltale light for left-hand turn indicators flashes.

Switching on right flashing turn indicators

- Switch on the ignition.




- Press right-hand turn indicator button **2**.

▶ The turn indicators are cancelled automatically after you have ridden for approximately 10 seconds, or covered a distance of about 200 m.◀

- » Right-hand turn indicators switched on.
- » Telltale light for right-hand turn indicator flashes.

Cancelling turn indicators



- Press cancel button **3**.
 - » Flashing turn indicators switched off.
 - » Turn indicator telltale light is off.

Stowage compartment

Stowage compartment in right side panel

The stowage compartment is integrated into the right side panel and opens with the ignition key.

Opening stowage compartment



- Use the ignition key to turn lock barrel **1** to right angles with the forward direction of travel.

- » Lock of the stowage compartment unlocked.
- Push the lock barrel in.
- » The lid opens.

Closing stowage compartment



- Snap the lid of the compartment closed and push it down.
- » The lock engages with an audible click.
- Use the ignition key to turn the lock barrel in line with the forward direction of travel.

- » Lock of the stowage compartment locked.

Automatic Stability Control ASC^{OE}

Deactivating ASC function

- Switch on the ignition.

 You have the option of deactivating the ASC function while the motorcycle is on the move. ◀



- Press and hold down ASC button **1**.

 ASC warning light shows; if self-diagnosis has not completed the ASC warning light changes from flashing to ON.

- When the ASC warning light comes on, release the ASC button within five seconds.
- » The ASC function is deactivated.

 ASC warning light remains ON.

Activating ASC function



- Press and hold down ASC button **1**.

 ASC warning light goes out; if self-diagnosis has not completed the ASC warning light changes from ON to flashing.

- When the ASC warning light goes out, release the ASC button within five seconds.
- » The ASC warning light remains off.
- » If ASC self-diagnosis did not complete, the ASC warning light continues to flash.
- » The ASC function is activated.
- Instead of pressing the ASC button, you have the option of switching the ignition off and then on again.

 An ASC fault has occurred if the ASC warning light shows when the motorcycle accelerates to a speed in excess of 10 km/h after the ignition was switched off and then on again.◀


Front and rear seats

Remove the rear seat

- Make sure the ground is level and firm and place the motorcycle on its stand.




- Turn the key counter-clockwise in the seat lock.



- At the same time, press down on the rear seat.
- Lift the seat at the rear and release the key.

with OE Seat heating:



- Disconnect plug 1.◀




- Pull the seat to the rear to release it from its holders.



- Lift the rear of the front seat.

with OE Seat heating:




- Disconnect plug **2**.
- Lift the seat up to remove.

Front-seat adjustment

The front seat can be raised or lowered to either of two positions.

Adjusting front seat

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Remove the rear seat (➡ 66)
- Removing front seat (➡ 67)



- Remove seat supporting rod **1** and reinsert it in the appropriate holder.

Removing front seat

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Remove the rear seat (➡ 66)


- Installing front seat (➡ 68)
- Installing rear seat (➡ 68)

Installing front seat

! If too much pressure is applied in the forward direction, there is a danger that the motorcycle will be pushed off its stand.

Always make sure that the motorcycle is stable and firmly supported. ◀


with OE Seat heating:



- Connect plug **2**. ◀



- Push the front seat forward into seat supporting rod **1**. Make sure that the seat is correctly located.



- If you install the seat in the low position, check that the seat's rubber buffers **3** en-

gage the bottom mounts in the frame.




- Firmly press the front seat into the mount.

Installing rear seat

! If too much pressure is applied in the forward direction, there is a danger that the motorcycle will be pushed off its stand.

Always make sure that the motorcycle is stable and firmly supported. ◀

with OE Seat heating:




- Connect plug 1. ◀



- Push the rear seat into the holders in such a way that the tongues engage the corresponding holders.

- Press down firmly at the rear of the seat.
» The seat engages with an audible click.

Helmet holder Helmet holder underneath rear seat



Helmet holder 1 is on the rear right, underneath the rear seat.

Using helmet holder

- Make sure the ground is level and firm and place the motorcycle on its stand.

- Remove the rear seat (➡ 66)




 The helmet catch can scratch the panelling. Make sure the lock is out of the way when you hook the helmet into position. ◀

- Use the wire rope available as an optional extra to secure the helmet to helmet holder 1.
- Installing rear seat (➡ 68)

Mirrors


Adjusting mirrors



- Move the mirror to the desired position by pressing it lightly at the corner.

Windscreen

Adjustable windscreen



The windscreen is steplessly height-adjustable.

Adjusting windscreen



- Switch on the ignition.

- Press the top section of button **1**.
 - » Windscreen higher
- Press the bottom section of button **1**.
 - » Windscreen lower

Spring preload

Spring preload and weight

It is essential to set spring preload to suit the load carried by the motorcycle. Increase spring preload when the motorcycle is heavily loaded and reduce spring preload accordingly when the motorcycle is lightly loaded.

Adjusting spring preload for rear wheel



Your motorcycle's handling will suffer if you do not match the spring-preload

and damping-characteristic settings.


Adjust the damping characteristic to suit spring preload. ◀



Adjusting spring preload while the motorcycle is being ridden can lead to accidents.

Do not attempt to adjust spring preload unless the motorcycle is at a standstill. ◀

- Make sure the ground is level and firm and place the motorcycle on its stand.



- If you want to increase spring preload, turn knob **1** in the direction indicated by the **HIGH** arrow.
- If you want to reduce spring preload, turn knob **1** in the direction indicated by the **LOW** arrow.



Spring preload, basic setting

- Knob at "STD" mark on scale at side (Rider weighing 85 kg, motorcycle fully fuelled)

Shock absorbers


Shock-absorber settings and spring preload

Damping must be adapted to suit spring preload. An increase in spring preload requires firmer damping, a re-

duction in spring preload requires softer damping.

Adjusting rear shock absorber

- Make sure the ground is level and firm and place the motorcycle on its stand.




! Your motorcycle's handling will suffer if you do not match the spring-preload and damping-characteristic settings.

Adjust the damping characteristic to suit spring preload. ◀

! There is a risk of injury by burns if you adjust the damping characteristic while the end silencer is hot. Use a screwdriver extension and wear protective gloves. ◀

- Adjust the rear shock absorber, using a screwdriver to turn adjusting screw **1**.



- If you want a harder damping characteristic, use a screwdriver to turn the adjusting screw in the direction indicated by the H arrow.

- If you want a softer damping characteristic, use a screwdriver to turn the adjusting screw in the direction indicated by the S arrow.



Rear suspension, basic setting

- One-up, rider weighing 85 kg
- Turn the adjusting screw as far as it will go in the direction indicated by the H arrow and then turn it back one and a half turns in the direction indicated by the S arrow.

Electronic Suspension Adjustment ESA^{OE}

Settings



Electronic Suspension Adjustment ESA provides a convenient way of adapting the motorcycle to different conditions.

Three spring preload settings can be combined with three damping characteristics to fine-tune the motorcycle's suspension to the load it carries and the surface over which you want to ride. The damping characteristic is

shown in panel **1** of the multifunction display, and spring preload in panel **2**. The odometer readings are not shown while the ESA readout is active.

Calling up settings

- Switch on the ignition.



- Briefly press button **1**.
 - » The current setting is displayed.
 - » The reading remains visible for a few seconds before disappearing automatically.

Adjusting suspension damping

- Switch on the ignition.



- Briefly press button **1**.
 - » The current setting is displayed.
- Press button **1** once briefly.

The display field starts at the current status and cycles through the following sequence:

comf Comfortable damping characteristic

norm Normal damping characteristic

sport Sporty damping characteristic

- The setting shown on the display is automatically accepted as the damping characteristic if you allow a certain length off time to pass without pressing button **1**. During the setting procedure, the display flashes.

▶ You can adjust the damping characteristic while the motorcycle is on the move.◀

Adjusting spring preload

- Start the engine.



- Briefly press button **1**.
 - » The current setting is displayed.
- Press and hold down button **1** until the reading changes.

The display field starts at the current status and cycles through the following sequence:

 One-up

 One-up with luggage

 Two-up (with luggage)

- Spring preload is adjusted to the setting shown on the display if you do not press button **1** within one second. During the setting procedure, the display flashes.

▶ You cannot adjust spring preload while the motorcycle is on the move.◀

Tyres

Check the tyre pressures

 Incorrect tyre pressures impair the motorcycle's handling characteristics and can lead to accidents. Always check that the tyre pressures are correct.◀

 At high road speeds, tyre valves have a tendency to open as a result of centrifugal force.

In order to avoid a sudden loss of tyre pressure, fit a metal valve cap with rubber sealing ring to the rear tyre and make sure that the cap is screwed on firmly. ◀

 Incorrect tyre pressure reduces the operating life of the tyres.

Always check that the tyre pressures are correct. ◀

- Check tyre pressures against the data below.

 Tyre pressure, front
– 2.2 bar (One-up, tyre cold)
– 2.5 bar (Two-up and/or with luggage, tyre cold)

 Tyre pressure, rear
– 2.5 bar (One-up, tyre cold)
– 2.9 bar (Two-up and/or with luggage, tyre cold)

If tyre pressure is too low:

- Correct tyre pressure.

Riding

Safety instructions	78
Checklist	80
Starting	80
Running in	83
Parking your motorcycle	84
Refuelling	86
Tyre pressure control RDC ^{OE} ..	87
Brake system, general	88
Brake system with BMW Motorrad Integral ABS	89
Electronic engine management with BMW Motorrad ASC ^{OE}	92

Safety instructions

Rider's equipment

Do not ride without the correct clothing. Always wear:

- Helmet
- Motorcycling jacket and trousers
- Gloves
- Boots

This applies even to short journeys, and to every season of the year. Your authorised BMW Motorrad dealer will be glad to advise you on the correct clothing for every purpose.

Speed

If you ride at high speed, always bear in mind that various boundary conditions can adversely affect the handling of your motorcycle:

- Settings of the spring-strut and shock-absorber system
- Imbalanced load
- Loose clothing
- Insufficient tyre pressure
- Poor tyre tread
- Etc.

Correct loading



Overloading and imbalanced loads can adversely affect the motorcycle's handling.

Do not exceed the permissible gross weight and be sure to comply with the instructions on loading. ◀

Alcohol and drugs



Even small amounts of alcohol or drugs will adversely affect your perception and your ability to assess situations and make decisions, and slow down your

reflexes. Medication can exacerbate these effects.

Do not ride your motorcycle after consuming alcohol, drugs and/or medication. ◀

Risk of poisoning

Exhaust fumes contain carbon monoxide, which is colourless and odourless but highly toxic.



Inhaling the exhaust fumes therefore represents a health hazard and can even cause loss of consciousness with fatal consequences.

Do not inhale exhaust fumes. Do not run the engine in an enclosed space. ◀

High voltage

 Touching live parts of the ignition system with the engine running can cause electric shock.

Do not touch parts of the ignition system when the engine is running. ◀

Catalytic converter

If misfiring causes unburned fuel to enter the catalytic converter, there is a danger of overheating and damage.

For this reason, observe the following points:

- Do not run the fuel tank dry.
- Do not attempt to start or run the engine with a spark-plug cap disconnected.
- Stop the engine immediately if it misfires.
- Use only unleaded fuel.
- Comply with all specified maintenance intervals.

 Unburned fuel will destroy the catalytic converter.

Note the points listed for protection of the catalytic converter. ◀

Risk of fire

Temperatures at the exhaust are high.

 Flammable materials (e.g. hay, leaves, grass, clothing and luggage, etc.) could ignite if allowed to come into contact with the hot exhaust pipe.

Do not permit flammable materials to come into contact with the hot exhaust system. ◀

 Cooling would be inadequate if the engine were allowed to idle for a lengthy period with the motorcycle at a standstill: overheating would result.

In extreme cases, the motorcycle could catch fire. Do not allow the engine to idle unnecessarily. Ride away immediately after starting the engine. ◀

Tampering with the control unit of the electronic engine-management system

 Tampering with the control unit of the electronic engine-management system can damage the motorcycle and cause accidents. Do not tamper with the control unit of the electronic engine-management system. ◀

 Tampering with the control unit of the electronic engine-management system can result in mechanical loads that the motorcycle's com-

ponents are not designed to withstand. Damage caused in this way is not covered by the warranty.

Do not tamper with the control unit of the electronic engine-management system. ◀

Checklist

Use the following checklist to check important functions, settings and wear limits before you ride off.

- Brakes
- Brake-fluid levels, front and rear
- Clutch
- Clutch fluid level
- Shock absorber setting and spring preload
- Tyre-tread depth and tyre pressures

- Cases correctly installed and luggage secured

At regular intervals:

- Engine oil level (every refuelling stop)
- Brake-pad wear (every third refuelling stop)

Starting

Side stand


You cannot start the motorcycle with the side stand extended and a gear engaged. The engine will switch itself off if you start it with the gearbox in neutral and then engage a gear before retracting the side stand.

Gearbox

You can start the engine when the gearbox is in neutral or if you pull the clutch with a gear engaged. Do not pull the clutch until after you have

switched on the ignition, as otherwise the engine will refuse to start. When the gearbox is in neutral, the green neutral telltale light is on and the gear indicator in the multifunction display shows N.


Starting engine



- Kill switch **1** in run position **A**.
- Switch on the ignition.
 - » Pre-ride check is performed. (➡ 81)
 - » ABS self-diagnosis is performed. (➡ 82)

with OE Automatic Stability Control (ASC):

- Switch on the ignition.
- » Pre-ride check is performed. (➡ 81)
- » ABS self-diagnosis is performed. (➡ 82)
- » ASC self-diagnosis is performed. (➡ 82)◀



- Press starter button **1**.

▶ If ambient temperatures are very low, you might find it necessary to open the throttle slightly when starting the engine. At ambient tem-

peratures below 0 °C, disengage the clutch after switching on the ignition.◀

▶ The start attempt is automatically interrupted if battery voltage is too low. Recharge the battery before you start the engine, or use jump leads and a donor battery to start.◀

- » The engine starts.
- » If the engine refuses to start, consult the troubleshooting chart in the section entitled "Technical data". (➡ 144)

Pre-ride check

The instrument cluster runs a test of the 'General' warning light when the ignition is switched on. The warning light shows first red and then yellow, so that you can check that it is in working or-

der. This pre-ride check is indicated by the word **CHECK!** appearing in the display. If the motorcycle is equipped with the cruise control optional extra, **SET** lights up as well. The test is aborted if you start the engine before it completes.

Phase 1

⚠ General warning light lights up red.

- The **CHECK!** reminder appears on the display.

Phase 2

⚠ General warning light lights up yellow.

- The **CHECK!** reminder appears on the display.

SET Telltale light, cruise control (OE) shows

If the 'General' warning light is not displayed:



Some malfunctions cannot be indicated if the 'General' warning light cannot be displayed.

Check that the 'General' warning light comes on, and that it lights up yellow and then red. ◀

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

ABS self-diagnosis

BMW Motorrad Integral ABS performs self-diagnosis to ensure its operability. Self-diagnosis is performed automatically when you switch on the ignition. The motorcycle has to move forward at

a speed above 5 km/h for the wheel sensors to be tested.

Phase 1

- » Test of the diagnosis-compatible system components with the motorcycle at a standstill.



ABS warning light flashes.



Possible national variant of the ABS warning light.

Phase 2

- » Test of the wheel sensors as the motorcycle pulls away from rest.



ABS warning light flashes.



Possible national variant of the ABS warning light.

ABS self-diagnosis completed

- » The ABS warning light goes out.

If an indicator showing an ABS fault appears when ABS self-diagnosis completes:

- You can continue to ride. Bear in mind that neither the ABS function nor the integral braking function is available.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

ASC self-diagnosis^{OE}

BMW Motorrad ASC performs self-diagnosis to ensure its operability. Self-diagnosis is performed automatically when you switch on the ignition. The engine must be running and the motorcycle must

reach a speed of at least 5 km/h in order for ASC self-diagnosis to complete.

Phase 1

- » Test of the diagnosis-compatible system components with the motorcycle at a standstill.



ASC warning light slow-flashes.

Phase 2

- » Test of the diagnosis-compatible system components while the motorcycle is on the move.



ASC warning light slow-flashes.

ASC self-diagnosis completed

- » The ASC warning light goes out.

If an indicator showing an ASC fault appears when ASC self-diagnosis completes:

- You can continue to ride. Bear in mind that the ASC function is not available.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Running in

The first 1000 km

- While running in the motorcycle, vary the throttle opening and engine-speed range frequently.
- Try to do most of your riding during this initial period on twisting, fairly hilly roads, avoiding high-speed main roads and highways if possible.



Exceeding the specified engine speeds while running in will lead to increased engine wear.

Keep to the specified engine speeds for running in. ◀

- Do not exceed the rpm limits recommended for running in.



Running-in speed

– <math><4000 \text{ min}^{-1}</math>

- No full-load acceleration.
- Avoid low engine speeds at full load.
- Do not omit the first inspection after 500 - 1200 km.

Brake pads

New brake pads must "bed down" and therefore do not achieve their optimum friction levels during the first 500 km. You can compensate for this

initial reduction in braking efficiency by exerting greater pressure on the levers.

 New brake pads can extend stopping distance by a significant margin. Apply the brakes in good time.◀

Tyres

New tyres have a smooth surface. This must be roughened by riding in a restrained manner at various heel angles until the tyres are run in. This running in procedure is essential if the tyres are to achieve maximum grip.

 Tyres do not have their full grip when new and there is a risk of accidents at extreme angles of heel. Avoid extreme angles of heel.◀

Parking your motorcycle

Placing motorcycle on side stand

 If the ground is soft or uneven, there is no guarantee that the motorcycle will rest firmly on the stand. Always check that the ground under the stand is level and firm.◀

- Switch off the engine.
- Pull the handbrake lever.
- Hold the motorcycle upright and balanced.
- Use your left foot to extend the side stand fully.

 The side stand is designed to support only the weight of the motorcycle. Do not lean or sit on the motorcycle with the side stand extended.◀

- Slowly lean the motorcycle to the side until its weight is taken by the stand and dismount to the left.

 If the motorcycle is on the side stand, the surface of the ground will determine whether it is better to turn the handlebars to the left or right. However, the motorcycle is more stable on a level surface with the handlebars turned to the left than with the handlebars turned to the right.

On level ground, always turn the handlebars to the left to set the steering lock.◀

- Turn the handlebars to full left or right lock.
- Check that the motorcycle is standing firmly.

 On a gradient, the motorcycle should always face uphill; select 1st gear.◀

Removing motorcycle from side stand

 Brake servo assistance is not available when the ignition is off; the motorcycle can start to roll.

Particularly when the motorcycle is parked on a gradient, switch on the ignition and wait for the ABS to complete its self-diagnosis. ◀

- Unlock the steering lock.
- Switch on the ignition.
- Wait for ABS self-diagnosis to complete.
- From the left, grip the handlebars with both hands.
- Pull the handbrake lever.
- Swing your right leg over the seat and lift the motorcycle to the upright position.
- Hold the motorcycle upright and balanced.

 An extended side stand can catch on the ground when the motorcycle is moving and lead to a fall.

Retract the side stand before moving the motorcycle. ◀

- Sit on the motorcycle and use your left foot to retract the side stand.

Placing motorcycle on centre stand

 If the ground is soft or uneven, there is no guarantee that the motorcycle will rest firmly on the stand.

Always check that the ground under the stand is level and firm. ◀

- Switch off the engine.
- Dismount and keep your left hand on the left handlebar grip.

- With your right hand, grip the rear grab handle or the rear frame.
- Place your right foot on the pin of the centre stand, and press the stand down until its curved feet touch the ground.
- Place your full body weight on the centre stand and at the same time pull the motorcycle to the rear.

 Excessive movements could cause the centre stand to retract, and the motorcycle would topple in consequence.

Do not lean or sit on the motorcycle with the centre stand extended. ◀

- Check that the motorcycle is standing firmly.

Removing motorcycle from centre stand

! Brake servo assistance is not available when the ignition is off; the motorcycle can start to roll.

Particularly when the motorcycle is parked on a gradient, switch on the ignition and wait for the ABS to complete its self-diagnosis. ◀

- Switch on the ignition.
- Wait for ABS self-diagnosis to complete.
- Place your left hand on the left handlebar grip.
- With your right hand, grip the rear grab handle or the rear frame.
- Push the motorcycle forward off the centre stand.
- Check that the centre stand has fully retracted.

Refuelling

! Fuel is highly flammable. A naked flame close to the fuel tank can cause a fire or explosion.

Do not smoke. Never bring a naked flame near the fuel tank. ◀

! Fuel expands when hot. Fuel escaping from an overfilled tank could make its way onto the rear tyre. This could cause a fall.


Do not fill the tank past the bottom edge of the filler neck. ◀

! Fuel attacks plastics, which become dull or unsightly.

Wipe off plastic parts immediately if they come into contact with fuel. ◀

! Leaded fuel will destroy the catalytic converter. Use only unleaded fuel. ◀

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Open the protective cap.
- Open the fuel tank cap with the ignition key by turning it counter-clockwise.
- Refuel with fuel of the grade stated below; do not fill the tank past the bottom edge of the filler neck.

 The ratings for performance and consumption are quoted for the recommended grade of fuel. ◀

 Recommended fuel grade
- 95 ROZ/RON (Super unleaded)
- 91 ROZ/RON (Regular unleaded (fuel grade, usable with power- and consumption-related restrictions))
 Usable fuel capacity
- 27 l
 Reserve fuel
- 4 l

- Press the filler cap down firmly to close.

- Remove the key and close the protective cap.

Tyre pressure control RDC^{OE}

Function

A sensor integrated into each tyre measures the air temperature and the air pressure inside the tyre and transmits this information to the control unit.

Each sensor has a centrifugal-force tripswitch that does not enable transmission of the measured values until the motorcycle has accelerated to about 30 km/h. The display shows -- for each tyre until the tyre-pressure signal is received for the first time. The sensors continue to transmit the measured-value signals for approximately 15 minutes

after the motorcycle comes to a stop.

The control unit can administrate four sensors, so two different sets of wheels with RDC sensors can be alternated on the motorcycle. An error message is issued if wheels without sensors are fitted to a motorcycle equipped with an RDC control unit.

Temperature compensation

The tyre-pressure readings shown by the multifunction display are temperature-compensated; the reference tyre temperature for these readings is always 20 °C. The air lines available to the public in petrol stations and motorway service areas almost invariably show temperature-dependent

tyre pressures, so in most instances these gauge readings will not tally with the readings shown by the multifunction display.

Tyre-pressure ranges

The RDC control unit differentiates between three air-pressure ranges, all of which are parameterised for the motorcycle:

- Air pressure within permitted tolerance.
- Air pressure close to limit of permitted tolerance.
- Air pressure outside permitted tolerance.

A warning is also issued if tyre pressure drops sharply but stays within the permitted tolerance.

Brake system, general

Descending mountain passes

 There is a danger of the brakes fading if you use only the rear brakes when descending mountain passes. Under extreme conditions, the brakes could overheat and suffer severe damage. Use both front and rear brakes, and make use of the engine's braking effect as well. ◀

Wet brakes

 After the motorcycle has been washed, ridden through water or ridden in the rain, the brake discs and pads might be wet and the brakes might not take effect immediately. Apply the brakes in good time

until the brakes have dried out. ◀

Salt on brakes

 The brakes may fail to take effect immediately if the motorcycle was ridden on salt-covered roads and the brakes were not applied for some time. Apply the brakes in good time until the salt layer on the brake discs and brake pads has been removed. ◀

Oil or grease on brakes

 Oil and grease on the brake discs and pads considerably diminish braking efficiency. Especially after repair and maintenance work, make sure that the brake discs and brake pads are free of oil and grease. ◀

Dirt or mud on brakes



When riding on loose surfaces or muddy roads, the brakes may fail to take effect immediately because of dirt or moisture on the discs or brake pads. Apply brakes in good time until the brakes have been cleaned. ◀



The brake pads will wear more rapidly if you ride frequently on unsurfaced tracks or poor roads. Check the thickness of the brake pads more frequently and replace the brake pads in good time. ◀

Brake system with BMW Motorrad Integral ABS

Partially integral brakes

Your motorcycle is equipped with partially integral brakes. Both front and rear brakes are applied when you pull the handbrake lever. The foot-brake lever acts only on the rear brake.

When actively intervening in the braking process, the BMW Motorrad Integral ABS adapts braking-force distribution between front and rear brakes to suit the load on the motorcycle.



The integral braking function makes it very difficult to spin the rear wheel by opening the throttle with the front brake applied to keep the motorcycle stationary (burn-

out). Attempted burn-outs can result in damage to the rear brake and the clutch. Do not attempt burn-outs. ◀

How does ABS work?

The amount of braking force that can be transferred to the road depends on factors that include the coefficient of friction of the road surface. Loose stones, ice and snow or a wet road all have much lower coefficients of friction than a clean, dry asphalt surface. The lower the coefficient of friction, the longer the braking distance.

If the rider increases braking pressure to the extent that braking force exceeds the maximum transferrable limit, the wheels start to lock and the motorcycle loses its directional stability; a fall is imminent. Before this situation

can occur, ABS intervenes and adapts braking pressure to the maximum transferrable braking force, so the wheels continue to turn and directional stability is maintained irrespective of the condition of the road surface.

What are the effects of surface irregularities?

Humps and surface irregularities can cause the wheels to lose contact temporarily with the road surface; if this happens the braking force that can be transmitted to the road can drop to zero. If the brakes are applied under these circumstances the ABS has to reduce braking force to ensure that directional stability is maintained when the wheels regain contact with the road surface. At this instant the BMW Mo-

torrad Integral ABS must assume an extremely low coefficient of friction, so that the wheels will continue to rotate under all imaginable circumstances, because this is the precondition for ensuring directional stability. As soon as it registers the actual circumstances, the system reacts instantly and adjusts braking force accordingly to achieve optimum braking.

What feedback does the rider receive from the BMW Motorrad Integral ABS?

If the ABS system has to reduce braking force on account of the circumstances described above, vibration is perceptible through the handbrake lever.

When the handbrake lever is pulled, brake pressure is also

built up at the rear wheel by the integral function. If the brake pedal is depressed after the handbrake lever is pulled, the brake pressure built up beforehand is perceptible as counter-pressure sooner than is the case when the brake pedal is depressed either before or at the same time as the brake lever is pulled.

How can stopping distance be minimised?

Each time the brakes are applied, a load distribution shift takes place with the load shifting forward from the rear to the front wheel. The sharper the motorcycle decelerates, the more load is shifted to the front wheel. The higher the wheel load, the more braking force can be

transmitted without the wheel locking.

To optimise stopping distance, apply the front brakes rapidly and keep on increasing the force you apply to the brake lever. This makes the best possible use of the dynamic increase in load at the front wheel. Remember to pull the clutch at the same time. In the "panic braking situations" that are trained so frequently braking force is applied as rapidly as possible and with the rider's full force applied to the brake levers; under these circumstances the dynamic shift in load distribution cannot keep pace with the increase in deceleration and the tyres cannot transmit the full braking force to the surface of the road. ABS has to intervene to keep the front wheel from locking;

this increases stopping distance.

Rear wheel lift

Even under severe braking, a high level of tyre grip can mean that the front wheel does not lock up until very late, if at all. Consequently, ABS does not intervene until very late, if at all. Under these circumstances the rear wheel can lift off the ground, and the outcome can be a highside situation in which the motorcycle can flip over.



Severe braking can cause the rear wheel to lift off the ground. When you brake, bear in mind that ABS control cannot be relied on in all circumstances to prevent the rear wheel from lifting clear of the ground.◀

What is the design baseline for BMW Motorrad Integral ABS?

Within the limits imposed by physics, the BMW Motorrad Integral ABS ensures directional stability on any surface. The system is not optimised for special requirements that apply under extreme competitive situations off-road or on the track.

Special situations

The speeds of the front and rear wheels are compared as one means of detecting a wheel's incipient tendency to lock. If the system registers implausible values for a lengthy period the ABS function is deactivated for safety reasons and an ABS fault message is issued. Self-diagnosis has

to complete before fault messages can be issued. In addition to problems with the BMW Motorrad Integral ABS, exceptional riding conditions can lead to a fault message being issued.

Exceptional riding conditions:

- Heating up with the motorcycle on the centre stand or an auxiliary stand, engine idling or with a gear engaged.
- Rear wheel locked by the engine brake for a lengthy period, for example while descending off-road.

If a fault message is issued on account of exceptional riding conditions as outlined above, you can reactivate the ABS function by switching the ignition off and on again.

What significance devolves on regular maintenance?



Invariably, a technical system cannot perform beyond the abilities dictated by its level of maintenance.

In order to ensure that the BMW Motorrad Integral ABS is always maintained in optimum condition, it is essential for you to comply strictly with the specified inspection intervals. ◀

Reserves for safety

The potentially shorter braking distances which BMW Motorrad Integral ABS permits must not be used as an excuse for careless riding. ABS is primarily a means of ensuring a safety margin in genuine emergencies.

Take care when cornering. When you apply the brakes on a corner, the motorcycle's weight and momentum take over and even BMW Motorrad Integral ABS is unable to counteract their effects.

Electronic engine management with BMW Motorrad ASC^{OE}

How does ASC work?

The BMW Motorrad ASC compares the speed of rotation of the front wheel and the rear wheel. The differential is used to compute slip as a measure of the reserves of stability available at the rear wheel. If slip exceeds a certain limit the electronic engine management system intervenes, adapting engine torque accordingly.

What is the design baseline for BMW Motorrad ASC?

BMW Motorrad ASC is designed as an assistant system for the rider and for use on public roads. The extent to which the rider affects ASC control can be considerable (weight shifts when cornering, items of luggage loose on the motorcycle), especially when style of riding takes rider and machine close to the limits imposed by physics. The system is not optimised for special requirements that apply under extreme competitive situations off-road or on the track. You have the option of deactivating the BMW Motorrad ASC system for these circumstances.



Even ASC is constrained by the laws of physics. Invariably, the rider bears responsibility for assessing road and traffic conditions and adopting his or her style of riding accordingly.

Do not take risks that would negate the additional safety offered by this system. ◀

Special situations

In accordance with the laws of physics, the ability to accelerate is restricted more and more as the angle of heel increases. Consequently, there can be a perceptible lag in acceleration out of very tight bends.

The speeds of the front and rear wheels are compared as one means of detecting the rear wheel's incipient tendency to spin or slip sideways.

If the system registers implausible values for a lengthy period the ASC function is deactivated for safety reasons and an ASC fault message is issued. Self-diagnosis has to complete before fault messages can be issued.

The BMW Motorrad ASC can shut down automatically under the exceptional riding conditions outlined below.

Exceptional riding conditions:

- Riding for a lengthy period with the front wheel lifted off the ground (wheelie) and ASC deactivated.
- Rear wheel rotating with the motorcycle held stationary by applying the front brake (burn-out).
- Heating up with the motorcycle on the centre stand or an auxiliary stand, en-

engine idling or with a gear engaged.

Accelerating the motorcycle to a speed in excess of 10 km/h after switching the ignition off and then on again reactivates the ASC.

If the front wheel lifts clear of the ground under severe acceleration, the ASC reduces engine torque until the front wheel regains contact with the ground.

Under these circumstances, BMW Motorrad recommends rolling the throttle slightly closed so as to restore stability with the least possible delay.

When riding on a slippery surface, never snap the throttle twistgrip fully closed without pulling the clutch at the same time. Engine

braking torque can cause the rear wheel to lock, with a corresponding loss of stability. The BMW Motorrad ASC is unable to control a situation of this nature.

Accessories

General instructions	96
Power socket	96
Luggage	97
Case	98
Topcase ^{OA}	100

General instructions

BMW Motorrad recommends the use of parts and accessories for your motorcycle that are approved by BMW for this purpose.

Genuine BMW parts and accessories and other products which BMW has approved can be obtained from your authorised BMW Motorrad dealer, together with expert advice on their installation and use.

These parts and products have been tested by BMW for safety, function and suitability. BMW accepts product liability for them.

Conversely, BMW is unable to accept any liability whatsoever for parts and accessories which it has not approved.



BMW Motorrad cannot assess each non-BMW product to determine whether it can be used on or in connection with BMW motorcycles without constituting a safety hazard. Country-specific official authorisation does not suffice as assurance. Tests conducted by these instances cannot make provision for all operating conditions experienced by BMW motorcycles and, consequently, they are not sufficient in some circumstances. Use only parts and accessories approved by BMW for your motorcycle.◀

Whenever you are planning modifications, comply with all the legal requirements. Make sure that the motorcycle does not infringe national road-vehicle construction and use regulations.

Power socket

Ratings

The supply to the socket is cut off automatically if battery voltage is low or the load exceeds the maximum rating.



On-board socket, front left

with OE (Additional) socket:



On-board socket, rear left◀

Operating electrical accessories

You can start using electrical accessories only when the ignition is switched on. The accessory remains operational if the ignition is subsequently switched off. In order to ensure that the drain on the on-board power supply system is minimised, the supply to the power socket is cut off approximately 15 minutes after the ignition is switched off,

and it is also temporarily interrupted during the start procedure.

Cable routing

The cables from the power socket to the auxiliary device must be routed in such a way that they:

- do not impede the rider
- do not restrict or obstruct the steering angle and handling characteristics
- cannot be trapped

 Incorrectly routed cables can impede the rider. Route the cables as described above.◀

Luggage

Correct loading

 Overloading and imbalanced loads can adversely affect the motorcycle's handling.

Do not exceed the permissible gross weight and be sure to comply with the instructions on loading.◀

Fitting a luggage system will affect the handling of your motorcycle. The maximum speed recommended for riding with loaded cases is 180 km/h. If the large or small topcase available is fitted, the maximum permissible speed is 180 km/h.

- Set spring preload, damping characteristic and tyre pressures to suit total weight.
- Make sure that the weight is uniformly distributed between right and left.


- Pack heavy items at the bottom and toward the in-board side.
- Max. load in each case (left and right): 10 kg.
- Max. load in tank rucksack 5 kg.

Case

Opening cases




- Turn the key to the OPEN position in the case lock.
 - » The case is unlocked.




- Press lock barrel **1**.
 - » Lever **2** pops up.
- Flip the release lever to the rear.
- Open the lid.

Closing cases



- Pull release lever **2** all the way to the back.
- Close the lid of the case and press it down. Check that nothing is trapped between the lid and the case.




Removing cases



- Push release lever **2** down.
 - » The release lever engages.
- Turn the key to the LOCK position in the case lock.
 - » The case is closed.


- Turn the key to the RELEASE position in the case lock.
 - » The handle pops out.



- Pull handle **3** out and then pull it up as far as it will go.
 - » The case is released and can be removed.

Installing cases

- Pull the case handle up as far as it will go.



- Seat the case in holders **4**.



- Push case handle **3** down until it engages.
- » The case is correctly engaged on its holders.


- Turn the key to the LOCK position in the case lock.
- » The case is closed.
- Check that the case is secure.

Topcase^{OA}

Opening topcase




- Turn the key to the OPEN position in the topcase lock.
- » The topcase is unlocked.



- Press lock barrel **1**.
- » Lever **2** pops up.
- Pull the release lever up.
- » The lid of the topcase opens.

Closing topcase



- Pull release lever **2** all the way to the back.
- Close the lid of the topcase and press it down. Check that nothing is trapped between the lid and the case.



- Push release lever **2** down.
 - » The release lever engages.
- Turn the key to the LOCK position in the topcase lock.
 - » The topcase is locked.

Removing topcase


- Turn the key to the RELEASE position in the topcase lock.
 - » The handle pops out.



- Pull handle **3** up as far as it will go.
- Lift the topcase at the rear and pull it off the luggage carrier.

Installing topcase

- Pull the handle up as far as it will go.



- Hook the topcase into position on the luggage carrier. Make sure that hooks **4** are securely seated in the corresponding keepers **5**.



- Push handle **3** down until it engages.
 - » The topcase is correctly engaged on its carrier.
- Turn the key to the LOCK position in the topcase lock.
 - » The topcase is locked.
- Check that the topcase is secure.

Maintenance

General instructions	104
Toolkit	104
Engine oil	105
Brake system, general	107
Brake pads.....	108
Brake fluid	109
Clutch	111
Tyres	112
Rims.....	112
Wheels	112
Front-wheel stand	119
Bulbs	120
Jump starting	130
Battery.....	132

General instructions

The Maintenance chapter describes straightforward procedures for checking and replacing certain wear parts. Special tightening torques are listed as applicable. The tightening torques for the threaded fasteners on your motorcycle are listed in the section entitled "Technical data".

You will find information on more extensive maintenance and repair work in the Repair Manual on DVD/CD-ROM (RepROM) for your motorcycle, which is available from your authorised BMW Motorrad dealer.


Some of the work calls for special tools and a thorough knowledge of motorcycles. If you are in doubt consult a specialist workshop, prefer-

ably your authorised BMW Motorrad dealer.

Toolkit

Removing toolkit

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Remove the rear seat (➔ 66)



- Remove the rubber strap and remove tools wallet **1**.

Standard on-board toolkit



1 Screwdriver, reversible blade, with extension

- Removing and installing turn indicator glass
- Adjusting rebound stage

2 Tool for oil cap

- Removing and installing plug of oil filler neck

3 Torx wrench, T25


- Removing and installing rear light glass

- Removing and installing battery retainer

On-board toolkit service kit

Your authorised BMW Motorrad dealer can provide supplementary toolkit that you will need if you are considering undertaking more extensive work.

You will find information on undertaking work of this nature in the Repair Manual on the DVD/CD-ROM also obtainable from your authorised BMW Motorrad dealer.



1 extending tool holder

- Adapters to accommodate all tools

2 1/4" bits

- 5x Torx bits
- 2x cross-head bits
- 1x plain screwdriver bit

3 3/8" adapter for socket-head screws, w/f 22

- Removing and installing front axle

4 Electric torch

- LED bulb

5 Set of spanners

- Removing and installing rear wheel

6 Adapter

- Adapter for 1/4" bits
- 9x12 mm and 3/8" swivel adapters

Engine oil

Checking the engine oil level



The engine can seize if the oil level is low, and this can lead to accidents. Always make sure that the oil level is correct. ◀




The oil level varies with the temperature of the oil. The higher the temperature, the higher the level of oil in the sump. Checking the oil level with the engine cold or after no more than a short ride will lead to misinterpret-

ation; this in turn, means that the engine will be operated with the incorrect quantity of oil.


In order to ensure that the engine oil level is read correctly, check the oil level only after a lengthy trip. ◀

▷ The insufficient oil pressure warning does not fulfil the function of an oil gauge. The only way of checking whether the oil level is correct is to check the oil sight glass. ◀

- Check that the engine is at operating temperature, make sure the ground is level and firm and place the motorcycle on its centre stand.



- Check the oil level in sight glass **1**.



 Engine oil, specified level

– Oil level visible in sight glass


If the oil level is below the MIN mark:

- Topping up the engine oil (→ 106)

If the oil level is above the MAX mark:

- Have the oil level corrected by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Topping up the engine oil



 Damage to the engine can result if it is operated without enough oil, but

the same also applies if the oil level is too high.

Always make sure that the oil level is correct. ◀

- Wipe the area around the filler neck clean.
- Use the tool from the toolkit to remove cap **1** from the engine oil filler neck.
- Top up the engine oil to the specified level.
- Use the tool from the toolkit to install cap **1** in the engine oil filler neck.

Brake system, general Dependability of the brake system

A fully functional brake system is a basic requirement for the road safety of your motorcycle.

Do not ride the motorcycle if you have any doubts about

the dependability of the brake system.

Under these circumstances have the brake system checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.



Incorrect working practices endanger the reliability of the brakes.

Have all work on the brake system performed by a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀

Checking operation of brakes

- Switch on the ignition.
- Wait for ABS self-diagnosis to complete.
- Pull the handbrake lever.
- » The pressure point must be clearly perceptible.

- » The noise of the hydraulic pump of the BMW Integral ABS must be clearly audible.
- Press the footbrake lever.
- » The pressure point must be clearly perceptible.
- » The noise of the hydraulic pump of the BMW Integral ABS must be clearly audible.

If the hydraulic pump does not run or if the pressure points are not clearly perceptible:

- Have the brakes checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.


Brake pads

Checking brake-pad thickness, front brakes


 Brake pads worn past the minimum permissible thickness can cause a reduction in braking efficiency and under certain circumstances they can cause damage to the brake system.

In order to ensure the dependability of the brake system, do not permit the brake pads to wear past the minimum permissible thickness. ◀

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Visually inspect the left and right brake pads to ascertain their thickness.



 Front brake pads, wear-indicating mark

– The wear-indicating marks must be clearly visible on the pads.

If the wear indicating marks are no longer clearly visible:


- Have the brake pads replaced by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Checking brake pad thickness, rear brakes

 Brake pads worn past the minimum permissible thickness can cause a reduction in braking efficiency and under certain circumstances they can cause damage to the brake system.

In order to ensure the dependability of the brake system, do not permit the brake pads to wear past the minimum permissible thickness. ◀

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Visually inspect the brake pads of the rear brake caliper from the left to ascertain their thickness.



Rear brake pads, material thickness

– Wear limit

– 1 mm

Make sure that the brake disc is not visible through the bore in the inboard brake block.


- Have the brake pads replaced by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Brake fluid

Checking brake-fluid level, front brakes

 A low fluid level in the brake reservoir can allow air to penetrate the brake system. This significantly reduces braking efficiency. Check the brake-fluid level at regular intervals. ◀

- Make sure the ground is level and firm and place the motorcycle on its centre stand.
- Move the handlebars to the straight-ahead position.



- Check the brake fluid level in reservoir **1**.

▶ The brake fluid level in the brake fluid reservoir drops as the brake pads wear. ◀



Brake fluid level, front

– DOT4 brake fluid

– Do not permit the brake fluid level to drop below the MIN mark. (Brake-fluid reservoir horizontal)

If the brake fluid level drops below the permitted level:



A low fluid level in the brake reservoir can allow air to penetrate the brake system. This significantly reduces braking efficiency.

Check the brake-fluid level at regular intervals. ◀

- Have the defect rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Checking brake-fluid level, rear brakes




A low fluid level in the brake reservoir can allow air to penetrate the brake system. This significantly reduces braking efficiency. Check the brake-fluid level at regular intervals. ◀

- Make sure the ground is level and firm and place the motorcycle on its centre stand.



- Check the brake fluid level in reservoir **1**.

▶ The brake fluid level in the brake fluid reservoir drops as the brake pads wear. ◀



Brake fluid level, rear

– DOT4 brake fluid

– Do not permit the brake fluid level to drop below the MIN mark. (Brake-fluid reservoir horizontal)

If the brake fluid level drops below the permitted level:



A low fluid level in the brake reservoir can allow air to penetrate the brake system. This significantly reduces braking efficiency.

Check the brake-fluid level at regular intervals. ◀

- Have the defect rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Clutch

Checking clutch operation

- Pull the clutch lever.
 - » The pressure point must be clearly perceptible.
- If the pressure point is not clearly perceptible:
- Have the clutch checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Tyres

Checking tyre tread depth



Your motorcycle's handling and grip can be impaired even before the tyres wear to the minimum tyre tread depth permitted by law. Have the tyres changed in good time before they wear to the minimum permissible tread depth. ◀

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Measure the tyre tread depth in the main tread grooves with wear marks.

▷ Tyres have wear indicators integrated into the main tread grooves. The tyre is worn out when the tyre tread has worn down to the level of the marks. The loca-

tions of the marks are indicated on the edge of the tyre, e.g. by the letters TI, TWI or by an arrow. ◀

If the tyre tread no longer complies with the minimum legally required tread depth:

- Replace tyre.

Rims

Checking rims

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Visually inspect the rims for defects.
- Have damaged rims checked and, if necessary, replaced by a specialist workshop, preferably an authorised BMW Motorrad dealer.


Wheels

Approved wheels and tyres

For each size of tyre BMW Motorrad tests certain makes, and approves those that it certifies as roadworthy. If BMW Motorrad has not approved the wheels and tyres, it cannot assess their suitability or provide any guarantee of road safety.

Use only wheels and tyres approved by BMW Motorrad for your type of motorcycle. You can obtain detailed information from your authorised BMW Motorrad dealer or on the Internet at www.bmw-motorrad.com.

RDC label^{OE}




 Incorrect tyre-removal procedures can result in damage to the RDC sensors. Be sure to notify the authorised BMW Motorrad dealer or specialist workshop that the wheel is fitted with an RDC sensor. ◀

If the motorcycle is equipped with RDC, each wheel rim bears an adhesive label indicating the position of the RDC sensor. When changing the tyre, take care not to damage the RDC sensor. Be sure to


draw the attention of the authorised BMW Motorrad dealer or specialist workshop to the fact that the wheel is fitted with an RDC sensor.

Removing front wheel

- Make sure the ground is level and firm and place the motorcycle on its centre stand.




- Remove screws **1** on left and right.
- Lift the mudguard forward to remove, pulling the two sides slightly apart.



 Once the calipers have been removed, there is a risk of the brake pads being pressed together to the extent that they cannot be slipped back over the brake disc on reassembly. Do not operate the handbrake lever when the brake calipers have been removed. ◀


- Remove securing screws **2** of the left and right brake calipers.



- Force the brake pads slightly apart by rocking brake calipers **3** back and forth **A** against brake discs **4**.
- Mask off the parts of the wheel rim that could be scratched in the process of removing the brake calipers.
- Carefully pull the brake calipers back and out until clear of the brake discs.
- Raise the front of the motorcycle until the front wheel can rotate freely. BMW Motorrad recommends the BMW Motorrad front wheel

stand for lifting the motorcycle.

- Fitting the front wheel stand (➔ 119)



- Release axle clamping screw **5**.
- Remove quick-release axle **6**, while supporting the wheel.

▶ BMW Motorrad can supply an adapter for removing the quick-release axle. This adapter can be combined with any commercially available w/f 22 open-end or ring spanner.

The BMW special tool number is 363691 and the adapter is available from your authorised BMW Motorrad dealer. The supplementary toolkit available as an optional accessory also includes a tool for removing the quick-release axle. ◀



- Roll the front wheel forward to remove.
- Remove the spacing bushing from the left-hand side of the wheel hub.

Installing front wheel

 Threaded fasteners not tightened to the specified torque can work loose or their threads can suffer damage.

Always have the security of the fasteners checked by a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀

 There is a risk of damaging parts of the front brake, particularly the BMW Integral ABS, in the course of the procedure described below.

Take care not to damage the brake system, in particular the ABS sensor with cable and the ABS sensor ring. ◀


 The front wheel must be installed right way round to rotate in the correct direction.

Note the direction-of-rotation arrows on the tyre or the wheel rim. ◀

- Slip the spacing bushing into the left-hand side of the wheel hub.



- Roll the front wheel into position in the front suspension.
- Do not damage the ABS sensor on the left-hand side when rolling in the wheel.



- Install quick-release axle **6** and tighten to specified torque.



Quick-release axle in axle holder

– 50 Nm

- Install axle clamping screw **5** and tighten to specified torque.



Quick-release axle clamp screws


– 19 Nm

- Remove the front wheel stand.
- Slip the brake calipers onto the brake discs.



! The cable of the ABS sensor could chafe through if it comes into contact with the brake disc. Make sure that the ABS sensor cable is routed correctly. ◀

- Make sure that ABS sensor cable **7** is correctly routed.




- Install securing screws **2** and tighten to specified torque.



Brake caliper to slider tube

– 30 Nm

- Remove the adhesive tape from the wheel rim.




- Install screws **1** on left and right.
- Switch on the ignition.
- Wait for self-diagnosis to complete.
- Operate the brake until the pressure point is perceptible.

Remove the rear wheel


! Parts of the exhaust system can be hot. Do not touch hot parts of the exhaust system. ◀

- Make sure the ground is level and firm and place

the motorcycle on its centre stand.




- Slacken clamping screw **1** on the silencer.
- Do not remove the sealing grease from the clamp.



- Remove screw **2** for the bracket of the end silencer from the rear footrest.



- Turn the end silencer out.
- Engage first gear.



- Remove studs **3** from the rear wheel, while supporting the wheel.
- Roll the rear wheel out toward the rear.

Installing rear wheel

 Threaded fasteners not tightened to the specified torque can work loose or their threads can suffer damage.

Always have the security of the fasteners checked by a specialist workshop, prefer-

ably an authorised BMW Motorrad dealer. ◀

- Insert the rear wheel into the centering hole.



- Tighten screws **3** until hand-tight and then tighten to specified torque in diagonally opposite sequence.




Rear wheel to wheel carrier

– Tightening sequence:
Tighten in diagonally opposite sequence

– 60 Nm




- Turn the end silencer to its initial position.



 If the gap between the rear wheel and the end silencer is too small, the rear wheel can overheat.

The clearance between the rear wheel and the end silencer must be at least 20 mm. ◀

- Install screw **2** for the bracket of the end silencer in the rear footrest, but do not tighten it.




- Align clamp **1** on the end silencer with mark **A** and tighten to specified torque.



Torca clamp to silencer and elbow

– 55 Nm



- Tighten screw **2** securing the bracket to the rear footrest to specified torque.



Rear silencer to
footrest system

– 19 Nm


stand is available from your authorised BMW Motorrad dealer.

! The BMW Motorrad front wheel stand is not designed to support motorcycles not fitted with a centre stand or without other auxiliary stands. A motorcycle resting only on the front wheel stand and the rear wheel can topple.

Place the motorcycle on its centre stand or another auxiliary stand before lifting the front wheel with the BMW Motorrad front-wheel stand. ◀

Fitting the front wheel stand

- Make sure the ground is level and firm and place the motorcycle on its centre stand or the auxiliary stand.




- Slacken adjusting screws **1**.
- Push the two adapters **2** apart until the front forks fit between them.
- Use locating pins **3** to set the front-wheel stand to the desired height.
- Centre the front-wheel stand relative to the front wheel and push it against the front axle.

Front-wheel stand

Use

A front-wheel stand for simple, safe changing of the front wheel is available from BMW Motorrad. The BMW special tool number is 36 3 970 and the front-wheel



- Align the two adapters **2** so that the front forks are securely seated.
- Tighten adjusting screws **1**.



! If the motorcycle is on the centre stand and is raised too far, the centre stand will lift clear of the ground and the motorcycle could topple to one side. When raising the motorcycle, make sure that the centre stand remains on the ground. ◀

- Apply uniform pressure to push the front-wheel stand down and raise the motorcycle.

Bulbs

General instructions

A warning appears in the multifunction display if a bulb is defective. If the brake light or rear light fails, the warning is accompanied by the General warning light lighting up yellow. If the rear light fails the second filament of the brake light shines at reduced brightness to double as a rear light. Even though you have this substitute rear light, the indicators in the display tell you that a bulb defect has occurred.

! A defective bulb places your safety at risk because it is easier for other users to oversee you and your motorcycle. Replace defective bulbs as soon as possible; always

carry a complete set of spare bulbs if possible.◀

! The bulb is pressurised and can cause injury if damaged.

Wear protective goggles and gloves when changing bulbs.◀

▷ The types of bulb fitted to your motorcycle are listed in the section entitled "Technical data".◀


▷ Do not touch the glass of new bulbs with your fingers. Use a clean, dry cloth to hold the bulbs when handling them. Dirt deposits, in particular oil and grease, interfere with heat radiation from the bulb. This leads to overheating and shortens the bulb's operating life.◀

Replacing high-beam headlight bulb


! If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Always make sure that the motorcycle is stable and firmly supported.◀

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Switch off the ignition.

▷ Turn the handlebars to the left to facilitate access.◀



- Turn cover **1** counter-clockwise and remove it.
- Remove the high-beam/low-beam headlight bulb (➡ 123)
- Install the high-beam/low-beam headlight bulb (➡ 124)



- Install cover **1**.
- Check that the bulb is correctly seated (by looking in through the headlight lens).

Replacing left low-beam headlight bulb

 If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Always make sure that the motorcycle is stable and firmly supported. ◀

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Switch off the ignition.

 Turn the handlebars to the left to facilitate access. ◀



- Turn cover **1** counter-clockwise and remove it.
- Remove the high-beam/low-beam headlight bulb (➡ 123)

- Install the high-beam/low-beam headlight bulb (➡ 124)



- Install cover **1**.
- Check that the bulb is correctly seated (by looking in through the headlight lens).


Replacing right low-beam headlight bulb

 If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Always make sure that the

motorcycle is stable and firmly supported. ◀

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Switch off the ignition.

▶ Turn the handlebars to the left to facilitate access. ◀




- Turn cover **1** counter-clockwise and remove it.
- Remove the high-beam/low-beam headlight bulb (➡ 123)

- Install the high-beam/low-beam headlight bulb (➡ 124)




- Install cover **1**.
- Check that the bulb is correctly seated (by looking in through the headlight lens).

Removing high-beam/low-beam headlight bulb




- Disconnect plug **1**.



- Disengage spring clip **2** at left and right and secure it

(preferably by hooking it into the headlight housing).



- Remove bulb **3**.

Installing high-beam/low-beam headlight bulb

- Replace the defective bulb.


 High-beam headlight bulb

– H7 / 12 V / 55 W




High-beam headlight bulb


– H7 / 12 V / 55 W



- Install bulb **3**, making sure that lug **4** is pointing up and that the bulb is securely seated.



- Engage spring retainer **2** on left and right.



- Install plug **1**.


Side-light bulbs, left and right

The procedure for replacing the left side-light bulb is described below. The procedure for replacing the right side-light bulb is analogous.


Replacing parking-light bulb

 If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Always make sure that the motorcycle is stable and firmly supported. ◀


- Make sure the ground is level and firm and place the motorcycle on its stand.
- Switch off the ignition.



- Apply firm forward pressure with the flat of your hand to push the mirror back out of the anchorage.




- While holding the side panel, remove screw **1**.




- Remove fairing side panel **2**.



- The side-light bulb is accessible through the aperture.



- Turn bulb socket **3** counter-clockwise to remove it from the headlight housing; to do so, pivot lever **4** at the socket down (right side of motorcycle: pivot the lever up).




- Pull bulb **5** out of the bulb holder.
- Replace the defective bulb.




Parking-light bulb

– W5W / 12 V / 5 W




- Insert bulb **5** into the bulb socket.
- Turn the bulb socket clockwise to install it in the headlight housing.




- Install fairing panel **2**; make sure that the lug of the pan-

el is correctly seated in the corresponding recess.



- Install screw **1**.



! The mirrors can easily work loose from their anchoring if the rubber holders or snap-fit studs are greased. Do not grease the rubber holder or snap-fit stud. ◀

- Install the mirror in the mirror housing, making sure that the three plugs all engage in their corresponding mounts.
- Check that the bulb is correctly seated (by looking in through the headlight lens).


Replacing brake-light, rear light and rear-indicator bulbs

! If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Always make sure that the motorcycle is stable and firmly supported. ◀


- Make sure the ground is level and firm and place the motorcycle on its stand.
- Switch off the ignition.



- Remove screws **1** on left and right.



- Pull the bulb housing to the rear until it is clear of holders **2**.



- Turn bulb holder **3** counter-clockwise to remove it from the bulb housing.
- Press bulb **4** into its socket and turn it counter-clockwise to remove.
- Replace the defective bulb.

 Bulb of tail light/brake light

– P21W / 12 V / 21 W




Rear flashing turn indicator bulbs


– P21W / 12 V / 21 W

with OE White turn indicators:

– PY21W / 12 V / 21 W◁



- Install bulb **4** in bulb socket **3**.
- Install the bulb socket in the bulb housing.



- Seat the bulb housing in holders **2**.




- Install screws **1** on left and right.

Replacing front turn indicator bulb


! If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Always make sure that the motorcycle is stable and firmly supported. ◀

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Switch off the ignition.



- Apply firm forward pressure with the flat of your hand to

push the mirror out of the anchorage.



- Turn bulb holder **1** counter-clockwise to remove it from the bulb housing.
- Press bulb **2** into its socket and turn it counter-clockwise to remove.
- Replace the defective bulb.

 Front flashing turn indicator bulbs


– P21W / 12 V / 21 W




Front flashing turn indicator bulbs

with OE White turn indicators:

– PY21W / 12 V / 21 W◀



- Install bulb **2** in bulb socket **1**.
- Install the bulb socket in the bulb housing.



! The mirrors can easily work loose from their anchoring if the rubber holders or snap-fit studs are greased. Do not grease the rubber holder or snap-fit stud.◀

- Install the mirror in the mirror housing, making sure that the three plugs all engage in their corresponding mounts.

Jump starting

Jump starting

! The wires leading to the power socket do not have a load-capacity rating adequate for jump-starting the engine. Excessively high current can lead to a cable fire or damage to the vehicle electronics.

Do not use the on-board socket to jump-start the engine of the motorcycle.◀

! Touching live parts of the ignition system with the engine running can cause electric shock.

Do not touch parts of the ignition system when the engine is running.◀

! A short-circuit can result if the crocodile clips of the jump leads are accident-

ally brought into contact with the motorcycle.

Use only jump leads fitted with fully insulated crocodile clips at both ends. ◀



Jump-starting with a donor-battery voltage higher than 12 V can damage the vehicle electronics.

Make sure that the battery of the donor vehicle has a voltage rating of 12 V. ◀



If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Always make sure that the motorcycle is stable and firmly supported. ◀

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Remove the rear seat (➡ 66)

- Removing front seat (➡ 67)
- When jump-starting the engine, do not disconnect the battery from the on-board electrical system.
- Remove the protective cap from the battery's positive terminal.
- Run the engine of the donor vehicle during jump-starting.
- Begin by connecting one end of the red jump lead to the positive terminal of the discharged battery and the other end to the positive terminal of the donor battery.
- Then connect one end of the black jump lead to the negative terminal of the donor battery, and the other end to the negative terminal of the discharged battery.
- Start the engine of the vehicle with the discharged battery in the usual way; if the engine does not start, wait a few minutes before repeating the attempt in order to protect the starter motor and the donor battery.
- Allow both engines to idle for a few minutes before disconnecting the jump leads.
- Disconnect the jump lead from the negative terminals first, then disconnect the second lead from the positive terminals.



Do not use proprietary start-assist sprays or other products to start the engine. ◀

- Installing front seat (➡ 68)
- Installing rear seat (➡ 68)

Battery

Maintenance instructions

Correct upkeep, recharging and storage will prolong the life of the battery and are essential if warranty claims are to be considered.

Compliance with the points below is important in order to maximise battery life:

- Keep the surface of the battery clean and dry
- Do not open the battery
- Do not top up with water
- Be sure to read and comply with the instructions for charging the battery on the following pages
- Do not turn the battery upside down

 If the battery is not disconnected, the on-board electronics (e.g. clock, etc.) gradually drain the battery.

This can cause the battery to run flat. If this happens, warranty claims will not be accepted.

If the motorcycle is to be out of use for more than four weeks, disconnect the battery or connect a suitable trickle charger to the battery.◀

 BMW Motorrad has developed a trickle-charger specially designed for compatibility with the electronics of your motorcycle. Using this charger, you can keep the battery charged during long periods of disuse, without having to disconnect the battery from the motorcycle's on-board systems. You can obtain additional information from your authorised BMW Motorrad dealer.◀

Charging battery when connected

 Charging the connected battery directly at the battery terminals can damage the vehicle electronics. Always disconnect the battery from the on-board circuits before recharging it with a charger connected directly to the battery posts.◀

 Only chargers suitable for this mode of charging can be used to recharge the battery via the on-board socket. Unsuitable chargers could cause damage to the motorcycle's on-board electrics. Use BMW chargers with the part numbers 71 60 7 688 864 (220 V) or, as applicable, 71 60 7 688 865 (110 V). If you are in doubt, disconnect the battery from the on-board systems and

connect the charger directly to the battery. ◀

 If you switch on the ignition and the multifunction display and telltale lights fail to light up, the battery is completely flat. Attempting to charge a completely flat battery via the on-board socket can cause damage to the motorcycle's electronics.

If a battery has discharged to the extent that it is completely flat, it has to be disconnected from the on-board circuits and charged with the charger connected directly to the battery posts. ◀

- Charge via the power socket, with the battery connected to the motorcycle's on-board electrical system.

 The motorcycle's on-board electronics know when the battery is

fully charged. The on-board socket is switched off when this happens. ◀

- Comply with the operating instructions of the charger.

 If you are unable to charge the battery through the power socket, you may be using a charger that is not compatible with your motorcycle's electronics. If this happens, disconnect the battery from the on-board systems and connect the charger directly to the battery. ◀

Charging battery when disconnected

- Charge the battery using a suitable charger.
- Comply with the operating instructions of the charger.
- Once the battery is fully charged, disconnect the

charger terminal clips from the battery terminals.

 The battery has to be recharged at regular intervals in the course of a lengthy period of disuse. See the instructions for caring for your battery. Always fully recharge the battery before restoring it to use. ◀

Remove the battery

 If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Always make sure that the motorcycle is stable and firmly supported. ◀

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Switching off the ignition
- Remove the rear seat (➔ 66)

- Removing front seat (➡ 67)



⚠ Disconnection in the wrong sequence increases the risk of short-circuits.

Always proceed in the correct sequence.◀

- Remove screw **1**.
- Disconnect negative battery lead **2** first.
- Then pull back the protective cap and disconnect positive lead **3**.
- Lift the battery up and out; work it slightly back and

forth if it is difficult to remove.

Install the battery

⚠ If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Always make sure that the motorcycle is stable and firmly supported.◀

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Switch off the ignition.
- Insert the battery into the battery compartment, with the positive terminal on the right in the forward direction of travel.



- Engage the battery retainer at the bottom, slip it over the battery and tighten screw **1** to the specified torque.

⚠ Installation in the wrong sequence increases the risk of short-circuits. Always proceed in the correct sequence. Never install the battery without the protective cap.◀

- Connect positive lead **3** first and tighten the fastener until hand-tight.

- Fit the protective cap to the positive terminal of the battery.
- Then connect negative lead **2** and tighten the fastener until hand-tight.
- Switch on the ignition.
- Without starting the engine, fully open the throttle for at least one second so that the control unit of the engine management system can register the throttle-valve positions.
- Switch off the ignition.
- Installing front seat (➡ 68)
- Installing rear seat (➡ 68)
- Set the clock (➡ 49)

Care

Care products	138
Washing the motorcycle	138
Cleaning easily damaged components	139
Paint care	140
Protective wax coating	140
Laying up the motorcycle	140
Restoring motorcycle to use	141

Care products

BMW Motorrad recommends that you use the cleaning and care products you can obtain from your authorised BMW Motorrad dealer. The substances in BMW Care Products have been tested in laboratories and in practice; they provide optimised care and protection for the materials used in your vehicle.

 The use of unsuitable cleaning and care products can damage vehicle components.

Do not use solvents such as cellulose thinners, cold cleaners, fuel or the like, and do not use cleaning products that contain alcohol. ◀

Washing the motorcycle

BMW Motorrad recommends that you use BMW insect remover to soften and wash off insects and stubborn dirt on painted parts prior to washing the motorcycle.

To prevent stains, do not wash the motorcycle immediately after it has been exposed to strong sunlight and do not wash it in the sun. Make sure that the motorcycle is washed frequently, especially during the winter months.

To remove road salt, clean the motorcycle with cold water immediately after every trip.

 After the motorcycle has been washed, ridden through water or ridden in the rain, the brake discs and

pads might be wet and the brakes might not take effect immediately.

Apply the brakes in good time until the brakes have dried out. ◀

 Warm water intensifies the effect of salt.

Use only cold water to wash off road salt. ◀

 The high pressure of steam cleaners can damage seals, the hydraulic brake system, the electrical system, and the seat.

Do not use a steam jet or high-pressure cleaning equipment. ◀

Cleaning easily damaged components

Plastics

Clean plastic parts with water and BMW plastic care emulsion. This includes in particular:

- Windscreen and slipstream deflectors
- Headlight lens made of plastic
- Glass cover of the instrument cluster
- Black, unpainted parts

 If plastic parts are cleaned using unsuitable cleaning agents, the surfaces can be damaged.

Do not use cleaning agents that contain alcohol, solvents or abrasives to clean plastic parts.

Even fly-remover pads or cleaning pads with hard

surfaces can produce scratches.◀

 Soften stubborn dirt and insects by covering the affected areas with a wet cloth.◀

Windscreen

Clean off dirt and insects with a soft sponge and plenty of water.

 Fuel and chemical solvents attack the material of the windscreen; the windscreen becomes opaque or dull. Do not use cleaning agents.◀

Chrome

Use plenty of water and BMW shampoo to clean chrome, particularly if it has been exposed to road salt. Use chrome polish for additional treatment.

Radiator

Clean the radiator regularly to prevent overheating of the engine due to inadequate cooling.

For example, use a garden hose with low water pressure.

 Cooling fins can be bent easily.

Take care not to bend the fins when cleaning the radiator.◀

Rubber

Treat rubber components with water or BMW rubber-care products.

 Using silicone sprays for the care of rubber seals can cause damage.

Do not use silicone sprays or other care products that contain silicon.◀

Paint care

Washing the motorcycle regularly will help counteract the long-term effects of substances that damage the paint, especially if your motorcycle is ridden in areas with high air pollution or natural sources of dirt, for example tree resin or pollen.

Remove particularly aggressive substances immediately, however, as otherwise the paint can be affected or become discoloured. Substances of this nature include spilt fuel, oil, grease, brake fluid and bird droppings. We recommend BMW vehicle polish or BMW paint cleaner for this purpose.

Marks on the paintwork are particularly easy to see after the motorcycle has been washed. Remove stains of

this kind immediately, using cleaning-grade benzene or petroleum spirit on a clean cloth or ball of cotton wool. BMW Motorrad recommends BMW tar remover for removing specks of tar. Remember to wax the parts treated in this way.

Protective wax coating

BMW Motorrad recommends applying only BMW car wax or products containing carnauba wax or synthetic wax.

The best way to see whether the paint has to be protected is that water no longer forms pearls.

Laying up the motorcycle

- Clean the motorcycle.
- Remove the battery.

- Spray the brake and clutch lever pivots and the main and side stand pivots with a suitable lubricant.
- Coat bright metal and chrome-plated parts with an acid-free grease (e.g. Vaseline).
- Stand the motorcycle in a dry room in such a way that there is no load on either wheel. Authorised BMW Motorrad dealers can provide suitable auxiliary stands.

 Before laying the vehicle up out of use, have the engine oil and the oil filter element changed by a specialist workshop, preferably an authorised BMW Motorrad dealer. Combine work for laying up/restoring to use with a BMW service or inspection.◀

Restoring motorcycle to use

- Remove the protective wax coating.
- Clean the motorcycle.
- Install a charged battery.
- Before starting: work through the checklist.

Technical data

Troubleshooting chart	144
Threaded fasteners	145
Engine	146
Riding specifications	148
Clutch	149
Transmission	149
Final drive	150
Running gear	150
Brakes	151
Wheels and tyres	151
Electrics	152
Frame	154
Dimensions	154
Weights	155

Troubleshooting chart

Engine does not start at all or is difficult to start.

Possible cause	Remedy
Kill switch activated.	Kill switch in operating position (run).
Side stand extended and gear engaged.	Retract the side stand (➡ 80).
Gear engaged and clutch not disengaged.	Select neutral or pull clutch lever (➡ 80).
Clutch pulled when ignition was OFF	Switch on the ignition, then pull the clutch lever.
No fuel in tank.	Refuelling (➡ 86)
Battery not adequately charged.	Charge the battery when connected (➡ 132)

Threaded fasteners

Front wheel	Value	Valid
Quick-release axle clamp screws		
M8 x 35	19 Nm	
Quick-release axle in axle holder		
M24 x 1.5	50 Nm	
Brake caliper to slider tube		
M8 x 32 - 10.9	30 Nm	
Rear wheel	Value	Valid
Rear wheel to wheel carrier		
Wheel flange with cut thread, M10 x 40 x 1.25	Tighten in diagonally opposite sequence	
	60 Nm	
Rear silencer to footrest system		
M8 x 35	19 Nm	

Rear wheel	Value	Valid
Torca clamp to silencer and elbow		
M8	55 Nm	

Engine

Engine, type	Four-stroke opposed twin, air-cooled with oil-cooled exhaust ports, installed longitudinally, two overhead camshafts, electronic fuel injection
Effective displacement	1170 cm ³
Cylinder bore	101 mm
Piston stroke	73 mm
Compression ratio	12.0 : 1
Nominal output	81 kW, Over: 7500 min ⁻¹
with OE Power reduction:	74 kW, Over: 7500 min ⁻¹
Maximum torque	115 Nm, Over: 6000 min ⁻¹
Maximum permissible engine speed	8000 min ⁻¹

Idle speed	1150 $^{+150}_{+50}$ min ⁻¹ , Temporary increase in idle speed possible if electric power demand is high.
Fuel	
Recommended fuel grade	95 ROZ/RON, Super unleaded 91 ROZ/RON, Regular unleaded (fuel grade, usable with power- and consumption-related restrictions)
Usable fuel capacity	27 l
Reserve fuel	4 l
Engine oil	
Engine, oil capacity	4 l, with filter change
Lubricant	Engine oil, 20W-50
Engine oil, quantity for topping up	0.5 l, difference between MIN and MAX
Oil grades	Engine oils of API classification SF or better. Engine oils of ACEA classification A2 or better. BMW Motorrad recommends not using synthetic oils for the first 10,000 km. Please do not hesitate to contact your authorised BMW Motorrad dealer if you have any questions relating the choice of a suitable engine oil for your motorcycle.

Permissible viscosity classes	
SAE 5 W- ≥ 30	-20...20 °C, Operation at low temperatures
SAE 10 W-40	-10...30 °C, Operation at moderate temperatures
SAE 15 W- ≥ 40	≥ 0 °C
SAE 20 W- ≥ 40	≥ 0 °C
SAE 5 W- ≥ 50	≥ -20 °C, High-grade and synthetic oils, operation in all temperature ranges
SAE 10 W- ≥ 50	≥ -20 °C, High-grade and synthetic oils, operation in all temperature ranges

Riding specifications

Top speed	>200 km/h
-----------	-----------

Clutch

Clutch type	Single dry plate with high-leverage pressure plate
-------------	--

Transmission

Gearbox type	Helical 6-speed gearbox with integral reaction damper, claw-action shift by sliding sleeves
--------------	---

Gear ratios

Gearbox transmission ratios	1.824 (31:17 teeth), Primary transmission ratio 2.277 (41:18 teeth), 1st gear 1.583 (38:24 teeth), 2nd gear 1.259 (34:27 teeth), 3rd gear 1.033 (31:30 teeth), 4th gear 0.903 (28:31 teeth), 5th gear 0.805 (29:36 teeth), 6th gear
-----------------------------	---

Final drive

Rear wheel drive, type	Shaft drive with bevel gears
------------------------	------------------------------

Running gear

Front suspension, type	BMW Telelever, with anti-dive top fork bridge, leading link pivot-mounted on engine and telescopic forks, central spring strut supported by leading link and main frame
Front suspension, total suspension travel	120 mm, at wheel
Spring strut, rear, type	Central spring strut with single-tube gas-filled shock absorber, adjustable rebound damping and hydraulically adjustable spring preload
with OE Electronic Suspension Adjustment (ESA):	Central spring strut with single-tube gas-filled shock absorber, 3-stage electrically adjustable rebound damping and 3-stage electrohydraulically adjustable initial spring tension
Total suspension travel at rear wheel	135 mm

Brakes

Front brakes, type	Hydraulically operated twin disc brake with 4-piston fixed calipers and floating brake discs
Brake-pad material, front	Sintered metal
Rear brakes, type	Hydraulically operated disc brake with 2-piston floating caliper and fixed disc
Brake-pad thickness, rear	Organic material

Wheels and tyres

Front wheel, type	Cast wheel with 5 double spokes, MT H2
Front wheel, rim size	3.50" x 17"
Front wheel, tyre designation	120/70 ZR17
Rear wheel, type	Cast wheel with 5 double spokes, MT H2
Rear wheel, rim size	5.50" x 17"
Rear wheel, tyre designation	180/55 ZR17

Tyre pressures

Tyre pressure, front

2.2 bar, One-up, tyre cold
2.5 bar, Two-up and/or with luggage, tyre cold

Tyre pressure, rear

2.5 bar, One-up, tyre cold
2.9 bar, Two-up and/or with luggage, tyre cold**Electrics**

Current limit value, on-board sockets

10 A

Fuses

All circuits are electronically protected, so plug-in fuses are no longer necessary. If an electronic fuse trips and de-energises a circuit, the circuit is active as soon as the ignition is switched on after the fault has been rectified.

Battery

Type, battery

Gel battery

Battery rated voltage

12 V

Battery rated capacity

19 Ah

Spark plugs

Spark plug manufacturer and designation	Bosch YR5LDE NGK DCPR 8 EKC
Spark plug electrode gap	0.8±0.1 mm, When new 1 mm, Wear limit
Secondary spark plug manufacturer and designation	Bosch YR5LDE NGK DCPR 8 EKC
Secondary spark plug, electrode gap	0.8±0.1 mm, When new 1 mm, Wear limit

Lighting

High-beam headlight bulb	H7 / 12 V / 55 W
Low-beam headlight bulb	H7 / 12 V / 55 W
Parking-light bulb	W5W / 12 V / 5 W
Bulb of tail light/brake light	P21W / 12 V / 21 W
Front flashing turn indicator bulbs	P21W / 12 V / 21 W
with OE White turn indicators:	PY21W / 12 V / 21 W
Rear flashing turn indicator bulbs	P21W / 12 V / 21 W
with OE White turn indicators:	PY21W / 12 V / 21 W

Frame

Type, frame	Tubular steel front frame with tubular steel rear frame, load-bearing drive unit
Data plate location	Underneath seat
Vehicle identification number location	Front frame top centre

Dimensions

Length of motorcycle	2230 mm
Height of motorcycle	1430 mm, To top of windscreen when lowered, at DIN unladen weight
maximum width across cases	980 mm
Maximum width (Across mirrors)	905 mm
Front-seat height	820...840 mm, At unladen weight
with OE Front seat low:	780...800 mm

Weights

Unladen weight	259 kg, DIN unladen weight, ready for road 90 % load of fuel, without optional extras
Permissible gross weight	495 kg
Maximum payload	236 kg

Service

BMW Motorrad service	158
BMW Motorrad service quality	158
BMW Motorrad Service Card: on-the-spot breakdown assistance	159
BMW Motorrad service network	159
Maintenance work	159
Maintenance schedules	160
Confirmation of maintenance work	161
Confirmation of service	166

BMW Motorrad service

Advanced technology requires specially adapted methods of maintenance and repair.

 If maintenance and repair work is performed inexpertly, it could result in consequential damage and thus constitute a safety risk. BMW Motorrad recommends you to have all the associated work on your motorcycle carried out by a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀

Your authorised BMW Motorrad dealer can provide information on the specified Service, Inspection and Annual Inspection work needed. Have all maintenance and repair work carried out

confirmed in the "Service" chapter in this manual. Authorised BMW Motorrad dealers are supplied with the latest technical information and have the necessary technical know-how. BMW Motorrad recommends that you contact your authorised BMW Motorrad dealer if you have questions regarding your motorcycle.

BMW Motorrad service quality

Along with its reputation for engineering quality and high reliability, BMW Motorrad is a byword for excellent quality of service.

To ensure that your BMW is always in optimum condition, BMW Motorrad recommends that you have the maintenance work required for your motorcycle carried out reg-

ularly, preferably by your authorised BMW Motorrad dealer. For generous treatment of claims submitted after the warranty period has expired, evidence of regular maintenance is essential.

Certain signs of wear, moreover, may otherwise not be noticed until it is too late to put them right at moderate cost. Your authorised BMW Motorrad dealer's mechanics know every detail of your motorcycle and can take remedial action if necessary before minor faults develop into serious problems. By having the necessary repairs done properly and in good time, you save time and money in the long run.

BMW Motorrad Service Card: on-the-spot breakdown assistance

In the event of a breakdown, the BMW Motorrad Service Card issued with each new BMW motorcycle enables you to access an extensive range of services such as breakdown assistance, motorcycle transportation etc. (details can differ from country to country). In the event of a breakdown, contact BMW Motorrad's Mobile Service. The specialists will provide the necessary advice and assistance.

You will find important country-specific contact addresses and the after-sales service organisation phone numbers in the "Service Kontakt / Service Contact"

brochures, along with information on Mobile Service and the dealership network.

BMW Motorrad service network

BMW Motorrad has an extensive after-sales service network in place to look after you and your motorcycle in more than 100 countries. In Germany alone, you have the best possible access to approximately 200 authorised BMW Motorrad dealers.

All information concerning the international dealership network can be found in the brochures entitled "Service Contact Europe" and "Service Contact Africa, America, Asia, Australia, Oceania".

Maintenance work Intervals

Some maintenance tasks have to be performed after a certain time, others depend on the distance covered by the motorcycle.

BMW Running-in Check

The BMW running-in check has to be performed when the motorcycle has covered between 500 km and 1,200 km

BMW Annual Inspection

Some maintenance work has to be carried out at least once a year. Other tasks depend on the distance the motorcycle has covered.

BMW Service

After the first 10,000 km and every additional 20,000 km (30,000 km, 50,000 km, 70,000 km, etc.) if this distance is covered within a year.

BMW Inspection

After the first 20,000 km and every additional 20,000 km (40,000 km, 60,000 km, 80,000 km, etc.) if this distance is covered within a year.

Maintenance schedules

The maintenance schedule for your motorcycle depends on the equipment fitted, and on the motorcycle's age and the distance it has covered. Your authorised BMW Motorrad dealer will be happy to supply

a copy of the current maintenance schedule for your motorcycle on request.

Confirmation of maintenance work

BMW Pre-delivery Check

Carried out in accordance with manufacturer's instructions

Date, stamp, signature

BMW Running-in Check

Carried out in accordance with manufacturer's instructions

Odometer reading _____

Brake fluid, new

Date, stamp, signature

BMW Service

- BMW Annual Inspection
- BMW Service
- BMW Inspection

Carried out in accordance with manufacturer's instructions

Odometer reading_____

- Brake fluid, new

Date, stamp, signature

BMW Service

- BMW Annual Inspection
- BMW Service
- BMW Inspection

Carried out in accordance with manufacturer's instructions

Odometer reading_____

- Brake fluid, new

Date, stamp, signature

BMW Service

- BMW Annual Inspection
- BMW Service
- BMW Inspection

Carried out in accordance with manufacturer's instructions

Odometer reading_____

- Brake fluid, new

Date, stamp, signature

BMW Service

- BMW Annual Inspection
- BMW Service
- BMW Inspection

Carried out in accordance with manufacturer's instructions

Odometer reading_____

- Brake fluid, new

Date, stamp, signature

BMW Service

- BMW Annual Inspection
- BMW Service
- BMW Inspection

Carried out in accordance with manufacturer's instructions

Odometer reading_____

- Brake fluid, new

Date, stamp, signature

BMW Service

- BMW Annual Inspection
- BMW Service
- BMW Inspection

Carried out in accordance with manufacturer's instructions

Odometer reading_____

- Brake fluid, new

Date, stamp, signature

BMW Service

- BMW Annual Inspection
- BMW Service
- BMW Inspection

Carried out in accordance with manufacturer's instructions

Odometer reading_____

- Brake fluid, new

Date, stamp, signature

BMW Service

- BMW Annual Inspection
- BMW Service
- BMW Inspection

Carried out in accordance with manufacturer's instructions

Odometer reading_____

- Brake fluid, new

Date, stamp, signature

BMW Service

- BMW Annual Inspection
- BMW Service
- BMW Inspection

Carried out in accordance with manufacturer's instructions

Odometer reading_____

- Brake fluid, new

Date, stamp, signature

BMW Service

- BMW Annual Inspection
- BMW Service
- BMW Inspection

Carried out in accordance with manufacturer's instructions

Odometer reading_____

- Brake fluid, new

Date, stamp, signature

BMW Service

- BMW Annual Inspection
- BMW Service
- BMW Inspection

Carried out in accordance with manufacturer's instructions

Odometer reading_____

- Brake fluid, new

Date, stamp, signature

BMW Service

- BMW Annual Inspection
- BMW Service
- BMW Inspection

Carried out in accordance with manufacturer's instructions

Odometer reading_____

- Brake fluid, new

Date, stamp, signature

- A**
- Abbreviations and symbols, 6
 - ABS
 - Warning light, 24
 - Accessories
 - General instructions, 96
 - Anti-theft alarm, 18
 - ASC
 - Function description, 92
 - Switch off, 65
 - Switching on, 65
- B**
- Battery
 - Charging battery when connected, 132
 - Charging battery when disconnected, 133
 - Installation, 134
 - Maintenance instructions, 132
 - Removal, 133
 - Warning, battery charge current, 30
 - Brake fluid
 - Checking fluid level, front brakes, 109
 - Checking fluid level, rear brakes, 110
 - Brake lever
 - Adjusting handbrake lever, 60
 - Brake pads
 - Checking front, 108
 - Checking rear, 109
 - Running in, 83
 - Brakes, 107
 - Fluid reservoir, rear, 15
 - Front fluid reservoir, 11
 - Safety instructions, 88
 - Technical data, 151
 - Bulbs
 - general instructions, 120
 - Replacing brake-light bulb, 127
 - Replacing front turn indicator bulb, 129
 - Replacing high-beam headlight bulb, 121
 - Replacing left low-beam headlight bulb, 122
 - Replacing parking-light bulb, 125
 - Replacing rear light bulb, 127
 - Replacing rear turn indicator bulb, 127
 - Replacing right low-beam headlight bulb, 122
 - Technical data, 153
 - Warning, bulb failure, 30, 31
- C**
- Case
 - Closing, 98
 - Installing, 99
 - Opening, 98
 - Removing, 99
 - Centre stand
 - Placing motorcycle on centre stand, 85
 - Removing motorcycle from centre stand, 86
 - Checklist, 80

Clock
 Adjusting, 18, 49

Clutch
 Adjusting clutch lever, 60
 Checking operation, 111
 Fluid reservoir, 13
 Technical data, 149

Confirmation of maintenance work, 161

Cruise-control system, 16, 54
 Deactivating, 56
 Resuming cruising speed, 56
 Setting road speed, 54
 Step-by-step acceleration, 55
 Step-by-step deceleration, 55
 Stepless acceleration, 55
 Stepless deceleration, 56
 Switching off, 56
 Switching on, 54
 Telltale light, 24

Currency, 7

D
Dimensions
 Technical data, 154

E
Electrics
 Technical data, 152

Emergency off switch (kill switch), 17, 57

Engine
 Starting, 80
 Technical data, 146
 Warning, engine electronics, 28

Engine oil
 checking level, 105
 Filler neck, 11
 Sight glass, 11
 Technical data, 147
 Temperature gauge, 24
 topping up, 106
 Warning, engine oil level, 29
 Warning, engine oil pressure, 29

Equipment, 7

ESA, 16
 Adjusting spring preload, 74
 Adjusting suspension damping, 73
 Calling up settings, 73

EWS
 Function description, 45
 Warning, 28

F
Final drive
 Technical data, 150

Frame
 Technical data, 154

Front seat
 Adjusting, 15, 67
 Heating, 17, 58
 Installation, 68
 Removal, 67

Front-wheel stand, 119

- Fuel
 - Filler neck, 13
 - Quantity reading, 24
 - refuelling, 86
 - Warning, fuel down to reserve, 28
- Fuses, 152
- G**
 - Gear indicator, 24
 - Grip heating, 17, 57
- H**
 - Handlebar fittings
 - Feneral view, left side, 16
 - Feneral view, right side, 17
 - Hazard warning flashers, 16, 17
 - Switching off, 47
 - Switching on, 46
 - Headlight
 - Adjusting headlight beam throw, 62
 - Adjustment for driving on left/driving on right, 62
 - high-beam headlight, 19
 - low-beam headlight, 19
 - side lights, 19
 - Helmet holder, 15, 69
 - High-beam headlight, 16
 - Telltale light, 24
 - Horn, 16
- I**
 - Idle
 - Telltale light, 24
 - Ignition
 - Switching off, 44
 - Switching on, 44
 - Ignition switch, 44
 - Immobiliser
 - Function description, 45
 - Warning, 28
 - Instrument cluster
 - Overview, 18
 - Sensor for lighting, 18
- J**
 - Jump start, 130
- K**
 - Keys, 46
- L**
 - Laying up, 140
 - Lights
 - Adjusting headlight beam throw, 11, 63
 - Switching off parking lights, 62
 - Switching on high-beam headlight, 61
 - Switching on low-beam headlight, 61
 - Switching on parking lights, 62
 - Switching on side lights, 61
- M**
 - Maintenance
 - Feneral instructions, 104
 - Intervals, 159
 - Mirrors
 - adjusting, 70
 - Multifunction display, 18
 - Adjusting dimmer, 48
 - Overview, 22

O

- Odometer and tripmeters
 - Odometer, 47
 - Resetting tripmeter, 48
 - Selecting tripmeter, 47
- On-board computer
- Oil level, 53
- Range, 51
- Resetting average consumption, 53
- Resetting average speed, 52
- Selecting readings, 50

P

- Power socket, 11, 96
- Pre-ride check, 81

R

- Range, 51
- Rear seat
 - Heating, 13, 59
 - Installation, 68
 - Removal, 66
- Refuelling, 86

- Reserve
 - Warning, 28
- Residual range, 50
- Restoring to use, 141
- Rev. counter, 18
- Running gear
 - Technical data, 150
- Running in, 83

S

- Safety instructions, 78
 - Brakes, 88
 - Correct loading, 78
- Service, 158
- Service Card, 159
- Side stand
 - Placing motorcycle on side stand, 84
 - Removing motorcycle from side stand, 85
 - starting the engine, 80
- Spark plugs
 - Technical data, 153
- Speedometer, 18

- Spring preload
 - Adjusting, 70
- Spring preload, rear
 - Adjusting, 15, 70
- Starter, 17
- Starting, 80
- Steering lock
 - Locking, 45
- Stowage compartment, 64
- Suspension damping, rear
 - Adjusting, 11, 72

T

- Technical data
 - Brakes, 151
 - Bulbs, 153
 - Clutch, 149
 - Dimensions, 154
 - Electrics, 152
 - Engine, 146
 - Engine oil, 147
 - Final drive, 150
 - Frame, 154
 - Running gear, 150
 - Spark plugs, 153

- Standards, 7
- Transmission, 149
- Tyre pressures, 4, 152
- Weights, 155
- Wheels and tyres, 151
- Telltale lights, 18
 - Overview, 24
- Toolkit
 - Service kit, 105
 - Standard equipment, 104
- Topcase
 - Closing, 101
 - Installing, 101
 - Opening, 100
 - Removing, 101
- Torques, 145
- Transmission
 - Starting engine, 80
 - Technical data, 149
- Troubleshooting chart, 144
- Turn indicators
 - Left, 16, 63
 - Right, 17, 63
 - Switching off, 17, 64
 - Telltale lights, 24
- Type plate, 15
- Tyre pressure control (ReifenDruck-Control)
 - Label on wheel rim, 113
 - Operation, 49
- Tyres
 - Approved tyres, 112
 - Checking tread depth, 112
 - Checking tyre pressures, 74
 - Inflation pressures, 4, 152
 - Running in, 84
 - Table of air pressures, 15
 - Technical data, 151
- V**
 - Vehicle
 - General view, left side, 11
 - General view, right side, 13
 - Laying up, 140
 - Parking, 84
 - Restoring to use, 141
- W**
 - Warning lights, 18
 - Overview, 24
 - Warning light, general, 24
 - Warnings
 - Mode of presentation, 25
 - Warnings, overview, 26, 34, 38, 40
 - Weights
 - Technical data, 155
 - Wheels
 - Installing front wheel, 115
 - Installing rear wheel, 117
 - Remove the rear wheel, 116
 - Removing front wheel, 113
 - Technical data, 151
 - Windscreen
 - Adjusting, 13, 16, 70

Details described or illustrated in this booklet may differ from the motorcycle's actual specification as purchased, the accessories fitted or the national-market specification. No claims will be entertained as a result of such discrepancies.

Dimensions, weights, fuel consumption and performance data are quoted to the customary tolerances.

The right to modify designs, equipment and accessories is reserved.

Errors and omissions excepted.

© 2006 BMW Motorrad

Not to be reproduced either wholly or in part without written permission from BMW

Motorrad, After Sales.

Printed in Germany.

Important data for refuelling

Fuel

Recommended fuel grade	95 ROZ/RON, Super unleaded 91 ROZ/RON, Regular unleaded (fuel grade, usable with power- and consumption-related restrictions)
------------------------	--

Usable fuel capacity	27 l
----------------------	------

Reserve fuel	4 l
--------------	-----

Tyre pressures

Tyre pressure, front	2.2 bar, One-up, tyre cold 2.5 bar, Two-up and/or with luggage, tyre cold
----------------------	---

Tyre pressure, rear	2.5 bar, One-up, tyre cold 2.9 bar, Two-up and/or with luggage, tyre cold
---------------------	---

BMW recommends 

Order No. 01 41 7 704 051
06.2006, 3rd edition

