

Rider's Manual

R 1200 RT



BMW Motorrad



Welcome to BMW

We congratulate you on your choice of a motorcycle from BMW and welcome you to the community of BMW riders.

Familiarise yourself with your new motorcycle so that you can ride it safely and confidently in all traffic situations. Please read this Rider's Manual carefully before starting to use your new BMW motorcycle. It contains important information on how to operate the controls and how to make the best possible use of all your BMW's technical features. In addition, it contains information on maintenance and care to help you maintain your motorcycle's reliability and safety, as well as its value.

If you have any questions concerning your motorcycle, your authorised BMW motorcycle dealer will gladly provide advice and assistance.

We hope you enjoy reading this Rider's Manual and wish you many a pleasant, safe journey on your BMW motorcycle.

Best wishes,

BMW Motorrad

Table of contents

Use the index (➡ 159), to find a certain topic quickly.

Welcome to BMW	1
General information	4
Overview	7
General view, left side	9
General view, right side	11
Underneath the seat	13
Handlebar fitting, left	14
Handlebar fitting, right	15
Instrument cluster	16
Headlight	17
Status indicators	19
Multifunction display	20
Warning and telltale lights	21
Warning indicators	21
ABS warnings	27

Operation	33
Ignition switch and steering lock	34
Electronic immobiliser ..	36
Hazard warning flashers	37
Odometer and tripmeters	37
Clock	38
Display dimming	39
On-board computer ^{OE}	39
Cruise control ^{OE}	42
Emergency off switch (kill switch)	45
Grip heating ^{OE}	45
Seat heating ^{OE}	46
Handlebar levers	47
Lights	48
Turn indicators	50
Stowage compartment	51
Front and rear seats	52
Helmet holder	54
Mirrors	55

Windscreen	55
Spring preload	55
Shock absorbers	56
Wheels	57
Riding	59
Safety instructions	60
Safety check	62
First time out	62
Before you start	63
Starting	66
Riding	69
Running in	69
Engine speed	70
Shifting gear	71
Placing motorcycle on its side stand	73
Removing motorcycle from side stand	75
Placing motorcycle on centre stand	77
Removing motorcycle from centre stand	79
Fuel	79
Brake system	80

Accessories 85

General instructions 86

On-board sockets 86

Luggage system 89

Maintenance 95

Toolkit 97

Engine oil 98

Brakes 99

Clutch 103

Wheels 103

Front-wheel stand 111

Bulbs 112

Jump starting 118

Battery 120

Splash guard 123

Care 125

Cleaning and care 126

Laying up 128

Restoring to use 129

Technical data 131

Threaded fasteners 132

Tyre pressures 134

Engine 135

Power transmission 136

Frame and

suspension 137

Wheels and tyres 139

Fuel and lubricants 140

Electrical system 143

Dimensions and

weights 145

Riding

specifications 146

Service 147

BMW Motorrad

service 148

Confirmation of

maintenance work 151

Confirmations of

service 155

Index 159

General information

About this Rider's Manual

We have tried to make all the information in this Rider's Manual easy to find. The quickest access to a particular topic or item is by consulting the detailed alphabetical index (➡ 159).

Chapter 1 of this Rider's Manual will provide you with an initial overview of your motorcycle. When the time comes to sell your BMW, please remember to hand over this Rider's Manual; it is an important part of your motorcycle.

Symbols and abbreviations



Indicates warnings that you must comply with for reasons of your safety and the safety of others, and to protect your motorcycle against damage.



Special information on operating and inspecting your motorcycle as well as maintenance and adjustment procedures.

◀ Indicates the end of an item of information.

• Instruction.

» Result of an activity.

(➡ 4) Reference to a page with more detailed information.

OE Optional extra
Your motorcycle was assembled complete with all the optional extras you ordered.

OA Optional accessory
You can obtain optional accessories through your authorised BMW motorcycle dealer; optional accessories have to be retrofitted to the motorcycle.

EWS Electronic immobiliser

DWA Anti-theft alarm system

ABS Anti-lock braking system

Custom equipment

When you ordered your BMW motorcycle, you chose various items of custom equipment. This Rider's Manual describes optional extras (OE) offered by BMW and selected optional accessories (OA). This explains why the manual may also contain descriptions of equipment which you have not ordered. Please note, too, that your motorcycle might not be exactly as illustrated in this manual on account of country-specific differences. If your BMW was supplied with equipment not described in this Rider's Manual, you will find these features described in separate manuals.

Technical data

All dimensions, weights and power ratings stated in the Rider's Manual are quoted to the standards and comply with the tolerance requirements of the Deutsche Institut für Normung e. V. (DIN). Versions for individual countries may differ.

Currency

The high safety and quality standards of BMW motorcycles are maintained by constant development work on designs, equipment and accessories. Because of this, your motorcycle may differ from the information supplied in the Rider's Manual. Nor can errors and omissions be entirely ruled out. We hope you will appreciate that no

claims can be entertained on the basis of the data, illustrations or descriptions in this manual.

BMW Service

Advanced technology requires specially adapted methods of maintenance and repair.



If maintenance and repair work is performed inexpertly, it could result in consequential damage and thus constitute a safety risk. BMW recommends that you have the necessary work on your motorcycle performed either by an authorised BMW motorcycle dealer or by a workshop that operates to BMW specifications and employs suitably trained personnel. ◀

Your authorised BMW motorcycle dealer can provide information on the specified Service, Inspection and Annual Inspection work needed.

Have all maintenance and repair work carried out confirmed in the "Service" chapter (► 148) in this manual.

Authorised BMW motorcycle dealers are supplied with the latest technical information and have the necessary technical know-how.

Consequently, we recommend that you contact your authorised BMW motorcycle dealer if you have any questions regarding your motorcycle.

Rider's equipment

Do not ride without the correct clothing. Always wear:

- helmet
- motorcycling jacket and trousers
- gloves
- boots

This applies even to short journeys, and to every season of the year. Your authorised BMW motorcycle dealer will be glad to advise you on the correct clothing for every purpose.

General view, left side	9
General view, right side.....	11
Underneath the seat	13
Handlebar fitting, left	14
Handlebar fitting, right	15
Instrument cluster	16
Headlight	17




General view, left side

- 1** Adjuster for headlight beam throw underneath the instrument cluster (➡ 49)
- 2** Brake-fluid reservoir (➡ 102)
- 3** Radio operating panel^{OE}
- 4** On-board socket (➡ 86)
- 5** On-board socket^{OE/OA} (➡ 86)
- 6** Adjuster, rear shock absorber (➡ 55)
- 7** Oil sight glass (➡ 98)
- 8** Filler neck, engine oil (➡ 99)



General view, right side

- 1 Seat lock (➡ 52)
- 2 Switch, rear-seat heating^{OE} underneath the rear seat (➡ 47)
- 3 Mount, tank rucksack^{OE} (➡ 94)
- 4 Filler neck, fuel tank
- 5 Brake-fluid reservoir, front (➡ 102)
- 6 Electrically adjustable windscreen (➡ 55)
- 7 Stowage or radio compartment^{OE} (➡ 51)





Underneath the seat

- 1** Height adjuster, front seat
( 53)
- 2** Battery ( 120)
- 3** Brake-fluid reservoir, rear
( 102)
- 4** Adjuster, spring preload,
rear ( 55)
- 5** On-board toolkit ( 97)
- 6** Type plate
- 7** Helmet holder ( 54)
- 8** Table of tyre pressures
- 9** Label, payload

Handlebar fitting, left

- 1 Switch, cruise control^{OE}
(➡ 42)
- 2 Pushbutton, hazard warning flashers (➡ 37)
- 3 Radio operating panel^{OE}
- 4 Pushbutton, windscreen adjustment (➡ 55)
- 5 Pushbutton, horn
- 6 Pushbutton, left flashing turn indicators (➡ 50)
- 7 Switch, high-beam headlight and headlight flasher (➡ 48)






Handlebar fitting, right


- 1** Pushbutton, on-board computer^{OE} (➡ 39)
- 2** Emergency off switch (kill switch) (➡ 45)
- 3** Pushbutton, starter
- 4** Switch, grip heating^{OE} (➡ 45)
- 5** Pushbutton, flashing turn indicators, right (➡ 50)
- 6** Pushbutton, flashing turn indicators off (➡ 51)
- 7** Switch, front-seat heating^{OE} (➡ 46)

Instrument cluster

- 1 Speedometer
- 2 Warning and telltale lights (➡ 21)
- 3 Multifunction display (➡ 20)
- 4 Rev. counter
- 5 Telltale light, anti-theft alarm^{OE}
- 6 Adjuster, clock (➡ 38)
- 7 Control, odometer (➡ 37)
- 8 Sensor, lights for instrument cluster

 The instrument-cluster lighting has automatic day and night switchover. The brightness of the night setting is variable (➡ 39). ◀





Headlight

- 1 High-beam headlight
- 2 Low-beam headlight
- 3 Side light

Multifunction display	20
Warning and telltale lights	21
Warning indicators	21
ABS warnings	27



Multifunction display

- 1 Fuel gauge
- 2 Display, radio^{OE}
- 3 Display area for warning symbols
- 4 Gear indicator
- 5 Oil temperature gauge
- 6 Display, on-board computer^{OE} (→ 39)
- 7 Odometer
- 8 Display area for clock, seat heating^{OE}, display dimming.

Fuel capacity

 The height of the bar indicates the level of fuel in the fuel tank.


Gear indicator

 The gear indicator shows which gear is selected. If no gear is engaged, the gear indicator displays 0; the 'neutral' telltale light also lights up.

Oil temperature

 The height of the bar indicates the oil temperature.

Warning and telltale lights



- 1 Telltale light, left turn indicator
- 2 Telltale light, high-beam headlight
- 3 Telltale light, neutral
- 4 ABS warning light (or  depending on national-market specification)
- 5 Telltale light, right turn indicator

- 6 Telltale light, cruise-control system
- 7 Warning light, general

Warning indicators

Warnings are displayed by means of symbols in the multi-function display. In some cases, an additional general warning light lights up red or yellow. A number of warnings may be issued simultaneously.

 Warning lights and symbols in the display appear only when the emergency off switch ( 45) (kill switch) is in the 'run' position. ◀

Overview

The warnings are listed in the table below, along with the page numbers of the pages you can refer to for more information.

Light	Symbol	Meaning	Explanations
		Ignition key not authorised.	(➡ 36)
		Low-beam headlight, high-beam headlight, side-light or turn-indicator bulb defective.	(➡ 26)
		Ambient temperature below 3 °C (on-board computer ^{OE})	(➡ 26)
 yellow		Fuel down to reserve	(➡ 24)
 yellow		Fault in the engine electronics	(➡ 24)
 yellow		Rear light or brake light bulb defective	(➡ 26)
 yellow		Front/rear bulbs defective	(➡ 26)
 red		Engine-oil temperature too high	(➡ 24)

Light	Symbol	Meaning	Explanations
 red		Engine-oil pressure too low	(➡ 25)
 red		Battery is no longer being charged	(➡ 26)
 red		Brake switch defective	(➡ 27)
	 1 flash per second	ABS pull-away test not completed	(➡ 28)
	 4 flashes per second	ABS self-diagnosis not completed	(➡ 28)
 red		Relay for ABS warning lights defective	(➡ 28)
 red	 1 flash per second	ABS function not available	(➡ 29)
 red	 4 flashes per second	ABS in residual braking mode	(➡ 29)
 1 red flash per second	 1 flash per second	Insufficient brake fluid	(➡ 30)
 4 red flashes per second	 4 flashes per second	Two or more ABS faults	(➡ 31)

Electronic immobiliser

 Immobiliser symbol is displayed.

The key being used is not authorised for starting, or communication between key and engine electronics is disrupted.

- Remove all other vehicle keys located near the ignition key (➡ 34).
- Use the reserve key.
- Have the defective key replaced, preferably by an authorised BMW motorcycle dealer (➡ 36).

Fuel reserve

 General warning light lights up yellow.

 Fuel reserve symbol is displayed and flashes 10 times.

The fuel tank contains a fuel reserve of a maximum of 4 litres. The on-board computer shows the estimated residual operating range (➡ 39).

 Lack of fuel can result in the engine cutting out unexpectedly and this could result in a hazardous situation. Do not run the fuel tank dry. ◀

 Lack of fuel could result in misfiring and this in turn could damage the catalytic converter. Do not run the fuel tank dry. ◀

- Refuel.

Oil temperature

 General warning light lights up red.

 Oil temperature gauge flashes 10 times.

Oil temperature too high.

 Continuing to ride with the engine overheated can result in engine damage. ◀

- If possible, ride in the part-load range to cool down the engine.
- Switch off the engine if you are caught in a traffic jam.

Engine electronics

 General warning light lights up yellow.

 Engine electronics symbol is displayed.

Fault in the engine electronics. In exceptional cases, the engine stops and can no longer be started. Otherwise, the engine runs in emergency operating mode.

You can continue to ride, but bear in mind that the usual engine output is not available.



The engine is running in emergency operating mode. Engine power might be reduced and this can cause hazardous situations, particularly if you attempt to overtake other road users.

Adapt your style of riding to the reduced level of engine power. ◀

Engine oil pressure



General warning light lights up red.



Engine oil pressure symbol is displayed.

Insufficient engine oil pressure
The "engine oil pressure" warning indicates that there is no oil pressure or that the oil

pressure in the lubricating oil circuit is too low; under no circumstances is it to be regarded as fulfilling the function of an oil gauge. The warning must disappear when oil pressure builds up 1 to 2 seconds after the engine starts.

If the "engine oil pressure" warning is displayed while the motorcycle is being ridden, take account of the traffic situation and:

- Disengage the gear.
- Operate the kill switch.
- Bring the motorcycle safely to a halt.
- Check the engine oil level.



There are other engine-related problems besides a low engine-oil level that can trigger the "engine-oil pressure" warning. Continuing to ride in these cases can cause engine damage.

If the "engine oil pressure" warning is issued, do not continue to ride if a check shows that the engine oil level is correct. ◀

- Have the fault rectified by a specialist workshop, preferably an authorised BMW motorcycle dealer.

Battery charge current



General warning light lights up red.



Battery charge current symbol is displayed.

The battery is no longer being charged. You can continue to ride only until the battery is discharged.



A discharged battery can result in the engine cutting out unexpectedly, causing a hazardous situation. If possible, do not continue your journey. ◀

- Have the fault rectified as soon as possible by a specialist workshop, preferably an authorised BMW motorcycle dealer.

Defective bulb



A defective bulb places your safety at risk because it is easier for other users to oversee you and your motorcycle.

Replace defective bulbs as soon as possible; always carry a complete set of spare bulbs if possible. ◀



General warning light lights up yellow.



Defective bulb symbol with arrow pointing to the rear is displayed.

Rear light or brake light bulb defective.

- Replace bulbs (► 116).



Defective bulb symbol with arrow pointing to the front is displayed.

Low-beam headlight, high-beam headlight, side-light or turn-indicator bulb defective.

- Replace bulbs (► 112).



General warning light lights up yellow.



Defective bulb symbol with two arrows is displayed.

A combination of the bulb defects described above has occurred.

- Replace bulbs (► 112).

Ice warning



Symbol for ice warning is displayed (motorcycle with on-board computer^{OE} only).

The air temperature measured at the motorcycle is lower than 3 °C: Risk of black ice.



The ice warning does not mean that there is no risk of black ice forming at measured temperatures above 3 °C. Always take extra care when temperatures are low and think well ahead; remember that the danger of black ice is particularly high on bridges and where the road is in the shade. ◀

ABS warnings



ABS warnings are indicated by a combination of the general warning light and the ABS warning light (or  depending on national-market specification). Both warning lights can light up continuously or flash at a rate of one or four flashes per second.

General warning light



General warning light red.

Brake switch defective or incorrectly adjusted. BMW Integral ABS detects the driver's braking request by the pressure build-up from the brake lever. There may be an unusual response from the brakes. You can continue to ride. However, bear in mind that the brakes may respond in a manner to which you are not accustomed.



There is a defect in the brake system that can lead to abnormal braking. Think well ahead and brake carefully; avoid severe braking. ◀

- Have the fault rectified as soon as possible by a specialist workshop, preferably an authorised BMW motorcycle dealer.

ABS warning light

 ABS warning light flashes once per second.

ABS function not available because pull-away test (➡ 69) not completed.

You can continue to ride. To prevent the wheels from locking:

- Do not use emergency braking until the pull-away test has been completed.

 Without the ABS function, the wheels could lock under braking.

Think well ahead and brake carefully; avoid severe braking. ◀

 ABS warning light flashes four times per second.

Only residual braking function available in both brake circuits, because self-diagnosis (➡ 65) has not completed.

You can continue to ride. However, bear in mind that until self-diagnosis has completed, neither the ABS function nor the brake booster is available.

 Without the ABS function, the wheels could lock under braking; without servo-assisted brakes, considerably greater force is required to brake.

Think well ahead and brake carefully; avoid severe braking. ◀

- If circumstances permit, do not apply the brakes until self-diagnosis has completed.

General warning light and ABS warning light

 General warning light red.

 ABS warning light ON.

The controller of the ABS warnings is defective. ABS faults cannot be displayed. You can continue to ride, but bear in mind that you will not receive warning of ABS faults, if they occur.



ABS warnings not available. ABS faults cannot be indicated.

Think well ahead and brake carefully; avoid severe braking. ◀

- Have the fault rectified as soon as possible by a specialist workshop, preferably an authorised BMW motorcycle dealer.



General warning light red.



ABS warning light flashes once per second.

ABS function (► 81) unavailable in at least one brake circuit.

You can continue to ride. However, bear in mind that the ABS function is not available.



Without the ABS function, the wheels could lock under braking.

Think well ahead and brake carefully; avoid severe braking. ◀

- Have the fault rectified as soon as possible by a specialist workshop, preferably an authorised BMW motorcycle dealer.



General warning light red.



ABS warning light flashes 4 times per second.

Only residual braking function (► 83) available in at least one brake circuit.

You can continue to ride. However, bear in mind that neither the ABS function nor the brake booster is available.



Without the ABS function, the wheels could lock under braking; without servo-assisted brakes, considerably greater force is required to brake.

Think well ahead and brake carefully; avoid severe braking. ◀

- Have the fault rectified as soon as possible by a specialist workshop, preferably an authorised BMW motorcycle dealer.



General warning light flashes red once per second.



ABS warning light flashes once per second.

Fluid level in at least one wheel brake circuit too low.



The ABS wheel brake circuit is a closed system; you cannot check the fluid level in this circuit at the brake-fluid reservoirs. ◀

Several factors, including very badly worn brake pads, can trigger this warning.



Worn brake pads can lengthen braking distance by a significant margin. Think well ahead and brake carefully; avoid severe braking. ◀



Worn brake pads can damage the brake discs. Think well ahead and brake carefully; avoid severe braking. ◀

- Stop and check the thickness of the brake pads (mm 100).
- Have worn brake pads replaced as soon as possible by a specialist workshop, preferably an authorised BMW motorcycle dealer.

If brake pad thickness is sufficient:

- Check the following functions:

- Ignition off, brake pressure present at the brake levers.
- Brakes acting on both wheels.
- Brake system leaktight, no signs of brake fluid escaping.

If any of the above criteria is not satisfied:



There is a defect in the brake system.

Do not continue to ride. ◀

If these criteria are satisfied, you can continue riding. However, bear in mind that a loss of brake fluid that cannot be detected might be the cause of the warning.



There is a fault in the brake system that can lead to decreased braking efficiency.

Think well ahead and brake carefully; avoid severe braking. ◀

- Have the fault rectified as soon as possible by a specialist workshop, preferably an authorised BMW motorcycle dealer.



General warning light flashes red four times per second.



ABS warning light flashes four times per second.

There are two faults:

- Only residual braking function (▶ 83) available in at least one brake circuit, indicated by the general warning light and the ABS warning light flashing 4 times per second.
- Fluid level in the BMW Integral ABS is too low, indicated by the general and ABS warning lights flashing once per second.

See the fault descriptions above.

Ignition switch and steering lock	34
Electronic immobiliser	36
Hazard warning flashers	37
Odometer and tripmeters	37
Clock	38
Display dimming	39
On-board computer ^{OE}	39
Cruise control ^{OE}	42
Emergency off switch (kill switch)	45
Grip heating ^{OE}	45
Seat heating ^{OE}	46
Handlebar levers	47
Lights	48
Turn indicators	50
Stowage compartment	51

Front and rear seats	52
Helmet holder	54
Mirrors	55
Windscreen	55
Spring preload	55
Shock absorbers	56
Wheels	57

Ignition switch and steering lock

Keys

You receive one master key and one spare key. If a key is lost, please note the information on the electronic immobiliser (EWS) (► 24).



Ignition switch and steering lock, tank filler cap lock and the seat and case locks are all operated with the same key. The topcase^{OA} is available in two different sizes; if you wish you can arrange to have the topcase fitted with a lock that can be opened with this key as well. ◀

Switching on the ignition



- Turn the key to the ○ position.
 - » Side lights and all function circuits switched on.
 - » Pre-ride check is performed (► 63).
 - » ABS self-diagnosis is performed (► 65).
 - » Engine can be started.

Switching off the ignition



- Turn the key to the ⊗ position.
 - » Ignition and lights are switched off.
 - » The radio remains operational for a limited period of time (see the operating instructions for the radio^{OE}).
 - » Electrically powered accessories remain operational for a limited period of time (► 87).

- » The battery can be recharged via the on-board socket (➡ 120).
- » Handlebars not locked.
- » The key can be removed in this position.

 Brake servo assistance is not available when the ignition is off.

Do not switch off the ignition while the motorcycle is being ridden. ◀

 If the motorcycle is laid up for a prolonged period with the ignition lock in this position, recharge the battery every four weeks (➡ 120). ◀

Locking the handlebars



- Turn the handlebars to the full left or right lock position.
- Turn the key to the  position for OFF, while moving the handlebars slightly.
 - » Ignition, lights and all function circuits switched off.
 - » Handlebars locked.
 - » In this position, you can remove the key.

 If the motorcycle is laid up for a prolonged period with the ignition lock in this position, recharge the battery every two months (➡ 120). ◀

 When you prop the motorcycle on the side stand, the surface of the ground will determine whether it is better to turn the handlebars to the left or right. On level ground, a secure stance is ensured only with the handlebars turned to the left. On level ground, always turn the handlebars to the left and lock them in this position. ◀

Electronic immobiliser

The electronic immobiliser helps protect your BMW motorcycle from theft, and this enhanced security is at your disposal without any need for you to set parameters or activate additional systems. The engine of a motorcycle fitted with this electronic immobiliser can be started only with the keys that belong to the vehicle. You can also have your authorised BMW motorcycle dealer bar individual keys, for example if a key goes missing. The engine cannot be started with a key that has been barred.

In-key security

An electronic component is integrated into each of your keys. The motorcycle's electronics exchange certain continuously changing signals with the electronics in the key; these signals are specific to your motorcycle and they are transmitted via the ring aerial in the ignition lock. The ignition is not enabled for starting until the key has been recognised as authorised for your motorcycle.



A spare key attached to the same ring as the ignition key used to start the engine could "upset" the electronics, in which case the enabling signal for starting is not issued. The "EWS" warning is displayed in

the multifunction display. Always keep the spare key separately from the ignition key. ◀

Replacement and extra keys

You can obtain replacement/extra keys only through an authorised BMW motorcycle dealer. The keys are part of an integrated security system, so the dealer is under an obligation to check the legitimacy of all applications for replacement/extra keys.

If you want to have a lost key barred, you have to bring with you all the keys that belong to the motorcycle. A key that has been barred can subsequently be cleared and reactivated for use.

Hazard warning flashers

Switching on the hazard warning flashers



- Switch on the ignition.
- Press hazard warning flashers button **1**.
- » Hazard warning flashers in operation.
- » Left/right turn indicator tell-tale lights flash.
- Switch off the ignition.

- » The hazard warning flashers continue to operate.
- » Left/right turn indicator tell-tale lights off.

▶ You can also switch on the hazard warning flashers by simultaneously pressing the buttons for the left and right turn indicators. ◀

▶ The hazard warning flashers place a strain on the battery. Do not use the hazard warning flashers for longer than absolutely necessary. ◀

Switching off the hazard warning flashers

- Press hazard warning flashers button **1**.
- » Hazard warning flashers cease to operate.

▶ Switching on a turn signal temporarily deactivates the hazard warning flashers. The hazard warning flashers switch on again as soon as the turn signal is cancelled. ◀

Odometer and tripmeters

Odometer



The odometer reading appears in display field **1**.

Selecting the tripmeter

- Switch on the ignition.

 When you switch on the ignition, the tripmeter reading shown when the ignition was switched off reappears on the multifunction display. ◀



- Briefly press tripmeter button **3** once.

- » The following alternate in display field **2**:
- Tripmeter 1 (Trip I)
 - Tripmeter 2 (Trip II)

If your motorcycle is fitted with an on-board computer^{OE} (► 39), the tripmeter readings in display field **1** alternate with the odometer reading.

Resetting the tripmeter

- Switch on the ignition.
 - Select the desired tripmeter.
 - Press tripmeter button **3** and hold it down for longer than 2 seconds.
- » The tripmeter is reset to zero.

Clock



Attempting to set the clock while riding the motorcycle can lead to accidents. Set the clock only when the motorcycle is stationary. ◀

- Switch on the ignition.



- Press button **1** for longer than 2 seconds.
- » Hours reading **2** starts to flash.

- Briefly press button **1**.
 - » The hour increments by one each time you press the button.
- Press button **1** for longer than 2 seconds.
 - » Minutes reading **3** starts to flash.
- Briefly press button **1**.
 - » The minute increments by one each time you press the button.
- Press button **1** for longer than 2 seconds.
 - » Setting confirmed.

Display dimming

The brightness of the backlit multifunction display is variable.




- Press button **1**.
 - » The level of dimming appears in display field **2**.
- Press button **1** again.
 - » The brightness of the display increases one level each time you press the button. Each time you press the button after maximum brightness is reached, brightness is reduced by one level.

On-board computer^{OE}

Selecting readings

- Switch on the ignition.



- Briefly press BC button **1**.



» Each time you press the button, display field **2** cycles through the following readings:

- Residual range
- Average speed
- Average consumption
- Oil level
- Ambient temperature

Residual range

Residual range is calculated on the basis of your style of riding and the amount of fuel left in the tank; the reading indicates the estimated distance you can travel before the fuel supply runs out.

If the motorcycle is resting on its side stand, the level in the tank cannot be measured correctly, so this estimate of residual operating range will be inaccurate.


When you refuel (ignition switched off) the on-board computer does not register the increase in fuel level unless more than 2 litres are added to the fuel already in the tank. The tank must contain at least 5 litres of fuel for the fuel-gauge reading and the residual range to be recalculated.

The residual range is only an approximate reading. Consequently, you should not try to use the full residual range before refuelling.

Average speed

Elapsed time since the last "RESET" is used as the basis for calculating average speed. Times during which the engine was stopped are excluded from the calculation.

Resetting average speed



- Repeatedly press BC button 1 until the average speed appears in the display.
- Hold the BC button down for at least 2 seconds (RESET).
 - » The display shows "---.- km/h"

Average consumption

Average consumption is calculated by dividing the distance covered since the last RESET by the corresponding amount of fuel used.

Resetting average consumption

- Repeatedly press the BC button until the average consumption appears in the display.
- Hold the BC button down for at least 2 seconds (RESET).
 - » The display shows "---.- l/100 km"

Oil level check



The "Oil" reading gives you an indication of the engine oil level. The preconditions for the oil level check are as follows:

- Engine idling (for at least 10 seconds)
- Engine at operating temperature
- Side stand retracted

The readings mean:



Oil level is correct.



Check the oil level (→ 98).



Oil level cannot be measured (conditions as stated above not satisfied).

The most recently measured level is displayed for 5 seconds when you next switch on the ignition.

 The oil-level sensor might be faulty if "Check the oil level" appears in the display and does not go out, although a check of the oil sight glass shows that the oil level is correct.

Under these circumstances, contact your authorised BMW motorcycle dealer. ◀

Ambient temperature

The current ambient temperature is displayed. An ice warning ( 26) appears if the ambient-temperature reading drops below 3 °C. The display automatically switches from any other mode to the temperature reading when the temperature drops below this threshold for the first time. The reading flashes until you select some other display mode.

Cruise control^{OE}



Activating the system

- Set switch **1** to **ON**.
- » Red telltale light **2** in the switch lights up.

Setting road speed



- Briefly push button **3** in the **SET** direction (arrow).



- » The **yellow** SET telltale light of the cruise control system lights up.
- » The motorcycle maintains your current cruising speed and the setting is saved.

Step-by-step acceleration



- Briefly push button **3** in the **SET** direction
- » Speed is increased by approx. 2 km/h each time you push the button, and the new setting is saved.

Stepless acceleration

- Push button **3** in the **SET** direction (arrow) and hold it in this position.
- » The motorcycle accelerates steplessly.
- Release button **3**.
- » The motorcycle maintains your current cruising speed and the setting is saved.

Step-by-step deceleration



- Briefly push button **3** in the **RES** direction (arrow).
- » Speed is decreased by approx. 2 km/h each time you push the button, and the new setting is saved.

Stepless deceleration

- Push button **3** in the **RES** direction (arrow) and hold it in this position.
- » The motorcycle decelerates steplessly and the new setting is saved.

Deactivating the system

When you actuate the:

- Brakes
- Clutch
- Throttle twistgrip (turn the twistgrip back past the normal closed-throttle position)

the cruise-control system is deactivated.

- » The **yellow** SET telltale light of the cruise control system goes out.
- » The **red** telltale light in the switch remains on.

Resuming former cruising speed

- Push button **3** in the **RES** direction.
- » The **yellow** SET telltale light of the cruise control system lights up.
- » The motorcycle resumes the previous cruising speed and this setting is saved.


 Opening the throttle does not deactivate the cruise-control system. If you release the twistgrip the motorcycle will decelerate only to the cruising speed saved in memory, even though you might have intended slowing to a lower speed. ◀

Deactivating the system



- Move switch **1** to **OFF**.
- » The system is deactivated.
- » Button **3** is locked.

Emergency off switch (kill switch)



Emergency off switch **1** is a kill switch for switching off the engine during or after a fall.

 Operating kill switch **1** when riding can cause the rear wheel to lock, provoking a fall.


Do not operate the kill switch when riding. ◀

- Turn kill switch **1** to left or right to position **B**.
 - » The engine electronics control unit switches the engine off.
 - » The radio^{OE} is switched off.
 - » The engine cannot be started while the switch is in this position.


 If you move the kill switch to the **B** position while the ignition is switched on, the BMW Integral ABS remains operational (► 81). ◀

Grip heating^{OE}

 Grip heating can be activated only when the engine is running. The increase in power consumption caused by the grip heating can drain the battery if you are riding at low engine speeds. If the charge level is low, grip heating is switched off to ensure the battery's starting capability. ◀



1 Grip heating switch



- 2** Heating off
- 3** 50% heating power (one dot)
- 4** 100% heating power (three dots)

Seat heating^{OE}

 Seat heating can be activated only when the engine is running. The increase in power consumption caused by the heating can drain the battery if you are riding at low engine speeds. If the charge


level is low, the heating is switched off to ensure the battery's starting capability. ◀




When the seat heating is on, bottom display field **1** contains a symbol for the front seat (left) and the rear seat (right), indicating the heating power for each seat.

- One dot:
50 % heating power
- Two dots:
100 % heating power

Seat heating, front seat




- 1** Switch for seat heating, front seat




- 2** Heating off
- 3** 50 % heating power
- 4** 100 % heating power

Seat heating, rear seat



1 Switch for seat heating, rear seat



2 Switch in centre position:
Heating off

- 3** Pushed back:
100 % heating power
- 4** Pushed forward:
50 % heating power



Switching on the grip heating or the seat heating or some other heavy electrical consumer can cause a sudden drop in the voltage in the motorcycle's electrical system. In order to ensure the voltage supply under these circumstances, idle speed is temporarily increased to up to 1300 rpm. ◀


Handlebar levers

Adjusting the clutch lever



Attempting to adjust the clutch lever while riding the motorcycle can lead to

accidents. Adjust the clutch lever only when the motorcycle is stationary. ◀




- The distance between handlebar grip and clutch lever can be adjusted to any of three positions by means of adjuster **A**.
 - » Position 1:
minimum span
 - » Position 3:
maximum span

Adjusting the handbrake lever



Attempting to adjust the brake lever while riding the motorcycle can lead to accidents.

Adjust the brake lever only when the motorcycle is stationary. ◀



- The distance between handlebar grip and brake lever can be adjusted to any of four positions by means of adjuster **B**.

- » Position 1:
minimum span
- » Position 4:
maximum span

Lights

Side lights

The side lights switch on automatically when the ignition is switched on.



The side lights are a strain on the battery. Do not switch the ignition on for longer than absolutely necessary. ◀

Low-beam headlight

The low-beam headlight switches on automatically when you start the engine.



With the engine switched off, you can switch on the lights by switching on the

high-beam headlight with the ignition switched on or by operating the headlight flasher. ◀

High-beam headlight/ headlight flasher



- Press the top part of switch **1** for the high-beam headlight.
- » High-beam headlight switched on. Move switch **1** for the high-beam headlight to the centre position.
- » High-beam headlight switched off.

- Press the bottom part of switch **1** for the high-beam headlight.
- » Headlight flasher.

Parking lights

You can switch on the parking lights only immediately after switching off the ignition.



- Switch off the ignition.
- Press left-hand turn indicator switch **1**.
- » Parking lights switched on.
- Switch the ignition on and off again.
- » Parking lights switched off.

Adjusting headlight beam throw


Headlight beam throw is kept constant when spring preload is adjusted to suit load.

- Adjust the spring-preload and shock-absorber settings to suit load (➡ 55).
- Consult a specialist workshop, preferably an authorised BMW motorcycle dealer, if you are unsure whether the headlight basic setting is correct.

Spring preload adjustment might not suffice if the motorcycle is very heavily loaded. To avoid dazzling oncoming traffic:



- Use pivot lever **1** to adjust the headlight.



- A** Neutral position
- B** High load

Adjusting headlight for RHD/LHD traffic

When riding in countries where traffic drives on the opposite side of the road to that in which the vehicle was registered, the asymmetric low headlight beam will dazzle oncoming traffic.



Adhesive films with unsuitable adhesives can damage the plastic of the headlight lens.

Use only suitable adhesive films. ◀


- Have the headlight adjusted to the relevant conditions by a specialist workshop, preferably an authorised BMW motorcycle dealer.

Turn indicators

Switching on turn indicators



- Press left-hand turn indicator button **1**.
 - » Left-hand turn indicator switched on.
 - » Telltale light for left-hand turn indicator flashes.



- Press right-hand turn indicator button **2**.
 - » Right-hand turn indicator switched on.
 - » Telltale light for right-hand turn indicator flashes.

Switching off the turn indicators



- Press cancel button **3**.
 - » Turn indicator off.
 - » Turn indicator telltale light is off.


Stowage compartment

Opening the stowage compartment

The ignition key opens the stowage compartment integrated into the fairing on the right.



- Use the ignition key to unlock the stowage compartment.
 - » Lock barrel **1** is at right angles to the direction of travel.
- Push the lock barrel in.
 - » The lid opens.



Closing the stowage compartment


- Snap the lid of the compartment closed and push it down.
 - » The lock engages with an audible click.
- Use the ignition key to lock the lid.
 - » The lock barrel is in line with the direction of travel.

Front and rear seats


Removing the seat



- Turn the key counter-clockwise in the seat lock.



- When doing so, press the rear seat down.
- Lift the seat at the rear and release the key.




- If the seat has seat heating^{OE}, disconnect plug **1**.



- Pull the seat to the rear to release it from its holders.




- Raise the front seat at the rear.



- If the seat has seat heating^{OE}, disconnect plug **2**.
- Lift the seat up to remove.

Adjusting front seat

The front seat can be raised or lowered to either of two positions.



- Adjust the seat by removing seat supporting rod **1** and reinserting it in the appropriate holder.

Installing seats




If too much pressure is applied in the forward direction, there is a danger that the motorcycle will be pushed off its stand.

Make sure that the motorcycle is steady on its stand. ◀

- If the front seat has seat heating^{OE}, connect the plug.



- Slip the front seat forward onto seat supporting rod **1**. Check that the seat is correctly seated.



- If you install the seat in its low position, make sure that rubber buffers **2** engage the bottom mount on the frame.




- Firmly push the front seat into the mount.
- If the rear seat has seat heating^{OE}, connect the plug.



- Slide the rear seat into the holders in such a way that the tongues engage their mounts.
- Firmly press down on the seat at the rear.
 - » The seat engages with an audible click.

Helmet holder



Helmet holder **1** is on the rear right, underneath the rear seat.



Helmet holder **1** will accommodate one motorcycle helmet.


- Remove the rear seat (► 52).
- Use the wire rope from the toolkit to secure the helmet to the holder.
- Install the seat.



The helmet catch can scratch the side panel. Note the position of the helmet catch when you secure the helmet. ◀

Mirrors

Adjusting mirrors



- Move the mirrors into the desired position by pressing lightly on one of the corners.

Windscreen

Adjusting windscreen

- Switch on the ignition.



- Press the top part of button **1**:
 - » Windscreen higher
- Press the bottom part of button **1**:
 - » Windscreen lower




Spring preload

Adjusting spring preload for rear wheel

You should adjust spring preload to suit the load on the motorcycle. Increase spring preload when the motorcycle is heavily loaded and reduce spring preload accordingly when the motorcycle is lightly loaded.

- Make sure the ground is level and firm and place the motorcycle on its centre stand or side stand.




To increase spring preload:

- Turn knob **1** in the direction indicated by the HIGH arrow.

To decrease spring preload:

- Turn knob **1** in the direction indicated by the LOW arrow.



Basic setting for one-up riding:

- Set the knob to the "STD" mark on scale **2** at the side (red dots).



This is the basic setting for a motorcycle carrying a full load of fuel and a rider weighing 85 kg. ◀



Your motorcycle's handling will suffer if you do not match the spring-preload and damping-characteristic settings.


Adjust the damping characteristic to suit spring preload. ◀

Shock absorbers

Adjusting rear shock absorber

You should adjust the damping characteristic to suit spring preload. An increase in spring preload requires firmer damping, a reduction in spring preload requires softer damping.

- Make sure the ground is level and firm and place the motorcycle on its centre stand or side stand.



- Adjust the rear shock absorber, using a screwdriver to turn adjusting screw **1**.



Harder damping:

- Turn adjusting screw **1** in the direction indicated by the **H** arrow.

Softer damping:

- Turn adjusting screw **1** in the direction indicated by the **S** arrow.

Basic setting for one-up riding:

- Turn adjusting screw **1** all the way in the direction indicated by the **H** arrow.
- Back off adjusting screw **1** by three-quarters of a turn in the direction indicated by the **S** arrow.

 This is the basic setting for a motorcycle carrying a full load of fuel and a rider weighing 85 kg. ◀



Your motorcycle's handling will suffer if you do not match the spring-preload and damping-characteristic settings.

Adjust the damping characteristic to suit spring preload. ◀

Wheels

Checking tyre pressures



Incorrect tyre pressures adversely affect the handling of the motorcycle and can lead to accidents.

Always keep the tyres inflated to the correct pressures. ◀



Incorrect tyre pressures result in accelerated tyre wear.

Always keep the tyres inflated to the correct pressures. ◀

The correct tyre pressures
(measured with tyres cold) are:

One-up:

- front 2.2 bar
- rear 2.5 bar

One-up with luggage:

- front 2.5 bar
- rear 2.9 bar

Two-up

(with luggage):

- front 2.5 bar
- rear 2.9 bar



At high road speeds, tyre valves have a tendency to open as a result of centrifugal force.

Fit metal valve caps with rubber seals and screw them on firmly to prevent sudden deflation. ◀

Safety instructions	60
Safety check	62
First time out	62
Before you start	63
Starting	66
Riding	69
Running in	69
Engine speed	70
Shifting gear	71
Placing motorcycle on its side stand	73
Removing motorcycle from side stand	75
Placing motorcycle on centre stand	77
Removing motorcycle from centre stand	79

Fuel	79
Brake system	80

Safety instructions

Speed

If you ride at high speed, always bear in mind that various boundary conditions can adversely affect the handling of your motorcycle:

- settings of the spring-strut and shock absorber system
- imbalanced load
- loose clothing
- insufficient tyre pressure
- worn tyres
- etc.

Correct loading



Overloading can adversely affect the motorcycle's handling.

Do not exceed the permissible gross weight and permissible wheel loads (► 145). ◀

Alcohol and drugs



Even small amounts of alcohol or drugs will adversely affect your perception and your ability to assess situations and make decisions, and slow down your reflexes. Medication can exacerbate these effects.

Do not ride your motorcycle after consuming alcohol, drugs or medication. ◀

Risk of poisoning

Exhaust fumes contain carbon monoxide, which is colourless and odourless but highly toxic.



Inhaling the exhaust fumes therefore represents a health hazard and can even cause loss of consciousness with fatal consequences. Do not inhale exhaust fumes. Do not run the engine in an enclosed space. ◀

High voltage



Touching live parts of the ignition system with the engine running can lead to electric shocks. Do not touch parts of the ignition system when the engine is running. ◀

Catalytic converter

If misfiring causes unburned fuel to enter the catalytic converter, there is a danger of overheating and damage.

For this reason, observe the following points:

- Do not run the fuel tank dry.
- Do not attempt to start or run the engine with a spark-plug cap disconnected.
- Stop the engine immediately if it misfires.
- Use only unleaded fuel.
- Comply with all specified maintenance intervals.



Unburned fuel will destroy the catalytic converter.

Note the points listed for protection of the catalytic converter. ◀

Risk of fire

Temperatures at the exhaust are high.



Flammable materials (e.g. hay, leaves, grass, clothing and luggage, etc.) could ignite if allowed to come into contact with the hot exhaust pipe.

Do not permit flammable materials to come into contact with the hot exhaust system. ◀



Cooling would be inadequate if the engine were allowed to idle for a lengthy period with the motorcycle at a standstill: overheating would result. In extreme cases, the motorcycle could catch fire. Do not allow the engine to idle unnecessarily. Ride away immediately after starting the engine. ◀

Tampering with the control unit of the electronic engine-management system



Tampering with the control unit of the electronic engine-management system can damage the motorcycle and cause accidents. Do not tamper with the control unit of the electronic engine-management system. ◀



Tampering with the control unit of the electronic engine-management system can result in mechanical loads that the motorcycle's components are not designed to withstand. Damage caused in this way is not covered by the warranty.

Do not tamper with the control unit of the electronic engine-management system. ◀

Safety check

Prior to every journey

Use the following checklist to check important functions, settings and wear limits before you ride off.

Checklist

- Brakes (➡ 103)
- Brake fluid level (➡ 102)
- Clutch (➡ 103)
- Warning and telltale lights (➡ 21)
- Shock absorber setting (➡ 56) and spring preload (➡ 55)
- Wheel rims (➡ 103), tread depth (➡ 103) and tyre pressures (➡ 57)
- Load, gross weight (➡ 145)
- Luggage system (➡ 89)

At regular intervals:

- Engine oil level (every time you refuel) (➡ 98)
- Brake pads (every second/third time you refuel) (➡ 101)

First time out

Safe handling of your motorcycle

You have to take the time to familiarise yourself with your motorcycle's unique character:

- Acceleration
- Roadholding
- Cornering
- Braking

Bear in mind, too, that the engine has to be run in over the first 1,000 km (➡ 69).

The description of the BMW Integral ABS starts on page (➡ 81).




BMW Integral ABS incorporates a brake booster, so braking efficiency is significantly higher than with conventional brake systems. Inadvertently severe braking can lead to dangerous situations, particularly when the motorcycle is cornering.

Practice braking with BMW Integral ABS under safe conditions. ◀

Before you start

Switching on the ignition



- See the notes on the electronic immobiliser (EWS) (▶ 24).
- Kill switch **1** in operating position **A**.
- Switch on the ignition.
 - » Pre-ride check is performed.
 - » BMW Integral ABS: ABS self-diagnosis is performed.

Pre-ride check

A pre-ride check is performed after you switch on the ignition. Communication between the various control units is tested in this check. The multi-function display shows the following in the order in which they are described below:

Phase 1



General warning light lights up red. The display shows "CHECK".

Phase 2



General warning light lights up yellow. "SET" lights up (only if the motorcycle is fitted with cruise control^{OE}).



Phase 3



The "DWA" battery warning for the anti-theft alarm lights up if the voltage level of the batteries in the anti-theft alarm system^{OE} is too low.



If a warning light or the word "CHECK" is not displayed, a malfunction cannot be indicated if one occurs in the corresponding system. Observe the various displays. ◀

If a light or symbol is not displayed:

- Have the fault rectified as soon as possible by a specialist workshop, preferably an authorised BMW motorcycle dealer.

Once the pre-ride check completes, the various gauges and indicators show their current values.



The pre-ride check is aborted if you start the engine before it completes. You can ride off and you will receive warning of faults if they occur. ◀

ABS self-diagnosis



The BMW Integral ABS performs self-diagnosis and a pull-away test to ensure its operability (► 69). Self-diagnosis is performed automatically when you switch on the ignition.

Self-diagnosis is not performed unless both brake levers are in their fully released positions. Only the residual braking function (► 83) is available until self-diagnosis completes.

- Release the brake levers.
- Switch on the ignition.

Phase 1



General warning light lights up red.



ABS warning light (or ) depending on national-market specification) flashes 4 times per second .

Self-diagnosis is in progress.

Phase 2



ABS warning light flashes once per second.

Self-diagnosis is complete.

The ABS warning light goes out when the pull-away test completes (► 69).



If you switch on the ignition while the brakes are applied, then start the engine and ride off immediately, the BMW Integral ABS remains in its residual braking function mode. Self-diagnosis is performed as soon as the brake levers are in their fully released positions for the first time. Until this completes the ABS function is not available; the same applies to power assistance for the brakes.

Wait for ABS self-diagnosis to complete before you start the engine. ◀



Starting on gradients: Switch on the ignition with gear engaged, clutch lever released and both brake levers released. When self-di-

agnosis completes, apply the brakes, disengage the clutch, and start the engine. ◀

Side stand

You cannot start the motorcycle with the side stand extended and a gear engaged. The engine will switch itself off if you start it with the gearbox in neutral and then engage a gear before retracting the side stand.


Gearbox

You can start the engine when the gearbox is in neutral or if you pull the clutch with a gear engaged. Switch on the ignition before you pull the clutch. When the gearbox is in neutral, the green neutral telltale light is on and the gear indicator in the multifunction display shows 0.

Starting



Do not turn the throttle twistgrip when starting the engine. At ambient temperatures below 0 °C, disengage the clutch after switching on the ignition. ◀



- Press starter button **1**.
- » The engine starts.
- Observe instruments and display for warnings and information (► 21).

 The start attempt is automatically interrupted if battery voltage is too low. Recharge the battery before you start the engine, or use jump leads and a donor battery to start (►► 118).◀

 High engine speeds while the engine is cold accelerate engine wear. Avoid high engine speeds when the engine is cold.◀

 Consult the troubleshooting chart below if the engine refuses to start.◀

Troubleshooting chart

Fault: Engine does not start at all or is very difficult to start.

Possible cause	Remedy	see page
Kill switch activated	Set the kill switch to its RUN position	( 45)
Side stand extended and gear engaged	Retract the side stand fully	( 66)
Gear engaged, clutch not disengaged	Select neutral or pull clutch lever	( 66)
Clutch pulled when ignition was OFF	Switch on the ignition, then pull the clutch lever	( 63)
No fuel in tank	Refuel	( 79)
Battery not adequately charged	Recharge the battery	( 120)

Riding

ABS pull-away test



ABS ABS warning light (or  depending on national-market specification) flashes once per second.

The BMW Integral ABS checks the ABS sensors when you pull away after starting. The ABS warning light then goes out and the BMW Integral ABS is active.

Running in

- While running in the motor-cycle, vary the throttle opening and engine-speed range frequently.
- Try to do most of your riding during this initial period on twisting, fairly hilly roads, avoiding high-speed main roads and highways if possible.



Exceeding the specified engine speeds while running in will lead to increased engine wear. Keep to the guideline values as stated below. ◀

For the first 1,000 km:

- Engine speed max. 4,000 rpm.
- No full-load acceleration.
- Avoid low engine speeds at full load.
- The first inspection should always be performed after 500 to 1,200 km.

Brake pads

New brake pads must bed down and therefore do not achieve their optimum friction levels during the first 500 km. This initial reduction in braking efficiency can be compensated for by exerting greater pressure on the levers.



New brake pads can extend stopping distance by a significant margin. Think well ahead and brake carefully; avoid severe braking. ◀

Tyres

New tyres have a smooth surface. This must be roughened by riding in a restrained manner at various heel angles until the tyres are run in. This running in procedure is essential if the tyres are to achieve maximum grip.



Tyres do not have their full grip when new and there is a risk of accident at extreme angles of heel. Avoid extreme angles of heel. ◀


Engine speed

Do not use the high end of the engine-revolutions range in any gear unless the engine is at operating temperature. When the revolution counter needle enters the red zone on the dial, the throttle-valve angle is limited in order to protect the engine against overspeeding. The governor cuts in at 8,000 rpm.

Load-dependent speed increase

If the voltage in the on-board electrics drops below the level needed to power the electric consumers, idle speed is temporarily increased to max. 1,300 rpm in order to maintain the supply (see also ►► 47).

Shifting gear



Attempting to shift gear with the clutch engaged can damage the gearbox. Always disengage the clutch in order to shift gears. ◀



The gear indicator in the multifunction display tells you which gear is engaged. ◀



Placing motorcycle on its side stand



If the ground is soft or uneven, there is no guarantee that the motorcycle will rest firmly on the stand. Always check that the ground under the stand is level and firm. ◀

You must be seated on the motorcycle:

- Switch off the engine.
- Pull the handbrake lever.
- Hold the motorcycle upright and balanced.
- Use your left foot to extend the side stand fully (arrow).
- Slowly lean the motorcycle to the side until its weight is taken by the stand and dismount to the left.

- Turn the handlebars to full left or right lock.
- Check that the motorcycle is standing firmly.



If the motorcycle is on the side stand, the surface of the ground determines whether it is better to turn the handlebars to the left or right. However, the motorcycle is more stable on a level surface with the handlebars turned to the left than with the handlebars turned to the right. On level ground, always turn the handlebars to the left and lock them in this position. ◀



The side stand is designed to support only the weight of the motorcycle. Do not lean or sit on the motorcycle with the side stand extended. ◀



On a gradient, the motorcycle should always face uphill; select 1st gear. ◀



Removing motorcycle from side stand



Brake servo assistance is not available when the ignition is off; the motorcycle can start to roll.

Particularly when the motorcycle is parked on a gradient, switch on the ignition and wait for the ABS to complete its self-diagnosis (▮▮▮▮ 65). ◀

- Unlock the ignition lock, switch on the ignition.
- Wait for ABS self-diagnosis to complete.
- From the left, grip the handlebars with both hands.
- Pull the handbrake lever.
- Swing your right leg over the seat and lift the motorcycle to the upright position.

- Hold the motorcycle upright and balanced.
- Sit on the motorcycle and use your left foot to retract the side stand.



An extended side stand can catch on the ground when the motorcycle is moving and lead to a fall.

Retract the side stand before moving the motorcycle. ◀



Placing motorcycle on centre stand



If the ground is soft or uneven, there is no guarantee that the motorcycle will rest firmly on the stand.

Always check that the ground under the stand is level and firm. ◀


- Switch off the engine.
- Dismount and keep your left hand on the left handlebar grip.
- With your right hand, grip the rear grab handle or the rear frame.
- Place your right foot on the pin of the centre stand, and press the stand down until its curved feet touch the ground.

- Place the full weight of your body on the centre stand, while pulling the motorcycle to the rear (arrow).
- Check that the motorcycle is standing firmly.



Excessive movements could cause the centre stand to retract, and the motorcycle would topple in consequence.

Do not lean or sit on the motorcycle with the centre stand extended. ◀



Removing motorcycle from centre stand

 Brake servo assistance is not available when the ignition is off; the motorcycle can start to roll.

Particularly when the motorcycle is parked on a gradient, switch on the ignition and wait for the ABS to complete its self-diagnosis (▮▮▮ 65). ◀

- Unlock the ignition lock, switch on the ignition.
- Wait for ABS self-diagnosis to complete.
- Place your left hand on the left handlebar grip.
- Grip the rear grab handle with your right hand.
- Push the motorcycle forward off the centre stand.

- Check that the centre stand has fully retracted.

Fuel

Refuelling

 Fuel is flammable and explosive.

Do not smoke. Never bring a naked flame near the fuel tank. ◀

 Fuel expands when hot (for instance if the fuel tank is in the sun).

Do not fill the tank past the bottom edge of the filler neck. ◀

 Fuel can damage plastic parts.

Do not permit fuel to come into contact with body panels. ◀

- Make sure the ground is level and firm and place the motorcycle on its centre stand or side stand.



- Open the protective cap.
- Using the ignition key, turn the fuel cap in the direction indicated by the arrow to open the tank.
- Refuel with fuel of the approved grade.



- Press the filler cap down firmly to close.
- Remove the key and close the protective cap.

Fuel grade

 Leaded fuel will destroy the catalytic converter. Use only unleaded fuel. ◀

The engine is designed to run on:

- Super Plus (Premium) unleaded (98 RON, 88 MON)

Use fuel of this grade by preference, in order to achieve rated performance and fuel consumption.

You can also run the engine on fuel of the following grade:

- Super unleaded (95 RON, 85 MON)

Capacity

- Usable fuel capacity: 27 litres
- including reserve of: approx. 4 litres

 The fuel gauge in the multifunction display works only when the ignition is switched on. ◀

Brake system

General Descending mountain passes

 There is a danger of the brakes fading if you use only the rear brakes when descending mountain passes. Under extreme conditions, the brakes could overheat and suffer severe damage. Use both front and rear brakes, and make use of the engine's braking effect as well. ◀

Wet brakes

 After the motorcycle has been washed, ridden through water or ridden in the rain, the brake discs and pads might be wet and the brakes

might not take effect immediately.

Bear in mind that this extends your stopping distance, because the brakes have to either dry out as you ride, or dry themselves when applied. ◀

Salt on brakes



The full braking effect can be delayed if the motorcycle is ridden on salt-covered roads and the brakes are not applied for some time.

Bear in mind that this extends your stopping distance, because the force of friction has to remove the layer of salt when the brakes are applied. ◀

Oil or grease on brakes



Oil and grease on the brake discs and pads considerably diminish braking

efficiency.

It is particularly important to check the brake pads and discs after repair and maintenance work is carried out, to make sure they are free of oil and grease. ◀

Dirt or mud on brakes



When the motorcycle is ridden on loose surfaces or muddy roads, the brakes may fail to take effect immediately because of dirt or moisture on the discs or brake pads.

Bear in mind that this extends your stopping distance, because the brakes have to clean themselves when applied. ◀

BMW Integral ABS

In extreme situations, it takes skill and sensitive control of the brakes to pull up safely on a motorcycle. If the front brakes lock and the wheel skids, the necessary longitudinal and lateral stabilising forces are lost, and a fall can result. For this reason, the rider seldom makes full use of available braking performance in an emergency.

By preventing both wheels from locking and optimising braking-force distribution by means of the integral function, BMW Integral ABS offers improved braking efficiency (► 81). Making full use of the motorcycle's technical braking capacity will minimise braking distances noticeably, even

when road conditions are poor. When the motorcycle is ridden in a straight line, the BMW Integral ABS is able to handle emergency braking safely.

Reserves for safety

The potentially shorter braking distances which BMW Integral ABS permits must not be used as an excuse for careless riding. ABS is primarily a means of ensuring a safety margin in genuine emergencies.

Take care when cornering. When you apply the brakes on a corner, the motorcycle's weight and momentum take over and even BMW Integral ABS is unable to counteract their effects.

Integral brakes

Your motorcycle is equipped with integral brakes. Both front and rear brakes are applied when you pull the handbrake lever. The footbrake lever acts only on the rear brake.

The electronic controller in the BMW Integral ABS regulates braking-force distribution between front and rear wheels. Braking-force distribution depends on load and is recalculated every time the ABS controller comes into action.

Brake booster

The hydraulic pump in the BMW Integral ABS boosts the braking force acting on the wheel when the brakes are applied. By boosting the braking force in this way,

BMW Integral ABS achieves higher braking efficiency than standard brake systems.

Antilock braking system (ABS)

ABS prevents the wheels locking under braking, thus contributing significantly to road safety.

Rear wheel lift

Even under severe braking, a high level of tyre grip can mean that the front wheel does not lock up until very late, if at all. Consequently, ABS does not intervene until very late, if at all. Under these circumstances the rear wheel can lift off the ground, and the outcome can be a highsidings situation in which the motorcycle can flip over.



Severe braking can cause the rear wheel to lift off the ground.

Bear in mind that ABS cannot be relied on in all circumstances to prevent the rear wheel from lifting clear of the ground. ◀

Residual braking function

When the ignition is off, while self-diagnosis is in progress, and if a fault develops in the BMW Integral ABS, the hydraulic brake boost provided by the BMW Integral ABS is not available in the brake circuits in question, and only a residual braking function is available. Under these circumstances, therefore, you must apply higher pressure to the brake levers in question in order to apply the brakes, and

lever travel is longer. When the residual braking function is active, the ABS function is unavailable in the brake system in question. Under these circumstances, moreover, the integral braking function is partially or entirely unavailable.



Without the assistance of the ABS function, the wheels could lock when the brakes are applied, and without the brake booster you have to apply considerably more force in order to slow the motorcycle.

Think well ahead and brake carefully; avoid severe braking. Have the fault rectified as soon as possible by a specialist workshop, preferably an authorised BMW motorcycle dealer. ◀



The brake-lever travel needed to build up braking pressure can be considerably longer when the system is in residual braking function mode, so it is advisable to set the brake lever to a wider span (► 47). ◀



When the residual braking function is active for both brake circuits, the noise of the pump is no longer audible when you operate the brake levers. ◀

Checking the brake system

The brake system requires regular maintenance in order to ensure that it operates reliably (► 99).

General instructions	86
On-board sockets	86
Luggage system	89

General instructions

BMW recommends the use of parts and accessories for your motorcycle that are approved by BMW for this purpose.

Genuine BMW parts and accessories and other products which BMW has approved can be obtained from your authorised BMW motorcycle dealer, together with expert advice on their installation and use.

These parts and products have been tested by BMW for safety, function and suitability. BMW accepts product liability for these products. Conversely, BMW is unable to accept any liability whatsoever for parts and accessories which it has not approved.



BMW cannot examine or test each product of outside origin to ensure that it can be used on or in connection with BMW motorcycles without constituting a safety hazard. County-specific official authorisation does not suffice as assurance. Tests conducted by these instances cannot make provision for all operating conditions experienced by BMW motorcycles and, consequently, they are not sufficient in some circumstances. Use only parts and accessories approved by BMW for your motorcycle. ◀

Whenever you are planning modifications, comply with all the legal requirements. The motorcycle must not infringe national road-vehicle construction and use regulations.

On-board sockets



On-board socket, front left.



On-board socket^{OE} rear left.

Supply

The on-board sockets carry a 12 V supply. The maximum total current rating for all sockets is 10 A.

The supply to the socket is cut off automatically if battery voltage is low or the load exceeds the maximum rating.

The socket is automatically reactivated the next time the ignition is switched on. The

precondition for reactivation is that the reason for cut-off no longer applies.

Operating electrical accessories

You can start using electrical accessories only when the ignition is switched on. The accessories remain operational if the ignition is subsequently switched off. In order to ensure that the drain on the on-board power supply system is minimised, the supply to the power sockets is cut off approximately 15 minutes after the ignition is switched off, and it is also temporarily interrupted during the start procedure. The same applies to the supply for the permanently installed accessories.

Cable routing

The cables from the power socket to the auxiliary device must be routed in such a way that they:

- do not impede the rider
- do not restrict or obstruct the steering angle and handling characteristics
- cannot be trapped



Improperly routed cables can impede the rider. Route the cables as described above. ◀



Luggage system

Fitting a luggage system will affect the handling of your motorcycle. The recommended top speed with the cases loaded is 180 km/h. The maximum permissible top speed with the small or large topcase^{OA} fitted is 180 km/h.

Correct loading



Overloading can impair the stability of your motorcycle, as can an unbalanced load.

Never exceed the motorcycle's permissible gross weight (► 145). Comply with the instructions for loading below. ◀


- Set spring preload (► 55), damping characteristic (► 56) and tyre pressures (► 57) to suit total weight.
- Make sure that the weight is uniformly distributed between right and left.
- Pack heavy items at the bottom and toward the inboard side.
- Max. load in each case (left and right): 10 kg.
- Max. load in tank rucksack 5 kg.

Case

Opening the case



- Unlock the case.
 - » The lock barrel is at right angles to the direction of travel.




- Press lock barrel **1**.
 - » Lever **2** pops up.
- Pivot lever **2** down.



- Open lid.

Closing the case



- Pull lever **2** back as far as it will go.
- Close lid **3** and press it down. Check that nothing is trapped between the lid and the case.



- Push lever **2** down.
 - » The lever engages.
- Lock the case.
 - » The lock barrel points in the direction of travel.

Removing the case

- Unlock the case.
 - » The lock barrel is at right angles to the direction of travel.



- Turn the key clockwise (left case) or counter-clockwise (right case).
 - » Handle **4** pops out.



- Pull the handle out and then pull it up as far as it will go.
 - » The case is released and can be removed.

Installing the case

- Unlatch the handle and pull it up as far as it will go.



- Locate the case in holders **5** and check that it is securely seated.



- Push the handle of the case down until it engages (the coloured indicator on the handle must disappear).
- » The case is correctly engaged on its holders.
- Lock the case.
- » The lock barrel points in the direction of travel.


Topcase^{OA}

Installing topcase


- Lock the topcase.
- » The lock barrel is horizontal.




- Turn the key clockwise.
- » Handle 6 pops out.



- Pull handle 6 up as far as it will go.




- Hook the topcase into position on the carrier. Make sure that hooks 7 are securely seated in the corresponding keepers 8.




- Push the handle down until it engages (the coloured indicator on the handle must disappear).
- » The topcase is correctly engaged on its carrier.

Removing the topcase




- Lock the topcase.
 - » The lock barrel is horizontal.
- Turn the key clockwise.
- » Handle **6** pops out.
- Pull handle **6** up as far as it will go.



- Lift the topcase at the rear and pull it off the carrier.

Opening the topcase



- Unlock the topcase.
 - » The lock barrel is vertical.
- Press lock barrel 7.
- » Locking lever 8 pops out.



- Fully open the locking lever.
- Open lid.

Closing the topcase



- Fully open locking lever 8.
- Close lid and press it down. Check that nothing is trapped between the lid and the case.
- Push the locking lever down until it engages.
- Lock the topcase.
 - » The lock barrel is horizontal.

Tank rucksack^{OA}



- You can fit a specially designed tank rucksack to your motorcycle.
- See the separate instructions for use for information on using the tank rucksack.

Toolkit	97
Engine oil	98
Brakes	99
Clutch	103
Wheels	103
Front-wheel stand	111
Bulbs	112
Jump starting	118
Battery	120
Splash guard	123

The 'Maintenance' chapter describes work involving the replacement of wear parts that can be performed with minimum effort.

The types of threaded fastener used for the various components are listed in the 'Technical Data' (► 132). You can use this chart to set aside the required tools.

Special tightening torques are listed as applicable. Threaded fasteners for which a suitable tool is included in the toolkit are marked accordingly.


If you are interested in information on more extensive work, we recommend the repair manual on CD-ROM which applies to your particular

motorcycle. You can obtain a copy from your authorised BMW motorcycle dealer.

Toolkit

The toolkit is underneath the rear seat.

- Remove the rear seat (➡ 52).




- The tools wallet **1** is held in place by a rubber strap. You can obtain a more extensive, additional set of tools from your authorised BMW motorcycle dealer.



Contents of the toolkit:

- 1** Screwdriver, reversible blade, with extension
- 2** Tool for oil cap
- 3** TORX® wrench, T25
- 4** Steel cable for helmet holder



Contents of additional set of tools^{OA}:

- 1** TORX® wrenches T25, T30, T40, T45, T50
- 2** Open-ended spanners, w/f 8mm/10mm, 10mm/13 mm, 15 mm, 17 mm
- 3** Puller tool, direct ignition coil
- 4** Socket wrench, w/f 17
- 5** Spark plug socket spanner with TORX® wrench as lever
- 6** Screwdriver blade

Engine oil

Checking the engine oil level

Check the oil level at regular intervals.

 The oil level varies with the temperature of the oil. The higher the temperature, the higher the level of oil in the sump.

Check the engine oil level immediately after a lengthy journey. ◀


 Damage to the engine can result if it is operated without enough oil, but the same also applies if the oil level is too high. Always make sure that the oil level is correct. ◀

 The engine can seize if the oil level is low, and this can lead to accidents. Always make sure that the oil level is correct. ◀


 Checking the oil level with the engine cold or after no more than a short ride will lead to misinterpretation; this in turn, means that the engine will be operated with the incorrect quantity of oil. In order to ensure that the engine oil level is read correctly, check the oil level only after a lengthy trip. ◀

- Check that the engine is at operating temperature, make sure the ground is level and firm and place the motorcycle on its centre stand.

- Wait 5 minutes after switching off the engine.



- Check the oil level in sight glass **1**.




The oil level must be visible in the sight glass. The difference between the min. and max. marks is equal to approximately 0.5 litre.

Topping up the engine oil

If the oil is below the minimum level:

- Wipe the area around the filler neck clean.
- Using the tool from the toolkit, remove filler plug **1**.
- Pour in the correct quantity of engine oil thorough the filler neck.
- Using the tool from the toolkit, hand-tighten filler plug **1**.



Brakes

A properly functioning brake system is a basic requirement for the road safety of your motorcycle.



Incorrect working practices endanger the reliability of the brakes.

Have all work on the brake system carried out by a specialist workshop, preferably an authorised BMW motorcycle dealer. ◀

Do not ride the motorcycle if you have any doubts about the dependability of the brake system. In this case:

- Have the brake system checked by a specialist workshop, preferably an authorised BMW motorcycle dealer.

Checking operation

- Switch on the ignition.
- Wait for the ABS self-diagnosis to complete.
- Pull the handbrake lever.
 - » The pressure point must be clearly perceptible.
 - » The noise of the hydraulic pump of the BMW Integral ABS must be clearly audible.
- Press the footbrake lever.

- » The pressure point must be clearly perceptible.
- » The noise of the hydraulic pump of the BMW Integral ABS must be clearly audible.


Brake pads




Brake pads worn past the minimum permissible thickness can impair braking efficiency and under certain circumstances they can cause damage to the brake system. In order to ensure the dependability of the brake system, do not permit the brake pads to wear past the minimum permissible thickness. ◀

Checking front brake pad thickness

- Make sure the ground is level and firm and place the motorcycle on its centre stand or side stand.



- Visually inspect the left and right brake pads to ascertain their thickness.




Wear indicating marks **1** must be clearly visible on the pads. If the wear indicating marks are no longer clearly visible:


- Have the brake pads replaced by a specialist workshop, preferably an authorised BMW motorcycle dealer.

Checking rear brake pad thickness

- Make sure the ground is level and firm and place the motorcycle on its centre stand or side stand.




- Visually inspect the brake pads from the left to ascertain their thickness.




Make sure that the brake disc is not visible through bore **1** in the inboard brake pad. If the brake disc is visible:

- Have the brake pads replaced immediately, preferably by an authorised BMW motorcycle dealer.



Wear indicator, brake pads **2**



Wear indicator **2** indicates the condition of the rear brake pads. The number of rings visible is a measure of residual brake-pad thickness:


- 3 rings: at least 75 %
- 2 rings: at least 50 %
- 1 ring: 50 to 25 %
- No rings visible:
- Check brake-pad thickness; replace the brake pads if necessary.

Checking brake fluid level



Changing the position of the brake-fluid reservoir can allow air to penetrate the brake system.

Do not turn the handlebar fitting on the handlebar. ◀



1 Minimum brake fluid level, front



2 Minimum brake fluid level, rear

- Make sure the ground is level and firm and place the motorcycle on its centre stand.
- Turn the handlebars to a position in which the front brake-fluid reservoir is horizontal.
- Check the level of fluid in the reservoirs.



The brake fluid level remains constant despite wear of the brake pads. ◀

Any drop in brake fluid level, even if the level remains above the minimum mark, is indicative of a fault in the brake system.



A low fluid level in the brake reservoir can allow air to penetrate the brake system. This significantly reduces braking efficiency.

Think well ahead and brake carefully; avoid severe braking. ◀

- Have the fault rectified as soon as possible by a specialist workshop, preferably an authorised BMW motorcycle dealer.

Clutch

Checking operation

- Pull the clutch lever.
 - » The pressure point must be clearly perceptible.

Do not ride the motorcycle if you have any doubts about the dependability of the clutch. In this case:

- Have the clutch checked by a specialist workshop, preferably an authorised BMW motorcycle dealer.

Wheels

For each size of tyre BMW Motorrad tests certain makes, and approves those that it certifies as roadworthy. If BMW Motorrad has not approved the wheels and tyres, it cannot assess their suitability or provide any guarantee of road safety. Use only wheels and tyres approved by BMW Motorrad for your type of motorcycle.

You can obtain detailed information from your authorised BMW motorcycle dealer or by visiting www.bmw-motorrad.com on the Internet.

Checking rims

- Make sure the ground is level and firm and place the motorcycle on its centre stand or side stand.
- Visually inspect the rims for defects.
- Have damaged rims checked and, if necessary, replaced by a specialist workshop, preferably an authorised BMW motorcycle dealer.

Checking tyre tread depth

Do not allow the tyres to wear past the minimum depth permitted by law in the country of use.

 Your motorcycle's handling and grip can be impaired even before the tyres wear to the minimum tyre tread depth permitted by law. Have the tyres changed in good time before they wear to the minimum permissible tread depth. ◀

 Tyres have wear indicators integrated into the main tread grooves. If the tyre tread has worn down to the level of the marks, the tyre is completely worn. The locations of the marks are indicated on the edge of the tyre, e.g. by the letters TI, TWI or by an arrow. ◀


- Measure the tyre tread depth only in the main tread grooves with wear indicating marks.

Removing front wheel


 You will find an overview of the types of threaded fastener used on (➡ 132). ◀

 There is a risk of damaging parts of the front brakes, particularly the BMW Integral ABS, in the course of the procedure described below.


Take care not to damage the brake system, in particular the ABS sensor with cable and the ABS sensor ring. ◀



- Place the motorcycle on its centre stand.
- Remove screws **1** from the front mudguard on left and right.
- Pull the front mudguard forward to remove, spreading the sides slightly apart at the same time.



- Remove securing screws **2** of the left and right brake calipers.



- Force brake calipers **3** slightly apart by rocking them back and forth **A** against the brake discs **4**.

 Once the calipers have been removed, there is a risk of the brake pads being pressed together to the extent that they cannot be slipped back over the brake disc on reassembly.

Do not operate the handbrake lever when the brake calipers have been removed. ◀


- Mask off the parts of the wheel rim that could be scratched in the process of removing the brake calipers.
- Pull the brake calipers back and out until clear of the brake discs.



When the motorcycle is standing on its centre stand: if the motorcycle is raised too far at the front the centre stand will lift clear of the ground and the motorcycle could topple to one side. When raising the motorcycle, make sure that the centre stand remains on the ground. ◀



- Raise the front of the motorcycle until the front wheel can rotate freely. It is advisable to use the BMW Motorrad front wheel stand (► 111) for this purpose.



- Remove axle clamping screw **5**.
- Remove quick-release axle **6**, while supporting the wheel.

 An adapter for removing the front wheel is available from BMW Motorrad. This adapter can be combined with any commercially available w/f 22 open-end or ring spanner. The BMW special tool number is 363690 and the

adapter is available from your authorised BMW motorcycle dealer. ◀



- Lower the front wheel to the ground between the front forks.
- Roll the front wheel forward to remove.

Installing front wheel

 The types of screw used are listed, complete with tightening torques, on  132). ◀

 Threaded fasteners not tightened to the specified torque can work loose or their threads can suffer damage. Always have the security of the fasteners checked by a specialist workshop, preferably an authorised BMW motorcycle dealer. ◀

 There is a risk of damaging parts of the front brake, particularly the BMW Integral ABS, in the course of the procedure described below. Take care not to damage the brake system, in particular the ABS sensor with cable and the AMS sensor ring. ◀



The front wheel must be installed right way round to rotate in the correct direction.

Note the direction-of-rotation arrows on the tyre and the wheel rim. ◀




- Roll the front wheel into the front wheel guide.
- Raise the front wheel, install quick-release axle **6** complete with the spacer, and tighten to 50 Nm.


- Tighten axle clamping screw **5** to 19 Nm.
- Remove the front wheel stand.
- Ease the brake calipers on to the brake discs.



The cable of the ABS sensor could chafe through if it comes into contact with the brake disc. Make sure that ABS sensor cable **7** is routed correctly. ◀



- Install securing screws **2** for the left and right brake calipers and tighten to 30 Nm.



- Install the mudguard and tighten securing screws **1**.
- Remove the adhesive tape from the wheel rim.

The front brakes have to be operated a few times to bed the brake pads against the brake discs.

- Switch on the ignition.
- Wait for self-diagnosis to complete (►► 65).

- Firmly pull the handbrake lever a number of times, until the pressure point is perceptible.



Braking efficiency is impaired if the brake pads are not correctly bedded against the discs.


Before riding off, check that the brake pads are correctly bedded against the discs. ◀

Removing rear wheel



The types of screw used are listed on (►► 132). ◀


- Place the motorcycle on its centre stand.



- Slacken clamp **1** on the silencer.



Do not remove the sealing grease from the clamp. ◀



- Remove screw **2** for the bracket of the end silencer from the rear footrest.



- Turn the end silencer out.
- Engage first gear.
- Remove studs **3** from the rear wheel, while supporting the wheel.
- Lower the rear wheel to the ground.
- Roll the rear wheel out toward the rear.

Installing rear wheel



The types of screw used are listed, complete with tightening torques, on (► 132). ◀




Threaded fasteners not tightened to the specified torque can work loose or their threads can suffer damage. Always have the security of the fasteners checked, preferably an authorised BMW motorcycle dealer. ◀


- Roll the rear wheel into position at the rear wheel hub.
- Lift the rear wheel onto the rear wheel hub.




- Install rear-wheel studs **3** and tighten in diagonally opposite sequence to 60 Nm.
- Turn the end silencer to its initial position.




- Install screw **2** for the bracket of the end silencer in the rear footrest, but do not tighten it at this point.



A lack of clearance between the rear wheel and the end silencer can result in damage to the tyre. The clearance between rear wheel and end silencer is correct when the handle of screwdriver **4** from the toolkit can be slipped between the two. ◀



- Align clamp **1** on the end silencer with mark **A** and tighten to 55 Nm.




- Tighten screw **2** for the bracket of the end silencer in the rear footrest to 19 Nm.


Front-wheel stand

A front-wheel stand for simple, safe changing of the front wheel is available from BMW Motorrad. The BMW special tool number is 363971 and the front-wheel stand is available from your authorised BMW motorcycle dealer. You also need the adapters with the BMW special tool number 363972.

Fitting the front wheel stand



- Place the motorcycle on its centre stand.
- Slacken adjusting screws **1**.
- Push pins **2** apart until the front forks fit between them.
- Use locating pins **3** to set the front-wheel stand to the desired height.
- Centre the front-wheel stand relative to the front wheel and push it against the front axle.



- Push pins **2** in until the front forks are securely located.
- Tighten adjusting screws **1**.



- Apply uniform pressure to push the front-wheel stand down and raise the motorcycle.

 When the motorcycle is standing on its centre stand: if the motorcycle is raised too far at the front the centre stand will lift clear of the ground and the motorcycle could topple to one side.

When raising the motorcycle, make sure that the centre stand remains on the ground. ◀

Bulbs

Information on bulbs

The 'bulb defect' symbol (➡ 26) appears in the display if a bulb is defective. If the brake or rear light fails, the symbol is accompanied by the general warning light, which lights up yellow.

 A defective bulb places your safety at risk because it is easier for other users to oversee you and your motorcycle.

Replace defective bulbs as soon as possible; always carry a complete set of spare bulbs if possible. ◀

 The types of bulb used are listed on page 144. ◀

 Do not touch the glass of new bulbs with your fingers. Use a clean, dry cloth to hold the bulbs when handling them. Dirt deposits, in particular oil and grease, interfere with heat radiation from the bulb. This leads to overheating and shortens the bulb's operating life. ◀

Replacing high-beam headlight bulb



The bulb is pressurised and can cause injury if damaged.

Wear protective goggles and gloves when changing bulbs. ◀




If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Make sure that the motorcycle is steady on its stand. ◀




Turn the handlebars to the left to facilitate access. ◀


- Switch off the ignition.




- Turn cover **1** counter-clockwise and remove it.



- Disconnect plug **2**.




- Disengage spring clip **3** at left and right and secure it (preferably by hooking it into the headlight housing).



- Remove bulb **4**.

Installation is the reverse of the removal procedure.



- When installing, make sure that lug **5** is pointing up and that the bulb is securely seated.
- Check that the bulb is correctly seated (by looking in through the headlight lens).

Replacing low-beam headlight bulb, left



Turn the handlebars to the left to facilitate access. ◀

- Switch off the ignition.




- Turn cover **1** counter-clockwise and remove it.
- From this point on, the procedure is the same as that for replacing the high-beam headlight bulb.

Replacing low-beam headlight bulb, right



Turn the handlebars to the right to facilitate access. ◀

- Turn cover **1** counter-clockwise and remove it.



- From this point on, the procedure is the same as that for replacing the left low-beam headlight bulb.


Replacing side-light bulbs




If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Make sure that the motorcycle is steady on its stand. ◀

The procedure for replacing the left side-light bulb is described below. The procedure for replacing the right side-light bulb is analogous.


- Switch off the ignition.



- Apply firm forward pressure with the flat of your hand to push the mirror back out of the anchorage.




- Remove screws **1**, while holding fairing panel **2**.




- Remove fairing panel **2**.



- The side-light bulb is accessible through aperture **4**.




- Turn bulb holder **5** counter-clockwise to remove it from the headlight housing; pivot lever **6** in the shell down (on the right side of the motorcycle: pivot the lever up).



- Remove bulb **7** from the bulb holder.

Installation is the reverse of the removal procedure.

- Use a clean, dry cloth to hold the new bulb.
- Check that the bulb is correctly seated (by looking in through the headlight lens).



- When installing fairing panel **2**, make sure that the lug of the panel is correctly seated in the corresponding recess.



- When installing the mirror housing, make sure that the three plugs all engage in their corresponding mounts.

Replacing brake-light, rear light and rear-indicator bulbs



If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Make sure that the motorcycle is steady on its stand. ◀


- Switch off the ignition.



- Remove screws **1** on left and right.



- Pull the bulb housing to the rear until it is clear of holders **2**.



- Turn bulb holder **3** counter-clockwise to remove it from the bulb housing.
- Press the bulb into its socket and turn it counter-clockwise to remove.


Installation is the reverse of the removal procedure.

- Use a clean, dry cloth to hold the new bulb.


Replacing front turn indicator bulb

⚠ If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Make sure that the motorcycle is steady on its stand. ◀

- Switch off the ignition.



- Apply firm forward pressure with the flat of your hand to push the mirror back out of the anchorage.



- Turn bulb holder **1** counter-clockwise to remove it from the bulb housing.
- Press bulb **2** into its socket and turn it counter-clockwise to remove.

Installation is the reverse of the removal procedure.

- Use a clean, dry cloth to hold the new bulb.



- When installing the mirror housing, make sure that the three plugs all engage in their corresponding mounts.

 The mirror must be firmly seated in the mounts to keep it secure.

Do not use lubricants when installing the mirrors. ◀

Jump starting

 The wires leading to the power socket do not have a load-capacity rating adequate for jump-starting the engine. Excessively high current can lead to a cable fire or damage to the vehicle electronics.

Do not use the on-board socket to jump-start the engine. ◀

 Do not use proprietary start-assist sprays or other products to start the engine. ◀



A short-circuit can result if the crocodile clips of the jump leads are accidentally brought into contact with the motorcycle.

Use only jump leads fitted with fully insulated crocodile clips at both ends. ◀



Jump-starting with a donor-battery voltage higher than 12 V can damage the vehicle electronics.

Make sure that the battery of the donor vehicle has a voltage rating of 12 V. ◀

- When jump-starting the engine, do not disconnect the battery from the on-board electrical system.
- Remove the seats (► 52).
- Run the engine of the donor vehicle during jump-starting.

- Begin by connecting one end of the red jump lead to the positive terminal of the discharged battery and the other end to the positive terminal of the donor battery.
- Then connect one end of the black jump lead to the negative terminal of the donor battery, and the other end to the negative terminal of the discharged battery.
- Start the engine of the vehicle with the discharged battery in the usual way; if the engine does not start, wait a few minutes before repeating the attempt in order to protect the starter and the donor battery.
- Allow both engines to idle for a few minutes before disconnecting the jump leads.

- Disconnect the jump lead from the negative terminals first, then disconnect the second lead from the positive terminals.

- Reinstall the seats.



Touching live parts of the ignition system with the engine running can cause electric shock.

Do not touch parts of the ignition system when the engine is running. ◀

Battery

Maintenance instructions

Your motorcycle is supplied with a maintenance-free battery.

Correct upkeep, recharging and storage will prolong the life of the battery and are essential if warranty claims are to be considered.

Compliance with the points below is important in order to maximise battery life:

- Keep the surface of the battery clean and dry.
- Do not open the battery.
- Be sure to read and comply with the instructions for charging the battery on the following pages.
- Do not turn the battery upside down.



If the battery is not disconnected, the on-board electronics (e.g. clock, etc.) will gradually drain the battery. This can cause the battery to run flat. If this happens, warranty claims will not be accepted.

If the motorcycle is to be out of use for more than four weeks, disconnect the battery or connect a suitable trickle charger to the battery. ◀



BMW Motorrad has developed a trickle-charger specially designed for compatibility with the electronics of your motorcycle. Using this charger, you can keep the battery charged during long periods of disuse, without having to disconnect the battery from the motorcycle's on-board

systems. More information is available on request from your authorised BMW motorcycle dealer. ◀

Charging the battery when connected

If the telltale lights do not light up and the multifunction display remains blank when you switch on the ignition, the battery is completely flat.



Attempting to charge a completely flat battery via the on-board socket can cause damage to the motorcycle's electronics.

If the battery is completely flat it must always be recharged directly at the terminals. ◀

- Do not attempt to recharge a completely flat battery via the on-board socket;

instead, disconnect the battery from the on-board system and connect the charger directly to the battery terminals.

- Comply with the operating instructions of the charger.

 Your authorised BMW motorcycle dealer will be happy to provide information on suitable chargers. ◀

If the battery is only partially discharged, it can be recharged via the on-board socket.

- If electrical accessories are connected to an additional on-board socket^{OE}, disconnect them before connecting the charger.
- Switch on the ignition.

- Plug the charger into the on-board socket. Comply with the operating instructions of the charger.
- Switch off the ignition.

 The motorcycle's on-board electronics know when the battery is fully charged. The on-board socket is switched off when this happens. ◀

 If you are unable to charge the battery via the power socket, you may be using a charger that is not compatible with your motorcycle's electronics. If this happens, disconnect the battery from the on-board systems and connect the charger directly to the battery. ◀

Charging the battery when disconnected

 The battery has to be recharged at regular intervals in the course of a lengthy period of disuse.

See the instructions for caring for your battery. Always fully recharge the battery before restoring it to use. ◀

- Charge the battery using a suitable charger.
- Comply with the operating instructions of the charger.
- Once the battery is fully charged, disconnect the charger terminal clips from the battery terminals.

Removing battery



The types of screw used are listed on (→ 132). ◀



If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Make sure that the motorcycle is steady on its stand. ◀

- Switch off the ignition.



- Remove screw **1**.



- Disconnect the battery's negative lead **2** first.
- Then disconnect the battery's positive lead **3**.
- Lift the battery up and out; work it slightly back and forth if it is difficult to remove.

Installing battery



If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Make sure that the motorcycle is steady on its stand. ◀

- Switch off the ignition.
- Insert the battery into the battery compartment, with the positive terminal on the right in the direction of travel.
- Engage the clip at the bottom, slip it over the battery, and hand-tighten screw **1**.
- Install positive lead **3** first and hand-tighten the screw.
- Then install negative lead **2** and hand-tighten the screw.
- Switch on the ignition.
- Without starting the engine, hold the throttle twistgrip in the fully open position for at least one second so that the electronic engine management system can register the throttle-valve positions.
- Switch off the ignition.

 Remember to reset the clock after reconnecting the battery. ◀

Splash guard

The motorcycle has an adjustable splash guard.



- Slacken screw **1**, move the splash guard to the appropriate position and hand-tighten the screw.

Cleaning and care	126
Laying up.....	128
Restoring to use	129

Cleaning and care

Regular cleaning, using the correct methods, is an important factor in maintaining the value of your motorcycle. It also ensures that safety-relevant parts remain in full working order.

Care products

We recommend that you use the cleaning and care products you can obtain from your authorised BMW motorcycle dealer. The materials in BMW Care Products have been tested in laboratories and in practice; they provide optimised care and protection for the materials used in your vehicle.



The use of unsuitable cleaning and care products can damage vehicle components.

Do not use solvents such as cellulose thinners, cold cleaners, fuel or the like, and do not use cleaning products that contain alcohol. ◀

Washing the motorcycle

We recommend that you use BMW insect remover to soften and wash off insects and stubborn dirt on painted parts prior to washing the motorcycle. To prevent stains, do not wash the motorcycle immediately after it has been exposed to strong sunlight and do not wash it in the sun.

Make sure that the motorcycle is washed frequently, especially during the winter

months.

To remove road salt, wash the motorcycle down immediately with cold water at the end of the journey.



Warm water intensifies the effect of salt.

Use only cold water to wash off road salt. ◀



Wet brake discs reduce braking efficiency.

After washing the motorcycle, dry the brakes by braking. ◀



The high pressure of steam cleaners can damage seals, the hydraulic brake system, the electrical system, adhesive labels and badges. Do not use a steam jet or high-pressure cleaning equipment. ◀

Plastics

Clean plastic parts with water and BMW plastic care emulsion. This includes in particular:

- Windscreens
- Headlight lens made of plastic
- Covering glass of the instrument cluster
- Black, unpainted parts



If plastic parts are cleaned using unsuitable cleaning agents, the surfaces can be damaged.

Do not use cleaning agents that contain alcohol, solvents or abrasives to clean plastic parts. Even fly-remover pads or cleaning pads with hard surfaces can produce scratches. ◀



Soften stubborn dirt and dead insects by covering the affected areas with a wet cloth. ◀

Windscreen

Clean off dirt and insects with a soft sponge and plenty of water.



Fuel and chemical solvents attack the windscreen.

Do not use detergent products. ◀

Chrome

Especially in the case of road salt, carefully clean chrome with plenty of water and BMW vehicle shampoo. Use chrome polish for additional treatment.

Paint care

Washing the motorcycle regularly will help counteract the long-term effects of substances that damage the paint, especially if your motorcycle is ridden in areas with high air pollution or natural sources of dirt, e.g. tree resin or pollen.

However, remove particularly aggressive materials immediately; otherwise changes in the paint or discolouration can occur. These include spilt fuel, oil, grease, brake fluid and bird droppings. BMW vehicle polish or BMW paint cleaner are recommended here. Contamination on the paint finish is particularly easy to see after the motorcycle has been washed. Remove stains of this

kind immediately using cleaning-grade benzene or petroleum spirit on a clean cloth or ball of cotton wool. We recommend that specks of tar be removed with BMW tar remover. Then add a protective wax coating to the paint at these locations.

Protective wax coating

For the protective wax coating of paint, we recommend that you use only BMW vehicle wax or agents that contain carnauba wax or synthetic waxes. The best way to see whether the paint has to be protected is that water no longer forms pearls.

Touching up

Your authorised BMW motorcycle dealer is equipped with suitable systems for rapid and low-cost correction of minor paint damage. We recommend that minor paintwork flaws be rectified with a BMW paint spray or a BMW paint pencil and larger paint damage be dealt with at your authorised BMW motorcycle dealer by a specialised repair paint job carried out in accordance with works specifications with original BMW paints.

Rubber

Treat rubber components with water or BMW rubber protection coating agent.



Using silicone sprays for the care of rubber seals can cause damage.

Do not use silicone sprays or other care products that contain silicon. ◀

Laying up

- Clean the motorcycle.
- Remove the battery (► 122).
- Spray the brake and clutch lever pivots and the centre and side stand pivots with a suitable lubricant.
- Coat bright metal/chrome-plated parts with an acid-free grease (e.g. Vaseline)
- Place the motorcycle on its centre stand in a dry room.
- Raise the engine with the front wheel stand in such a way that both wheels are clear of the ground.



Before laying the vehicle up out of use, have the engine oil and the oil filter element changed by a specialist workshop, preferably your authorised BMW motorcycle dealer. Combine work for laying up/restoring to use with a maintenance service or inspection. ◀

Restoring to use

- Remove the protective wax coating.
- Clean the motorcycle.
- Install a charged battery (▶▶▶ 122).
- Perform the safety checks (▶▶▶ 62).
- Check the brakes (▶▶▶ 99).
- Check the tyre pressures (▶▶▶ 57).

Threaded fasteners	132
Tyre pressures	134
Engine	135
Power transmission	136
Frame and suspension	137
Wheels and tyres	139
Fuel and lubricants	140
Electrical system	143
Dimensions and weights	145
Riding specifications	146

Threaded fasteners

Activity	Type of threaded fastener	Tightening torque
Front wheel		
Mudguard	Internal TORX® T25 (1)	hand-tight
Brake caliper	Internal TORX® T45	30 Nm
Quick-release axle	Allen screw w/f 22	50 Nm
Axle clamping screw	Internal TORX® T45	19 Nm
Rear wheel		
End silencer to footrest	Internal TORX® T45	19 Nm
Clamp on end silencer	Hex head w/f 15	55 Nm
Studs for rear wheel	Internal TORX® T50	60 Nm
Bulb housing		
Brake and rear light	Phillips screw, large (1)	hand-tight
Front turn indicators	Internal TORX® T25 (1)	hand-tight

Threaded fasteners

Activity	Type of threaded fastener	Tightening torque
Battery		
Battery-terminal clamps	Hex head w/f 10	hand-tight
Securing bracket	Phillips screw, large (1)	hand-tight
Splash guard		
Splash guard	Internal TORX® T25 (1)	hand-tight

(1) in the toolkit

Tyre pressures

Tyre pressures measured when tyres are cold.

Accessories and loads	Front	Rear
One-up	2.2 bar	2.5 bar
One-up with luggage	2.5 bar	2.9 bar
Two-up (with luggage)	2.5 bar	2.9 bar

Engine

Engine

Type	Four-stroke opposed-twin engine
Displacement	1,170 cc
Bore/stroke	101/73 mm
Compression ratio	12.0 : 1

Power output

Maximum rated output	81 kW
- at engine speed	7,500 rpm

Torque

Max. torque	115 Nm
- at engine speed	6,000 rpm

Engine speeds

Engine speed, maximum	8,000 rpm
Idle speed	1,150 ± 50 rpm (increasing to max. 1,300 rpm to ensure electricity supply)

Consumption

Fuel consumption at constant 90 km/h	3.6 l/100 km
Fuel consumption at constant 120 km/h	4.8 l/100 km
Maximum permissible oil consumption	1 l/1,000 km

Power transmission

Clutch

Type	Single dry plate with high-leverage pressure plate
------	--

Transmission

Type	6- speed gearbox with dog-clutch engagement mechanism and integral vibration damper
Overall ratios	1st gear = 2.277 2nd gear = 1.583 3rd gear = 1.259 4th gear = 1.033 5th gear = 0.903 6th gear = 0.805

Rear-wheel drive

Transmission from gearbox to rear wheel drive	Universal shaft with integrated torsional damper
Rear-wheel drive	Bevel gears
Final drive ratio	2.62 : 1

Frame and suspension

Frame

Type	Tubular steel front frame with tubular steel rear frame, load-bearing drive unit
Location of type plate	On rear-frame bridge, underneath the seat
Location of vehicle identification number (VIN)	On right of steering head

Front brake

Type	Two floating brake discs with 4-piston fixed calipers, sintered metal brake pads
------	--

Rear brake

Type	One fixed brake disc with 2-piston floating caliper, organic brake pads
------	---

Front suspension

Type	BMW Telelever
Steering lock angle	2 x 42°
Front wheel castor in normal-load position	109.9 mm

Rear suspension

Type	BMW EVO Paralever swinging arm
------	--------------------------------

Frame and suspension

Front suspension system

Type	Central spring strut with coil spring and twin-tube, gas-filled shock absorber.
Spring travel (bump)	65 mm
Spring travel (rebound)	55 mm
Total suspension travel	120 mm

Rear suspension system

Type	Central spring strut with single-tube gas-filled shock absorber, steplessly adjustable rebound-stage damping and steplessly adjustable spring preload
Spring travel (bump)	105 mm
Spring travel (rebound)	30 mm
Total suspension travel (at wheel)	135 mm

Wheels and tyres

Front wheel

Type	Cast wheel with 5 double spokes, MT H2
Rim size	3.50 x 17"
Tyre size	120/70-ZR17

Rear wheel

Type	Cast wheel with 5 double spokes, MT H2
Rim size	5.50 x 17"
Tyre size	180/55-ZR17

Fuel and lubricants

Engine oil

Oil grade	Brand-name HD oil of API classification SL or higher; CD or CE amendments are permissible; or brand-name HD oil of CCMC classification G4 or G5; amendment PD2 is permissible.
Capacity (with filter change)	4.0 l
Capacity (without filter change)	3.7 l
Top-up volume between MIN and MAX	0.5 l

BMW recommends Castrol



Fuel and lubricants

Engine-oil viscosity classes depend on outside temperatures

-20 °C – 10 °C	SAE 20
0 °C – 30 °C	SAE 30
20 °C – above 30 °C	SAE 40
-10 °C – over 30 °C	SAE 20 W-50
-15 °C – above 30 °C	SAE 15 W-50
-15 °C – 30 °C	SAE 15 W-40
-20 °C – 20 °C	SAE 10 W-40
-20 °C – 10 °C	SAE 10 W-30

Oil additives are not necessary.

Fuel and lubricants

Transmission oil

Grade	SAE 90 GL5
Capacity	approx. 0.9 l

Fuel

Fuel grade	Super Plus (premium) unleaded minimum octane number 98 (RON)
Capacity of fuel tank	27 l
Reserve volume	4 l

Brake fluid

Grade	DOT 4
	We recommend BMW brake fluid

Electrical system

Battery

Type	12 V, 19 Ah gel battery, maintenance-free
------	---

Spark plugs

Spark plugs	BOSCH YR5LDE
Electrode gap	0.8 mm ($\pm$ 0.1 mm)
Wear limit	1.0 mm

Fuses

All circuits are electronically protected, so plug-in fuses are not necessary. If an electronic fuse trips and de-energises a circuit, the circuit is active as soon as the ignition is switched on after the fault has been rectified.

Electrical system

Bulbs

Headlight type	Triple freeform headlight
High-beam headlight	H7 halogen bulb 12 V, 55 W
Low-beam headlight	H7 halogen bulb 12 V, 55 W (2x)
Side lights	12 V, W5 W (2 x)
Brake/rear light	12 V, P21 W (2 x)
Flashing turn indicators	12 V, P21 W
Flashing turn indicators, white ^{OE}	12 V, PY21 W

On-board sockets

Ratings	12 V, total max. 10 A
---------	-----------------------

Dimensions and weights

Dimensions

Maximum length	2,230 mm
Maximum width with cases	980 mm
Maximum width across mirrors	905 mm
Maximum height (windscreen lowered)	1,430 mm
Maximum height (windscreen raised)	1,560 mm
Seat height	820-840 mm
Height of seat (low front seat ^{OE})	780-800 mm
Wheelbase	1,484.6 mm
Ground clearance	156.1 mm

Weights

Unladen weight (ready for road, fuel tank full)	259 kg
Maximum payload	236 kg
Permissible gross weight	495 kg

Permissible wheel loads

Front	200 kg
Rear	330 kg

Riding specifications

Speeds

Top speed	over 200 km/h
Acceleration 0-100 km/h	3.6 s

Noises

Ride-past noise level	80 dB (A)
Stationary noise level	88 dB (A) at 3,750 rpm

BMW Motorrad	
service	148
Confirmation of	
maintenance work	151
Confirmations of service	155

BMW Motorrad service

BMW Motorrad service quality

BMW Motorrad stands not only for good handling and a high degree of reliability, but also for an excellent quality of service. To ensure that your BMW is always in optimum condition, we recommend that you have the regular maintenance work required for your motorcycle carried out, preferably by your authorised BMW motorcycle dealer. For generous treatment of claims submitted after the warranty period has expired, evidence of regular maintenance is essential.

Certain signs of wear, moreover, may otherwise not be noticed until it is too late to put them right at moderate cost. Your author-

ised BMW motorcycle dealer knows every detail of your motorcycle and can take remedial action if necessary before minor faults develop into serious problems. By having the necessary repairs done properly and in good time, you save time and money in the long run.

BMW Motorrad Service Card – On-the-spot breakdown assistance

With all new BMW motorcycles, the BMW Motorrad Service Card protects you in the event of a breakdown with an extensive range of services such as breakdown assistance, motorcycle transportation etc. (differing regulations are possible in individual countries). In the event of a breakdown, contact BMW

Motorrad's Mobile Service. Here you will find our specialists ready to help in both word and deed.

Important country-specific contact addresses and the relevant after-sales service organisation phone numbers as well as information on Mobile Service and the dealership network can be found in the "Service Kontakt / Service Contact" brochures.

BMW Motorrad service network

Our extensive after-sales service organisation network is able to look after you and your motorcycle in more than 100 countries. In Germany alone, you have the best possible access to approximately 200 authorised BMW motorcycle dealers.

All information concerning the international dealership network can be found in the brochure "Service Contact Europe" or "Service Contact Africa, America, Asia, Australia, Oceania".

You will be given the relevant brochure for your country together with your motorcycle; you can obtain both brochures from your authorised BMW motorcycle dealer.

Maintenance work

Some maintenance tasks have to be performed after a certain time, others depend on the distance covered by the motorcycle.

BMW Running-in Check

The BMW running-in check has to be performed when the motorcycle has covered between 500 km and 1,200 km

BMW Annual Inspection

Some maintenance work has to be carried out at least once a year. Other tasks depend on the distance the motorcycle has covered.

BMW Service

After the first 10,000 km and every further 20,000 km (30,000 km, 50,000 km, 70,000 km, etc.) if this distance is covered within a year.

BMW Inspection

After the first 20,000 km and every further 20,000 km (40,000 km, 60,000 km,

80,000 km, etc.) if this distance is covered within a year.

Maintenance schedules

The maintenance schedule for your motorcycle depends on the equipment fitted, and on the motorcycle's age and the distance it has covered. Your authorised BMW motorcycle dealer will be happy to supply a copy of the current maintenance schedule for your motorcycle on request.



Every authorised BMW motorcycle dealer has a fixed scale of charges based on labour times and carefully calculated hourly rates. Fuel, lubricants and similar substances, filters, gaskets etc. are charged separately. ◀

**BMW
Pre-delivery Check**

Carried out in accordance with
manufacturer's instructions

Date, stamp, signature

**BMW Running-In
Check**

Carried out in accordance with
manufacturer's instructions

Odometer reading

Brake fluid changed:

BMW Integral ABS

- ☐ Wheel circuit
- ☐ Control circuit

Date, stamp, signature

Confirmation of maintenance work

BMW Service

- ☐ BMW Annual Inspection
- ☐ BMW Service
- ☐ BMW Inspection

Carried out in accordance with
manufacturer's instructions

Odometer reading

Brake fluid changed:

BMW Integral ABS

- ☐ Wheel circuit
- ☐ Control circuit

Date, stamp, signature

BMW Service

- ☐ BMW Annual Inspection
- ☐ BMW Service
- ☐ BMW Inspection

Carried out in accordance with
manufacturer's instructions

Odometer reading

Brake fluid changed:

BMW Integral ABS

- ☐ Wheel circuit
- ☐ Control circuit

Date, stamp, signature

BMW Service

- ☐ BMW Annual Inspection
- ☐ BMW Service
- ☐ BMW Inspection

Carried out in accordance with
manufacturer's instructions

Odometer reading

Brake fluid changed:

BMW Integral ABS

- ☐ Wheel circuit
- ☐ Control circuit

Date, stamp, signature

Confirmation of maintenance work

BMW Service

- ☐ BMW Annual Inspection
- ☐ BMW Service
- ☐ BMW Inspection

Carried out in accordance with
manufacturer's instructions

Odometer reading

Brake fluid changed:

BMW Integral ABS

- ☐ Wheel circuit
- ☐ Control circuit

Date, stamp, signature

BMW Service

- ☐ BMW Annual Inspection
- ☐ BMW Service
- ☐ BMW Inspection

Carried out in accordance with
manufacturer's instructions

Odometer reading

Brake fluid changed:

BMW Integral ABS

- ☐ Wheel circuit
- ☐ Control circuit

Date, stamp, signature

BMW Service

- ☐ BMW Annual Inspection
- ☐ BMW Service
- ☐ BMW Inspection

Carried out in accordance with
manufacturer's instructions

Odometer reading

Brake fluid changed:

BMW Integral ABS

- ☐ Wheel circuit
- ☐ Control circuit

Date, stamp, signature

Confirmation of maintenance work

BMW Service

- ☐ BMW Annual Inspection
- ☐ BMW Service
- ☐ BMW Inspection

Carried out in accordance with
manufacturer's instructions

Odometer reading

Brake fluid changed:

BMW Integral ABS

- ☐ Wheel circuit
- ☐ Control circuit

Date, stamp, signature

BMW Service

- ☐ BMW Annual Inspection
- ☐ BMW Service
- ☐ BMW Inspection

Carried out in accordance with
manufacturer's instructions

Odometer reading

Brake fluid changed:

BMW Integral ABS

- ☐ Wheel circuit
- ☐ Control circuit

Date, stamp, signature

BMW Service

- ☐ BMW Annual Inspection
- ☐ BMW Service
- ☐ BMW Inspection

Carried out in accordance with
manufacturer's instructions

Odometer reading

Brake fluid changed:

BMW Integral ABS

- ☐ Wheel circuit
- ☐ Control circuit

Date, stamp, signature

Confirmation of maintenance work

BMW Service

- ☐ BMW Annual Inspection
- ☐ BMW Service
- ☐ BMW Inspection

Carried out in accordance with
manufacturer's instructions

Odometer reading

Brake fluid changed:

BMW Integral ABS

- ☐ Wheel circuit
- ☐ Control circuit

Date, stamp, signature

BMW Service

- ☐ BMW Annual Inspection
- ☐ BMW Service
- ☐ BMW Inspection

Carried out in accordance with
manufacturer's instructions

Odometer reading

Brake fluid changed:

BMW Integral ABS

- ☐ Wheel circuit
- ☐ Control circuit

Date, stamp, signature

BMW Service

- ☐ BMW Annual Inspection
- ☐ BMW Service
- ☐ BMW Inspection

Carried out in accordance with
manufacturer's instructions

Odometer reading

Brake fluid changed:

BMW Integral ABS

- ☐ Wheel circuit
- ☐ Control circuit

Date, stamp, signature

Record of all work carried out in workshop

[illegible]

Confirmation of service

Instrument cluster replaced

at distance

(odometer reading)

Date, stamp, signature

Instrument cluster replaced

at distance

(odometer reading)

Date, stamp, signature

Instrument cluster replaced

at distance

(odometer reading)

Date, stamp, signature

A

Abbreviations, 4

ABS

Antilock braking system, 82

BMW Integral ABS, 81

Brake booster, 82

Pull-away test, 69

Rear wheel lift, 82

Self-diagnosis, 65

Warning, 27

Warning light, 21

Accessories

BMW optional extras, 4

Cable routing, 87

General instructions, 86

Non-BMW products, 5

Operation via power socket, 87

Accessory

BMW optional accessories, 4

Adjusting mirrors, 55

Adjusting rear shock

absorber, 56

Anti-theft alarm telltale light, 16

B

Battery, 13

Charging when

connected, 120

Charging when

disconnected, 121

Maintenance instructions, 120

Removing, 122

Technical data, 143

Warning indicator for charge

current, 26

BMW Service

Annual inspection, 149

Confirmation of maintenance

work, 151

Confirmation of service, 154

Information, 5

Inspection, 149

Maintenance schedules, 149

Maintenance service, 149

Running-in check, 149

Service Card, 148

Worldwide, 148

Brake

Adjusting the handbrake
lever, 48

Brake-fluid reservoir, 9

Bulb for brake light,
replacing, 116

Front fluid reservoir, 11

Rear fluid reservoir, 13

Residual braking function, 83

Safety instructions, 80

Brake pads, 69

Brakes, 99

Brake pads, 100

Checking front brake pad
thickness, 100

Checking operation, 99

Checking rear brake pad
thickness, 101

Checking the fluid level, 102

Bulbs, 112

Information, 112

Replacing brake-light, rear-
light and rear-indicator
bulbs, 116

Replacing high-beam
headlight bulb, 113
Replacing low-beam headlight
bulb, left, 114
Replacing low-beam headlight
bulb, right, 114
Replacing side-light bulbs, 115
Technical data, 144
Warning indicator for defective
bulb, 26

C

Care

Care products, 126
Chrome, 127
Paint, 127
Plastics, 127
Protective wax coating, 128
Rubber, 128
Touching up, 128
Washing the motorcycle, 126
Windscreen, 127

Case

Installing, 91

Cases

Closing, 90
Correct loading, 89
Opening, 89

Catalytic converter, safety
information, 61

Centre stand

Extending, 77
Retracting, 79

Checklist, 62

Clock

Adjusting, 16
Display, 20
Setting, 38

Clutch

Checking operation, 103

Cruise-control system

Function, 42
Switch, 14

Currency, 5

D

Display dimming

Display, 20

E

Electronic engine-management
system

Tampering with control unit, 61

Electronic immobiliser

Display, 24
Explanations, 36
Warning, 24

Emergency off switch (kill
switch), 15, 45

Engine, 140

Oil temperature gauge, 20

Engine electronics

Warning indicator, 24

Engine oil, 99

Checking the oil level, 98, 99
Oil filler neck, 9
Oil sight glass, 9
Technical data, 140
Temperature warning, 24
Warning indicator for oil
pressure, 25

Engine, technical data, 135

F

- Front seat
 - Height adjuster, 13
- Front-wheel stand, 111
- Fuel
 - Fuel gauge, 20
 - Grade, 80
 - Quality, 142
 - Refuelling, 79
 - Reserve, 24
- Fuel tank capacity, 80
- Fuses, 143

G

- Gear indicator, 20, 21
- Gearbox, 66
 - Gear shifts, 70
 - Position on starting, 63
 - Technical data, 136
- General view
 - Right side, 11
- General view,
 - left side, 9
- Grip heating, 15, 45

H

- Handlebar fitting
 - Left, 14
 - Right, 15
- Handlebar levers
 - Adjusting brake lever, 48
 - Adjusting clutch lever, 47
- Hazard warning flashers, 14, 37
- Headlight
 - Adjustment for right-hand/left-hand traffic, 50
 - Overview, 17
- Headlights
 - Adjusting beam throw, 9, 49
- Helmet holder, 13, 54
- High-beam headlight
 - Bulb, 17
 - Switching on, 14
 - Telltale light, 21
- Horn, 14

I

- Ice warning
 - Warning
 - risk of black ice, 26
- Ignition
 - Switching off, 34
 - Switching on, 34, 63
- Inflation pressures, 134
- Installing battery, 122
- Instrument cluster, 16
 - light sensor, 16
 - Multifunction display, 20
 - Speedometer, 16

J

- Jump starting, 118

K

- Keys
 - Ignition keys, 34
 - Replacement keys, 36

L

Laying up, 128

Lights

Headlight flasher, 14, 48

Parking lights, 49

Side lights, 48

Switching on the high-beam
headlight, 48

Switching on the low-beam
headlight, 48

Locking the handlebars, 35

Low-beam headlight

Bulb, 17

Replacing bulb, 114

Luggage

Safety information, 60

Luggage system, 89

M

Motorcycle equipment, 5

Multifunction display, 16

N

Neutral, telltale light, 21

O**Odometer**

Control, 16

Reading, 20

Oil capacity, 98

Oil filler neck, 99

Oil temperature

Display, 21

On-board computer

Display, 20

Operation, 39

P

Parking your motorcycle, 73, 77

Payload

Label, 13

Power socket, 9, 144

Pre-ride check, 63

R**Radio**

Display, 20

Radio compartment, 11

Rear light, replacing bulb, 116

Rear shock absorber

Adjustment, 9

Residual braking function, 83

Restoring to use, 129

Rev. counter, 16

Rider's equipment, 6

Running in

Brake pads, 69

General information, 69

Tyres, 70

S

Safety check before a
journey, 62

Safety instructions, 60

Seat

Adjusting front seat, 53

Installing, 53

Lock, 52

Removing, 52

Seat heating, 46

Display, 20

Front seat, 46

Rear seat, 11

- Seat lock, 11
- Shifting gear, 71
- Side light
 - Bulb, 17
- Side lights
 - Replacing bulbs, 115
- Side stand
 - Extending, 73
 - Position for starting, 66
 - Retracting, 75
- Spark plugs, technical data, 143
- Speed
 - Safety information, 60
 - Technical data, 146
- Splash guard, 123
- Spring preload
 - Adjusting, 55
 - Adjusting rear, 13
- Starter, 15
- Starting, 66
- Stowage compartment, 11, 51
- Symbols, 4

T

- Table of tyre pressures, 13
- Tank rucksack, 94
 - Mount, 11
- Technical data
 - Dimensions and weights, 145
 - Electrical system, 143
 - Engine, 135
 - Frame and suspension, 137
 - Fuel and lubricants, 140
 - Information, 5
 - Power transmission, 136
 - Riding specifications, 146
 - Threaded fasteners, 132
 - Wheels, 139
- Telltale lights, 16, 21
- Threaded fasteners, 132
- Tightening torques, 132
- Toolkit, 13, 97
- Topcase
 - Closing, 94
 - Installing, 92
 - Opening, 94
 - Removing, 93

Tripmeter

- Resetting, 38

Troubleshooting chart, 68

Turn indicator

- Left, 14

- Replacing the front bulb, 117

- Right, 15

Turn indicators

- Switching off, 15, 51

- Switching on, 50

- Telltale lights, 21

Type plate, 13

Tyres

- Checking pressures, 57

- Checking tread depth, 103

- Tyre pressures, 134

W

Warning indicator

- Fuel reserve, 24

Warning indicators, 21

- Notes, 21

- Overview, 22

Warning lights, 16, 21

Warning symbols, 20

Warnings, 4

Wheels, 103

- Checking rims, 103

- Checking tread depth, 103

- Installing front wheel, 106

- Installing rear wheel, 109

- Removing front wheel, 104

- Removing rear wheel, 108

- Technical data, 139

- Tyre pressures, 134

Windscreen

- Adjusting, 55

- Adjustment, 14

- Care, 127

- Electrically adjustable, 11

Vehicle/dealership data

Vehicle data

Model

Vehicle identification number

Colour code

First registration

Registration number

Dealership data

Person to contact in Service

Ms./Mr.

Phone number

Dealership address/phone
(company stamp)

Details described or illustrated in this booklet may differ from the motorcycle's actual specification as purchased, the accessories fitted or the national-market specification. No claims will be entertained as a result of such discrepancies. Dimensions, weights, fuel consumption and performance data are quoted to the customary tolerances.

The right to modify designs, equipment and accessories is reserved.

Errors and omissions excepted.

© 2004 BMW Motorrad

Not to be reproduced either wholly or in part without written permission from BMW Motorrad, After Sales.

Printed in Germany

BMW recommends Castrol



The most important data for a filling station stop can be found in the following chart:

Fuel

Designation	Super unleaded	
RON	98	
MON	88	
Fuel tank capacity	27 l	

Tyre pressures

	Front	Rear
One-up	2.20 bar	2.50 bar
One-up with luggage	2.50 bar	2.90 bar
Two-up (with luggage)	2.50 bar	2.90 bar

BMW Motorrad

Order No.:
01 41 7 680 901
11.2004
1st edition GB / RF



**The Ultimate
Driving Machine**

How does ABS work?

The maximum braking force it is possible to transfer to the carriageway depends, among other things, on the road surface's coefficient of friction. Gravel, ice and snow, and water on the road, have significantly poorer coefficients of friction than a dry, clean asphalt road surface. The poorer the road's coefficient of friction, the longer the braking distance.

If the maximum braking force it is possible to apply to the road is exceeded when the rider increases brake pressure, the wheels will begin to lock and directional stability is lost; a fall threatens. Before this situation can arise, ABS intervenes and

adapts the braking pressure to the maximum braking force it is possible to transfer so that the wheels continue to turn and driving stability is maintained whatever the prevailing road conditions.

What happens with bumps in the road?

Corrugated road surfaces or bumps in the road can cause the tyres to temporarily lose contact with the road surface and hence the braking force it is possible to apply to drop to zero. If the brakes are applied in this situation, the ABS must reduce the braking pressure to ensure driving stability when contact with the road surface is restored. At this moment, BMW Motorrad Integral ABS

must assume extremely low coefficients of friction (gravel, ice, snow) so that the wheels turn in any conceivable situation and thus the stability of the motorcycle is ensured. Once the actual circumstances are detected, the system will set the brake pressure to the optimum value.

What do we observe during rider safety training?

Braking in which ABS has to intervene has, by comparison with normal braking, a significantly higher demand for electricity which puts a heavy load on the battery. The battery is constantly being charged in normal riding so that it always has sufficient capacity available.

If the motorcycle is not to be ridden for several weeks, a trickle charger, which can be obtained from your BMW Motorrad dealer, should be connected or the battery disconnected and then recharged before starting riding again.

During rider safety training, an unusual number of ABS-controlled braking operations take place in rapid succession interspersed with periods of waiting and assessment in which the motorcycle is not being ridden. The battery is put under heavy load by the ABS control actions, but at the same time it is not being recharged as practically no riding is being done.

In isolated cases, in this artificially created situation,

braking operations in which the brake lever is operated with maximum force and extreme speed, in combination with declining on-board supply voltage, can bring the ABS up to its technical limits in which its control function is no longer fulfilled.

Field observations carried out by BMW Motorrad indicate that a comparable situation has not arisen in traffic or even during training rides.

The following notes must be observed during safety training:

- check the warning and indicator lamps before any braking exercise
- ride the motorcycle over sufficient distance to charge the battery after a maximum of five braking exercises

- switch off consumers such as seat and grip heating, radio, navigation system and accessories connected to the power sockets
- in pauses and discussions, switch off the ignition; if the engine is switched off with the emergency off switch, the lights and all electronic systems remain switched on and drain the battery

How can I achieve the shortest braking distance?

Dynamic load distribution between the front and rear wheels changes under braking. The heavier the brakes are applied, the more load is transferred to the front brake. The greater the load on the wheel, the more braking force can be transferred.

To achieve the shortest braking distance, it is necessary to apply the front brake gradually and with increasing force. This makes best use of the dynamic increase in load on the front wheel. At the same time, the clutch should be disengaged.

In emergency braking as it is often taught, in which the brake pressure is generated as quickly as possible and with all possible force, the dynamic load distribution cannot follow the increasing deceleration and the braking force cannot be completely transferred to the road. The ABS has to intervene to ensure that the front wheel does not lock up; this reduces the brake pressure and the braking distance is extended.

What happens if ABS control fails?

A fault in BMW Motorrad Integral ABS is indicated by a corresponding warning display in the instrument cluster. If only ABS control fails, the Integral system and the brake servo action remain operational. If these systems also fail, the residual brake function is applied. In this case, the forces to be applied to the brake levers will be significantly higher and the lever travel required will be longer. The residual brake function is a mechanical function and is always available in the event of the failure of the BMW Motorrad Integral ABS, whatever the battery condition. It meets all requirements of legislation around the world

on the design of brakes for motor vehicles and allows the rider to brake the motorcycle. The following notes must be observed for riding with the residual braking function:

- set the brake lever to maximum travel
- always brake with both front and rear brakes
- where it is safe to do so, try out the brakes so that you can learn the brakes' response characteristics
- be aware of the prevailing road conditions and adapt your braking force accordingly
- since this is an emergency-run function, you should visit a specialist workshop, or better still a BMW Motorrad dealer, as quickly as possible

What is the role of regular maintenance?



Any technical system is only ever as good as its maintenance.

The service intervals specified must be kept to without fail to ensure that the BMW Motorrad Integral ABS is in an optimum maintenance condition. ◀

What is the design specification for BMW Motorrad Integral ABS?

BMW Motorrad Integral ABS ensures stability of the motorcycle on any surface within the bounds of physics.

The system is not designed for special requirements such as those that arise under extreme conditions of competition off-road or on the racetrack.

BMW Motorrad

Order No:
01 41 7 699 271
07.2005
1st edition GB/RF



The Ultimate
Riding Machine