Maintenance Instructions (US Model) R 850 RT R 1150 RT

BMW Motorrad On-board documentation

consisting of Rider's Manual and Maintenance Instructions



٢

Please note



This symbol indicates precautions and measures which are essential in pro-tecting the rider or other persons from severe or fatal injury.



▲ CAUTION

Specific instructions and safety precautions intended to prevent damage to the motorcycle. Disregarding them may render the warranty invalid.



Specific instructions on how to operate, control, adjust or look after items of equipment on the motorcycle. For safety reasons and to maintain the value of your motorcycle, regular maintenance intervals have been established.

Always keep to the specified maintenance intervals. This is the only way to ensure that warranty claims are not invalidated. The contents of the maintenance schedules are subject to change, for reasons of safety, due to modifications in materials etc.

Your authorized BMW motorcycle retailer is the best place to keep you informed as to current Services, Inspections and Annual Services.

Important!

BMW refuses to accept liability for damage or consequential damage due to repairs or service work performed by workshops other than BMWauthorized workshops. Therefore, we recommend having the maintenance work carried out and confirmed in the Maintenance Instructions by the specially trained experts at your authorized BMW motorcycle retailer.

authorized BMW motorcycle retailers are supplied with the latest technical information and have the necessary technical know-how and specially trained staff.

Please contact your authorized BMW motorcycle retailer if you have any questions regarding your motorcycle.

authorized BMW motorcycle retailers are fully informed about all aspects of your motorcycle and will gladly advise and assist you.

Best wishes,

BMW Motorrad

For your own safety, use only genuine BMW spare parts and accessories approved by BMW.

If you choose original accessories and spare parts that have been tested and approved by the manufacturer, you can be sure that BMW has performed the appropriate tests to confirm their suitability for use on your motorcycle. BMW accepts full liability for these products. Note, however, that BMW is unable to accept liability for spare parts and accessories which it has not approved.

BMW cannot assess every single product of outside origin in order to decide whether it can be used on or with a BMW vehicle without constituting a safety hazard.

Nor is approval by an official technical inspection authority, or even the granting of a general operating permit necessarily a sufficient guarantee, since these test procedures are not always adequate.

Genuine BMW spare parts, accessories and other products which BMW has approved can be obtained from all authorized BMW motorcycle retailers, together with expert advice on their installation and use. Maintenance work is divided into Service, Inspection and Annual Inspection.

BMW Inspection 600 miles (1,000 km)

BMW Break-in Check after the first 600 miles (1,000 km).

BMW Service

After the first 6,000 miles (10,000 km) and every additional 12,000 miles (20,000 km) (18,000 miles (30,000 km), 30,000 miles (50,000 km), 45,000 miles (70,000 km) etc.)

BMW Inspection

After the first 12,000 miles (20,000 km) and every additional 12,000 miles (20,000 km) (25,000 miles (40,000 km), 37,000 miles (60,000 km), 50,000 miles (80,000 km) etc.) **BMW Annual Inspection**

Certain items of maintenance work depend on elapsed time as well as the distance the motorcycle has been driven. They must therefore be carried out at least once a year (e.g. changing brake fluid).

If these items cannot be performed during a Service or an Inspection, an Annual Inspection must be performed.

Every authorized BMW motorcycle retailer has a fixed scale of charges based on work times and carefully calculated hourly rates. Fuel, lubricants and similar substances, filters, gaskets etc. are charged separately.

Maintenance schedule

If you are interested, you can view and download the current maintenance schedule for your motorcycle on the Internet at www.bmw-motorrad.com/ maintenance.

BMW Pre-Delivery Check

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

BMW Inspection 600 miles (1,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

BMW Service 6,000 miles (10,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

BMW Inspection 12,000 miles (20,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

BMW Service 18,000 miles (30,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

BMW Service 30,000 miles (50,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

MW Service

BMW Inspection 24.000 miles (40.000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

BMW Inspection 36,000 miles (60,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

BMW Service 42,000 miles (70,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

BMW Inspection 48,000 miles (80,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

BMW Service 54,000 miles (90,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

BMW Inspection 60,000miles (100,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

BMW Service 66,000 miles(110,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

BMW Service 78,000 miles (130,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

Date, stamp, signature

BMW Inspection 72,000 miles(120,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

BMW Inspection 84,000 miles (140,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

BMW Service 90,000 miles (150,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

BMW Inspection 96,000 miles (160,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

BMW Service 102,000 miles (170,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

BMW Inspection 108,000 miles (180,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

BMW Service 118,000 miles (190,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

BMW Service 130,000 miles (210,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

Date, stamp, signature

BMW Inspection 124,000 miles (200,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

Date, stamp, signature

BMW Inspection 136,000 miles (220,000 km)

Performed in accordance with manufacturer's instructions

Odometer reading

BMW Annual Inspection	BMW Annual Inspection
Performed in accordance with	Performed in accordance with
manufacturer's instructions	manufacturer's instructions
Brake fluid changed:	Brake fluid changed:
Without BMW Integral ABS	Without BMW Integral ABS
annually	annually
yes 🗌 no 🗌	yes no
With BMW Integral ABS	With BMW Integral ABS
Wheel Circuit - annually	Wheel Circuit - annually
yes 🗌 no 🗋	yes no
Control circuit - every 2 years	Control circuit - every 2 years
yes no	yes no
Clutch fluid changed:	Clutch fluid changed:
ever <u>y 2</u> years	every 2 years
yes 🗋 no 🗋	yes no
Date, stamp, signature	Date, stamp, signature
BMW Annual Inspection	BMW Annual Inspection
Performed in accordance with	Performed in accordance with
manufacturer's instructions	manufacturer's instructions
Brake fluid changed:	Brake fluid changed:
Without BMW Integral ABS	Without BMW Integral ABS
annually	annually
yes no	yes no
With BMW Integral ABS	With BMW Integral ABS
Wheel Circuit - annually	Wheel Circuit - annually
yes no	yes no
Control circuit - every 2 years	Control circuit - every 2 years
yes no	yes no
Clutch fluid changed:	Clutch fluid changed:
every 2 years	every 2 years
yes no	yes no
Date, stamp, signature	Date, stamp, signature

C ANA C

Inspection	BMW Annual Inspection
ordance with	Performed in accordance with
	manufacturer's instructions
anged:	Brake fluid changed:
U U	Without BMW Integral ABS
-9-04.7 NBC	annually
al ABS	With BMW Integral ABS
nually	Wheel Circuit - annually
	yes no
very 2 years	Control circuit - every 2 years
	yes no
anged:	Clutch fluid changed:
_	every 2 years
	yes no
ature	Date, stamp, signature
In an a still an	
	BMW Annual Inspection
	Performed in accordance with
	manufacturer's instructions
•	Brake fluid changed:
egral ABS	Without BMW Integral ABS
	annually
	yes no
	With BMW Integral ABS
nually	Wheel Circuit - annually
/ery 2 years	Control circuit - every 2 years
angodi	
angeu.	Clutch fluid changed: every 2 years
	ves no
ature	Date, stamp, signature
	nually //ery 2 years anged: // ature Inspection rdance with structions anged: // gral ABS // ABS // // // // // // // // // // // // //

11

Confirmation of service

BMW Service

Record of all work performed in workshop			
Work performed	km/mile	Date	


The list is intended as a record of maintenance, warranty and repair work, the installation of optional accessories and, if appropriate, special campaign work.

Confirmation of service

Record of all work performed in workshop		
km/mile	Date	
		1
		0
		i

The list is intended as a record of maintenance, warranty and repair work, the installation of optional accessories and, if appropriate, special campaign work.

Confirmation of service



Odometer replaced Odometer reading is not total distance covered. Odometer reading

Date, stamp, signature

Odometer replaced

Odometer reading is not total distance covered.

Odometer reading

Date, stamp, signature

Date, stamp, signature

Odometer replaced

Odometer reading is not total distance covered.

Odometer reading

Your motorcycle is equipped with Digital Motor Electronic (MOTRONIC) engine management and a high-power ignition system.

When the engine is running or the ignition is switched on, do not touch electrically live components, terminals or wiring.

Risk of fatal accident! Work on the electrical system only when the circuit has been broken (switch off ignition and lights). For greater safety, disconnect and insulate the negative battery lead. If you intend to perform the maintenance and general care work described in the following section yourself, you must possess the necessary knowledge of technical matters and mechanical skills. Your motorcycle is built to high technological standards. Special tools and purposedesigned diagnosis and testing equipment, together with the appropriate knowledge, are needed to keep your motorcycle in optimum working order.

Authorized BMW motorcycle retailers have the necessary technical know-how and specially trained staff.

They can guarantee that your motorcycle is always maintained in a fault-free technical condition. Remember: the safety and reliability of your motorcycle are the most important considerations. You should therefore not attempt any complex repair or maintenance tasks. Keep to the specified Inspection and Service intervals.

BMW refuses to accept liability for damage or consequential damage due to repairs or service work performed by workshops other than BMWauthorized workshops.

Technical modifications

The data stored in the MOTRONIC control unit is the result of extensive experimental and testing work. Tampering with the MOTRONIC control unit represents an increased safety risk for the rider.

Tampering with the MOTRONIC control unit invalidates the warranty.

There is only limited scope for technical modifications to the motorcycle.

Whenever you are planning such modifications, comply with all applicable legal requirements. The motorcycle must not infringe your national roadvehicle construction and use regulations.

Your authorized BMW motorcycle retailer will gladly advise you on technical requirements, the manufacturer's recommendations and the overall benefit likely to be obtained.

Genuine BMW parts

For reasons of safety, use only genuine BMW parts and accessories.

Genuine BMW parts are identical with those fitted to your motorcycle as original equipment.

BMW Motorrad shall assume no liability whatsoever for spare parts and accessories of other manufacturers. Malfunction: Engine does not start at all or is very difficult to start

		,
Possible cause	Remedy	See 🗯 Page
Wrong ignition key position	Operate correctly	Rider's Manual
Kill switch on	Operate correctly	Rider's Manual
Side stand out and gear engaged	Operate correctly	Rider's Manual
Power supply interrupted	Blown fuse	₩ 47
Gear engaged, clutch not released	Select neutral or pull clutch lever	Rider's Manual
No fuel in tank	Add fuel	Rider's Manual
Fuel pump not working	Blown fuse 6	₩ 47
Wrong twistgrip/ choke setting	Operate correctly	Rider's Manual
Blocked air filter element	Replace	₩ 48
Spark plug/leads or caps wet	Blow out/dry with compressed air	
Insufficient battery charge	Recharge battery	₩ 49


For more serious faults – and those not detailed on pages 15 to 59 – take your motorcycle to a BMW-certified workshop, preferably an authorized BMW motorcycle retailer, to be repaired.

More detailed technical information is available in the following publications:

- BMW Repair Manual
- BMW electrical circuitdiagrams brochure

Removing front wheel





A CAUTION

When removing, avoid damage to brake lines, brake disks, brake pads or the wheel rim (mask off with tape if necessary). Keep dirt and moisture away from the wheel bearings. Do not damage the ABS sensor cable, the ABS sensor ring or the ABS sensor.


• Place the motorcycle on its main stand on a flat, firm surface

Apply a load over the rear wheel so that the motorcycle cannot tip forward.

- Remove the 4 retaining bolts 1 and 2
- Take off the front wheel mudguard **3**

Mark the installed position on the tire and ABS sensor ring; note also the direction-of-rotation arrow if it is marked on the tire.

Removing front wheel




- Unscrew the retaining bolts **4** for the left/right brake calipers
- Remove the ABS sensor wire from the clip (next to the upper retaining screw for the left brake caliper)
- Push the brake pads back slightly by rocking the brake calipers
- Carefully take off the left and right brake calipers

▲ CAUTION

Do not scratch the rim when forcing back the brake pads or removing the calipers (apply masking tape if necessary). To prevent damage to the brake caliper and possible difficulty when assembling: never apply the brake lever when the brake calipers have been removed.

Check the brake pads (# 32) (have them replaced if necessary).

Removing front wheel




- Remove axle bolt 5
- Slacken off axle clamp bolts **1** on the left and right
- Insert a suitable screwdriver through hole **A** into the quick-release axle **2**
- Pull out the quick-release axle
 2 by turning it slightly

- Remove speedometer drive 4 and spacer bush 3
- Roll the front wheel forward and out

A CAUTION

When setting down the front wheel, avoid damage to the brake disks and ABS sensor ring. Keep dirt and moisture away from the wheel bearings.

Installing front wheel



• Roll the front wheel in between the fork stanchions

ACAUTION

To prevent the speedometer shaft from being damaged, the nose **A** on the slide tube must be inserted in the notch **B** on the speedometer drive.


- Insert spacer bushing and speedometer drive.
 - Looking forward:
 - left: speedometer drive 4
 - right: spacer bushing 3

A CAUTION

Avoid damage to brake lines, disks and pads when installing. Keep dirt and moisture away from the wheel bearings. Do not damage the ABS sensor cable, the ABS sensor ring or the ABS sensor.

Note arrow on tire indicating correct direction of rotation.


Installing front wheel



- Clean the quick-release axle,
 1, grease it, and insert it from the right, turning slightly at the same time
- Tighten the axle bolt **3** hand-tight
- Tighten the axle clamp bolts 2 hand-tight
- Compress the front fork firmly several times
- Tighten axle bolt **3** to its tightening torque

- Tighten axle clamp bolts **2** on the left/right to their tightening torque
- Mount left and right brake calipers on brake disks
- Tighten the brake caliper bolts **4** to their tightening torque
- Press the ABS sensor wire into the clip (next to the upper left brake-caliper mounting bolt)

Installing front wheel



Maintenance and care

A CAUTION

Always have the tightening torques checked by a BMWcertified workshop, preferably by an authorized BMW motorcycle retailer.

ACAUTION

Watch spacer bushings.

- Install the front mudguard 3
- Insert mounting bolts 1 and 2 and tighten them carefully

Tightening torque:


Brake caliper bolts	30 Nm
Axle bolt	30 Nm
Axle clamp bolts	22 Nm

Once the brake calipers have been completely installed and the ignition has been switched on and successful self-diagnosis has been performed, the handbrake lever must be depressed to restore full function.

Removing rear wheel








ACAUTION

When removing, avoid damage to brake lines, brake disks, brake pads or the wheel rim (mask off with tape if necessary).

Do not damage the ABS sensor cable, the ABS sensor ring or the ABS sensor.

- Place the motorcycle on its main stand on a flat, firm surface (
 Rider's Manual, Chapter 3).
- Apply a load at the front wheel so that the motorcycle cannot tip toward the rear
- · Select first gear
- Take off the rear seat
- Take out the two Phillipshead screws **1** in the rear body section
- Remove hex bolt **2**, working from underneath
- Take off rear wheel cover 3

Removing rear wheel




A CAUTION

Do not scratch the wheel when forcing back the brake pads or removing the caliper (apply masking tape if necessary). To prevent damage to the brake caliper and possible difficulty when assembling: never operate the brake lever when the brake calipers have been removed.

- Unscrew brake caliper bolts 4
- Push the brake pads back slightly by lightly rocking the brake calipers
- Carefully take off the brake caliper **5**

Check the brake pads (••• 33) and have them replaced if necessary.


Removing rear wheel



- Remove the four wheel studs
 1 with taper rings 2
- Lift the rear wheel off the centering spigot and carefully roll it out to the rear
- Watch shim 3

Protect the wheel hub contact face against dust and dirt.

Installing rear wheel



▲ CAUTION

Use only wheel studs with the same length code number. Do not oil or grease the wheel studs.


Avoid damage to brake lines, brake disk, brake pads or the rim when installing.

Do not damage the ABS sensor cable, the ABS sensor ring or the ABS sensor.

- Check that the wheel centering and contact surfaces for the wheel hub and the shim are free of grease
- Push shim **3** onto the wheel centering spigot
- Insert rear wheel into centering hole
- Hand-tighten wheel bolts **1** with taper rings **2**, then tighten to specified preload torque diagonally
- Tighten the wheel studs **1** crosswise to the tightening torque

Installing rear wheel

Maintenance and care



• Carefully place brake caliper **1** over the brake disk

A CAUTION

Ensure that retaining bracket **A** is positioned correctly.


• Tighten brake caliper bolts **2** with washers to the correct torque

ACAUTION

Always have the tightening torques checked by a BMWcertified workshop, preferably an authorized BMW motorcycle retailer.


Tightening torque:

Installing rear wheel



- Install rear wheel cover **3** with bolts **1** and **2**
- Attach the rear seat, engage it in position and check that it is firmly located

Once the brake calipers have been completely installed and the ignition has been switched on, and successful self-diagnosis has been performed, the foot brake and hand brake levers must be actuated. Maintenance and care



Front brake

A CAUTION

Have the brake pads replaced before the minimum permitted thickness is reached.

For your safety, we recommend having work on the brake system performed by a BMWcertified workshop, preferably an authorized BMW motorcycle retailer.

• Place the motorcycle on its main stand

- Conduct a visual inspection of both brake pads and the brake calipers to ensure that they all bear the same colored marking **2**
- Visually check brake pad thickness

Minimum pad thickness: Wear indicating mark 1 must be clearly visible on the brake pads.

 If the wear indicating mark is no longer clearly visible: have the brake pads changed by a BMW-certi-

fied workshop, preferably an authorized BMW motorcycle retailer.

Checking brake pads



Rear brake

ACAUTION

Have the brake pads replaced before the minimum permitted thickness is reached.


For your safety, we recommend having work on the brake system performed by a BMWcertified workshop, preferably an authorized BMW motorcycle retailer.

- Place the motorcycle on its main stand
- Remove system case
- Visually check brake pad thickness

Minimum pad thickness:Make sure that the brake disk is not visible through the bore 1 in the inner brake pad.

 If the brake disk is visible through the hole 1 in the inner brake shoe:

have the brake pads changed by a BMW-certified workshop, preferably an authorized BMW motorcycle retailer.



- Place motorcycle on main (center) stand
- Remove system case
- Take off complete two-section dualseat
- Remove bolt **9** and take off side section **8**
- Carefully pull off turn indicator/mirror housing and hold
- Turn the bulb holder counterclockwise to release it, and pull it out

A CAUTION

Watch different bolt lengths.

- Unscrew mounting bolts **1** to **7** and **10** to **19**
- Carefully remove entire side trim
- Assembly is performed in reverse order
- To ease installation of the turn indicator/mirror housing, grease the retaining clips lightly

A CAUTION

First press in turn indicator/mirror housing by striking gently. After installing, always check that it is firmly located.

The right-hand side trim should be removed in the same way.

Your motorcycle is equipped with Digital Motor Electronic (MOTRONIC) engine management and a high-power ignition system.

Work on the electrical system only when the circuit has been broken (switch off ignition and lights). For greater safety, disconnect and insulate the negative battery lead. When the engine is running or the ignition is switched on, do not touch electrically live components, terminals or wiring.

– Risk of fatal accident!


ACAUTION

Your motorcycle is equipped with one bulb for each of low beam headlamp, high beam headlamp, parking light, brake light and rear light, two bulbs for the fog lamp and four bulbs for the indicators.

Failure of any one of these bulbs can result in problems with visibility and being seen by others.

You should therefore always carry spare bulbs on the motorcycle.

Do not touch the glass of new bulbs with your bare fingers. Use a clean, dry cloth to hold the bulbs when inserting them. Dirt deposits, in particular oil and grease, interfere with heat radiation from the bulb. This leads to overheating and shortens the bulb's operating life.



Rear/brake light, rear turn indicators


▲ CAUTION

Switch off the ignition before changing a bulb.

The dimmed brake light takes over the function of the rear light should the rear light fail. A warning lamp lit in the cockpit indicates that this is the case. (Im Rider's Manual, Chapter 3). Do not touch the glass of new bulbs with your fingers. Use a clean, dry cloth to hold the bulbs when inserting them.

- Place motorcycle on main (center) stand
- Take off the rear seat
- Unscrew and remove the two knurled nuts **1**
- Take off the combined turn indicator/rear light assembly
- Turn holder **2** to the left to release it from its catch, and pull it out
- Press the bulb **3** in and it turn counter-clockwise to release it
- Assembly is performed in reverse order
- Top: Brake light 12 V 21 W
- Bottom: Rear light 12 V 10 W
- turn indicator bulbs 12 V 21 W

Maintenance and care



Front turn indicators

ACAUTION

Switch off the ignition before changing a bulb.

Do not touch the glass of new bulbs with your fingers. Use a clean, dry cloth to hold the bulbs when inserting them.


- Place the motorcycle on its main stand
- Carefully pull off mirror/indicator housing **3** and hold it
- Turn the bulb socket **1** counter-clockwise to release it from its catch and pull it out

- Press bulb **2** into socket and disengage by turning counter-clockwise.
- Remove the bulb
- Assembly is performed in reverse order
- To ease installation of the turn indicator/mirror housing, grease the retaining clips lightly

ACAUTION

First press in turn indicator/mirror housing at front by striking gently. After installing, always check that it is firmly located.

Front indicator bulbs: 2
 12 V 21 W



Parking light


▲ CAUTION

Switch off the ignition before changing a bulb.

Do not touch the glass of new bulbs with your fingers. Use a clean, dry cloth to hold the bulbs when inserting them.

- Place motorcycle on main (center) stand
- Pull bulb holder **1** downwards out of the headlight casing
- Remove bulb **2** by pressing it in and turning it counterclockwise at the same time
- Installation is the reverse of the removal procedure
- Parking light bulb 2:
 12 V 5 W






Low beam headlamp

▲ CAUTION

Switch off the ignition before changing a bulb.



Do not touch the glass of new bulbs with your fingers. Use a clean, dry cloth to hold the bulbs when inserting them.




- Place motorcycle on main (center) stand
- Turn the handlebars to the right
- Reach under the cockpit and push the clip **1** upwards (arrow)
- Remove the cover 2
- Remove the connector housing **6**

- Release the retaining clip **3** from its catch **4** by pushing down and squeezing together at the same time
- Remove the bulb 5
- Installation is the reverse of the removal procedure

Push the bulb base lug **7** into the recess **8**.

Dipped headlamp 5:
 H7 12 V 55 W

Maintenance and care



High beam headlamp:


High beam headlamp:
 H3 12 V 55 W

A CAUTION

Switch off the ignition before changing a bulb.

Do not touch the glass of new bulbs with your fingers. Use a clean, dry cloth to hold the bulbs when inserting them.

- Place the motorcycle on its main stand on a flat, firm surface
- Push the clip **1** upwards (arrow)
- Remove the cover 2
- Pull the plug-in cable **5** out from the socket housing **3**
- Push the grounding strap 9 downward
- Pull the bulb socket out of the headlight housing using the grab handle **12**



- Use a screwdriver to push in 1 retaining lug **6** on the left and one on the right and take apart the bulb socket
- Pull the H3 bulb out of the lamp ring **8**
- Installation is the reverse of the removal procedure
- High beam headlamp:
 H3 12 V 55 W

When installing, align the H1 bulb such that the slots **7** on the bulb socket slide into the guides in the lamp ring **8**.

When assembling the bulb socket, align the slot **10** on the lamp ring **8** such that it is pointing towards the bulb socket guide **11**.

Make sure the retaining lugs **6** engage.

When inserting the bulb socket into the headlamp, ensure that the grounding strap **9** engages in the two slots **4**.




Foglamp

▲ CAUTION

Switch off the ignition before changing a bulb.


Do not touch the glass of new bulbs with your fingers. Use a clean, dry cloth to hold the bulbs when inserting them.

- Place the motorcycle on its main stand on a flat, firm surface
- Remove the rubber cover 4
- Release the retaining clip **2** by pressing down and squeezing together at the same time
- Take out bulb 3
- Pull the plug-in cable **5** out from the socket housing **1**
- Fogllamp bulbs: H3 12 V 55 W



2 45

- Insert the new bulb 5, taking care to ensure that the slot 2 is pointing to the rear
- Click the retaining clip 4 into its catch 3
- Insert the plug-in cable **7** into the socket housing **1**
- Replace the rubber cover 6



A CAUTION

Before changing a fuse, switch off the ignition.


Never attempt to repair a blown fuse – risk of fire!

For this reason, always carry a number of spare fuses on the motorcycle.

Use only fuses of the specified rating and type.

Fuse assignment

- 1 Instrument cluster4 A
- 2 Parking light, ABS4 A
- 3 Power sockets, RID, radio, optional equipment plug, windshield adjustment ... 15 A
- 4 Horn......7.5 A
- **5** Motronic, RID, Motronic relay, diagnosis plug....10 A
- 6 Lambda probe, injector, fuel pump 10 A
- 7 Heated handles4 A
- 8 Low beam headlamp, instrument lighting......7.5 A9 High beam headlamp....7.5 A
- 10 Lighting relay, foglight 15 A
- **11** Radio4 A




Replacing fuses

- Place the motorcycle on its main stand
- Remove the dualseat
- Release and take off the cover of the central electrical equipment box
- Use the puller **12** supplied to pull the blown fuse out of its holder
- Insert a new fuse of the correct rating
- Close the lid of the central electrical equipment box
- Close and lock the seat

If the electrical system often displays faults, have it checked by a BMW-certified workshop, preferably by an authorized BMW motorcycle retailer.

Air filter





Replacing air filter element

- Place the motorcycle on its main stand
- · Remove the dualseat
- Disconnect air-temperature sensor plug connection **1**
- Unscrew two mounting bolts **3** from air filter cover **2**
- Remove the air filter cover **2** from the air filter housing

- Remove the old filter cartridge
 6 from the air filter housing
- Place the new filter element in position inside the air filter housing
- Installation is the reverse of the removal procedure

When installing, position the air filter cover as illustrated and the engage pins **4** in the tabs **5** on the air filter housing. Close the cover.

Gel batteries are maintenancefree. Compliance with the following instructions is important for achieving a long battery life:

ACAUTION

- Keep battery surface clean and dry
- Do not attempt to open battery
- Do not attempt to top up battery with water
- Use only electronically controlled battery chargers with a voltage limit of 14.4 V to charge battery.

Proper care, charging and storage will prolong the life of the battery and are essential for possible warranty claims.

WARNING

The motorcycle must not be jump-started using the power socket.

- Risk of fire!
- Push-start the motorcycle only when the engine is cold.

The load capacity of the wires leading to the power socket is not rated for jump-starting the engine.

▲ CAUTION

Do not attempt to jump-start the motorcycle if the battery is completely drained. Recharge the battery instead. Risk of damage to the control units.

Motorcycle out of use for extended periods

• The battery must be charged prior to storage periods of more than one month


A CAUTION

If the battery is not disconnected, the onboard electronics (clock etc.) will discharge the battery. This can cause the battery to become completely drained. In this case, warranty claims will not be accepted.

Disconnect the ground cable for from the battery prior to storage.

- Batteries that are not in use must be stored in a cool place. Do not shore a discharged battery
- If the battery is in storage for an extended period of time, recharge it approx. every 4 months. If the battery has not been disconnected from the motorcycle's systems, recharge it every 2 months at the latest
- Always fully recharge the battery before returning it to use

In case of doubt ask a specialist, preferably an authorized BMW motorcycle retailer, to prepare the vehicle for storage and to carry out the necessary battery maintenance and storage.



Removing battery

Avoid damage to fuel tank, wiring and hoses during removal work. Before disconnecting the battery, switch off the ignition.


To avoid short-circuits:

- First disconnect the negative battery lead (-),
- then the **positive** battery lead (+).

- Place the motorcycle on its main stand
- Remove the dualseat
- Remove the left-hand side trim (m+ 35)
- Remove the air filter cover (m+ 48)
- Remove the air intake pipe 1


Disconnecting the battery deletes all entries (e.g. faults, settings) stored in the Motronic control unit's memory. Loss of settings can temporarily impair the operating characteristics when the engine is restarted.

Battery



- Release the battery retaining clip **3**
- Disconnect the **negative** battery lead (-) **4**
- Pull out the battery to the left and hold it horizontally
- Open the protective cap on the battery positive pole **5** using a screwdriver
- Disconnect the **positive** battery lead (+) **6**
- Remove the battery

Battery



Installing battery

Before connecting the battery, switch off the ignition. To avoid short-circuits:


- Connect the positive battery lead (+) 3 first
- Close the protective cap 2 for the positive battery pole
- Never install the battery without the protective cap
- Connect the negative battery lead (-) 1

• Installation is the reverse of the removal procedure

Disconnecting the battery deletes all entries (e.g. faults, settings) stored in the Motronic control unit's memory. Loss of settings can temporarily impair the operating characteristics when the engine is restarted.

- Switch on the ignition
- Fully open the throttle once or twice
- The Motronic registers the throttle-valve positions

Cleaning/care



Regular cleaning using the correct methods is an important factor in maintaining the value of your motorcycle.


It also ensures that safety-relevant parts remain in full working order.

ACAUTION

Aggressive or deep-action cleaning products and solvents should not be used to clean rubber and plastic parts; they may cause damage.

Do not use a steam jet or highpressure cleaning equipment. High water pressure can damage seals, the hydraulic brake system or the complete electrical system.

Cleaning/care



Cleaning

- Place the motorcycle on its main stand
- Clean the wheels, engine, transmission and swinging arm with a mild detergent, following its manufacturer's instructions
- Thoroughly dry all wet surfaces
- Use only BMW care products to clean trim parts
- Do not use solvents or cleaning products to wash the instrument cluster, switches or the windshield Try not to scretch the wind-

Try not to scratch the windshield

- Remove tar splashes only with an approved cleansing agent – rinse the affected area thoroughly
- Clean dead flies and other insects or similar dirt deposits off the fork stanchions
- Treat painted and chromeplated surfaces regularly with the approved care products

After cleaning or before starting a journey, always test the brakes.

Cleaning/care





Removing road salt

• Wash the motorcycle down immediately with cold water at the end of the journey

Do not use warm water – this aggravates the effect of the salt

- Dry the motorcycle thoroughly
- Apply a wax-based corrosion inhibiting product to chromeplated parts
- After cleaning and drying the trim, apply a recommended wax polish

Cleaning the windshield

• Remove dirt and dead insects with a soft sponge and plenty of water

Soften stubborn dirt or insects by soaking with a wet paper towel.

Do not use cleaning agents. Fuel or chemical solvents attack the windshield material.



More ext

Touching up paint damage an author

• Use a BMW paint pen to repair minor damage to the paint work

▲ CAUTION

Comply with the manufacturer's working instructions and safety precautions.

More extensive c

More extensive damage should be attended to by a BMWcertified workshop, preferably an authorized BMW motorcycle retailer.

Care of muffler

• Use Autosol "Metal Polish" (BMW order no. 82 14 9 400 890) to touch up any (operational or environmental) discoloration of the exhaust system.

Storing



Storing

- Clean the motorcycle (m 54-57)
- Remove the battery (= 51-52)
- Spray the clutch lever pivots and the main and side stand pivots with a suitable lubricant
- Coat bright metal/chromeplated parts with an acid-free grease (e.g. Vaseline)
- Place the motorcycle on its main stand in a dry room
- Support it under the engine so that neither wheel is taking its weight

Before storing the vehicle have the engine oil and the oil filter element changed by a BMWcertified workshop, preferably your authorized BMW motorcycle retailer.

It is always a good idea to combine the preparations for storing and the post storage work with a Service check or Inspection by a BMW-certified workshop, preferably your authorized BMW motorcycle retailer.

Returning to use



59

Returning to use

- If necessary, remove protective wax coating
- Clean the motorcycle (m 54)
- Install a charged battery (m 53)
- Check/correct tire pressures (
 Rider's Manual, Chapter 2)
- Check the brakes (Im Rider's Manual, Chapter 2)
- Carry out safety checks (Im Rider's Manual, Chapter 2, 3)

	R 1150 RT	R 850 RT
Туре	,	ional oil-cooled en side camshaft oush rod-operated
Displacement	1,130 cm ³	848 cm ³
Maximum rated output in	accordance with	DIN 70 020
	70 kW	54 kW
- at engine speed	7,250 rpm	
Maximum torque	100 Nm	80 Nm
- at engine speed	5,500 rpm	
Permissible engine speed	ls	
Maximum speed	7,900 rpm	8,150 rpm
Idling speed	1,100 ^{±50} rpm	
Bore/stroke	3.98/2.78 in (101/70.5 mm)	3.44/2.78 in (87.5/70.5 mm)
Compression ratio	11.3 : 1	10.3 : 1
Fuel consumption as per	ISO 7118	
at a constant rate of approx. 56 mph (90 km/h)	50 mpg (4.7 l/100 km)	60 mpg (3.9 l/100 km)
at a constant rate of approx 75 mph (120 km/h)	42 mpg (5.6 l/100 km)	49 mpg (4.8 l/100 km)
Maximum oil consumption	2,350 mpg (1 l/1	,000 km)

	R 1150 RT R 850 RT	
Clutch	Lightweight single-plate dry clutch mounted on crankshaft, with increased-leverage diaphragm spring and starter gear ring.	
	Hydraulic actuation	
Clutch plate dia.	6.5 in (165 mm)	
Transmission	6-speed with claw shift and integral torsional vibration damper	
Gear ratios	1st gear = 3.863 2nd gear = 3.022 3rd gear = 2.393 4th gear = 1.961 5th gear = 1.700 6th gear (E) = 1.317	
Power transmission from transmission to rear wheel drive	By shaft protected within hollow swinging arm of Paralever rear sus- pension, with integral torsional vibration damper and two universal joints.	
Rear wheel drive	Crown wheel and pinion with Pal- loid teeth, running in anti-friction bearings; rear wheel directly flange- mounted to rear of crown wheel.	
Final drive ratio	1:2.91 1:3.2	

Frame and suspension

	R 1150 RT	R 850 RT
Frame	New, 3-part chas self-supporting el transmission unit rear frame made via a front frame n aluminum.	sis design. The ngine and is connected to a from steel tubing
Location of type plate and		
frame number	On right of front f	rame section
Front brake	hydraulically oper brake with 4-piston fixed cal drain adjustment less steel brake o	ipers, diagonal and floating stain-
	Sintered metal br Observe colored	•
Rear brake	Hydraulically actu with floating calip steel disk.	
	Sintered metal br	ake pads

Frame and suspension

	R 1150 RT	R 850 RT	
Wheel location			
Front		e wheel control a central spring	
Rear	swinging arm v torque arm for	compensating car- (Paralever) with cen-	
Steering lock angle of front wheel	2 x 34°		
Front wheel castor			
- in normal-load position	4.80 in (122 m	m)	

	R 1150 RT R 850 RT	
Front suspension	Central strut with linear-rate coil spring (with taper-wound ends) and twin-tube, gas-filled shock absorber.	
Spring compression	2.56 in (65 mm)	
Spring extension	2.17 in (55 mm)	
Total travel	4.72 in (120 mm)	
Fixed tube diameter	1.38 in (35 mm)	
Rear suspension	Central strut with coil spring and single-tube, gas-filled shock absorber. Continuously variable rebound damping setting.	
	Spring pre-load variable in 40 stages by means of hydraulic cylinder.	
Spring compression	4.13 in (105 mm)	
Spring extension	1.18 in (30 mm)	
Total travel (at wheel)	5.32 in (135 mm)	
Swinging arm length	19.92 in (506 mm)	

Frame and suspension


	R 1150 RT R 850 RT
Wheels and tires	BMW cast aluminum wheels with
	5 double spoke design,
	low cross-section tires
Front wheel	Angled rim shoulder and double tire - retaining hump
Size and designation	3.50 x 17 MT H2
Tire size and designation	120/70 ZR17
	TUBELESS
Rear wheel	Angled rim shoulder and double tire
	retaining hump
Size and designation	5.00 x 17 MT H2
Tire size and designation	170/60 ZR17
	TUBELESS
Tire pressure for cold tire	s
Solo Front	31.9 psi (2.20 bar)
Rear	36.3 psi (2.50 bar)
Rear passenger Front	36.3 psi (2.50 bar)
Rear	42.1 psi (2.90 bar)
Recommended minimum	tire tread depth
Front wheel	0.08 in (2 mm)
Rear wheel	0.12 in (3 mm)

Comply with legally specified minimum tread depth.

R 1150 RT R 850 RT

Engine oil

Brand-name HD oil of the API classification SF, SG or SH; CD or CE amendments are permissible; or brand-name HD oil of the CCMC classification G4 or G5; amendment PD2 is permissible.



The viscosity class depends on outside temperatures.

Temperatures above or below the limits quoted for the individual SAE classifications are permitted for brief periods only.

"Special Oils" are approved individually by BMW AG and available from your authorized BMW motorcycle retailer.

All engine oils supplied by BMW are subject to regular BMW quality assurance checks.

BMW does not approve the use of any upper-cylinder lubricants or similar oil additives.

Capacities, engine

- without filter replacement 3.7 quarts (3.50 l)

- if filter is renewed 4 quarts (3.75 l)





Lubricants and operating materials

	R 1150 RT	R 850 RT
Gear oil	Brand-name hy API class GL 5	
Capacity		
Transmission	approx. 0.85 qua (up to lower edg	arts (0.8 l) e of filler opening)
Rear wheel drive (after stripping down)	approx. 0.26 qu (up to lower edg	, ,
Viscosity class	EPV 00 altorna	The SAE OO AD
Viscosity class	EPX 90, alternatively SAE 90 API Super unleaded fuel as per DIN 51 607, minimum octane number 95 (RON) and 85 (MON) with cata- lytic converter, or selected super leaded fuels as per DIN 51 600, minimum octane number 95 (RON) and 85 (MON) for motorcycles with- out catalytic converter.	
Fuel type	Super unleade 51 607, minimu 95 (RON) and 8 lytic converter leaded fuels as minimum octan and 85 (MON) f	ed fuel as per DIN um octane number 85 (MON) with cata- r, or selected super per DIN 51 600, he number 95 (RON) or motorcycles with-

3

Lubricants and operating materials

	R 1150 RT R 850 RT
Bearing lubrication and lubricating points	Brand-name anti-friction bearing grease, usable temperature range - 13 °F to 284 °F (-25 °C+120 °C), drip point 374 °F (190 °C), high corrosion protection, good resistance to water and oxidation; e.g. Shell Retinax EP2
Brake fluid	DOT 4 We recommend BMW brake fluids
-	CAUTION Use only new brake fluid to DOT 4 specification.

R 1150 RT R 850 RT

Standard designation T 8/4

12 V 3 W

Spark plugs

Approved makes/types Primary spark plug Secondary spark plug	NGK BKR 7 EKC Bosch YR6LDE or NGK DCPR 8 EKC
Electrode gap	0.031 ^{+/-0.1} in (0.8 ^{+/-0.1} mm)
Wear limit	0.04 in (1.0 mm)
Fuses	"Minifuse" flat-socket fuses
Amperage ratings	4 A, 7.5 A, 10 A, 15 A
Headllamp	Halogen tandem headlight with foglamp
Bulbs	
Low beam headlamp	H7 halogen bulb 12 V 55 W
High beam headlamp:	H3 halogen bulb 12 V 55 W
Foglamp	H3 halogen bulb 12 V 55 W
Parking light	DIN 72 601 12 V 5 W Standard designation T 8/4
Brake light	DIN 72 601 12 V 21 W Standard designation P 25-1
Rear light	DIN 72 601 12 V 10 W Standard designation R 19/10
Flashing turn indicators	DIN 72 601 12 V 21 W Standard designation P 25-1
Turn indicator repeaters	DIN 72 601 12 V 4 W

Other indicator and warning DIN 72 601 lights, instrument lighting Standard designation W 10/3

Dimensions and weights

	R 1150 RT R 850 RT
Overall length	87.8 in (2,230 mm)
Width	
across mirrors	35.35 in (898 mm)
 over handlebar ends (with vibration dampers) 	30.43 in (773 mm)
across front footrests	23.5 in (597 mm)
across rear footrests	26.77 in (680 mm)
Overall height (excl. mirrors)	approx. 54.33 in (1,380 mm)
Seat height at curb weight	31.7/32.5/33.3 in (805/825/845 mm) 30.7/31.5/32.3 in (780/800/820 mm) ^{OE} 3x adjustable
Wheelbase	
- in normal-load position	58.46 in (1,485 mm)
Ground clearance	
- in normal-load position	6.02 in (153 mm)
Curb weight	
(ready to ride, tank full)	615 lbs (279 kg)
Dry weight	572 lb (259.5 kg)
Permissible total weight	1,091 bs (495 kg)
Permissible wheel loads	
Front	440.9 lbs (200 kg)
Rear	727.5 lbs (330 kg)

Performance data

B 850 BT

	RIIDURI	R ODU R I	
Top speed			
acc. to type approval test	124 mph (200 km	ı/h)	
Flexibility			3
4th gear 50-75 mph (80-120 km/h)	3.57 s	4.22 s	71
5th gear 50-75 mph (80-120 km/h)	4.49 s	5.27 s	Data
6th gear 50-75 mph (80-120 km/h)	6.78 s	8.39 s	Technical
Power-to weight ratio			CP
ready for road + rider (187 lbs/85 kg)	8.9 lbs/kW (4.05	kg/kW)	He
at total weight limit	15.9 lbs/kW (7 kg	/kW)	
Ride-past noise level			
to 97/24-9/EC	80 dB (A)		

B 1150 BT

A – E

A

Air filter, 48 Annual service, notes, 3

B

Battery Charging, 49 Installing, 53 Removing, 51 Warrantv. 49 Bore/stroke, 60 Brakes Brake fluid, 68 Minimum pad thickness, 32 Technical Data, 62 Wear indicating mark, 32 Bulbs Changing Foglamp, 44 High beam headlamp, 42 Low beam headlamp, 40 Parking light, 39 Rear/brake light, 37 Turn indicators, 37, 38 Notes, 36 Technical Data, 69

C

Capacity Engine, 66 Manual transmission, 67 Castor, 63 Cleaning plastic parts, 54 Cleaning, care Cleaning, 55 General instructions, 54, 56 Paint damage, 57 Road salt, 56 Clutch, 61 Compression ratio, 60 Confirmation of maintenance work Annual service, 11 Inspection, 4, 5, 6, 8, 9 Service, 4, 5, 6, 8, 9 Confirmation of odometer replacement, 14 Confirmation of service, 12, 13 Curb weight, 70

D

Dimensions, 70 Displacement, 60 Dry weight, 70

Е

Effect of road salt, 56 Electrical system, 69 Engine oil Capacity, 66 Consumption, 60 Technical Data, 66 Viscosity, 66 Engine speed limitations, 60 Engine, type, 60 Exhaust system, care products, 57

72

F

Flexibility, 71 Foglamp, 44 Frame, 62 Front wheel Installing, 23, 24, 25 Removing, 20, 21, 22 Technical Data, 65 Fuel Consumption, 60 Type, 67 Fuses Amperage ratings, 69 Assignment, 46

G

Gel battery, 49 General instructions, 15, 16 Ground clearance, 70

I

Idling speed, 60 Inspection Notes, 3 Installing brake caliper Front wheel, 24 Rear wheel, 30

L

Lubricants and operating materials, 66, 67, 68

Μ

Manual transmission Technical Data, 61 Maximum output, 60 Maximum speed, 60 Motorcycle Returning to use, 59 Storing, 58

0

Odometer replacement, confirmation, 14 Oil capacity Engine, 66 Manual transmission, 67

Ρ

Paralever, 63 Performance data, 71 Power-to weight ratio, 71 Pre-Delivery Check, 4

R

Rear wheel Installing, 29, 30, 31 Removing, 26, 27, 28 Technical Data, 65 Rear wheel drive Technical Data, 61 Removing brake caliper Rear wheel, 27 Removing mirror housing, 35 Removing rear-view mirror, 35 Removing turn indicator/mirror housing, 35, 38 Ride-past noise level, 71 Rims, 65

S – Z

S

Safety information, 2 Safety instructions Explanation, 78 Safety precautions, 15, 36 Seat height, 70 Service, notes, 3 Spark plugs, 69 Speedometer drive, 23 Spring travel, 64 Steam jet/high-pressure cleaning equipment, 54 Steering lock angle, 63 Storing, motorcycle, 58 Suspension, Technical Data, 64

Т

Technical Data, from page, 60 Telelever, 63 Tightening torques Brake caliper, 25, 30 Front wheel, 25 Rear wheel, 30 Tires, 65 Approved tire sizes, 65 Inflation pressure, 65 Technical Data, 65 Tread depth, 65 Top speed, 71 Torque, 60 Total weight, 70 Touching up paint damage, 57 Transmission Capacity, 67 Gear ratios, 61 Oil types, 67 Technical Data, 61 Tread depth, 65 Troubleshooting, 18 Troubleshooting chart, 18 Type plate, 62

W

Weights, 70 Wheel loads, 70 Wheel location, 63 Wheelbase, 70 Wheels, Technical Data, 65

Index 22

Motorcycle data		
Model	 	
Frame No.	 	
Color No.	 	
First registered on		
Registration No.		

Retailer data

Person to contact for Service work

Ms./Mr.

76

Tel. No.

Retailer's address with telephone No. (company stamp)

Details described or illustrated in this booklet may differ from the motorcycle's actual specification as purchased, the accessories fitted or the national-market specification. No claims will be considered as a result of such discrepancies.

Dimensions, weights, fuel consumption and performance data are quoted to the customary tolerances. The right to modify designs, equipment and accessories is reserved. Errors and omissions excepted. © 2004 BMW Motorrad Not to be reproduced either wholly or in part without written permission from BMW Motorrad, After Sales. Printed in Germany



BMW Motorrad Printed information

Order No.: 01 47 7 693 607 05.2004 4th edition US / RF



The Ultimate Driving Machine