



**BMW  
MOTORRAD**

# **RIDER'S MANUAL**

R 1250 RT



**MAKE LIFE A RIDE**

---

---

**Vehicle data**

Model

---

Vehicle Identification Number

---

Colour code

---

Date of first registration

---

Registration number

---

---

**Dealership details**

Person to contact in Service department

---

Ms/Mr

---

Phone number

---

Dealership address/phone number (company stamp)

---

# YOUR BMW.

We congratulate you on your choice of a vehicle from BMW Motorrad and welcome you to the community of BMW riders. Familiarise yourself with your new vehicle so that you can ride it safely and confidently in all traffic situations.

## **About this rider's manual**

Read this rider's manual carefully before starting your new BMW. It contains important information on how to operate the controls and how to make the best possible use of all your BMW's technical features.

In addition, it contains information on maintenance and care to help you maintain your vehicle's reliability and safety, as well as its value.

If the time comes to sell your BMW, please remember to hand over this rider's manual to the new owner. It is an important part of the vehicle.

We hope you will enjoy riding your BMW and that all your journeys will be pleasant and safe

BMW Motorrad.

|                                     |           |                                    |           |
|-------------------------------------|-----------|------------------------------------|-----------|
| <b>01 GENERAL INSTRUCTIONS</b>      | <b>2</b>  | <b>03 STATUS INDICATORS</b>        | <b>26</b> |
| Quick & easy reference              | 4         | Indicator and warning lights       | 28        |
| Abbreviations and symbols           | 4         | Menu view                          | 29        |
| Equipment                           | 5         | Pure Ride view                     | 30        |
| Technical data                      | 5         | My Vehicle view                    | 33        |
| Currency                            | 6         | Warning indicators                 | 35        |
| Additional sources of information   | 6         |                                    |           |
| Certificates and operating licences | 6         | <b>04 INSTRUMENT CLUSTER</b>       | <b>70</b> |
| Data memory                         | 6         | Warnings                           | 72        |
| Intelligent emergency call system   | 11        | Controls                           | 72        |
| Bluetooth®                          | 14        | My vehicle                         | 73        |
| Connectivity functions              | 15        | Operation                          | 74        |
|                                     |           | Settings                           | 76        |
|                                     |           | Bluetooth                          | 77        |
|                                     |           | Splitscreen                        | 79        |
|                                     |           | Navigation                         | 79        |
|                                     |           | Media                              | 82        |
|                                     |           | Telephone                          | 83        |
|                                     |           | Software version                   | 84        |
|                                     |           | Licence information                | 84        |
| <b>02 GENERAL VIEWS</b>             | <b>16</b> |                                    |           |
| General view, left side             | 18        | <b>05 OPERATION</b>                | <b>86</b> |
| General view, right side            | 19        | Ignition switch/steering lock      | 88        |
| Overall view of cockpit             | 20        | Ignition with Keyless Ride         | 89        |
| Under the rider's seat              | 21        | Emergency-off switch (kill switch) | 94        |
| Multifunction switch, left          | 22        | Intelligent emergency call         | 94        |
| Multifunction switch, right         | 23        | Lighting                           | 97        |
| Multifunction switch, right         | 24        |                                    |           |
| Instrument cluster                  | 25        |                                    |           |

|                                              |            |                                              |            |
|----------------------------------------------|------------|----------------------------------------------|------------|
| Dynamic Traction Control (DTC)               | 100        | Seats                                        | 148        |
| Electronic Suspension Adjustment (D-ESA)     | 101        | Spring preload                               | 150        |
| Riding mode                                  | 102        | Damping                                      | 151        |
| Cruise control                               | 103        |                                              |            |
| Distance control (Active Cruise Control ACC) | 106        | <b>08 RIDING</b>                             | <b>154</b> |
| Hill Start Control (HSC)                     | 112        | Safety information                           | 156        |
| Anti-theft alarm (DWA)                       | 115        | Regular check                                | 159        |
| Heating                                      | 118        | Starting                                     | 159        |
| Storage compartment                          | 121        | Running in                                   | 160        |
| Favourites buttons                           | 124        | Shifting gear                                | 161        |
| Central locking system                       | 125        | Brakes                                       | 162        |
| Cases                                        | 129        | Parking your motorcycle                      | 165        |
|                                              |            | Refuelling                                   | 166        |
|                                              |            | Securing motorcycle for transportation       | 171        |
| <b>06 AUDIO SYSTEM</b>                       | <b>132</b> |                                              |            |
| Radio                                        | 134        | <b>09 ENGINEERING DETAILS</b>                | <b>174</b> |
| Audio settings                               | 136        | General notes                                | 176        |
| Player                                       | 138        | Antilock Brake System (ABS)                  | 176        |
| Satellite radio                              | 138        | Dynamic Traction Control (DTC)               | 180        |
| HD Radio reception                           | 140        | Dynamic engine brake control                 | 181        |
| In-helmet audio playback                     | 141        | Distance control (Active Cruise Control ACC) | 182        |
|                                              |            | Electronic Suspension Adjustment (D-ESA)     | 185        |
| <b>07 ADJUSTMENT</b>                         | <b>142</b> | Riding mode                                  | 186        |
| Mirrors                                      | 144        | Dynamic Brake Control                        | 188        |
| Headlight                                    | 144        |                                              |            |
| Windscreen                                   | 144        |                                              |            |
| Clutch                                       | 145        |                                              |            |
| Brakes                                       | 147        |                                              |            |

|                             |     |
|-----------------------------|-----|
| Tyre pressure control (RDC) | 189 |
| Gear Shift Assistant        | 190 |
| Hill Start Control (HSC)    | 191 |
| ShiftCam                    | 193 |
| Adaptive headlight          | 193 |

---

## **10 MAINTENANCE** 196

|                      |     |
|----------------------|-----|
| General notes        | 198 |
| Toolkit              | 199 |
| Spring-strut cover   | 199 |
| Front-wheel stand    | 200 |
| Engine oil           | 200 |
| Brake system         | 202 |
| Clutch               | 207 |
| Coolant              | 207 |
| Tyres                | 209 |
| Wheel rims           | 210 |
| Wheels               | 210 |
| Silencer             | 218 |
| Lighting             | 221 |
| Jump-starting        | 221 |
| Battery              | 223 |
| Fuses                | 227 |
| Diagnostic connector | 229 |

---

## **11 ACCESSORIES** 232

|                      |     |
|----------------------|-----|
| General notes        | 234 |
| Power sockets        | 234 |
| Topcase              | 235 |
| Optional accessories | 238 |

---

## **12 CARE** 240

|                                    |     |
|------------------------------------|-----|
| Care products                      | 242 |
| Washing the vehicle                | 242 |
| Cleaning easily damaged components | 243 |
| Care of paintwork                  | 245 |
| Paint preservation                 | 245 |
| Laying up motorcycle               | 245 |
| Restoring motorcycle to use        | 246 |

---

## **13 TECHNICAL DATA** 248

|                              |     |
|------------------------------|-----|
| Troubleshooting chart        | 250 |
| Threaded fasteners           | 254 |
| Fuel                         | 256 |
| Engine oil                   | 257 |
| Engine                       | 257 |
| Clutch                       | 258 |
| Transmission                 | 258 |
| Final drive                  | 258 |
| Frame                        | 258 |
| Chassis and suspension       | 258 |
| Brakes                       | 259 |
| Wheels and tyres             | 259 |
| Electrical system            | 260 |
| Dimensions                   | 261 |
| Weights                      | 262 |
| Performance figures          | 262 |
| Radio                        | 262 |
| Speakers (vehicle-dependent) | 263 |

|                                          |            |                                            |            |
|------------------------------------------|------------|--------------------------------------------|------------|
| <b>14 SERVICE</b>                        | <b>264</b> | <b>Certification</b>                       |            |
| Reporting safety-relevant defects        | 266        | Tire Pressure Control                      | 306        |
| Recycling                                | 267        | Radio equipment audio system               | 306        |
| BMW Motorrad Service                     | 267        | Radio equipment intelligent emergency call | 307        |
| BMW Motorrad service history             | 268        |                                            |            |
| BMW Motorrad mobility services           | 269        | <b>INDEX</b>                               | <b>308</b> |
| Maintenance work                         | 269        |                                            |            |
| Maintenance schedule                     | 271        |                                            |            |
| BMW Motorrad running-in check            | 272        |                                            |            |
| Maintenance confirmations                | 273        |                                            |            |
| Service confirmations                    | 285        |                                            |            |
| <b>APPENDIX</b>                          | <b>288</b> |                                            |            |
| Declaration of Conformity                | 289        |                                            |            |
| Battery directive                        | 292        |                                            |            |
| Mid Range Radar                          | 294        |                                            |            |
| Radio equipment Wireless charging device | 297        |                                            |            |
| Radio equipment TFT instrument cluster   | 297        |                                            |            |
| Radio equipment electronic immobiliser   | 299        |                                            |            |
| Keyless Ride Key                         | 302        |                                            |            |
| Keyless Ride ECU                         | 304        |                                            |            |

# **GENERAL INSTRUCTIONS**

**01**

---

|                                            |           |
|--------------------------------------------|-----------|
| <b>QUICK &amp; EASY REFERENCE</b>          | <b>4</b>  |
| <b>ABBREVIATIONS AND SYMBOLS</b>           | <b>4</b>  |
| <b>EQUIPMENT</b>                           | <b>5</b>  |
| <b>TECHNICAL DATA</b>                      | <b>5</b>  |
| <b>CURRENCY</b>                            | <b>6</b>  |
| <b>ADDITIONAL SOURCES OF INFORMATION</b>   | <b>6</b>  |
| <b>CERTIFICATES AND OPERATING LICENCES</b> | <b>6</b>  |
| <b>DATA MEMORY</b>                         | <b>6</b>  |
| <b>INTELLIGENT EMERGENCY CALL SYSTEM</b>   | <b>11</b> |
| <b>BLUETOOTH®</b>                          | <b>14</b> |
| <b>CONNECTIVITY FUNCTIONS</b>              | <b>15</b> |

## 4 GENERAL INSTRUCTIONS

### QUICK & EASY REFERENCE

An important aspect of this rider's manual is that it can be used for quick and easy reference. Consulting the extensive index at the end of this rider's manual is the fastest way to find information on a particular topic or item. To first read an overview of your vehicle, please go to Chapter 2. All maintenance and servicing work on the vehicle is documented in the "Service" section. The record of the maintenance work you have had performed on your vehicle is a precondition for generous treatment of goodwill claims.

### ABBREVIATIONS AND SYMBOLS

 **CAUTION** Low-risk hazard. Non-avoidance can lead to slight or moderate injury.

 **WARNING** Medium-risk hazard. Non-avoidance can lead to fatal or severe injury.

 **DANGER** High-risk hazard. Non-avoidance leads to fatal or severe injury.

 **ATTENTION** Special notes and precautionary measures. Non-compliance can lead to damage to the vehicle or accessory and, consequently, to voiding of the warranty.

 Specific instructions on how to operate, control, adjust or look after items of equipment on the motorcycle.

- Instruction.
- » Result of an activity.
- ▮▮▮▮▮ Reference to a page with more detailed information.
- ◁ Indicates the end of a passage relating to specific accessories or items of equipment.



Tightening torque.



Technical data.

NV

National-market version.

|       |                                                                                                                                                                                 |
|-------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| OE    | Optional equipment. The vehicles are assembled complete with all the BMW Motorrad optional equipment originally ordered.                                                        |
| OA    | Optional accessories. You can obtain BMW Motorrad optional accessories through your authorised BMW Motorrad dealer; optional accessories have to be retrofitted to the vehicle. |
| ABS   | Anti-lock brake system.                                                                                                                                                         |
| ACC   | Active Cruise Control (distance control).                                                                                                                                       |
| ASC   | Automatic Stability Control.                                                                                                                                                    |
| D-ESA | Electronic Suspension Adjustment.                                                                                                                                               |
| DTC   | Dynamic Traction Control.                                                                                                                                                       |
| DWA   | Anti-theft alarm.                                                                                                                                                               |
| EWS   | Electronic immobiliser.                                                                                                                                                         |
| RDC   | Tyre pressure monitoring.                                                                                                                                                       |

---

## EQUIPMENT

When you ordered your BMW Motorrad, you chose various items of custom equipment. This rider's manual describes optional equipment (OE) and selected optional accessories (OA) provided by BMW. This explains why the manual may also contain descriptions of equipment that you might not have selected. Please note, too, that on account of country-specific differences, your motorcycle might not be exactly as illustrated.

If your motorcycle contains equipment that has not been described, its description can be found in a separate manual.

---

## TECHNICAL DATA

All dimensions, weights and power ratings stated in the rider's manual are quoted to the standards and comply with the tolerance requirements of the Deutsches Institut für Normung e. V. (DIN).

Technical data and specifications in this rider's manual are guide values. The vehicle-specific data may deviate from these, for example as a result

## 6 GENERAL INSTRUCTIONS

of selected optional equipment, the national-market version or country-specific measuring procedures. Detailed values can be taken from the vehicle registration documents, or can be obtained from your authorised BMW Motorrad retailer or another qualified service partner or specialist workshop. The specifications in the vehicle documents always have priority over the information provided in this rider's manual.

---

### CURRENCY

The high safety and quality standards of BMW motorcycles are maintained by constant development work on designs, equipment and accessories. Because of this, your vehicle may differ from the information supplied in the rider's manual. Nor can BMW Motorrad entirely rule out errors and omissions. We hope you will appreciate that no claims can be entertained on the basis of the data, illustrations or descriptions in these operating instructions.

---

### ADDITIONAL SOURCES OF INFORMATION

#### Authorised BMW Motorrad retailer

Your authorised BMW Motorrad retailer will be happy to answer any questions you may have.

#### Internet

The rider's manual for your vehicle, operating and installation instructions for accessories and general information about BMW Motorrad, in relation to technology, for example, are available for download from **[bmw-motorrad.com/manuals](http://bmw-motorrad.com/manuals)**.

---

### CERTIFICATES AND OPERATING LICENCES

The certificates for the vehicle and the official operating licences for accessories can be downloaded from **[bmw-motorrad.com/certification](http://bmw-motorrad.com/certification)**.

---

### DATA MEMORY

#### General

Control units are installed in the vehicle. Control units process data that they receive, for example, from vehicle sensors, or that they generate themselves or exchange between

each other. Some control units are required for the vehicle to function safely or provide assistance during riding, for example assistance systems. In addition, control units enable comfort or infotainment functions.

Information on data that has been stored or exchanged can be obtained from the manufacturer of the vehicle, for example via a separate booklet.

### **Personal reference**

Each vehicle is identified with a clear vehicle identification number. Depending on the country, the vehicle identification number, the number plate and the corresponding authorities can be referenced to ascertain the vehicle owner. There are also other ways to use data obtained from the vehicle to trace the rider or vehicle owner, for example using the Connected-Drive user account.

### **Data protection rights**

In accordance with applicable data protection laws, vehicle users have certain rights in relation to the manufacturer of the vehicle or in relation to companies which collect or process personal data.

Vehicle users have the right to obtain full information at no cost from persons or entities storing personal data of the vehicle user.

These entities may include:

- Manufacturer of the vehicle
- Qualified service partners
- Specialist workshops
- Service providers

Vehicle users have the right to request information on what personal data has been stored, for what purpose the data is used, and where the data comes from. To obtain this information, proof of ownership or use is required.

The right to information also includes information about data that has been shared with other companies or entities. The website of the vehicle manufacturer contains the applicable data protection information. This data protection information includes information on the right to have data deleted or corrected. The manufacturer of the vehicle also provides their contact details and those of the data protection officer on their website.

The vehicle owner can also request that a BMW Motorrad

## 8 GENERAL INSTRUCTIONS

retailer or another qualified service partner or specialist workshop read out the data that is stored in the vehicle for a charge.

The vehicle data is read out using the legally prescribed socket for on-board diagnosis (OBD) in the vehicle.

### **Legal requirements for the disclosure of data**

As part of its legal responsibilities, the manufacturer of the vehicle is obligated to make its stored data available to the relevant authorities. This data is provided in the required scope in individual cases, for example to clarify a criminal offence. In the context of applicable laws, public agencies are entitled in individual cases to read out data from the vehicle themselves.

### **Operating data in the vehicle**

Control units process data to operate the vehicle.

This includes, for example:

- Status reports of the vehicle and its individual components, for example wheel revolutions, wheel speed, deceleration
- Environmental conditions, for example temperature

The data is only processed in the vehicle itself and is generally non-permanent. The data is not stored beyond the operating period.

Electronic components, for example control units, contain components for storing technical information. Information can be temporarily or permanently stored on the vehicle condition, component loads, incidents or errors.

This information is generally used to document the condition of a component, a module, a system or the surrounding area, for example:

- Operating conditions of system components, for example filling levels, tyre pressure
- Malfunctions and faults in important system components, for example light and brakes
- Response of the vehicle in special riding situations, for example engagement of the driving dynamics systems
- Information on incidents resulting in damage to the vehicle

The data is necessary for the provision of control unit functions. Furthermore, the data is used to detect and rectify malfunctions and to enable the

vehicle manufacturer to optimise vehicle functions.

The vast majority of this data is non-permanent and is only processed in the vehicle itself. Only a small amount of the data is stored in incident or fault memories as required by events.

If services are accessed, for example repairs, service processes, warranty cases and quality assurance measures, this technical information can be read out of the vehicle together with the vehicle identification number.

The information can be read out by a BMW Motorrad retailer or another qualified service partner or specialist workshop. The legally stipulated socket for on-board diagnosis (OBD) in the vehicle is used to read out the data.

The data is obtained, processed and used by the relevant parts of the retailer network. The data is used to document the technical conditions of the vehicle, to help with error localization, to comply with warranty obligations and to improve quality.

In addition, the manufacturer has various product monitoring obligations arising from product liability legislation. To meet these obligations, the vehicle manufacturer requires technical data from the vehicle. The data from the vehicle can also be used to check warranty claims from the customer. Error and incident memories in the vehicle can be reset during servicing or repair work by a BMW Motorrad retailer or another qualified service partner or specialist workshop.

## **Data input and data transfer in the vehicle**

### **General**

Depending on the equipment, comfort and customised settings can be stored in the vehicle and can be changed or reset at any time.

This includes, for example:

- Settings of the windscreen position
- Chassis and suspension settings

If required, data can be entered in the entertainment and communication system of the vehicle, for example using a smartphone.

## 10 GENERAL INSTRUCTIONS

Depending on the individual equipment, this includes:

- Multimedia data, such as music for playback
- Contacts data for use in connection with a communication system or an integrated navigation system
- Entered destinations
- Data on the use of internet services. This data can be stored locally in the vehicle or is located on a device that is connected to the vehicle, for example smartphone, USB stick, MP3 player. If this data is stored in the vehicle, the data can be deleted at any time.

This data is transferred to third parties only if personally requested within the context of using online services. This depends on the selected settings when using the services.

### **Incorporation of mobile devices**

Depending on the equipment, mobile devices connected to the vehicle, for example smartphones, can be controlled using the operating elements of the vehicle.

The image and sound of the mobile device can then be out-

put via the multimedia system. At the same time, specific information is transferred to the mobile device. Depending on the type of integration, this includes, for example, position data and additional general vehicle information. This enables optimal use of the selected apps, for example navigation or music playback.

The type of additional data processing is determined by the provider of the respective app. The scope of the possible settings depends on the corresponding app and the operating system of the mobile device.

### **Services**

#### **General**

If the vehicle has a wireless connection, this enables the exchange of data between the vehicle and other systems. The wireless connection is enabled by the vehicle's own transceiver unit or using personally integrated mobile devices, for example smartphones. Online functions can be accessed through this wireless connection. These include online services and apps that are provided by the

vehicle manufacturer or by other providers.

### **Services of the vehicle manufacturer**

For online services of the vehicle manufacturer, the individual functions are described at suitable points, for example rider's manual, website of the manufacturer. At the same time, information is also provided on the relevant data protection law. Personal data may be used to provide online services. Data is exchanged using a secure connection, for example with the IT systems provided by the vehicle manufacturer.

Obtaining, processing and using personal data outside of the normal provision of services requires legal permission, contractual agreement or consent. It is also possible to have the entire data connection activated or deactivated. Statutory functions are excluded from this.

### **Services from other providers**

When using online services from other providers, these services are subject to the responsibility and the data protection and operating con-

ditions of the individual provider. The vehicle manufacturer has no influence on the content that is exchanged in this instance. Information on the type, scope and purpose of the data capture and use of personal data as part of the services of third parties can be ascertained from the individual provider.

---

## **INTELLIGENT EMERGENCY CALL SYSTEM**

—with intelligent emergency call<sup>OE</sup>

### **Principle**

The intelligent emergency call system enables manual or automatic emergency calls, for example in the event of an accident.

The emergency calls are received by an emergency call centre that is commissioned by the vehicle manufacturer.

For information on operating the intelligent emergency call system and its functions see (▮▮▮▮ 94).

## 12 GENERAL INSTRUCTIONS

### Legal basis

Processing of personal data using the intelligent emergency call system is in line with the following regulations:

–Protection of personal data:

Directive 95/46/EC of the European Parliament and of the Council.

–Protection of personal data:

Directive 2002/58/EC of the European Parliament and of the Council.

The legal basis for the activation and function of the intelligent emergency call system is the concluded Connected-Ride contract for this function, as well as the corresponding laws, ordinances and directives of the European Parliament and of the European Council.

The relevant ordinances and directives regulate the protection of natural persons during the processing of personal data.

The processing of personal data by the intelligent emergency call system satisfies the European directives for the protection of personal data.

The intelligent emergency call system processes personal data

only with the agreement of the vehicle owner.

The intelligent emergency call system and other services with additional benefits can process personal data only with the express permission of the person affected by the data processing, for example the vehicle owner.

### SIM card

The intelligent emergency call system operates via the mobile phone network using the SIM card installed in the vehicle.

The SIM card is permanently logged into the mobile phone network to enable rapid connection setup. Data is sent to the vehicle manufacturer in the event of an emergency.

### Improving quality

The data that is transferred in an emergency is also used by the manufacturer of the vehicle to improve product and service quality.

### Location determination

The position of the vehicle can be determined exclusively by the mobile phone network provider based on the mobile phone site locations. It is not possible for the provider to

trace a connection between the vehicle's VIN and the phone number of the installed SIM card. Only the manufacturer of the vehicle can link a VIN and the phone number of the SIM card installed in a particular vehicle.

### **Log data of emergency calls**

The log data of emergency calls is stored in a memory of the vehicle. The oldest log data is regularly deleted. The log data includes, for example, information on when and where an emergency call was made. In exceptional cases, the log data can be read out of the vehicle memory. As a rule, log data is only read out following a court order, and this is only possible if the corresponding devices are connected directly to the vehicle.

### **Automatic emergency call**

The system is designed so that, following a sufficiently serious accident, which is detected by sensors in the vehicle, an emergency call is automatically activated.

### **Sent information**

When making an emergency call using the intelligent emergency call system, the system forwards the same information to the designated emergency call centre as is forwarded to the public emergency operations centre by the statutory emergency call system eCall. In addition, the intelligent emergency call system sends the following additional information to an emergency call centre commissioned by the vehicle manufacturer and, if required, to the emergency services:

- Accident data, for example the direction of impact detected by the vehicle sensors, to assist the emergency services response.
- Contact details, for example the phone number of the installed SIM card and the phone number of the rider, if available, to enable rapid contact with those involved in the accident if required.

### **Data storage**

The data for an activated emergency call is stored in the vehicle. The data contains information on the emergency

## 14 GENERAL INSTRUCTIONS

call, for example the location and time of the emergency call.

The voice recordings of the emergency call are stored at the emergency call centre.

The voice recordings of the customer are stored for 24 hours in case details of the emergency call need to be analysed. After this, the voice recordings are deleted. The voice recordings of the employee of the emergency call centre are stored for 24 hours for quality assurance purposes.

### **Information on personal data**

The data that is processed as part of the intelligent emergency call is processed exclusively to carry out the emergency call. As part of its statutory obligation, the manufacturer of the vehicle provides information about the data that it has processed and any data that it still has stored.

### **Regional restriction**

A precondition for the operability of the intelligent emergency call function is that the national-market version has to include support for the region where the vehicle is currently in use.

More information about regional restrictions:

**[support.bmw-motorrad.com](https://support.bmw-motorrad.com)**

---

### **BLUETOOTH®**

Bluetooth is a short-range wireless technology. Bluetooth devices are short-range devices transmitting on the license-free ISM band (Industrial, Scientific, Medical) between 2.402...2.480 GHz. They can be operated anywhere in the world without a licence being required.

Although Bluetooth is designed to establish and sustain robust connections over short distances, as with every other wireless technology disruptions are possible. Interference can affect connections or connections can sometimes fail. Particularly when multiple devices operate in a Bluetooth network, with wireless technology of this nature it is not possible to ensure fault-free communications in every situation.

### **Possible sources of interference:**

–interference zones due to transmission masts and similar.

- devices with non-compliant Bluetooth implementations.
- proximity of other Bluetooth-compatible devices.
- shielding by metal objects or bodies.

## CONNECTIVITY FUNCTIONS

Connectivity functions include media, telephony and navigation. Connectivity functions can be used when the instrument cluster is connected to a mobile device and a helmet (III 77). For more information on the Connectivity functions go to:

**[bmw-motorrad.com/connectivity](http://bmw-motorrad.com/connectivity)**

 Depending on the mobile end device, the scope of Connectivity functions might be restricted.

### BMW Motorrad Connected app

The BMW Motorrad Connected app enables the user to call up usage data and vehicle status information. For some functions such as navigation, for example, the app has to be installed on the mobile device and paired to the instrument cluster. The app is used to

start route guidance and adjust the navigation.

 On some mobile devices, e.g. those with the iOS operating system, the BMW Motorrad Connected app has to be opened prior to use.

# GENERAL VIEWS


02

---

|                                    |           |
|------------------------------------|-----------|
| <b>GENERAL VIEW, LEFT SIDE</b>     | <b>18</b> |
| <b>GENERAL VIEW, RIGHT SIDE</b>    | <b>19</b> |
| <b>OVERALL VIEW OF COCKPIT</b>     | <b>20</b> |
| <b>UNDER THE RIDER'S SEAT</b>      | <b>21</b> |
| <b>MULTIFUNCTION SWITCH, LEFT</b>  | <b>22</b> |
| <b>MULTIFUNCTION SWITCH, RIGHT</b> | <b>23</b> |
| <b>MULTIFUNCTION SWITCH, RIGHT</b> | <b>24</b> |
| <b>INSTRUMENT CLUSTER</b>          | <b>25</b> |


# 18 GENERAL VIEWS

## GENERAL VIEW, LEFT SIDE



- 1** Clutch-fluid reservoir  
( 207)
- 2** Seat lock ( 148)
- 3** Passenger seat heating  
( 120)
- 4** Passenger grab handle
- 5** Passenger-seat socket for accessories ( 234)
- 6** Rear footrest
- 7** Rider footrest
- 8** Payload table (on left fork leg)  
Tyre pressures table (on left fork leg)

---


**GENERAL VIEW, RIGHT SIDE**

- |                                                                                                                      |                                                                                                                                 |
|----------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Brake-fluid reservoir, front<br>(➡ 205)                                                                     | <b>5</b> Behind the battery cover:<br>Battery (➡ 223)<br>Remote positive terminal<br>(➡ 221)<br>Diagnostic connector<br>(➡ 229) |
| <b>2</b> Vehicle identification<br>number (on steering-head<br>bearing)<br>Type plate (on steering-<br>head bearing) |                                                                                                                                 |
| <b>3</b> Coolant level indicator<br>(behind side panel)<br>(➡ 207)                                                   | <b>6</b> Brake-fluid reservoir, rear<br>(behind spring-strut cover)<br>(➡ 206)                                                  |
| <b>4</b> Oil filler opening<br>(➡ 200)                                                                               |                                                                                                                                 |

## 20 GENERAL VIEWS


### OVERALL VIEW OF COCKPIT

---



- 1** Favourites buttons (➡ 124)
- 2** Storage compartment, left (➡ 121)
- 3** Ignition switch/steering lock (➡ 88)
- 4** Storage compartment, right (➡ 121)
- 5** Power socket (➡ 234)
- 6** Fuel filler neck (➡ 167)

## UNDER THE RIDER'S SEAT



- 1 Fuses (➡ 227)
- 2 Toolkit (➡ 199)
- 3 Tool for adjusting spring preload (➡ 151)
- 4 Adjustment of rider's seat height (➡ 148)

## 22 GENERAL VIEWS


### MULTIFUNCTION SWITCH, LEFT



- |                                                           |                                                                |
|-----------------------------------------------------------|----------------------------------------------------------------|
| <b>1</b> High-beam headlight and headlight flasher (➡ 97) | <b>10</b> Distance control (Active Cruise Control ACC) (➡ 110) |
| <b>2</b> Cruise control (➡ 103)                           |                                                                |
| <b>3</b> Hazard warning lights (➡ 100)                    |                                                                |
| <b>4</b> Windscreen adjustment mechanism (➡ 144)          |                                                                |
| <b>5</b> Auxiliary headlights (➡ 98)                      |                                                                |
| <b>6</b> Turn indicators (➡ 100)                          |                                                                |
| <b>7</b> Horn                                             |                                                                |
| <b>8</b> MENU rocker button (➡ 73)                        |                                                                |
| <b>9</b> Multi-Controller (➡ 72)                          |                                                                |

## MULTIFUNCTION SWITCH, RIGHT

—with intelligent emergency call<sup>OE</sup>



- 1** Central locking system  
( 125)
- 2** Riding mode ( 102)
- 3** Emergency-off switch (kill switch) ( 94)
- 4** Starter button ( 159)
- 5** SOS button  
Intelligent emergency call  
( 94)

## 24 GENERAL VIEWS


### MULTIFUNCTION SWITCH, RIGHT

—without intelligent emergency call<sup>OE</sup>



- 1** Central locking system  
( 125)
- 2** Riding mode ( 102)
- 3** Emergency-off switch (kill switch) ( 94)
- 4** Starter button ( 159)

## INSTRUMENT CLUSTER



- 1 Indicator and warning lights (➡ 28)
- 2 Display (➡ 30)
- 3 Indicator light DWA (➡ 116)  
Keyless Ride (➡ 89)
- 4 Photosensor (for adapting the brightness of the instrument lighting)

# STATUS INDICATORS


03

---

|                                     |           |
|-------------------------------------|-----------|
| <b>INDICATOR AND WARNING LIGHTS</b> | <b>28</b> |
| <b>MENU VIEW</b>                    | <b>29</b> |
| <b>PURE RIDE VIEW</b>               | <b>30</b> |
| <b>MY VEHICLE VIEW</b>              | <b>33</b> |
| <b>WARNING INDICATORS</b>           | <b>35</b> |

## 28 STATUS INDICATORS

### INDICATOR AND WARNING LIGHTS



- 1 Turn indicators, left (➡ 100)
- 2 High-beam headlight (➡ 97)
- 3 General warning light (➡ 35)
- 4 Turn indicators, right (➡ 100)
- 5 Warning light, drive malfunction (➡ 51)
- 6 DTC (➡ 61)
- 7 ABS (➡ 60)
- 8 Automatic daytime riding light (➡ 99)
- 9 Auxiliary headlights (➡ 98)

## MENU VIEW




- |                                                                     |                                                    |
|---------------------------------------------------------------------|----------------------------------------------------|
| <b>1</b> Hill Start Control<br>(➡ 112)                              | <b>12</b> Central locking system<br>(➡ 125)        |
| <b>2</b> Speedometer                                                | <b>13</b> Muting (➡ 76)                            |
| <b>3</b> Cruise control (➡ 103)                                     | <b>14</b> Heating (➡ 118)                          |
| <b>4</b> Distance control ACC<br>(Active Cruise Control)<br>(➡ 110) | <b>15</b> Automatic daytime riding<br>light (➡ 99) |
| <b>5</b> Rider info. status line<br>(➡ 75)                          | <b>16</b> Outside temperature<br>warning (➡ 44)    |
| <b>6</b> Riding mode (➡ 102)                                        | <b>17</b> Ambient temperature                      |
| <b>7</b> Gear indicator                                             | <b>18</b> Menu section                             |
| <b>8</b> Splitscreen (➡ 79)                                         |                                                    |
| <b>9</b> Clock (➡ 76)                                               |                                                    |
| <b>10</b> Connection status<br>(➡ 77)                               |                                                    |
| <b>11</b> Operating pointer                                         |                                                    |

## 30 STATUS INDICATORS

### PURE RIDE VIEW

#### START SCREEN



- |                                                        |                                          |
|--------------------------------------------------------|------------------------------------------|
| 1 Rev. counter (➡ 31)                                  | 11 Connection status (➡ 77)              |
| 2 Speed Limit Info (➡ 82)                              | 12 Recommendation to up-shift (➡ 32)     |
| 3 Hill Start Control (➡ 112)                           | 13 Gear indicator                        |
| 4 Speedometer                                          | 14 Operating pointer                     |
| 5 Distance control ACC (Active Cruise Control) (➡ 110) | 15 Central locking system (➡ 125)        |
| 6 Cruise control (➡ 103)                               | 16 Muting (➡ 76)                         |
| 7 Rider info. status line (➡ 75)                       | 17 Heating (➡ 118)                       |
| 8 Riding mode (➡ 102)                                  | 18 Automatic daytime riding light (➡ 99) |
| 9 Splitscreen (➡ 79)                                   | 19 Outside temperature warning (➡ 44)    |
| 10 Clock (➡ 76)                                        | 20 Ambient temperature                   |

## REV. COUNTER



- 1 Scale
- 2 Upper/red engine speed range
- 3 Needle
- 4 Secondary indicator

engine speed range no longer changes.

 The red engine speed range changes depending on the coolant temperature: The colder the engine, the lower the engine speed at which the red engine speed range starts.

The warmer the engine, the higher the speed at which the red engine speed range starts. When operating temperature is reached, the display of the red

## 32 STATUS INDICATORS

### Range



Range readout **1** indicates how far you can ride with the fuel remaining in the tank. This distance is calculated on the basis of average consumption and the quantity of fuel on board.

–When the vehicle is propped on its side stand the slight angle of inclination means that the sensor cannot register the fuel level correctly. This is the reason why the range is recalculated only when the side stand is in the retracted position.

–The range is shown together with a warning once the fuel reserve has been reached.

–After a refuelling stop, range is recalculated if the amount of fuel in the tank is greater than the reserve quantity.

–The calculated range is only an approximate figure.

### Recommendation to upshift



The recommendation to upshift in Pure Ride view **1** or in status line **2** indicates the best time to upshift economically.

## MY VEHICLE VIEW


### START SCREEN



- 1 Check Control display  
Mode of presentation  
(➡ 35)
- 2 Coolant temperature  
(➡ 50)
- 3 Range (➡ 32)
- 4 Odometer
- 5 Service display (➡ 68)
- 6 Tyre pressure, rear  
(➡ 54)
- 7 On-board voltage  
(➡ 223)
- 8 Engine oil level (➡ 50)
- 9 Tyre pressure, front  
(➡ 54)


## 34 STATUS INDICATORS

### On-board computer and trip computer



The ON-BOARD COMPUTER and TRIP COMPUTER menu screens display vehicle and trip data, such as average values.

### Service requirements



When the next service is due within less than a month or within 1000 km, a white Check Control message is displayed.


## WARNING INDICATORS

### Mode of presentation

Warnings are indicated by the corresponding warning lights. Warnings are indicated by the 'General' warning light showing in combination with a dialogue in the display. The 'General' warning light shows yellow or red, depending on the urgency of the warning.




The status of the 'General' warning light matches the most urgent warning. The possible warnings are listed on the next pages.



### Check Control display

The messages differ in how they show on the display. Different colours and symbols are used depending on priority:

- Green CHECK OK **1**: no message, optimum values.
- White circle with small "i" **2**: information.
- Yellow warning triangle **3**: warning, value not ideal.
- Red warning triangle **3**: Warning message, value critical



### Values display

Symbols **4** differ in how they show on the display. The colours used differ and reflect the urgency of the message. Along with numerical values **8** with units **7**, texts **6** are displayed as well:

### Colour of the symbol


- Green: (OK) Current value is ideal.
- Blue: (Cold!) Current temperature is low.
- Yellow: (Low!/High!) Current value is too low or too high.

## 36 STATUS INDICATORS

- Red: (Hot!/High!) Current temperature or value is too high.
- White: (---) No valid value available. Dashes **5** are displayed instead of a numerical value.

 To some extent, individual values can be processed only after the vehicle has covered a certain distance or has reached a certain speed. Dashes are displayed as placeholders for as long as a measured value cannot be displayed because the preconditions for measurement have still to be met. If there are no valid measured values, there will be no assessment in the form of a coloured symbol.

- If there are two or more Check Control messages of equal priority, the messages keep changing in the order of their occurrence until they are acknowledged.
- If symbol **2** is actively displayed, it can be acknowledged by tilting the Multi-Controller to the left.
- Check Control messages are attached dynamically to the pages as additional tabs in the *My vehicle* menu. The message can be called up again as long as the fault persists.



### Check Control dialogue

Messages are output as Check Control dialogues **1**.

## Warnings, overview

| Indicator and warning lights                                                                        | Display text                                                                                                      | Meaning                                                    |
|-----------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------|
|                                                                                                     |  is displayed.                   | Outside temperature warning (▮▮▮ 44)                       |
|  shows yellow.     |  Remote key not in range.        | Radio-operated key out of range (▮▮▮ 44)                   |
|  shows yellow.     |  Keyless Ride failure            | Keyless Ride failed (▮▮▮ 45)                               |
|  shows yellow.     |  Remote key battery weak.        | Replacing battery of radio-operated key (▮▮▮ 45)           |
|                                                                                                     |  Vehicle voltage low.            | Voltage of the vehicle electrical system too low (▮▮▮ 45)  |
|  shows yellow.     |  Vehicle voltage critical!       | Voltage of the vehicle electrical system critical (▮▮▮ 46) |
|  flashes yellow.  |  Battery voltage critical!      | Charging voltage critical (▮▮▮ 46)                         |
|  shows yellow.   |  The faulty bulb is displayed. | Bulb faulty (▮▮▮ 47)                                       |
|  flashes yellow. |  The faulty bulb is displayed. |                                                            |
|  shows yellow.   |  Light control failure!        | Light control failed (▮▮▮ 48)                              |

## 38 STATUS INDICATORS

| Indicator and warning lights                                                                     | Display text                                                                                                                  | Meaning                                      |
|--------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------|
|                 | Alarm system batt. capacity weak.                                                                                             | Anti-theft alarm battery weak (▢▢▢▢ 48)      |
|  shows yellow.   |  Alarm system battery empty.                 | Anti-theft alarm battery flat (▢▢▢▢ 49)      |
|  shows yellow.   |  Alarm system failure                        | DWA failed (▢▢▢▢ 49)                         |
|  shows yellow.   |  Engine oil level<br>Check engine oil level. | Engine-oil level too low (▢▢▢▢ 50)           |
|  shows yellow.   |  Engine temp. high!                          | Engine temperature high (▢▢▢▢ 50)            |
|  shows red.      |  Engine overheating!                         | Engine overheated (▢▢▢▢ 51)                  |
|  shows.          |  Engine!                                     | Drive malfunction (▢▢▢▢ 51)                  |
|  flashes red.    |  Serious fault in the engine control!        | Serious drive malfunction (▢▢▢▢ 52)          |
|  flashes.       |                                                                                                                               |                                              |
|  shows yellow. |  No communication with engine control.     | Engine control failed (▢▢▢▢ 52)              |
|  shows.        |                                                                                                                               |                                              |
|  shows yellow. |  Fault in the engine control.              | Engine in emergency-operation mode (▢▢▢▢ 52) |

| Indicator and warning lights                                                                      | Display text                                                                                                                                                                                                                                        | Meaning                                                      |
|---------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------|
|  flashes red.    |  Serious fault in the engine control!                                                                                                                              | Serious fault in engine control (▮▮▮ 53)                     |
|  shows yellow.   |  Tyre pressure does not match setpoint                                                                                                                             | Tyre pressure close to limit of permitted tolerance (▮▮▮ 55) |
|  flashes red.    |  Tyre pressure does not match setpoint<br> Tyre press. control. Loss of pressure. | Tyre pressure outside permitted tolerance (▮▮▮ 55)           |
|                                                                                                   |  "---"                                                                                                                                                             | Transmission fault (▮▮▮ 56)                                  |
|  shows yellow.   |  "---"                                                                                                                                                             | Sensor faulty or system fault (▮▮▮ 57)                       |
|  shows yellow.   |  Tyre pressure check failure!                                                                                                                                      | Tyre pressure monitoring (RDC) failed (▮▮▮ 57)               |
|  shows yellow. |  RDC sensor battery weak.                                                                                                                                        | Battery for tyre pressure sensor weak (▮▮▮ 57)               |
|                                                                                                   |  Fall sensor faulty.                                                                                                                                             | Malfunction, drop sensor (▮▮▮ 58)                            |
|                                                                                                   |  Cannot start engine.                                                                                                                                            | Motorcycle dropped (▮▮▮ 58)                                  |

## 40 STATUS INDICATORS

| Indicator and warning lights                                                                        | Display text                                                                                                        | Meaning                                          |
|-----------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------|--------------------------------------------------|
|  shows yellow.      |  Emergency call system restricted. | Emergency call function restricted (▣▣▣▣ 58)     |
|  shows yellow.      |  Emergency call system error.      | Emergency call function failed (▣▣▣▣ 58)         |
|  shows yellow.      |  Side stand monitoring faulty.     | Malfunction, side stand monitor (▣▣▣▣ 59)        |
|  flashes regularly. |                                                                                                                     | ABS self-diagnosis not completed (▣▣▣▣ 59)       |
|  shows yellow.      |  Limited ABS availability!         | ABS fault (▣▣▣▣ 59)                              |
|  shows.             |                                                                                                                     |                                                  |
|  shows yellow.      |  ABS failure!                      | ABS failed (▣▣▣▣ 60)                             |
|  shows.             |                                                                                                                     |                                                  |
|  shows yellow.     |  ABS Pro failure!                 | ABS Pro failed (▣▣▣▣ 60)                         |
|  shows.           |                                                                                                                     |                                                  |
|  shows yellow.    |  ABS indicator light faulty!     | ABS indicator and warning light failed (▣▣▣▣ 61) |
|  quick-flashes.   |                                                                                                                     | DTC intervention (▣▣▣▣ 61)                       |

| Indicator and warning lights                                                                    | Display text                                                                                                      | Meaning                                               |
|-------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------|
|  slow-flashes. |                                                                                                                   | DTC self-diagnosis not completed (▣▣▣ 61)             |
|  shows.        |  Off!                            | DTC switched off (▣▣▣ 61)                             |
|                                                                                                 |  Traction control deactivated.   |                                                       |
|  shows yellow. |  Traction control limited!       | DTC restricted (▣▣▣ 62)                               |
|  shows.        |                                                                                                                   |                                                       |
|  shows yellow. |  Traction control failure!       | DTC fault (▣▣▣ 62)                                    |
|  shows.        |                                                                                                                   |                                                       |
|  shows yellow. |  Spring strut adjustment faulty! | D-ESA fault (▣▣▣ 63)                                  |
|  shows red.    |  Rear spring strut faulty.       | Serious suspension strut fault (▣▣▣ 63)               |
|                                                                                                 |  shows green.                   | Hill Start Control active (▣▣▣ 64)                    |
|                                                                                                 |  flashes yellow.               | Hill Start Control automatically deactivated (▣▣▣ 64) |
|                                                                                                 | HSC not available. Engine not running.                                                                            |                                                       |
|                                                                                                 | HSC not available. Side stand extended.                                                                           |                                                       |

## 42 STATUS INDICATORS

| Indicator and warning lights                                                                   | Display text                                                                                                                              | Meaning                                                                 |
|------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|
|                                                                                                |  is displayed.<br>HSC not available. Engine not running. | Hill Start Control cannot be activated (►► 64)                          |
|  shows yellow. |  Brake temp. high!                                       | The temperature of the brakes is too high (►► 64)                       |
|  shows yellow. |  Brake temp. critical!                                   | Temperature of brake critical (►► 65)                                   |
|  shows yellow. |  Cruise control has no function.                         | Cruise control failed (►► 66)                                           |
|  shows yellow. |  ACC temporarily failed.                                 | Distance control (Active Cruise Control ACC) temporarily failed (►► 66) |
|  shows yellow. |  Distance control failed.                                | Distance control (Active Cruise Control ACC) failed (►► 66)             |
|                                                                                                |  Audio system too hot: Level 3                         | Temperature of audio system too high (►► 67)                            |
|                                                                                                |  Audio system voltage high!                            | Voltage of audio system too high (►► 67)                                |
|                                                                                                |  Tank reserve level reached.                           | Fuel down to reserve (►► 67)                                            |

| Indicator and warning lights                                                                     | Display text                                                                                                                  | Meaning                                                                                                                |
|--------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|
|                                                                                                  |  The gear indicator flashes.                 | Gear not taught<br>(  67)             |
|  flashes green. |                                                                                                                               | Hazard warning lights system is switched on                                                                            |
|  flashes green. |                                                                                                                               | (  68)                                |
|                                                                                                  |  is displayed in white.<br>Service due!      | Service due<br>(  68)                 |
|  shows yellow.  |  is displayed in yellow.<br>Service overdue! | Service-due date has passed<br>(  69) |

## 44 STATUS INDICATORS

### Ambient temperature

The ambient temperature is displayed in the status line of the instrument cluster.

When the vehicle is at a standstill, the heat of the electrical machine can falsify the ambient-temperature reading. If the heat of the electrical machine is affecting it too much, dashes are temporarily shown in place of the value.



There is a risk of black ice if the ambient temperature falls below the limit value of approx. 3 °C.

The first time the temperature drops below this value, the ambient-temperature reading and the ice crystal symbol flash in the status line of the instrument cluster.

### Outside temperature warning



is displayed.

Possible cause:



The air temperature measured at the vehicle is lower than:

approx. 3 °C



### WARNING

**Risk of black ice forming even when temperature is above approx. 3 °C**

Risk of accident

- Always take extra care when temperatures are low; remember that there is particular danger of black ice forming on bridges and where the road is in shade.

- Ride carefully and think well ahead.

### Radio-operated key out of range

—with Keyless Ride<sup>OE</sup>



shows yellow.



Remote key not in range. Not possible to switch on ignition again.

Possible cause:

Communication between radio-operated key and propulsion-unit electronics is disrupted.

- Check the battery in the radio-operated key.  
—with Keyless Ride<sup>OE</sup>
- Replace the battery of the radio-operated key. (► 92)
- Use the spare key to continue your journey.

—with Keyless Ride<sup>OE</sup>

- Battery of the radio-operated key is empty or loss of the radio-operated key. (▣ 92)
- Remain calm if the Check Control dialogue appears on the display while you are riding. You can continue your journey, the engine will not switch off.
- Have the faulty radio-operated key replaced by an authorised BMW Motorrad retailer.

### Keyless Ride failed

—with Keyless Ride<sup>OE</sup>



shows yellow.



Keyless Ride failure  
Do not stop the engine. It may not be possible to restart the engine.

Possible cause:

The Keyless Ride control unit has diagnosed a communication fault.

- Do not switch off the motor. Proceed as directly as possible to an authorised workshop, preferably an authorised BMW Motorrad retailer.
- » Motor start with Keyless Ride can no longer be initiated.
- » DWA can no longer be activated.

### Replacing battery of radio-operated key

—with Keyless Ride<sup>OE</sup>



shows yellow.



Remote key battery weak. Function limited. Change battery.

Possible cause:

- The integral battery in the radio-operated key has lost a significant proportion of its original capacity. There is no assurance of how long the radio-operated key can remain operational.
- Replace the battery of the radio-operated key. (▣ 92)

### Voltage of the vehicle electrical system too low



Vehicle voltage low.  
Switch off unnecessary consumers.

The voltage of the vehicle electrical system is too low. If you continue to ride the motorcycle the on-board electronics will drain the battery.

Possible cause:

Consumers with high power consumption are in operation (such as heated body warmers), too many consumers are in operation at one time, or battery faulty.

## 46 STATUS INDICATORS

- Switch off non-essential consumers or disconnect them from the vehicle's electrical system.
- If the fault persists or occurs without consumers connected, have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Voltage of the vehicle electrical system critical



shows yellow.



Vehicle voltage critical! Consumers were switched off. Check battery condition.



### WARNING

#### Failure of the vehicle systems

Risk of accident

- Do not continue your journey.

The voltage of the vehicle electrical system is critical. The on-board electronics will drain the battery.

Possible cause:

Consumers with high power consumption are in operation (such as heated body warmers), too many consumers are in operation at one time, or battery faulty.

- Switch off non-essential consumers or disconnect them from the vehicle's electrical system.
- If the fault persists or occurs without consumers connected, have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Charging voltage critical



flashes yellow.



Battery voltage critical! Accident risk. Stop driving.



### WARNING

#### Failure of the vehicle systems

Risk of accident

- Do not continue your journey.

Battery is not being charged. The on-board electronics will drain the battery.

Possible cause:

Alternator malfunction, battery faulty or fuse has blown.

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Bulb faulty

 shows yellow.

 The faulty bulb is displayed:

 High beam faulty!

 Front left turn indicator faulty! or. Front right turn indicator faulty!

 Low-beam headlight faulty!

 Front side light faulty!

 Daytime riding light faulty!

—with additional headlight<sup>OE</sup>

 Left additional headlight faulty! or. Right additional headlight faulty!◁

 Tail light faulty!

 Brake light faulty!

 Rear left turn indicator faulty! or. Rear right turn indicator faulty!

 Number plate light faulty!

—Have it checked by a specialist workshop.

 flashes yellow.

—with adaptive head light<sup>OE</sup>

 The faulty bulb is displayed:

 Active headlight faulty.◁

### WARNING

**Vehicle overlooked in traffic due to failure of the lights on the vehicle**

Safety risk

- Always replace a faulty bulb at the earliest possible opportunity. Consult a specialist workshop, preferably an authorised BMW Motorrad Retailer.

## 48 STATUS INDICATORS

Possible cause:

One or more bulbs faulty.

- Identify faulty bulb or bulbs by visual check.
- Have LED light sources replaced as complete units; consult a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Light control failed



shows yellow.



Light control failure! Have it checked by a specialist workshop.



### WARNING

#### Vehicle overlooked in traffic on account of failure of the vehicle lighting

Safety risk

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

The vehicle lighting has partially or completely failed.

Possible cause:

Light control has diagnosed a communication fault.

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Anti-theft alarm battery weak

—with anti-theft alarm (DWA)<sup>OE</sup>



Alarm system batt. capacity weak. No restrictions. Make an appointment at a specialist workshop.



This error message is displayed briefly only after the Pre-Ride-Check completes.

Possible cause:

The integral battery in the anti-theft alarm has lost a significant proportion of its original capacity. There is no assurance of how long the anti-theft alarm can remain operational if the vehicle's battery is disconnected.

- Consult a specialist workshop, preferably an authorised BMW Motorrad retailer.

**Anti-theft alarm battery flat**

—with anti-theft alarm (DWA) <sup>OE</sup>



shows yellow.



Alarm system battery empty. No independent alarm. Make an appointment at a specialist workshop.



This error message is displayed briefly only after the Pre-Ride-Check completes. Possible cause:

The DWA battery is discharged. It is not possible to trigger an alarm after disconnecting the vehicle battery. All other functions of the DWA are functional.

- Consult a specialist workshop, preferably an authorised BMW Motorrad retailer.

**DWA failed**

—with anti-theft alarm (DWA) <sup>OE</sup>



shows yellow.



Alarm system failure. Have it checked by a specialist workshop.

Possible cause:

The DWA control unit has diagnosed a communication fault.

- Consult a specialist workshop, preferably an authorised BMW Motorrad retailer.
- » DWA can no longer be activated or deactivated.
- » False alarm possible.

**Electronic oil-level check**

The electronic oil-level check assesses the oil level in the engine as OK or Low!

The following preconditions have to be satisfied for electronic oil-level checking, and several measurements might have to be taken:

- Rider is sitting on the vehicle and vehicle has just been ridden at a speed of at least min. 10 km/h.
- Engine idling for at least 20 seconds.
- Engine is at operating temperature.
- Vehicle is standing upright on a smooth, level surface.
- Side stand is retracted and vehicle is not propped on its centre stand.
- The suspension strut is appropriately set for the load

## 50 STATUS INDICATORS

status, or D-ESA is in Auto load mode.

If measurement is incomplete or if these conditions are not met, the oil level cannot be judged by the system. Dashes (---) appear on the display instead of a reading.

### Engine-oil level too low



shows yellow.



Engine oil level  
Check engine oil  
level.

Possible cause:

The electronic oil-level sensor has registered a low oil level. If the vehicle is not standing upright on a smooth, level surface, the message might appear even though the oil level is correct. The next time you stop for fuel:

- Check the engine oil level.  
( 200)

If the oil level is too low:

- Topping up the engine oil.  
( 201)

If the oil level is correct:

- Check whether the preconditions for the electronic oil-level check are met.

If the message appears repeatedly, even though the oil

level is slightly below the **MAX** mark:

- Consult a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Engine temperature high



shows yellow.



Engine temp. high!  
Continue riding with  
restriction to allow  
cooling.



### ATTENTION

#### Riding with overheated engine

Engine damage

- Compliance with the information set out below is essential.

Possible cause:

The coolant level is too low.

- Check the coolant level.  
( 207)

If the coolant level is too low:

- Allow the motor to cool down. Top up the coolant. Have the cooling system checked by a specialist workshop, preferably an authorised BMW Motorrad retailer.

Possible cause:

The temperature sensor has detected a high temperature in the motor.

- If possible, ride in the part-load range to cool down the motor.
- If the motor temperature is frequently too high, have the fault rectified as soon as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Engine overheated



shows red.



Engine overheating! Stop when it is safe to do so and switch off the engine.



### ATTENTION

#### Riding with overheated engine

Engine damage

- Compliance with the information set out below is essential.

Possible cause:

The coolant level is too low.

- Check the coolant level.

( 207)

If the coolant level is too low:

- Allow the motor to cool down. Top up the coolant. Have the cooling system checked by a specialist workshop, preferably an authorised BMW Motorrad retailer.

Possible cause:

Engine is overheated.

- Carefully bring the vehicle to a stop, switch off the engine and wait until the engine has cooled down.
- If engine overheating is a frequent occurrence, have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Drive malfunction



shows.



Engine! Have it checked by a specialist workshop.

Possible cause:

The motor control unit has diagnosed a fault that affects pollutant emissions and/or reduces power.

- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad retailer.

## 52 STATUS INDICATORS

» You can continue riding; pollutant emissions are higher than the threshold values.

### Serious drive malfunction



flashes red.



flashes.



Serious fault in the engine control! Riding at mod. speed pos. Damage possible. Have checked by workshop.

Possible cause:

The engine control unit has diagnosed a fault that can lead to damage to the exhaust system.

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

» It is possible to continue to ride but not recommended.

### Engine control failed



shows yellow.



shows.



No communication with engine control. Multiple sys. affected. Ride carefully to the

next specialist workshop.

Possible cause:

Communication with the engine control unit has failed.

- You can continue to ride.

Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Engine in emergency-operation mode



shows yellow.



Fault in the engine control. Onward journey possible. Ride carefully to next specialist workshop.



### WARNING

#### Unusual ride characteristics when engine running in emergency-operation mode

Risk of accident

- Avoid accelerating sharply and overtaking.

Possible cause:

The electronic control unit has diagnosed a fault. In exceptional cases, the engine stops and refuses to start. Otherwise, the engine runs in emergency operating mode.

- You can continue to ride, but bear in mind that the usual engine performance might not be available.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### **Serious fault in engine control**



flashes red.



Serious fault in the engine control! Riding at mod. speed pos. Damage possible. Have checked by workshop.



### **WARNING**

#### **Engine damage when running in emergency-operation mode**

Risk of accident

- Ride slowly, avoid accelerating sharply and overtaking.
- If possible, have the vehicle picked up and have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad Retailer.

Possible cause:

The engine control unit has diagnosed a fault that can lead to serious consequential faults.

The engine is in emergency-operation mode.


- It is possible to continue to ride but not recommended.
- Avoid high load and rpm ranges if possible.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

## 54 STATUS INDICATORS

### Tyre pressure

—with tyre pressure control (RDC) <sup>OE</sup>

In addition to the MY VEHICLE menu screen and the Check Control messages, there is also the TYRE PRESSURE screen for showing the tyre pressures:



The values on the left are for the front wheel; those on the right are for the rear wheel. Actual and specified tyre pressures and the difference between them are displayed for each wheel.

Immediately after the ignition is switched on, only dashes are displayed. The sensors do not start transmitting tyre pressure signals until the first time the vehicle accelerates to more than the minimum speed stated below:



RDC sensor is not active

min. 30 km/h (The RDC sensor does not transmit its signal to the vehicle until a certain minimum speed has been reached.)



The tyre-pressure readings in the instrument cluster are temperature-compensated and are always referenced to the following tyre-air temperature:

20 °C



If the tyre symbol appears as well, showing yellow or red, this is a warning. The pressure difference is highlighted with an exclamation point in the same colour.



If the value in question is close to the limit of the permissible tolerance range, the reading is accompanied by the 'General' warning light showing yellow.



The 'General' warning light flashes red if the tyre pressure registered by the sensor is outside the permissible tolerance range.

For further information about BMW Motorrad RDC, see the section entitled "Engineering details" (189).

### **Tyre pressure close to limit of permitted tolerance**



shows yellow.



Tyre pressure does not match setpoint  
Check tyre pressure.

Possible cause:

Measured tyre pressure is close to the limit of permitted tolerance.

- Correct tyre pressure.
- Before adjusting tyre pressure, read the information on temperature compensation and adjusting pressure in the section entitled "Engineering details":

–with tyre pressure control (RDC)<sup>OE</sup>

» Temperature compensation (189)◁

–with tyre pressure control (RDC)<sup>OE</sup>

» Pressure adaptation (190)◁

» Find the correct tyre pressures in the following places:

–Back cover of the rider's manual

–Instrument cluster in the TYRE PRESSURE view

–Tyre pressures table

### **Tyre pressure outside permitted tolerance**



flashes red.



Tyre pressure does not match setpoint  
Stop immediately! Check tyre pressure.



Tyre press. control.  
Loss of pressure.  
Stop immediately! Check tyre pressure.



### **WARNING**

#### **Tyre pressure outside the permitted tolerance.**

Risk of accident, degradation of the vehicle's driving characteristics.

- Adapt your style of riding accordingly.

Possible cause:

Measured tyre pressure is outside permitted tolerance.

- Check the tyre for damage and to ascertain whether the vehicle can be ridden with the tyre in its present condition.

If the vehicle can be ridden with the tyre in its present condition:

## 56 STATUS INDICATORS

- Correct the tyre pressure at the earliest possible opportunity.
- Before adjusting tyre pressure, read the information on temperature compensation and adjusting pressure in the section entitled "Engineering details":
  - with tyre pressure control (RDC)<sup>OE</sup>
  - » Temperature compensation (189)◀
  - with tyre pressure control (RDC)<sup>OE</sup>
  - » Pressure adaptation (190)◀
  - » Find the correct tyre pressures in the following places:
    - Back cover of the rider's manual
    - Instrument cluster in the TYRE PRESSURE view
    - Tyre pressures table
- Have the tyre checked for damage by a specialist workshop, preferably an authorised BMW Motorrad retailer.

If you are unsure whether the vehicle can be ridden with the tyre in its present condition:

- Do not continue your journey.
- Notify the breakdown service.

### Transmission fault



"---"

Possible cause:

The vehicle has not reached the minimum speed (189).



RDC sensor is not active

min. 30 km/h (The RDC sensor does not transmit its signal to the vehicle until a certain minimum speed has been reached.)

- Increase speed above this threshold and observe the RDC readings. Assume that a permanent fault has not occurred unless the 'General' warning light comes on to accompany the symptoms. Under these circumstances:
- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad retailer.

Possible cause:

Wireless communication with the RDC sensors has been disrupted. Possible causes include radio-communication systems operating in the vicinity and interfering with the link between the RDC control unit and the sensors.

- Move to another location and observe the RDC readings. Assume that a permanent fault has not occurred unless the 'General' warning light comes on to accompany the symptoms. Under these circumstances:
- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Sensor faulty or system fault



shows yellow.



"----"

Possible cause:

Vehicle is fitted with wheels not equipped with RDC sensors.

- Retrofit a set of wheels equipped with RDC sensors.

Possible cause:

One or both RDC sensors have failed or a system fault has occurred.

- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Tyre pressure monitoring (RDC) failed



shows yellow.



Tyre pressure check failure! Function limited. Have it checked by a specialist workshop.

Possible cause:

The tyre pressure control (RDC) control unit has diagnosed a communication fault.

- Consult a specialist workshop, preferably an authorised BMW Motorrad retailer.
- » Tyre pressure warnings not available.

### Battery for tyre pressure sensor weak



shows yellow.



RDC sensor battery weak. Function limited. Have it checked by a specialist workshop.



This error message is displayed briefly only after the Pre-Ride-Check completes.

## 58 STATUS INDICATORS

Possible cause:

The integral battery in the tyre-pressure sensor has lost a significant proportion of its original capacity. There is no assurance of how long the tyre pressure monitoring system can remain operational.

- Consult a specialist workshop, preferably an authorised BMW Motorrad retailer.

### **Malfunction, drop sensor**

 Fall sensor faulty. Have it checked by a specialist workshop.

Possible cause:

The drop sensor is not available.

- Consult a specialist workshop, preferably an authorised BMW Motorrad retailer.

### **Motorcycle dropped**

 Cannot start engine. Stand motorcycle upright. Switch ignition on/off. Start the engine.

Possible cause:

The fall sensor has detected a fall and has cut out the motor.

- Hold the vehicle upright and check it for damage.
- Switch the ignition off and then on again or switch the

kill switch on and then off again.

### **Emergency call function restricted**

—with intelligent emergency call<sup>OE</sup>



shows yellow.



Emergency call system restricted. If this occurs again, have the vehicle checked by a specialist workshop.

Possible cause:

The emergency call cannot be made automatically or cannot be made via BMW.

- Observe the information on operating the intelligent emergency call from page (► 94) onwards.
- Consult a specialist workshop, preferably an authorised BMW Motorrad retailer.

### **Emergency call function failed**

—with intelligent emergency call<sup>OE</sup>



shows yellow.



Emergency call system error. Make an appointment at a specialist workshop.

Possible cause:

The control unit of the emergency call system has diagnosed a fault. The emergency call function has failed.

- Bear in mind that an emergency call cannot be made.
- Consult a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Malfunction, side stand monitor



shows yellow.



Side stand monitoring faulty. Onward journey possible. Engine will stop if stationary! Have checked by workshop.

Possible cause:



Side-stand switch or wiring damaged

The motor will switch off when speed drops below the minimum threshold. You cannot resume your journey.

min. 5 km/h

- Consult a specialist workshop, preferably an authorised BMW Motorrad retailer.

### ABS self-diagnosis not completed



flashes.

Possible cause:



ABS self-diagnosis not completed

ABS is not available, because self-diagnosis did not complete. (The motorcycle has to reach a defined minimum speed for the wheel speed sensors to be checked: 5 km/h)

- Pull away slowly. Bear in mind that the ABS function is not available until self-diagnosis has completed.

### ABS fault



shows yellow.



shows.



Limited ABS availability! Onward journey possible. Ride carefully to next specialist workshop.

## 60 STATUS INDICATORS

Possible cause:

The ABS control unit has detected a fault. The ABS function is available, subject to restrictions.

- You can continue to ride.  
Bear in mind the more detailed information on certain situations that can lead to an ABS fault message (178).

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### ABS failed



shows yellow.



shows.



ABS failure! Onward journey possible. Ride carefully to next specialist workshop.

Possible cause:

The ABS control unit has detected a fault. The ABS function is not available.

- You can continue to ride.  
Bear in mind the more detailed information on certain situations that can lead to an ABS fault message (178).

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### ABS Pro failed



shows yellow.



shows.



ABS Pro failure! Onward journey possible. Ride carefully to next specialist workshop.

Possible cause:

Monitoring of the ABS Pro function has detected a fault. The ABS Pro function is not available. The ABS function is still available. ABS provides support only for braking in straight-ahead driving.

- You can continue to ride.  
Bear in mind the more detailed information on certain situations that can lead to an ABS Pro fault message (178).
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

## ABS indicator and warning light failed



shows yellow.



ABS indicator light faulty! Onward journey possible. Check by specialist workshop required.

Possible cause:

The ABS indicator and warning light has failed.

- You can continue to ride.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

## DTC intervention



quick-flashes.

Possible cause:

The DTC has detected a degree of instability at the rear wheel and has intervened to reduce torque.

The indicator and warning light flashes longer than the duration of the DTC. This affords the rider visual feedback on control intervention even after the critical situation has been dealt with.

- You can continue to ride.  
Ride carefully and think well ahead.

## DTC self-diagnosis not completed



slow-flashes.

Possible cause:



DTC self-diagnosis not completed

The DTC function is not available, because self-diagnosis did not complete. (The motorcycle has to reach a defined minimum speed with the engine running for the wheel-speed sensors to be checked: min. 5 km/h)

- Pull away slowly. Bear in mind that the DTC function is not available until self-diagnosis has completed.

## DTC switched off



shows.



Off!



Traction control deactivated.

## 62 STATUS INDICATORS

Possible cause:

The rider has switched off the DTC system.

- Switch the DTC function on and off. (100)

### DTC restricted



shows yellow.



shows.



Traction control limited! Onward journey possible. Ride carefully to next specialist workshop.

Possible cause:

The engine control unit has detected a DTC fault.



### ATTENTION

#### Damaged components

Damage to sensors, for example, which causes malfunctions

- Do not transport any objects underneath the driver or passenger seat.
- Secure the toolkit.
- Do not damage the angular rate sensor.
- Bear in mind that the DTC function and other dynamic control system functions are restricted.

- You can continue to ride.

Bear in mind the more detailed information on situations that can lead to a DTC fault (180).

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### DTC fault



shows yellow.



shows.



Traction control failure! Onward journey possible. Ride carefully to next specialist workshop.

Possible cause:

The engine control unit has detected a DTC fault.



### ATTENTION

#### Damaged components

Damage to sensors, for example, which causes malfunctions

- Do not transport any objects underneath the driver or passenger seat.
- Secure the toolkit.

- Do not damage the angular rate sensor.
- Bear in mind that the DTC function and other dynamic control system functions are not available.
- You can continue to ride. Bear in mind the more detailed information on situations that can lead to a DTC fault (► 180).
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### D-ESA fault

—with Dynamic ESA<sup>OE</sup>



shows yellow.



Spring strut adjustment faulty! Onward journey possible. Ride carefully to next specialist workshop.

Possible cause:

The Dynamic ESA control unit has detected a fault. Components of the electronic suspension adjustment system are faulty or communication with the control unit is disrupted. In this condition, the motorcycle has too much damping and is uncomfortable

to drive, especially on roads in poor condition.

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Serious suspension strut fault



shows red.



Rear spring strut faulty. Stop when it is safe to do so and have it checked by a specialist workshop.

Possible cause:

A serious fault affecting the suspension strut has been detected.

- Stop carefully.
- Make sure the ground is level and firm and place the motorcycle on its centre stand.
- Check whether the rear wheel contacts the ground when the motorcycle is propped on its centre stand.
- » If the rear wheel does not contact the ground you can resume riding, adopting a moderate style of riding.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an

## 64 STATUS INDICATORS

authorised BMW Motorrad re-tailer.

- » If the rear wheel contacts the ground or there is uncertainty about the condition of the suspension strut, do not resume riding.



### WARNING

#### Impaired handling characteristics

Risk of falling

- Do not continue your journey.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad re-tailer.

#### Hill Start Control active



shows green.

Possible cause:

Hill Start Control (191) has been activated by the rider.

- Switch off Hill Start Control.
- Operate Hill Start Control. (113)

#### Hill Start Control automatically deactivated



flashes yellow.

HSC not available. Engine not running.

HSC not available. Side stand extended.

Possible cause:

Hill Start Control cannot be activated.

- Retract the side stand.
- » Hill Start Control is operational only with the side stand retracted.
- Start the engine.
- » Hill Start Control is operational only while the engine is running.

#### Hill Start Control cannot be activated



is displayed.

HSC not available. Engine not running.

Possible cause:

Hill Start Control cannot be activated.

- Retract the side stand.
- » Hill Start Control is operational only with the side stand retracted.
- Start the engine.
- » Hill Start Control is operational only while the engine is running.

#### The temperature of the brakes is too high



shows yellow.



Brake temp. high!  
Continue riding  
carefully to cool down.  
Avoid dynamic riding.



### **DANGER**

#### **Riding with overheated brakes**

Risk of accident due to failure of brakes

- Adapt your riding style accordingly.
- Avoid frequent braking by using the engine brake.



### **WARNING**

#### **Failure to observe service intervals**

Risk of accident

- Observe the valid service intervals for brakes.

Possible cause:

The temperature of the brake is in a critical range.

- By adopting a moderate riding style you can continue to ride until the warning light goes out.

#### **Temperature of brake critical**



shows yellow.



Brake temp. critical! Continue riding carefully to cool down. Avoid dynamic riding.



### **DANGER**

#### **Riding with overheated brakes**

Risk of accident due to failure of brakes

- Adapt your riding style accordingly.
- Avoid frequent braking by using the engine brake.



### **WARNING**

#### **Failure to observe service intervals**

Risk of accident

- Observe the valid service intervals for brakes.

Possible cause:

The temperature of the brake is in a critical range.

- By adopting a moderate riding style you can continue to ride until the warning light goes out.

## 66 STATUS INDICATORS

### Cruise control failed



shows yellow.



Cruise control has no function. Onward journey possible. Inspection at workshop required.

Possible cause:

The control unit has detected a fault.

- Bear in mind that the cruise control function is not available.
- You can continue to ride. Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Distance control (Active Cruise Control ACC) temporarily failed

—with Active Cruise Control<sup>OE</sup>



shows yellow.



ACC temporarily failed. Check front radar sensor for damage.

Possible cause:

The function of the front radar sensor is impaired.

- Bear in mind that the distance control function (ACC) is temporarily not available. Adaptive cruise control is still available.
- You can continue to ride. Check the front radar sensor. Remove dirt or objects obstructing the radar sensor.
- Comply with the care and cleaning instructions (► 244).

### Distance control (Active Cruise Control ACC) failed

—with Active Cruise Control<sup>OE</sup>



shows yellow.



Distance control failed. Have it checked by a specialist workshop.

Possible cause:

The control unit has detected a fault.

- Bear in mind that the distance control function (ACC) is not available. Adaptive cruise control is still available.
- You can continue to ride. Have the fault rectified as quickly as possible by a specialist workshop, preferably

an authorised BMW Motorrad retailer.

### Temperature of audio system too high

 Audio system too hot: Level 3 Audio system has been switched off.

The temperature of the control unit for the audio system is too high. The audio system is powered down.

Possible cause:

The audio system control unit has diagnosed an excessively high temperature.

- Protect the motorcycle from the direct rays of the sun.
- If the fault persists, have it rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Voltage of audio system too high

 Audio system voltage high! Audio system has been muted.

Possible cause:

The audio system control unit has diagnosed an excessively high voltage.

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an

authorised BMW Motorrad retailer.

### Fuel down to reserve

 Tank reserve level reached. Ride to the next filling station.



#### WARNING

#### Irregular engine operation or engine shutdown due to lack of fuel

Risk of accident, damage to catalytic converter

- Do not run the fuel tank dry.

Possible cause:

The fuel tank contains no more than the reserve quantity of fuel.



Reserve fuel

approx. 4 l

- Refuel. (157)

### Gear not taught

—with shift assistant Pro<sup>OE</sup>

 The gear indicator flashes.

Possible cause:

The gearbox sensor is not fully trained.

- Start the engine. (159)
- Select neutral N.

## 68 STATUS INDICATORS

- Extend and then retract the side stand, without touching the shift lever.
- Use clutch control to engage each gear in turn. In each gear repeatedly move the throttle twistgrip to the idle position and then re-open the throttle.
- » The gear indicator stops flashing when the gearbox sensor has been trained successfully.
- When the gearbox sensor has been taught successfully, Gear Shift Assistant Pro works as described (190).
- If teaching is not successful, have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Hazard warning lights system is switched on



flashes green.



flashes green.

Possible cause:

The driver has switched on the hazard warning lights system.

- Hazard warning lights.

(100)

### Service display



If service is overdue, the due date or the odometer reading at which service was due is accompanied by the 'General' warning light showing yellow.

If the service is overdue, a yellow Check Control message is displayed. Exclamation marks also draw your attention to the displays for service, service appointment and countdown distance in the MY VEHICLE and SERVICE REQUIREMENTS menu screens.



If the service-due indicator appears more than a month before the service date, the current date has to be corrected. This situation can occur if the battery was disconnected.

### Service due



is displayed in white.

Service due! Have service performed by a specialist workshop.

Possible cause:

Service is due, because of either distance covered or time expired.

- Have your vehicle serviced regularly by a specialist workshop, preferably an authorised BMW Motorrad retailer.
- » The vehicle remains operationally reliable and road-worthy.
- » The vehicle retains its value.

### **Service-due date has passed**



shows yellow.



is displayed in yellow.

Service overdue! Have service performed by a specialist workshop.

Possible cause:

Service is overdue because of the driving performance or the date.

- Have your vehicle serviced regularly by a specialist workshop, preferably an authorised BMW Motorrad retailer.
- » The vehicle remains operationally reliable and road-worthy.
- » The vehicle retains its value.

# **INSTRUMENT CLUSTER**

**04**

---

|                            |           |
|----------------------------|-----------|
| <b>WARNINGS</b>            | <b>72</b> |
| <b>CONTROLS</b>            | <b>72</b> |
| <b>MY VEHICLE</b>          | <b>73</b> |
| <b>OPERATION</b>           | <b>74</b> |
| <b>SETTINGS</b>            | <b>76</b> |
| <b>BLUETOOTH</b>           | <b>77</b> |
| <b>SPLITSCREEN</b>         | <b>79</b> |
| <b>NAVIGATION</b>          | <b>79</b> |
| <b>MEDIA</b>               | <b>82</b> |
| <b>TELEPHONE</b>           | <b>83</b> |
| <b>SOFTWARE VERSION</b>    | <b>84</b> |
| <b>LICENCE INFORMATION</b> | <b>84</b> |

## 72 INSTRUMENT CLUSTER

### WARNINGS



#### WARNING

##### Operation of a smartphone while riding the vehicle

Risk of accident

- Always comply with the road traffic regulations in force where you are riding.
- Do not use a smartphone while riding. This applies with the exception of applications without operation, such as hands-free telephony.



#### WARNING

##### Distraction from the road and loss of control


Operating the integrated information system and communication devices while driving results in a risk of accident

- Operate those systems or devices only when the traffic situation allows for it.
- If necessary, stop and operate the systems or devices when stationary.

When performing functions that can only be operated when the vehicle is stationary, an operational feedback message appears in the instrument cluster.

### CONTROLS

#### Multi-Controller



- 1** Multi-Controller
- A** Move the cursor up in lists  
Increase volume
- B** Move the cursor down in lists  
Reducing volume
- C** Activate function in accordance with feedback  
Confirm selection/setting  
Scrolling through menu screens

- D** Activate function in accordance with feedback or go back  
Return to Menu view after making settings  
Change up one level in the hierarchy  
Scrolling through menu screens

### MENU rocker button



#### Short-press the top section of MENU rocker button 1:

- In Menu view: Change up one level.
- In Pure Ride view: Change the display for rider info. status line.

#### Long-press the top section of MENU rocker button 1:

- In Menu view: Open the Pure Ride view.

#### Short-press the bottom section of MENU rocker button 1:

- Change down a level.

- Confirm selection/setting.

#### Long-press the bottom section of MENU rocker button 1:

- Change back to the last menu after a previous menu change effected by long-pressing the top section of the rocker button.

 Instructions given by the navigation system are displayed as a dialogue if the Navigation menu has not been called up. Operation of the MENU rocker button is temporarily restricted.

---

### MY VEHICLE

#### On-board computer and trip computer

The ON-BOARD COMPUTER and TRIP COMPUTER menu screens display vehicle and trip data, such as average values.

#### Call up the on-board computer

- Call up the My vehicle menu.
  - Scroll to the right until the ON-BOARD COMPUTER menu screen is displayed.
- » Alternatively, the on-board computer can also be shown on the splitscreen.

## 74 INSTRUMENT CLUSTER

- Switch on splitscreen view and select display. (►► 79)

### Reset the on-board computer

- Call up the on-board computer. (►► 73)
- Press down the MENU rocker button.
- Select **Reset all values** or **Reset individual values** and confirm.

The following values can be reset:



Break



Journey



Current



Speed



Consump.

### Call up the trip computer


- Call up the on-board computer. (►► 73)
- Scroll to the right until the **TRIP COMPUTER** menu screen is displayed.
  - » Alternatively, the trip computer can also be shown on the splitscreen.
- Switch on splitscreen view and select display. (►► 79)

### Reset the trip computer

- Call up the trip computer. (►► 74)
- Press down the MENU rocker button.
- Select **Autom. reset** or **Reset all values and confirm**.
  - » If **Autom. reset** is selected, the trip computer is automatically reset when a minimum of 6 hours have passed and the date has changed since the ignition was switched off.

## OPERATION

### Calling up menu



- Display the **Pure Ride** view. (►► 75)
- Short-press the bottom section of button **2**.

The following menus can be called up:

- My vehicle
- Radio
- Navigation
- Media

- Telephone
- Settings
- Repeatedly short-push Multi-Controller **1** to the right until the menu item you want is highlighted.
- Short-press the bottom section of button **2**.

### Display Pure Ride view

- Long-press the top section of the MENU rocker button.

### Changing display for rider info. status line

#### Requirement

The vehicle is at a standstill.  
The Pure Ride view is displayed.

- Switch on the ignition.  
( 88)
- » The instrument cluster shows all the information necessary for riding on public roads from the on-board computer (e.g. TRIP 1) and the trip computer (e.g. TRIP 2). The information can be displayed in the top status line.
- with tyre pressure control (RDC)<sup>OE</sup>
- » Information from the tyre pressure monitoring can also be displayed.◁
- Select the content of the top status line. ( 76)



- Long-press button **1** to obtain the Pure Ride view.
- Repeatedly short-press button **1** to select the value in the top status line **2**.

The following values can be displayed:

- Total distance
- Current distance 1
- Current distance 2
- Consumption 1 (Average)
- Consumption 2 (Average)
- Riding time 1
- Riding time 2
- Break 1

## 76 INSTRUMENT CLUSTER



Break 2



Speed 1 (Average)



Speed 2 (Average)

–with tyre pressure control  
(RDC) <sup>OE</sup>



Tyre pressure  $\triangleleft$



Fuel tank level



Range

### Select the content of the top status line

- Navigate to Settings, Display, Status line content.
- Switch on the desired displays.
- » You can switch between the selected displays in the top status line. If no displays are selected, only the range will be displayed.

---

## SETTINGS

### Adjusting volume

- Connect the rider's and passenger's helmets. (► 78)
- Increase volume: Turn Multi-Controller up.

- Reduce volume: Turn Multi-Controller down.
- Mute: Turn Multi-Controller all the way down.
- » Muting pauses media playback.

### Changing system settings

- Switch on the ignition. (► 88)
- Navigate to Settings, System settings.
- » You can change the following system settings here:
  - Date and time
  - Units
  - Language

### Adjusting brightness

- Navigate to Settings, Display, Brightness.
- Adjust display brightness.
- » When ambient brightness drops below a defined threshold, the display is dimmed to the brightness set here.
- » If the display is faulty, consult the troubleshooting chart in the section entitled "Technical data". (► 251)

### Reset all settings

- Call up the Settings menu.
- Select Reset all and confirm.

The settings in the following menus are reset to their default factory settings:

- Vehicle settings
  - System settings
  - Connections
  - Display
  - Information
- » The pairing of the vehicle to the current BMW Motorrad Connected-Ride account is reset.

---

## BLUETOOTH

### Pairing

Two Bluetooth devices have to recognise each other before they can communicate. This process of mutual recognition is known as pairing. When two devices have paired they remember each other, so the pairing process is conducted only once, on initial contact.

 On some mobile devices, e.g. those with the iOS operating system, the BMW Motorrad Connected app has to be opened prior to use.

During the pairing process, the instrument cluster searches for other Bluetooth-compatible devices within its reception range. The conditions that have to be satisfied before the audio system can recognise another device are as follows:

- The device's Bluetooth function must be active
- The device must be "visible" to others
- Other Bluetooth-compatible devices that are not to be paired (e.g. mobile phones and navigation systems) must be OFF.

Please consult the operating instructions for your communication system.

### Pairing

- Navigate to Settings, Connections.
- » Bluetooth connections can be established, managed and deleted in the CONNECTIONS menu. The following Bluetooth connections are displayed:

- Mobile device
- Rider's helmet
- Passenger helm.

The connection status for mobile devices is displayed.

### Connect mobile device

- Perform pairing. (➡ 77)
- Activate the mobile device's Bluetooth function (see mobile device's operating instructions).
- Select Mobile device and confirm.

## 78 INSTRUMENT CLUSTER

- Select **Pair new mobile device** and confirm.

Mobile devices are being searched for.

 flashes in the bottom status line during pairing.

Mobile devices found are displayed.

- Select and confirm mobile device.

 If the fuel tank is between the mobile device and the instrument cluster, the Bluetooth connection may be restricted. BMW Motorrad recommends keeping the mobile device above the fuel tank (e.g. carried in a jacket pocket).

- Follow the instructions on the mobile device.
- Confirm that the code matches.

» The connection is established and the connection status updated.

» If the connection is not established, consult the troubleshooting chart in the section entitled "Technical data". (►► 250)

» Depending on the mobile device, telephone data is transferred to the vehicle automatically.

» Telephone data (►► 84)

» If the phonebook is not displayed, consult the troubleshooting chart in the section entitled "Technical data". (►► 252)

» If the Bluetooth connection does not work as expected, consult the troubleshooting chart in the section entitled "Technical data". (►► 251)

### **Connect rider's and passenger's helmet**

- Perform pairing. (►► 77)

- Select **Rider's helmet or Passenger helm.** and confirm.

- Make the helmet's communication system visible.

- Select **Pair new rider's helmet or Pair new passenger helmet** and confirm.

Helmets are searched for.

 flashes in the bottom status line during pairing.

Helmets found are displayed.

- Select and confirm helmet.

» The connection is established and the connection status updated.

» If the connection is not established, consult the troubleshooting chart in the section entitled "Technical data". (►► 250)

» If the Bluetooth connection does not work as expected, consult the troubleshooting chart in the section entitled "Technical data". (▮▮▮ 251)

### Delete connections

- Navigate to Settings, Connections.
- Select Delete connections.
- To delete an individual connection, select the connection and confirm.
- To delete all connections, select Delete all connections and confirm.

---

## SPLITSCREEN

### Switching on splitscreen view and selecting display

- Display the Pure Ride view. (▮▮▮ 75)
- Repeatedly short-push the Multi-Controller to the right or left until the display you want appears.
- Alternatively: Long-push the Multi-Controller to the right to return to the display last selected in splitscreen view.

The following displays can be selected:

- ON-BOARD COMPUTER
- TRIP COMPUTER
- Navigation
- MEDIA

-with audio system<sup>OE</sup>  
MEDIA or RADIO can be displayed, depending on the selected audio source.◀

» The display you select is retained in memory, even after the ignition is switched off.

### Switching off splitscreen

- Display the Pure Ride view. (▮▮▮ 75)
- Repeatedly short-push the Multi-Controller to the left until the splitscreen view is switched off.
- Alternatively: Long-push the Multi-Controller to the left.

---

## NAVIGATION

### Precondition

The vehicle is connected via Bluetooth to a compatible mobile device.

The BMW Motorrad Connected app is installed on the connected mobile device.



On some mobile devices, e.g. those with the iOS operating system, the BMW Motorrad Connected app has to be opened prior to use.

## 80 INSTRUMENT CLUSTER

### WiFi connection

A Wi-Fi connection is used to transmit the map view from a mobile phone to the instrument cluster. Wi-Fi has to be activated on the mobile phone in order for the full scope of this functionality to be used. For more information on activating WiFi see the operating instructions for the mobile phone.

Depending on the specifics of the local situation, for example in the presence of numerous wifi networks, temporary restrictions and loss of connection are possible.

### Show the map view

- Connect a mobile device.  
( 77)
- Call up the BMW Motorrad Connected app.
- Call up the **Navigation** menu.

 If the **NAVIGATION** view is selected in the split-screen and the **NAVIGATION** menu is called up, the split-screen view is automatically exited and the navigation display is shown on the whole instrument cluster.

### Enter the destination address

- Connect a mobile device.  
( 77)
- Call up the BMW Motorrad Connected app and start the route guidance.
- Call up the **Navigation** menu.
  - » Active route guidance is displayed.
  - If WiFi is not activated on the mobile device, route guidance is displayed as arrow navigation.
  - » If active route guidance is not displayed, consult the troubleshooting chart in the section entitled "Technical data". ( 252)

### Select destination from recent destinations

- Navigate to **Navigation**, **Recent destinations**.
- Select and confirm destination.
- Select **Start route guidance**.

### Select destination from favourites

- The **FAVOURITES** menu shows all the destinations saved as favourites in the BMW Motorrad Connected app. You cannot use the instrument cluster to add favourites to the list.

- Navigate to Navigation, Favourites.
- Select and confirm destination.
- Select Start guidance.

### Enter special destinations

- Special destinations, such as points of interest, can be displayed on the map.
- Navigate to Navigation, POIs.

The following locations can be selected:

- At current location
  - At destination
  - Along the route
  - Select where the special destinations should be looked for.
- For example, the following special destination can be selected:
- Filling station
  - Select and confirm the special destination.
  - Select Start route guidance and confirm.

### Set route criteria

- Navigate to Navigation, Route criteria.
- The following criteria can be selected:
- Route type
  - Avoid
  - Select desired Route type.

- Switch desired Avoid on or off.

The number of avoidances activated is displayed in brackets.

### View the route information

- Navigate to Navigation, Settings and select Route info.

You can choose between the following options:

- Dest.
- Waypoint
- Select the desired option.
- » Countdown distance and time are displayed.

### Edit route guidance

- Navigate to Navigation, New destination.
- You can choose from the following destinations:
- Recent destinations
  - Favourites
  - POIs
  - Select a destination from one of the three destination categories.
  - Select Change route guidance in the destination entry.
  - Select Add as waypoint to add the selected destination as a waypoint.
  - Select Start guidance to overwrite the current destination.

## 82 INSTRUMENT CLUSTER

### End route guidance

- In menu **Navigation**, tilt the Multi-Controller to the left.
- Alternatively, in menu **Active route guidance**, select and confirm **Option End route guidance**.

### Switching spoken instructions on or off

- Connect the rider's and passenger's helmets. (➡ 78)
- Navigation instructions can be read out. For this purpose, **Spoken instruction** must be switched on.
- Navigate to **Navigation**, **Active route guidance**.
- Switch **Spoken instruction** on or off.

### Repeat last spoken instruction

- Navigate to **Navigation**, **Active route guidance**.
- Select **Current instruction** and confirm.

### Switch Speed Limit Info on or off

#### Requirement

Vehicle is connected to a compatible mobile device. The BMW Motorrad Connected app is installed on the mobile device.

- **Speed Limit Info** shows the maximum speed permitted at the time, if this inform-

ation is made available by the publisher of the map material in the navigation system.

- Navigate to **Settings**, **Display**.
- Switch **Speed Limit Info** on or off.


---

## MEDIA

### Precondition

The vehicle is connected to a compatible mobile device and helmet.

### Controlling music playback



- Call up the **Media** menu.

 BMW Motorrad recommends setting the volume for media and phone calls on the mobile device to maximum before riding off.

- Adjust volume. (➡ 76)
- To select the next track in the player: Short-tilt Multi-Controller **1** to the right.
- To select the preceding track or start of current track:

Short-tilt Multi-Controller **1** to the left.

- Call up context menu: Press bottom section of button **2**.

 Depending on the mobile end device, the scope of Connectivity functions might be restricted.

- » The following functions can be used in the context menu:
- Playback or Pause.
  - Select the Now playing, All artists, All albums or All tracks category for search and playback.
  - Select Playlists.

You can make the following adjustments in the Audio settings submenu:

- Switch Shuffle on or off.
- Select Repeat: Off, One (current track) or All.
- with audio system<sup>OE</sup>
- Select Output device.<
- with audio system<sup>OE</sup>
- Select Sound profile.<
- with audio system<sup>OE</sup>
- Set up Equaliser.<


» If the playlist is not shown on the display, consult the troubleshooting chart in the section entitled "Technical data". (► 252)

## TELEPHONE

### Precondition

The vehicle is connected to a compatible mobile device and helmet.

### Telephone calls



- Call up the Telephone menu.

 When a call is received, a pop-up window opens.

- Accept call: Tilt Multi-Controller **1** to the right.
- Reject call: Tilt Multi-Controller **1** to the left.
- End call: Tilt Multi-Controller **1** to the left.

### Muting

During active phone calls, the microphone in the helmet can be muted.

## 84 INSTRUMENT CLUSTER

### Phone calls with multiple participants

While a phone call is in progress, a second call can be accepted. The first phone call is put on hold. The number of active calls is shown in the Telephone menu. It is possible to switch between two phone calls.

### Telephone data

Depending on the mobile device, when pairing (▶▶ 77) completes telephone data are automatically sent to the vehicle.

Phone book: List of contacts saved on the mobile device

Call list: List of calls with the mobile device

Favourites: List of favourites saved on the mobile device

---

### SOFTWARE VERSION

- Navigate to Settings, Information, Software version.

---

### LICENCE INFORMATION

- Navigate to Settings, Information, Licences.



# OPERATION

# 05

---

|                                                     |            |
|-----------------------------------------------------|------------|
| <b>IGNITION SWITCH/STEERING LOCK</b>                | <b>88</b>  |
| <b>IGNITION WITH KEYLESS RIDE</b>                   | <b>89</b>  |
| <b>EMERGENCY-OFF SWITCH (KILL SWITCH)</b>           | <b>94</b>  |
| <b>INTELLIGENT EMERGENCY CALL</b>                   | <b>94</b>  |
| <b>LIGHTING</b>                                     | <b>97</b>  |
| <b>DYNAMIC TRACTION CONTROL (DTC)</b>               | <b>100</b> |
| <b>ELECTRONIC SUSPENSION ADJUSTMENT (D-ESA)</b>     | <b>101</b> |
| <b>RIDING MODE</b>                                  | <b>102</b> |
| <b>CRUISE CONTROL</b>                               | <b>103</b> |
| <b>DISTANCE CONTROL (ACTIVE CRUISE CONTROL ACC)</b> | <b>106</b> |
| <b>HILL START CONTROL (HSC)</b>                     | <b>112</b> |
| <b>ANTI-THEFT ALARM (DWA)</b>                       | <b>115</b> |
| <b>HEATING</b>                                      | <b>118</b> |
| <b>STORAGE COMPARTMENT</b>                          | <b>121</b> |
| <b>FAVOURITES BUTTONS</b>                           | <b>124</b> |
| <b>CENTRAL LOCKING SYSTEM</b>                       | <b>125</b> |
| <b>CASES</b>                                        | <b>129</b> |

## 88 OPERATION

### IGNITION SWITCH/STEERING LOCK

#### Keys

The motorcycle is supplied with one radio-operated key and one spare key. If a key is lost or mislaid, consult the information on the electronic immobiliser (EWS) (➡ 91).

The following locks are operated with the same key:

- Ignition switch/steering lock
- Cases locks
- Storage-compartment lock
- Fuel filler cap
- Seat lock

- with topcase<sup>OA</sup>
- Topcase

#### Engaging steering lock


- Turn the handlebars all the way to the left.



- Turn the vehicle key to position 1, while moving the handlebars slightly.
  - » Ignition, lights and all function circuits switched off.

- » Handlebars are locked.
- » Vehicle key can be removed.

#### Switching on ignition



- Insert the vehicle key into the ignition switch and turn it to position 1.
  - » Side lights and all function circuits are switched on.
  - » Pre-Ride-Check and self-diagnoses are performed. (➡ 160)

#### Switching off ignition



- Turn the ignition key to position 1.
  - » When the ignition is switched off, the instrument cluster remains switched on for a short

time and displays any existing fault messages.

- » Handlebars not locked.
- » Electrically powered accessories remain operational for a limited period of time.
- » Recharging via the socket in the cockpit is possible.
- » Vehicle key can be removed.
- The daytime riding light goes out soon after the ignition is switched off.

—with additional headlight<sup>OE</sup>

- The LED auxiliary headlights go out soon after the ignition is switched off.◀

## IGNITION WITH KEY-LESS RIDE

### Keys

—with Keyless Ride<sup>OE</sup>

 The indicator light for the radio-operated key flashes while the search for the radio-operated key is in progress.

The light goes out as soon as the radio-operated key or the emergency key is found.

The light goes out briefly if the search times out without the radio-operated key or the emergency key being found.

You receive one radio-operated key and one spare key. If a key is lost or mislaid, consult the

notes on the electronic immobiliser (EWS) (► 91).

Ignition, fuel filler cap and anti-theft alarm system all work with the radio-operated key. Seat lock, storage compartment, topcase and cases are locked and unlocked manually.

 The vehicle cannot be started or the central locking system locked or unlocked if the radio-operated key is not within range (e.g. key inside one of the cases or the topcase).

If the key is out of range, the ignition is switched off after approximately 90 minutes, the central locking system is **not** locked.

It is advisable to keep the radio-operated key on your person (e.g. in a jacket pocket) and to have the spare key with you as an alternative.



Range of the Keyless Ride radio-operated key

approx. 1 m

### Engaging steering lock

—with Keyless Ride<sup>OE</sup>

## 90 OPERATION

### Requirement

The handlebars are turned towards the left. Radio-operated key is within range.



- Press and hold down button **1**.
  - » The steering lock engages with an audible click.
  - » Ignition, lights and all function circuits switched off.
- Short-press button **1** to disengage the steering lock.

### Switching on ignition

—with Keyless Ride<sup>OE</sup>

### Requirement

Radio-operated key is within range.



- There are **two** ways of activating the ignition.

### Version 1:

- Short-press button **1**.
  - » Side lights and all function circuits are switched on.
  - » Daytime riding light is switched on.
    - with additional headlight<sup>OE</sup>
  - » LED auxiliary headlights are switched on.◁
  - » Pre-Ride-Check and self-diagnoses are performed. (160)

### Version 2:

- Steering lock is engaged; press and hold down button **1**.
  - » The steering lock disengages.
  - » Side lights and all function circuits switched on.
  - » Daytime riding light is switched on.
    - with additional headlight<sup>OE</sup>
  - » LED auxiliary headlights are switched on.◁

- » Pre-Ride-Check and self-diagnoses are performed.  
( 160)

### Switching off ignition

—with Keyless Ride<sup>OE</sup>

#### Requirement

Radio-operated key is within range.



- There are **two** ways of deactivating the ignition.

#### Version 1:

- Short-press button **1**.
  - » Light is switched off.
  - » Handlebars (steering lock) are not locked.

#### Version 2:

- Turn the handlebars all the way to the left.
- Press and hold down button **1**.
  - » Light is switched off.
  - » The steering lock engages.

### Electronic immobiliser (EWS)

The on-board electronics access the data saved in the vehicle key via a ring aerial in the R/C ignition lock. The ignition is not enabled for starting until the engine control unit has recognised the vehicle key as "authorised" for your motorcycle.



A second radio-operated key attached to the same ring as the radio-operated key used to start the engine could "irritate" the electronics, in which case the enabling signal for starting is not issued. Always keep the radio-operated keys separate from each other.

If you mislay a vehicle key, you can have the key in question barred by your authorised BMW Motorrad retailer. In order to have a key barred you must bring along all the other keys belonging to the motorcycle.

The engine cannot be started by a barred ignition key, but an ignition key that has been barred can subsequently be reactivated.

You can obtain spare keys only through an authorised

## 92 OPERATION

BMW Motorrad retailer. The ignition keys are part of an integrated security system, so the retailer is under an obligation to check the legitimacy of all applications for replacement/extra keys.

### **Battery of the radio-operated key is empty or loss of the radio-operated key**

—with Keyless Ride<sup>OE</sup>



- If a key is lost or mislaid, consult the notes on the electronic immobiliser (**EWS**) (▮▮▮ 91).
- If you happen to lose or mislay the radio-operated key while on a journey, you can start the vehicle with the spare key.
- If the battery of the radio-operated key is empty, the vehicle can be started by simply bringing the folded radio-operated key close to the ring aerial underneath the instrument cluster.

- Hold radio operated key **1** or the spare key to the left of and below instrument cluster **2**.



Time during which the motor has to be started. The unlocking procedure has to be repeated if this time is allowed to expire.

30 s

- » Pre-Ride-Check is performed.
- Key has been recognised.
- Engine can be started.
- Start the engine. (▮▮▮ 159)

### **Replacing battery of radio-operated key**

—with Keyless Ride<sup>OE</sup>

If the radio-operated key does not react when you short-press or long-press a button:

- Battery of the radio-operated key is not at full capacity.



Remote key battery weak. Function limited. Change battery.

## **DANGER**

### **Swallowing a battery**

Risk of injury or death

- An ignition key contains a button cell as its battery. Batteries or button cells, if swallowed, can cause serious or fatal injury within two hours, for example resulting from internal burns or caustic action.
- Keep ignition keys and batteries out of reach of children.
- If there is any suspicion that a battery or button cell has been swallowed or is inside a part of the body, seek medical assistance immediately.

- Change the battery.



- Press button **1**.
  - » Key bit flips out.
- Push battery cover **2** up.
- Remove battery **3**.

- Dispose of the old battery in accordance with all applicable laws and regulations; do not attempt to dispose of batteries as domestic waste.

## **ATTENTION**

### **Unsuitable or incorrectly inserted batteries**

Component damage

- Use a battery compliant with the manufacturer's specifications.
  - When inserting the battery, always make sure polarity is correct.
- Insert the new battery with the positive terminal up.



Battery type

For Keyless Ride radio-operated key

CR 2032

- Install battery cover **2**.
  - » Indicator light in the instrument cluster flashes.
  - » The radio-operated key is again ready for use.

## 94 OPERATION

### EMERGENCY-OFF SWITCH (KILL SWITCH)



- 1 Emergency-off switch (kill switch)



#### WARNING

##### Operation of the kill switch while riding

Risk of fall due to rear wheel locking

- Do not operate the kill switch when riding.

The emergency off switch is a kill switch for switching off the engine quickly and easily.



- A Engine switched off  
B Normal operating position (run)

### INTELLIGENT EMERGENCY CALL

—with intelligent emergency call<sup>OE</sup>

#### Emergency call via BMW

Press the SOS button in an emergency only.

The emergency call is not able to be ensured because of technical reasons due to unfavourable conditions, e.g. in areas where there is no mobile phone reception.

During an emergency call, the location of the vehicle, the choice of language and, if applicable, accident-related data are transmitted to BMW (11). Under unfavourable conditions, data transfer can be restricted or delayed. This can

lead to delayed processing of the emergency call. Even if an emergency call using BMW is not possible, the system may make an emergency call to a public emergency call number. This depends on the respective mobile phone network and the national regulations.


### Language for emergency call

Each vehicle has a language assigned to it depending on the market for which it is intended. The BMW Call Center answers in this language.


 The language for the emergency call can be changed only by the authorised BMW Motorrad retailer. The language assigned to the vehicle varies from the selectable language the rider can choose as the display language in the instrument cluster.

### Manual emergency call Requirement


An emergency has occurred. The vehicle is at a standstill. The ignition is switched on.




- Open cover **1**.
- Short-press SOS button **2**.



- » The time until transmission of the emergency call is displayed. During that time, it is possible to cancel the emergency call.
- To cancel an emergency call: Press SOS button **2** and hold it down for two seconds or switch the ignition off.
- Operate the emergency-off switch to stop the engine.
- Remove helmet.
- » After expiry of the timer, a voice contact to the BMW Call Center is established.



The connection was established.




- Provide information to the emergency services using the microphone **3** and speaker **4**.

## Automatic emergency call

The intelligent emergency call is active after the ignition is switched on and reacts if a fall or crash occurs.


## Emergency call in the event of a light fall

- A light fall or a crash was detected.
- » An acoustic signal is sounded.




» The time until transmission of the emergency call is displayed. During that time, it is possible to cancel the emergency call.

- To cancel an emergency call: Press the SOS button and hold it down for two seconds, or switch the ignition off.
- If possible, remove helmet and stop engine.
- » After expiry of the timer, a voice contact to the BMW Call Center is established.



The connection was established.



- Open cover **1**.
- Provide information to the emergency services using the microphone **3** and speaker **4**.

### Emergency call in the event of a severe fall

- A severe fall or a crash is detected.
- » The emergency call is placed automatically without delay.

## LIGHTING

### Side light

The side lights switch on automatically when the ignition is switched on.



The side lights place a strain on the battery. Switch on the ignition for a limited time only.

### Low-beam headlight

- Switch on the ignition. (▶▶▶ 88)
- Start the engine. (▶▶▶ 159)



- Alternatively: With the ignition switched on, pull switch **1**.

### High-beam headlight and headlight flasher

- Switch on the ignition. (▶▶▶ 88)



- Push switch **1** forward to switch on the high-beam headlight.
- Pull switch **1** back to operate the headlight flasher.



The high-beam headlight can also be switched on when the engine is not running.

## 98 OPERATION

### Headlight courtesy delay feature

- Switch off the ignition.  
( 88)



- Immediately after switching off the ignition, pull switch **1** back and hold it in that position until the headlight courtesy delay feature comes on.
  - » The vehicle's lights come on for one minute and then switch off automatically.
  - This can be used to light up the path to the house door after the vehicle has been parked, for example.

### Parking lights

- Switch off the ignition.  
( 88)



- Immediately after switching off the ignition, push button **1** to the left and hold it in that position until the parking lights come on.
- Switch the ignition on and off again to switch off the parking lights.

### Auxiliary headlights

–with additional headlight<sup>OE</sup>

#### Requirement

The low-beam headlight must be switched on.



The auxiliary headlights are approved as fog lights and can be used only in poor weather conditions. Always comply with the road traffic regulations in force in the country in which the vehicle is used.



- Press button **1** to switch on the auxiliary headlights.



shows.

- Press button **1** again to switch off the auxiliary headlights.

### Automatic daytime riding light



#### WARNING

**The automatic daytime riding light is not a substitute for the rider's personal judgement of the light conditions**

Risk of accident

- Switch off the automatic daytime riding light in poor light conditions.



#### WARNING

**Switching on the daytime riding light in the dark.**

Risk of accident

- Do not use the daytime riding light in the dark.



By comparison with the low-beam headlight, the daytime riding light makes the vehicle more visible to oncoming traffic. This improves daytime visibility.



The changeover between daytime riding light and low-beam headlight including front side lights can be effected automatically.

- Switch on the ignition.  
(→ 88)
- Call up the Settings menu and then select **Vehicle settings**.
- Select **Lights** and switch on **Auto. daytime light**.



is displayed.

» If the ambient brightness decreases below a certain value (e.g. in a tunnel) while the daytime riding light function is active, the low-beam headlight is automatically switched on. When sufficient ambi-

# 100 OPERATION

ent brightness is detected, the daytime riding light is switched back on.



shows.

## Hazard warning lights

- Switch on the ignition.

( 88)

 The hazard warning flashers place a strain on the battery. Do not use the hazard warning flashers for longer than absolutely necessary.



- Press button **1** to switch on the hazard warning lights system.

» Ignition can be switched off.

- To switch off the hazard warning lights system, switch on the ignition if necessary and press button **1** again.

## Turn indicators

- Switch on the ignition.

( 88)

- Navigate to **Settings**, **Vehicle settings** and select **Lights**.
- Switch **Comfort turn indicator** on or off.



- Push button **1** to the left or right, as appropriate, to switch on the turn indicators.
  - » If the comfort turn indicators function is switched on, the turn indicators are cancelled automatically when the speed-dependent distance is covered.
- Alternatively: Press button **1** to cancel the turn indicators.

---

## DYNAMIC TRACTION CONTROL (DTC)

### Switching DTC function off and on

- Switch on the ignition.  
( 88)
- Navigate to **Settings**, **Assist** and select **DTC**.
- Deactivate **DTC** to switch off Dynamic Traction Con-

trol (DTC) temporarily until the next time the ignition is switched on.



shows.

- Activate DTC to switch on Dynamic Traction Control (DTC). Alternatively: Switch ignition off and on again.



goes out, if self-diagnosis has not completed the DTC indicator and warning light starts flashing.

- For more information on Dynamic Traction Control (DTC) see the section entitled "Engineering details" (180).

## ELECTRONIC SUSPENSION ADJUSTMENT (D-ESA)

—with Dynamic ESA<sup>OE</sup>

### Possibilities for adjustment, Dynamic ESA

Dynamic ESA is an electronic system that enables your motorcycle's suspension to adjust automatically to suit the load the vehicle is carrying. For more information on Dynamic ESA see the section headed "Engineering details" (185).

### Adjusting suspension damping

- Switch on the ignition. (88)
- Navigate to **Settings, Assist** and select **Damping**.
- Select the desired suspension-damping setting.



You can adjust the damping characteristic while the motorcycle is on the move.



The suspension-damping setting is retained, even after the ignition is switched off.

### Adjusting for loaded state

- Start the engine. (159)
- Navigate to **Settings, Assist** and select **Load**.
- Select the desired loaded-state setting.



The load setting is retained, even after the ignition is switched off.



The load cannot be set while the motorcycle is in motion.

The following message is displayed if no load setting is possible: **Action not possible. Engine must be on.**

The following message is displayed if no load setting is possible because speed

## 102 OPERATION

is too high: Action not possible. Speed too high.

### RIDING MODE

#### Use

BMW Motorrad has developed operational scenarios for your motorcycle from which you can select the scenario suitable for your situation:

- ECO: Range-optimised riding.
- RAIN: Riding on rain-wet roads.
- ROAD: Riding on dry roads.
- with riding modes Pro<sup>OE</sup>
- DYNAMIC: Dynamic riding on dry roads.

The optimum interplay of engine characteristic and DTC control is provided for each of these scenarios.

–with Dynamic ESA<sup>OE</sup>

The chassis and suspension setting also adapts to the selected scenario.

For more information on the selectable riding modes see the section entitled "Engineering details" (186).

#### Setting riding mode

- Switch on the ignition.  
(88)



- Press button 1.



The riding mode currently active **2** is sent to the back and is displayed in the pop-up **3**. The guide **4** indicates how many riding modes are available.



- Repeatedly press button **1** until the riding mode you want is displayed.
- » With the motorcycle at a standstill, the selected mode is activated after approximately two seconds.
- » The following conditions must be satisfied for activation of a new riding mode while riding:
  - Throttle grip is in idle position.
  - Brake is not applied.
- » The riding mode selected in this way is retained, with the engine-characteristic and DTC adaptation settings, even after the ignition has been switched off.

## CRUISE CONTROL

### Switching on cruise control Requirement

DTC is switched on and ABS is active.




## WARNING

### Use of cruise control in unsuitable road conditions


Risk of falling

- Do not use cruise control when road conditions are unsuitable, for example in snow, ice, heavy rain, off-road or on slippery surfaces.
- Do not use cruise control on very twisty stretches of road.



- Slide switch **2** to the right.
- » Button **1** is enabled for operation.

### Setting road speed



- Short-push button **1** forward.

## 104 OPERATION

 Cruise control can also actuate the brake.



Adjustment range for cruise control (gear-dependent)

15...220 km/h



is displayed.

» The motorcycle maintains your current cruising speed and the setting is saved.

### Accelerating

 Depending on the speed unit set in the instrument cluster, the speed is increased or reduced in km/h or mph.



- Short-push button **1** forward.
  - » Speed is increased by approx. 1 km/h or 1 mph, as applicable, each time you push the button.
- Push button **1** forward and hold it in this position.

» Speed is increased in steps of 10 km/h or 5 mph, as applicable.

» The current speed is maintained and saved if button **1** is not pushed again.

### Decelerating

 Depending on the speed unit set in the instrument cluster, the speed is increased or reduced in km/h or mph.



- Short-push button **1** back.
  - » Speed is reduced by 1 km/h or 1 mph, as applicable, each time you push the button.
- Push button **1** back and hold it in this position.
  - » Speed is reduced in steps of 10 km/h or 5 mph, as applicable.
  - » The current speed is maintained and saved if button **1** is not pushed again.

### Deactivating cruise control

- Apply the brake or turn the throttle grip back past the idle position to deactivate cruise control.

 Cruise control is deactivated if the clutch is pulled for longer than 1.5 seconds.

» A message appears on the display.


### Automatic deactivation

Adaptive cruise control is deactivated automatically in the following situations:

- When engine speed drops below the minimum threshold (to prevent stalling).
- After several seconds when the vehicle is ridden at maximum engine speed.
- During ABS or DTC interventions.
- If a system fault occurs.

If adaptive cruise control experiences automatic deactivation, a message to this effect is displayed.

### Resuming former cruising speed



- Short-push button **1** back to return to the speed saved beforehand.

 Opening the throttle overrides cruise control briefly, without deactivating it. When the throttle twistgrip is released, speed drops back to the setting saved beforehand. If you want to reduce speed further you have to deactivate cruise control, for example by applying the brakes.



is displayed.

## 106 OPERATION

### Switching off cruise control



- Slide switch **2** to the left.  
» The system is deactivated.



disappears.

- » Button **1** is disabled.

### Configure the character of cruise control

- Switch on the ignition.  
( 88)
- Navigate to Settings, Assist and select Cruise control.
- Select ACC characteristics.
- Select the desired setting.  
» The following settings for acceleration and deceleration are possible:
  - Comfortable: Balanced acceleration and deceleration of the vehicle.
  - Dynamic: More sharply pronounced acceleration and deceleration of the vehicle for a more dynamic style of riding.

### DISTANCE CONTROL (ACTIVE CRUISE CONTROL ACC)

—with Active Cruise Control<sup>OE</sup>

### Safety information



#### WARNING

**ACC does not relieve the motorcyclist of their responsibility to ride safely**

Risk of accident due to misjudgement by the system

- ACC is a rider assistance system and not a safety system. The responsibility for correctly gauging visibility conditions and the traffic situation and intervening accordingly resides with you.

**WARNING****ACC cannot react to all objects and traffic situations**

Risk of accident

- ACC reacts only to the vehicle travelling ahead of you. This means that for example pedestrians, animals and oncoming vehicles are not detected. Cyclists cannot be reliably detected.
- A vehicle cutting into your lane ahead of you cannot be used as a control-intervention object until after a plausibility check in the radar. Consequently, a late and sharp application of the brakes can occur or the brakes might not be applied.
- Keep the traffic conditions under observation at all times and intervene actively whenever the situation requires.

**WARNING****ACC is not functional in certain situations**

Risk of accident due to non-application of the brakes and prompt to assume control

- The radar requires a clear viewing panel for object detection to work well. Object detection is restricted in heavy rain, fog or snow and also if the radar sensors are dirty or obstructed.
- Object detection can be disrupted by environmental influences such as strong reflections and electromagnetic disturbances.
- If the vehicle is involved in an accident or experiences an impact with an object or is dropped, the installed position of the radar sensor has to be checked.
- Keep the traffic conditions under observation at all times and intervene actively whenever the situation requires.



## WARNING

**ACC cannot detect all objects and traffic situations or interpret them correctly**

Risk of accident

- ACC might not be able to detect certain objects or complex traffic situations correctly, with the result that it does not issue a warning or slow the vehicle appropriately, or that it issues an incorrect warning and initiates inappropriate slowing of the vehicle. You have to apply the brakes yourself, for example when you come on the scene of an accident or approach a vehicle stopped at traffic lights or in congestion.
- Object detection can be restricted, for example in intersecting traffic, on twisting or hilly roads and when you ride offset from the vehicle ahead in your lane or if you weave from side to side in the lane.
- Keep the traffic conditions under observation at all times and intervene actively whenever the situation requires.



## WARNING

**ACC cannot compensate for excessive speed differences**

Risk of accident

- ACC cannot perform emergency braking. Retardation and the rate at which retardation increases are limited.
- High speed differences, for example when you come up fast behind a truck or when another vehicle cuts into your lane ahead of you, cannot be compensated for by the system.
- When the adjustment range of ACC is exceeded, object detection might be delayed on account of the high speed. Consequently, increased rider caution is required in these circumstances.
- Keep the traffic conditions under observation at all times and intervene actively whenever the situation requires.

**WARNING****ACC can lose sight of an object detected beforehand**

Risk of accident

- When ACC incorrectly deselects a detected object, the motorcycle accelerates back up to the road speed set beforehand. This can be the case in bends, for example.
- Keep the traffic conditions under observation at all times and intervene actively whenever the situation requires.

**WARNING****ACC cannot slow the vehicle sufficiently when the vehicle corners at high speed**

Risk of accident

- The cornering regulator reduces road speed when distance control is active and the bank angle is excessive. If a vehicle is detected ahead, retardation of the vehicle is built up more slowly while the motorcycle is banked.
- Ride at a correspondingly lower speed.

**ATTENTION****ACC might incorrectly detect certain objects and traffic situations**

Risk of injury due to unexpected brake intervention

- ACC might issue an unjustified warning and brake without justification in reaction to certain objects and complex traffic situations. For example a narrowed traffic lane (roadworks) or objects in the air (e.g. a bouncing ball or a plastic bag) can lead to a warning being issued or the brakes being applied by ACC.
- Keep the traffic conditions under observation at all times and intervene actively whenever the situation requires.



When riding in other countries, always comply with the country-specific regulations on the operation of radar sensors. If the radar sensor does not have the licence required by a particular country's laws, the radar sensor has to be disconnected. It is best to consult an authorised BMW Motorrad retailer.

# 110 OPERATION

## Toggle between cruise control and ACC

- Comply with the safety instructions (➡ 106).
- Switch on the ignition. (➡ 88)



### WARNING

#### Reduced assistance after changeover to cruise control

Risk of accident

- By contrast with ACC, cruise control does not react to traffic ahead. Instead, it matches the vehicle's road speed to the setting selected by the rider.
  - Keep the traffic conditions under observation at all times and intervene actively whenever the situation requires.
- Navigate to Settings, Assist, select Cruise control.
  - Activate or deactivate ACC.



- Alternatively, long-press button 1.

» This toggles between cruise control and ACC.

- Bear in mind the information on automatic deactivation (➡ 105).
- For more information on distance control with Active Cruise Control (ACC) see the section entitled "Engineering details" (➡ 182).

## Operating ACC Requirement

ACC is activated.

- Comply with the safety instructions (➡ 106).
- Switch on cruise control. (➡ 103)



is greyed.

- Set the road speed. (➡ 103)



At speeds above its adjustment range 30...160 km/h, the system

regulates to the maximum speed of 160 km/h.



- To switch on: Short-press button **1**.
  - » ACC is switched on.
  - » The approach distance you set appears briefly on the display.
- To switch off: Toggle to cruise control or switch off cruise control.
- Bear in mind the information on automatic deactivation (▮▮▮▮▶ 105).
- For more information on distance control with Active Cruise Control (ACC) see the section entitled "Engineering details" (▮▮▮▮▶ 182).

### Status indicators showing in the instrument cluster

When ACC is in operation, the following symbols can appear in the instrument cluster:

### Indicator lights

» No object detected:



shows green.

» Object detected:



shows green.

» Rider overrides by twisting the throttle grip to open the throttle:



shows green.

### Warning lights

» ACC switched off for system-related reason:



is displayed in red.

» A hazardous situation has been detected and cannot be averted.



flashes red.

If a warning light shows in the instrument cluster:

- Intervene actively to avert potential danger.

# 112 OPERATION

## Setting approach distance



- Short-press button 1.
  - » The approach distance you set appears briefly on the display.



### WARNING

#### Selected approach distance is too short for the riding situation

Risk of accident

- Adapt your approach distance to suit traffic and weather conditions.
  - Comply with the safety distance required by law.
- Repeatedly short-press button 1 until the approach distance you want is set.
    - » The following settings are available:



Short approach distance



Medium approach distance



Long approach distance

- » When the ACC detects a vehicle travelling in front, a depiction of a car appears in the symbol shown here to alert the rider.
- » The approach-distance setting is retained in memory, even after the ignition is switched off.

## HILL START CONTROL (HSC)

### Activating and deactivating Hill Start Control

- Switch on the ignition.  
( 88)
- Navigate to Settings, Assist and activate or deactivate Hill Start Control.



Symbol 1 for Hill Start Control is displayed in the Pure Ride view and in the top status line.

## Operating Hill Start Control Requirement

Vehicle stationary and upright, engine running.



### ATTENTION


#### Non-availability of Hill Start Control

Risk of accident

- Apply the brakes manually to hold the vehicle.



Hill Start Control is purely a comfort system that facilitates hill starts and consequently, is not to be confused with a parking brake.



- Apply firm pressure to handbrake lever **1** or to the footbrake lever and then quickly release the lever.



shows green.

- » Hill Start Control is activated.
- To switch off Hill Start Control, operate handbrake

lever **1** or the footbrake lever again.



disappears.

- Alternatively, ride off in 1st or 2nd gear.



Hill Start Control is deactivated automatically when the motorcycle pulls away.



disappears as soon as the brake is fully released.

- » Hill Start Control is deactivated.
- For more information on Hill Start Control see the section headed "Engineering details" (191).

## Operating Hill Start Control Pro

—with riding modes Pro<sup>OE</sup>

### Requirement

Vehicle stationary and upright, engine running.



### ATTENTION

#### Non-availability of Hill Start Control

Risk of accident

- Apply the brakes manually to hold the vehicle.




Hill Start Control Pro is purely a comfort system that facilitates hill starts and

## 114 OPERATION

consequently, is not to be confused with a parking brake.

 Hill Start Control Pro should not be used on gradients steeper than 40 %.



- Apply firm pressure to handbrake lever **1** or to the footbrake lever and then quickly release the lever.
- Alternatively, apply the brake for about one second beyond the vehicle reaching a standstill on an incline of at least 3 %.

 shows green.

» Hill Start Control Pro is activated.

- To switch off Hill Start Control Pro, operate handbrake lever **1** or the footbrake lever again.

 If Hill Start Control Pro has been deactivated by means of the handbrake lever,

automatic Hill Start Control is deactivated for the next 4 m.

 is displayed in white.

- Alternatively, ride off in 1st or 2nd gear.

 Pulling away from rest with the throttle grip turned to open the throttle automatically deactivates Hill Start Control Pro.

 disappears as soon as the brake is fully released.

» Hill Start Control Pro is deactivated.

- For more information on Hill Start Control Pro see the section headed "Engineering details" (191)

### Adjust Hill Start Control Pro

—with riding modes Pro<sup>OE</sup>

- Switch on the ignition.  
(88)
- Navigate to *Settings, Assist* and select *HSC Pro*.
- To switch off Hill Start Control Pro, select *Off*.
- » Hill Start Control Pro is deactivated.
- To switch on manual Hill Start Control Pro, select *Manual*.
- » Hill Start Control Pro can be activated by forcefully oper-

ating the handbrake or foot-brake lever.

- To switch on automatic Hill Start Control Pro, select *Auto*.
- » Hill Start Control Pro can be activated by forcefully operating the handbrake or foot-brake lever.
- » If the brake is actuated for approximately one second after the vehicle has come to a standstill and the motor-cycle is on a gradient of at least 3 %, Hill Start Control Pro is automatically activated.
- » The selected setting remains stored even after the ignition is switched off.


## ANTI-THEFT ALARM (DWA)

—with anti-theft alarm (DWA)<sup>OE</sup>

### Activation

- Switch on the ignition.  
( 88)
- Adapt DWA. ( 118)
- Switch off the ignition.  
( 88)
- » If the anti-theft alarm system (DWA) is activated, the alarm system is armed automatically when you switch the ignition off.
- » Activation takes approximately 30 seconds to complete.
- » Turn indicators flash twice.

- » Confirmation tone sounds twice (if programmed).
- » Anti-theft alarm (DWA) is active.
- with central locking system<sup>OE</sup>
- or
- with Keyless Ride<sup>OE</sup>




- Switch off the ignition.  
( 88)
- Press button **1** of the remote control or radio-operated key twice.



See also the other functions of the remote control for the central locking system.

- » Activation takes 30 seconds to complete.
- » Turn indicators flash twice.
- » Confirmation tone sounds twice (if programmed).
- » Anti-theft alarm (DWA) is active.◁

## 116 OPERATION



- To deactivate the tilt sensor (for example if you are about to transport the motorcycle on a train and the swaying movement of the moving train could trip the alarm), press button **1** on the remote control or the radio-operated key again during the activation phase.
  - » Turn indicators flash three times.
  - » Confirmation tone sounds three times (if programmed).
  - » Tilt sensor is deactivated.

### Alarm signal

A DWA alarm can be triggered by:

- Tilt sensor
- Switch-on attempt with an ignition key.
- Disconnection of the DWA anti-theft alarm from the motorcycle's battery (DWA internal battery in the anti-theft alarm provides power –


acoustic alarm only, the turn indicators do not flash).

 When the radio-operated key is within range, an alarm triggered by the tilt alarm sensor is suppressed.

All functions are sustained even if the internal battery of the DWA anti-theft alarm system is flat; the only difference is that an alarm cannot be triggered if the system is disconnected from the vehicle's battery.

An alarm lasts for approximately 26 seconds. While an alarm is in progress an alarm tone sounds and the turn indicators flash. The type of acoustic alarm tone can be set by an authorised BMW Motorrad retailer.

- with central locking system<sup>OE</sup>  
or
- with Keyless Ride<sup>OE</sup>



An activated alarm can be cancelled at any time by pressing button **2** of the remote control or radio-operated key without deactivating the DWA.

If an alarm was triggered while the motorcycle was unattended, the rider is notified accordingly by an alarm tone sounding once when the ignition is switched on. The indicator light in the instrument cluster then signals the reason for the alarm for one minute.


### Light signals issued by the indicator light:

- Flashes 1x: Tilt sensor 1
- Flashes 2x: Tilt sensor 2
- Flashes 3x: Ignition switched on with unauthorised key
- Flashes 4x: Disconnection of the DWA anti-theft alarm from the motorcycle's battery

- Flashes 5x: Tilt sensor 3

### Deactivation

- Switch on the ignition.  
( 88)
- » Turn indicators flash once.
- » Confirmation tone sounds once (if programmed).
- » DWA is switched off.
- with central locking system<sup>OE</sup>  
or
- with Keyless Ride<sup>OE</sup>



- Press button **1** on the remote control or the radio-operated key once.

- If the alarm function is deactivated by the radio-operated key and the ignition is not subsequently switched on, the alarm function is automatically reactivated after approx. 30 seconds if *Arm automatically* is switched on.
- » Turn indicators flash once.
- » Confirmation tone sounds once (if programmed).
- » DWA is switched off.◀

# 118 OPERATION

## Adapt DWA

- Switch on the ignition.  
( 88)
- Navigate to Settings, Vehicle settings and select Alarm system.  
» The following adaptation settings are available:
  - Adapting Warning signal
  - Switch Tilt sensor on or off
  - Switch Arming tone on or off
  - Switch Arm automatically on or off

## Possibilities for adjustment

**Warning signal:** Set the rising and falling or intermittent alarm tone.

**Tilt sensor:** Activate tilt sensor to monitor the inclination of the vehicle. The DWA anti-theft alarm is tripped if any attempt is made to steal a wheel or lift the vehicle for towing, for example.

 When the vehicle is going to be transported, deactivate the tilt sensor to prevent the anti-theft alarm (DWA) from being triggered.

**Arming tone:** In addition to turn indicators flashing, alarm tone sounds as confirmation of

activation/deactivation of the DWA.

**Arm automatically:** Automatic activation of the alarm function after the ignition is switched off.

---


## HEATING

### Operating heated handlebar grips

 The heating in the heated handlebar grips can be activated only when the engine is running.


 The increase in power consumption caused by having the heated handlebar grips switched on can drain the battery if you are riding at low engine speeds. If the charge level is low, the heated handlebar grips are switched off to ensure the battery's starting capability.

- Start the engine. ( 159)
- Navigate to Settings, Heating and select Grip heating.



The grips have five-stage heating. Stage five is for heating the grips quickly: it is advisable to switch back to a lower stage as soon as the grips are warm.

- Select the desired heating stage.




Selected heating stage **1** and seat-heating symbol **2** are displayed.

### Operate the rider's seat heating

—with seat heating<sup>OE</sup>


 Seat heating can be activated only when the engine is running.

- Start the engine. (159)
- Navigate to Settings, Heating and select Seat heating.



The rider's seat has five-stage heating. Stage five is for heating the seat quickly: it is advisable to switch back to a lower stage as soon as the seat is warm.

- Select the desired heating stage.



Selected heating stage **1** and seat-heating symbol **2** are displayed.

## 120 OPERATION

### Operating passenger-seat heating

—with seat heating<sup>OE</sup>

 Seat heating can be activated only when the engine is running.

- Start the engine. (159)




- Set switch **1** to the desired heating stage.



The rear seat has two-stage heating. Stage two is for heating the seat quickly: it is advisable to switch back to stage one as soon as the seat is warm.

- 2** Switch centred: Heating off.

- 3** Switch pressed at one dot: low heating power.
- 4** Switch pressed at two dots: high heating power.



Selected heating stage **1** and seat-heating symbol **2** are displayed.

## STORAGE COMPARTMENT

### Using left storage compartment



#### ATTENTION

#### High temperatures in the storage compartments, particularly in summer

Damage to objects stowed away, particularly electronic devices, such as mobile phones

- In summer, do not place heat-sensitive items in the storage compartment.
- Ask the manufacturer about possible usage restrictions and comply with the information provided.



#### ATTENTION

#### Vibrations when vehicle is moving

Damage to mobile phones carried on the vehicle

- Make sure that the mobile phone carried on the vehicle is suitable for use on the vehicle. Ask the manufacturer about related usage restrictions and comply with the information provided.

—with central locking system<sup>OE</sup>

- To open the lid, push the unlocked lock barrel down.◁



- Use the ignition key to open or close lock **1** of the storage compartment.
- To open the lid, push the unlocked lock barrel down.

### Using right storage compartment

—with comfort telephony with extended smartphone connectivity<sup>OE</sup>

## ATTENTION

### High temperatures in the storage compartments, particularly in summer

Damage to objects stowed away, particularly electronic devices, such as mobile phones

- In summer, do not place heat-sensitive items in the storage compartment.
- Ask the manufacturer about possible usage restrictions and comply with the information provided.

## ATTENTION

### Vibrations when vehicle is moving

Damage to mobile phones carried on the vehicle

- Make sure that the mobile phone carried on the vehicle is suitable for use on the vehicle. Ask the manufacturer about related usage restrictions and comply with the information provided.



- Use the ignition key to open or close lock **1** of the storage compartment.
- To open the lid, push the unlocked lock barrel down.

—with central locking system<sup>OE</sup>

- To open the lid, push the unlocked lock barrel down.◁

### Inductive charging

—with comfort telephony with extended smartphone connectivity<sup>OE</sup>



### Notes on use

The wireless charging pad **1** in the storage compartment on the right enables inductive charging of a smartphone

that supports this function. Alternatively, you can also charge a smartphone via the USB-charging interface **2** which takes priority over inductive charging.

### Dimensions

The storage compartment is suitable for smartphones up to max. 162 mm x 78 mm x 8.8 mm in size. If charging takes place via the USB charging interface, the size is decreased due to the cable connector.

### Charge current

This is a 5 V USB charging interface that provides a maximum charge current of 2.1 A (maximum charging power 10.5 W).

The wireless charging pad is a charging interface that provides a maximum charge current of 1 A (maximum charging power 5 W) at a charge voltage of 5 V.

### Ventilation

To ensure adequate circulation of air, a fan is switched on if the temperature in the storage compartment rises above 35 °C. While charging is in progress, the ventilation is

switched on at a temperature of 30 °C in the storage compartment.

### Charging smartphone

–with comfort telephony with extended smartphone connectivity<sup>OE</sup>

### Requirement

Ignition on.



- Pull clamping slider **2** to the rear.
- Lay the smartphone, display up, in the storage compartment.

 If protective covers are used on the smartphone, the charging capacity may be limited due to the increased distance to the charging platform.

- » Indicator light **1** shows steady green.
- The smartphone is charging.
- Push pin **3** beside clamping slider **2** to the left.
- » The smartphone is secured.

## 124 OPERATION

### Removing smartphone

—with comfort telephony with extended smartphone connectivity<sup>OE</sup>



- Pull clamping slider **2** to the rear.
- Pull tab **1** up to facilitate removal of smartphone **3**.

### Status indicator light

—with comfort telephony with extended smartphone connectivity<sup>OE</sup>

The meanings of the indicator light colours are as follows:

—Slowly flashing green: Ready for charging.

 The indicator light flashes for 5 seconds after the ignition is switched on.

—Continuous green light: Inductive charging or charging via USB in progress or completed.

—Fast yellow flashing: Excess temperature or obstructive

foreign object on the charging platform.

—Slowly flashing red: Failure of the fan.

—Continuous red light: General fault.

If a malfunction is present, charging is not possible. Have malfunctions rectified by a specialist workshop, preferably an authorised BMW Motorrad retailer.

## FAVOURITES BUTTONS

### Operating favourites buttons



Individual functions can be assigned to the favourites buttons.

- Light pressure on a button.
  - » The assigned function is displayed in the instrument cluster.
- Firm pressure on a button.
  - » The function assigned to the button is performed.

### Assigning functions

- Navigate to Settings, System settings, Favourite button.
  - Select a favourites button from Favourite button 1 to Favourite button 4.
  - Select the desired function or Not assigned.
- » The function is assigned to the selected favourites button.

## CENTRAL LOCKING SYSTEM

### Locking

—with central locking system<sup>OE</sup>



- Switch on the ignition and press button **1**.

 A separate remote control for central locking and the anti-theft alarm system is only included in vehicles without Keyless Ride.

- Alternatively: Press button **2** on the remote control or the radio-operated key.
- » The storage compartments and the cases are locked.

—with topcase<sup>OA</sup>

- » The topcase is locked.<
- » These locks cannot subsequently be unlocked manually.



is displayed.

—with anti-theft alarm (DWA)<sup>OE</sup>

- Note the information on the functions of the remote control for the anti-theft alarm in the section entitled "Operation".<

### Unlocking

—with central locking system<sup>OE</sup>



- Switch on the ignition and press button **1**.
  - Alternatively: Press button **2** on the remote control or the radio-operated key.
- » The storage compartments and the cases are unlocked.
- with topcase<sup>OA</sup>

- » The topcase is unlocked.<
- » Once a lock has been locked manually it subsequently has

## 126 OPERATION

to be unlocked manually as well.

- with anti-theft alarm (DWA)<sup>OE</sup>
- Note the information on the functions of the remote control for the anti-theft alarm in the section entitled "Operation".◁

### Emergency unlocking

- with central locking system<sup>OE</sup>

Proceed as follows to manually open cases and topcase if it is no longer possible to unlock the central locking system:

- Remove the cases. (►► 130)
- Open the case. (►► 129)



- First turn the key in the topcase lock 45° past the **LOCK** position, then turn it to the dot position and press in the lock barrel.
  - » The release lever pops open.

### Logging on the remote control

- with central locking system<sup>OE</sup>
- with anti-theft alarm (DWA)<sup>OE</sup>
- without Keyless Ride<sup>OE</sup>

If you intend to replace a lost remote control or use an additional remote control, you must always log on all remote controls.

- Proceed as follows to log on the remote controls:
- Switch on the ignition.  
(►► 88)



- Press button **2** on the remote control three times.
  - » One acoustic signal sounds.
- Switch off the ignition within ten seconds.

You can now log on the remote controls.

- Complete the following steps for each remote control:




- Press and hold down buttons **1** and **2**.
    - » LED **3** flashes for approximately ten seconds.
  - When LED **3** stops flashing, release buttons **1** and **2**.
    - » LED **3** lights up.
  - Press button **1** or button **2**.
    - » One acoustic signal sounds and LED **3** goes out.
- Proceed as follows to complete logon:
- Switch off the ignition.
    - (III 88)
    - » Three acoustic signals sound.
    - » Logon is also ended in the following situations:
      - 4 remote control units have been logged on.
      - No button pressed within approximately 30 seconds of logon on the first remote control.

### Synchronising remote controls

- with central locking system<sup>OE</sup>
- with anti-theft alarm (DWA)<sup>OE</sup>
- without Keyless Ride<sup>OE</sup>

If the central locking system stops responding to the signals from a remote control, the unit in question has to be synchronised. This can happen, for example, if the buttons on the remote control were pressed too frequently while the remote control was out of range of the anti-theft alarm ( DWA).

- The procedure for synchronising the remote controls is as follows:
- Switch on the ignition.
  - (III 88)



- Press and hold down buttons **1** and **2**.
  - » LED **3** flashes for approximately ten seconds.
- When LED **3** stops flashing, release buttons **1** and **2**.
  - » LED **3** lights up.

## 128 OPERATION

- Press button **1** or button **2**.  
» One acoustic signal sounds and LED **3** goes out.

### Replacing battery of remote control

- with central locking system<sup>OE</sup>
- with anti-theft alarm (DWA)<sup>OE</sup>
- without Keyless Ride<sup>OE</sup>

#### DANGER

##### Swallowing a battery

Risk of injury or death

- An ignition key contains a button cell as its battery. Batteries or button cells, if swallowed, can cause serious or fatal injury within two hours, for example resulting from internal burns or caustic action.
- Keep ignition keys and batteries out of reach of children.
- If there is any suspicion that a battery or button cell has been swallowed or is inside a part of the body, seek medical assistance immediately.

If you press a button on the remote control and the LED does not show or lights up only briefly:

- Replace the battery of the remote control.



- Open battery-compartment cover **1**.
- Dispose of the old battery in accordance with all applicable laws and regulations; do not attempt to dispose of batteries as domestic waste.

#### ATTENTION

##### Unsuitable or incorrectly inserted batteries

Component damage

- Use a battery compliant with the manufacturer's specifications.
  - When inserting the battery, always make sure polarity is correct.
- 
- Insert the new battery with the positive terminal up.




Battery type

For remote control of central locking

CR 1632

- » The LED on the remote control lights up, indicating that the remote control has to be synchronised.



- Press button **1** twice.
- » LED **3** flashes for a few seconds.
- » The remote control is again ready for use.

## CASES

### Opening cases

—with central locking system<sup>OE</sup>

- If necessary, unlock the central locking system.◁



- Turn the key in the case lock to the dot position and remove the key from the lock.



- Press lock barrel **1** down.
- » Release lever **2** pops up.
- Pull release lever **2** all the way up and open the case lid.

## 130 OPERATION

### Closing cases



- Pull release lever **2** all the way up.
- Close the lid of the case and press it down. Check that nothing is trapped between the lid and the case.

 The cases can also be locked by turning the lock to the **LOCK** position. In this case, ensure that the vehicle key is not left in the cases.

- Push release lever **2** down until it engages.
- Turn the key in the case lock to the **LOCK** position and remove the key from the lock.

### Removing cases




- Turn the key to the **RELEASE** position in the case lock.  
» The handle pops out.



- Pull carry handle **3** up as far as it will go.  
» The case is released and can be removed.

### Installing cases

- Pull the carry handle up as far as it will go.



- Seat the case in holders **4**.



- Push carry handle **3** down until it engages.
- Turn the key in the case lock to the **LOCK** position and remove the key from the lock.

### Maximum payload and maximum speed

Note the maximum payload and the maximum permissible speed.

The values for the combination described here are as follows:

|                                                                                     |                                             |
|-------------------------------------------------------------------------------------|---------------------------------------------|
|  | Maximum speed for riding with a loaded case |
| max. 180 km/h                                                                       |                                             |

|                                                                                   |                  |
|-----------------------------------------------------------------------------------|------------------|
|  | Payload per case |
| max. 10 kg                                                                        |                  |

# AUDIO SYSTEM

06

---

|                                 |            |
|---------------------------------|------------|
| <b>RADIO</b>                    | <b>134</b> |
| <b>AUDIO SETTINGS</b>           | <b>136</b> |
| <b>PLAYER</b>                   | <b>138</b> |
| <b>SATELLITE RADIO</b>          | <b>138</b> |
| <b>HD RADIO RECEPTION</b>       | <b>140</b> |
| <b>IN-HELMET AUDIO PLAYBACK</b> | <b>141</b> |

## RADIO

## Starting

- Switch on the ignition.

 The radio menu becomes available shortly after the ignition is switched on.

### Switch the radio on and off

- Call up the Radio menu and switch Radio on or off.  
» When the radio is switched off, Radio off appears in the bottom status line.

## Selecting source

- without Canada export<sup>NV</sup>
  - Call up the Source menu. Select Favourites, AM, FM or DAB (might not be available, depending on country).◀
- with Canada export<sup>NV</sup>
  - Select the Source menu. Select Favourites, AM, FM or SiriusXM. For the AM and FM wavebands you have the option of selecting HD Radio (might not be available, depending on country).◀

### Selecting station

- Select the source. (▶ 134)
- Select the FM stations menu.


 There is a channel menu for each selectable source.



- Select the source. (134)
- Select the FM stations menu.

 There is a channel menu for each selectable source.

 For HD Radio stations, the subprograms can be selected via the channel list.◀



- Turn Multi-Controller **1** in direction **A** or **B** to browse through the stations.
- Push the Multi-Controller to the right to select the station you want.

## Selecting frequency

- Call up the Source menu and select AM or FM.
- In the AM options or FM options menu, go to Search selection and


select the **Frequency** setting.

- Switch to the player.<

–with Canada export<sup>NV</sup>

- Call up the **Source** menu and select **AM** or **FM**.
- In the **AM options** or **FM options** menu, go to **Search selection** and select the **Frequency** setting.
- Switch to the player.

 For HD Radio stations, the subprograms within a frequency range can be selected.<




- Push Multi-Controller **1** to the left or right to select the frequency you want in the wave-band.

### **Saving channel**

- Select a station or frequency from the frequency band.
- Press the bottom section of the **MENU** rocker button.
- Select **Add to Favourites**.

» The station selected beforehand appears in the favourites list.



- Turn Multi-Controller **1** in direction **A** or **B** to select the memory slot of your choice.

» The current assignment of this memory slot appears on the display.

» If a station has already been assigned to the memory slot you select, a message to this effect appears on the display. Your choices are as follows:

- Select **Cancel** if you do not want to save the station you selected.
  - Select **Save** to overwrite the contents of the memory slot.
- » The list of channels is re-opened.

## 136 AUDIO SYSTEM

### Favourites list

Selected stations or frequencies can be saved as favourites. Up to 20 favourites can be saved.

There are two ways of adding favourites to the list:

#### Variant 1

- Select the station. (134)
- Select **Add to Favourites**.
  - » The station selected beforehand appears in the favourites list.
- Push the Multi-Controller to the right.
  - » The station you selected has been saved as a favourite.

#### Variant 2

- Select the station. (134)
- Push the Multi-Controller to the right again.
  - » The favourites list opens.
- Push the Multi-Controller to the right again.
  - » The station you selected has been saved as a favourite.
  - » The view automatically returns to the stations list.

### Delete the favourites list Requirement

A favourites list with at least one entry exists.

- Select **Delete Favourites list** at the bottom of the favourites list.

- » A dialogue opens.
- Confirm deletion.
- » The favourites list is deleted.

---


### AUDIO SETTINGS

#### Speakers and Bluetooth

Audio playback is via the on-board speakers, a Bluetooth-paired output device, or the speakers in the helmet. If the Bluetooth function is not available in a particular country, only audio playback via the speakers is available.

If a BMW Motorrad communication system with Bluetooth standard 2.0 or higher is connected, the volume control can be operated via the Multi-Controller. (141). When pairing devices that do not comply with Bluetooth standard 2.0 or higher, the volume cannot be controlled using the Multi-Controller.

## Adjusting volume



- Turn Multi-Controller **1** in direction **A** to increase volume.
- Turn Multi-Controller **1** in direction **B** to reduce volume.

## Select the output device

- Navigate to Media, Audio settings and select Output device.
- » The following settings are available:
  - Loudspeakers: Speakers selected for audio playback.
  - Helmet: Helmet or other Bluetooth-enabled output device selected for audio playback.
- » The default setting is Loudspeakers.

## Select the sound profile

- Navigate to Radio, Audio settings and select Sound profile.
- » The following settings are available:
  - Bass-Boost
  - Treble-Boost

- Voice
- Studio
- Balanced

- » The default setting is Bass-Boost. All sound profiles have an effect only when Loudspeakers is selected.
- » For an optimum sound experience without in-helmet playback, select the Studio sound profile. All other sound profiles are optimised for in-helmet playback.

## Adjusting sound settings

- Navigate to Radio, Audio settings and select Equaliser.
- » The following settings are available:
  - Treble: Reduce (-1...-5) or increase (+1...+5) treble
  - Bass: Reduce (-1...-5) or increase (+1...+5) bass
  - Volume equalisation: Switch off speed-dependent volume boost (1) or select a boost level (2...4).
- Select the menu item you want, select the setting of your choice and exit the menu.
- » The sound settings have an effect only when Loudspeakers is selected as the output device.

# 138 AUDIO SYSTEM

## Volume and speed

The audio system can automatically adapt the volume to the speed of the motorcycle. The rate at which the volume increases in relation to vehicle speed can be set in four stages. Level 4 corresponds to the biggest boost. Selecting level 1 switches speed-dependent volume boost off.

Automatic speed-dependent volume adjustment works only when **Loudspeakers** is selected as the output device.

---

## PLAYER

### Status indicators showing in the instrument cluster

—without Canada export<sup>NV</sup>

The following information (country-specific) is shown in the instrument cluster:

- Selected source (134).
- Station (134).
- Frequency
- Artist
- Track
- Waveband

—with Canada export<sup>NV</sup>

The following information (country-specific) is shown in the instrument cluster:

- Selected source (134).
- Station (139).
- Frequency
- Artist
- Track
- Waveband

## Change the station or frequency

### Requirement

Selecting a frequency is possible only in the AM or FM waveband and **Frequency** only when the appropriate item has been selected in the options.

- Select the source. (134)
- Push the Multi-Controller to the right to left select the station or the frequency you want.

 In order to change the frequency, go to menu **AM options** or **FM options** and select menu item **Frequency**.

---

## SATELLITE RADIO

—with Canada export<sup>NV</sup>

### Availability

The functions for reception of satellite radio described in this section are available only in countries in which reception of **SiriusXM** is possible.

### Subscribing to channel

You have to subscribe to a channel in order to listen to it. Subscribing to a channel can result in costs that are not borne by BMW Motorrad. For information on the available channels go to **siriusxm.com**.

### Activation of channels

To activate a channel, call 1-888-539-7474. The Radio ID is also required.

### Calling up information

Navigate to Radio, SiriusXM information to view the following list entry:

Radio ID: XXXXXXXXXXXX

For support, please contact SiriusXM Customer Care at: 1-888-539-7474


### Signal strength

If the signal is not strong enough, **SiriusXM No signal.** appears on the display.

### Selecting category and channel

- To change the category, call up the **SiriusXM stations** menu and select **Category**.
  - » The choices at your disposal are as follows:
    - All categories: Shows all subscribed channels.

- Category: Shows a category, e.g. **Rock**.
- Stations not inc.: Shows all not subscribed channels.
- Select the channel of your choice.




- Turn Multi-Controller **1** in direction **A** or **B** to select the channel of your choice from the selected category.

### Saving channel

- Select the category and channel. (►► 139)
- Push the Multi-Controller to the right to select a channel.
- Push Multi-Controller to the right again and select **Add to Favourites**.
  - » The favourites list is opened.

## 140 AUDIO SYSTEM



- Turn Multi-Controller **1** in direction **A** or **B** to select the memory slot of your choice.
  - » The current assignment of this memory slot appears on the display.
  - » If a station has already been assigned to the memory slot you select, a message to this effect appears on the display. Your choices are as follows:
- Select **Cancel** if you do not want to save the station you selected.
- Select **Save** to overwrite the contents of the memory slot.
  - » The favourites list closes automatically and the display returns to the preceding view.

### Calling up channel saved in memory

#### Requirement

The selected **Source** has to be **Favourites**.

- Select **Favourites**.
  - » The favourites list appears on the display.

- Push the Multi-Controller to the right to select the channel you want.

### System messages

Under appropriate circumstances, the following messages appear on the display:

SiriusXM Subscription updated.

Updating subscription.

SiriusXM Channel not subscribed.

No subscription to this channel.

SiriusXM No signal.

SiriusXM service interrupted because of a poor signal.

---

### HD RADIO RECEPTION

—with Canada export<sup>NV</sup>

The signal strength of HD Radio stations can vary from place to place. If the digital signal is not strong enough, the system automatically switches to reception of the analog signal. A short interruption in reception might occur as the changeover takes place. If AM is selected as the source, audio quality might be perceptibly poorer after this changeover. As soon as the digital signal is available again, reception auto-

matically returns to the HD Radio station.

---

## IN-HELMET AUDIO PLAYBACK

### Rider's helmet paired



If a rider's helmet is paired with a BMW Motorrad communication system with Bluetooth standard 2.0:

- The volume of playback via the in-helmet speakers can be adjusted directly using the Multi-Controller **1**.
- Any change in helmet volume is shown on the display.

The volume for helmet 2 cannot be controlled using the Multi-Controller.

# ADJUSTMENT

07

---

|                       |            |
|-----------------------|------------|
| <b>MIRRORS</b>        | <b>144</b> |
| <b>HEADLIGHT</b>      | <b>144</b> |
| <b>WINDSCREEN</b>     | <b>144</b> |
| <b>CLUTCH</b>         | <b>145</b> |
| <b>BRAKES</b>         | <b>147</b> |
| <b>SEATS</b>          | <b>148</b> |
| <b>SPRING PRELOAD</b> | <b>150</b> |
| <b>DAMPING</b>        | <b>151</b> |

# 144 ADJUSTMENT

## MIRRORS

### Adjusting mirrors



- Pivot the mirror to the correct position by pressing gently at the edge of the glass.

## HEADLIGHT

### Headlight beam throw and spring preload

Headlight beam throw is generally kept constant by adjustment of spring preload. Spring preload adjustment might not suffice only if the motorcycle is very heavily loaded. Under these circumstances, headlight beam throw has to be adjusted to suit the load carried by the motorcycle.

 If there are doubts about the correct headlight beam throw, have the setting checked by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Adjusting headlight beam throw

#### Requirement

If, for a high load, the adjustment of the spring pre-load is no longer sufficient not to dazzle oncoming traffic:



- Adjust headlight beam throw by turning adjusting screw **1**.

## WINDSCREEN

### Adjusting windscreen

- Switch on the ignition.  
( 88)
- » As you ride off, the windscreen automatically moves to its last position before the ignition was switched off.



- Press top section of button **1** to raise the windscreen.
  - Press bottom section of button **1** to lower the windscreen.
  - Switch off the ignition. (III 88)
    - » The windscreen automatically moves to the bottom end position.
- If the windscreen encounters resistance before it reaches its end position, the anti-trap mechanism goes active. The windscreen stops and the mechanism raises it slightly. After a few seconds the windscreen once again attempts to move to the bottom end position.
- Make sure that nothing obstructs the windscreen's freedom of movement.
    - » The windscreen does not automatically move to the bottom end position.
  - Switch on the ignition. (III 88)
  - Press button **1** to move the windscreen to its top and bottom end positions.
  - Switch off the ignition. (III 88)
    - » The windscreen's range of adjustment is calibrated.
    - » Windscreen does not react when button **1** is pressed.
  - Consult a specialist workshop, preferably an authorised BMW Motorrad retailer.
- There is no guarantee that the anti-trap system will function correctly if a windscreen that does not have BMW Motorrad approval is installed.
- Under these circumstances:
    - Before switching off the ignition, make sure that nothing obstructs the windscreen's freedom of movement.

## CLUTCH

### Adjusting clutch lever




#### WARNING

#### Adjusting the clutch lever while riding

Risk of accident

- Adjust the clutch lever only when the motorcycle is at a standstill.

## 146 ADJUSTMENT



- Turn adjuster knob **1** to the desired position.

 The adjuster knob is easier to turn when the clutch lever is pushed slightly forward.

» Adjustment options:

- Position 1: Narrowest span between handlebar grip and clutch lever.
- Position 4: Widest span between handlebar grip and clutch lever.


–with Option 719 Billet Pack Classic II<sup>OE</sup>

or

–with Option 719 Billet Pack Storm II<sup>OE</sup>

or

–with Option 719 Billet Pack Shadow II<sup>OE</sup>



- Turn adjustment lever **1** to the desired position.

» Adjustment options:

- From position **A**: Narrowest span between handlebar grip and clutch lever.
- In 5 steps toward position **B** to increase the span between handlebar grip and clutch lever.◁

## BRAKES

### Adjusting handbrake lever



#### WARNING

#### Adjusting the handbrake lever while riding

Risk of accident

- Do not attempt to adjust the handbrake lever unless the vehicle is at a standstill.



- Turn adjuster knob **1** to the desired position.

 The adjuster knob is easier to turn when the handbrake lever is pushed slightly forward.

» Adjustment options:

- Position 1: Narrowest span between handlebar grip and handbrake lever.
- Position 4: Widest span between handlebar grip and handbrake lever.


–with Option 719 Billet Pack Classic II<sup>OE</sup>

or

–with Option 719 Billet Pack Storm II<sup>OE</sup>

or

–with Option 719 Billet Pack Shadow II<sup>OE</sup>




- Turn adjustment lever **1** to the desired position.
- » Adjustment options:
  - From position **A**: Narrowest span between handlebar grip and handbrake lever.
  - In 5 steps toward position **B** to increase the span between handlebar grip and handbrake lever.◀

# 148 ADJUSTMENT

## SEATS

### Removing rider's seat



- Turn ignition key **2** clockwise.
- Slightly raise rider's seat **1** at the back.




- Work rider's seat **1** to the rear to disengage it from seat retainer bridge **3** and remove.

—with seat heating<sup>OE</sup>

- Disconnect plug connection **2** for the seat heating.◁
- Place the rider's seat, up-holstered side down, on a clean, dry surface.

### Installing rider's seat

—with seat heating<sup>OE</sup>




- Connect plug connection **1** for the seat heating.◁




- Position the rider's seat with mounts **2** in rubber buffers **1** on left and right.
- Lower the rear of the rider's seat and engage the seat in the latching mechanism.

### Adjusting rider's seat height

- Remove the rider's seat.  
(148)



- Push lock **1** forward and remove adjusting plate **2**.



- Turn the adjusting plate to the **L** position for the lower seat height.
- Turn the adjusting plate to the **H** position for the higher seat height.



- Insert the adjusting plate in the desired position into mountings **2** and then push it into lock **1**.
- Install the rider's seat. (→ 148)

### Removing passenger seat


- Remove the rider's seat. (→ 148)



- Remove screws **1**, using the appropriate tool from the on-board toolkit.
- Pull the passenger seat slightly forward and lift the seat slightly.

## 150 ADJUSTMENT


—with seat heating<sup>OE</sup>



- Disconnect the plug connection **1** of the seat heating and remove the passenger seat.◁
- Place the passenger seat, upholstered side down, on a clean, dry surface.

### Installing passenger seat

—with seat heating<sup>OE</sup>



- Connect plug connection **1** for the seat heating.◁



- Place passenger seat on the mountings **1**.



- Install screws **1**, using the appropriate tool from the on-board toolkit.

---

### SPRING PRELOAD

#### Adjustment

It is essential to set spring preload of the rear suspension to suit the load carried by the motorcycle. Increase spring preload when the vehicle is heavily loaded and reduce spring preload accordingly when the vehicle is lightly loaded.

## Adjusting spring preload for rear wheel



### WARNING

#### Adjusting spring preload while riding.

Risk of accident

- Do not attempt to adjust spring preload unless the motorcycle is at a standstill.
- Make sure the ground is level and firm and place the motorcycle on its stand.
- Remove the spring-strut cover. (► 199)



### WARNING

#### Spring preload setting and spring-strut damping setting not matched.

Impaired handling.

- Adjust spring-strut damping to suit spring preload.

- To increase spring preload, turn adjuster knob **1** clockwise with tool **2**.
- To reduce spring preload, turn adjuster knob **1** counter-clockwise with tool **2**.



Basic setting of spring preload, rear

–without Dynamic ESA<sup>OE</sup>

Turn the knob as far as it will go counter-clockwise (One-up without luggage)

Turn the adjuster knob as far as it will go counter-clockwise, then back it off 10 turns in the clockwise direction. (One-up with luggage)

Turn the knob as far as it will go clockwise (Two-up with luggage) ◀

- Install the spring-strut cover. (► 199)

## DAMPING

### Adjustment


Damping must be adapted to suit the surface on which the motorcycle is ridden and to suit spring preload.

## 152 ADJUSTMENT

- An uneven surface requires softer damping than a smooth surface.
- An increase in spring preload requires firmer damping, a reduction in spring preload requires softer damping.

### Adjusting damping for rear wheel

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Set the damping from the left-hand vehicle side.



- Turn the adjusting screw **1** clockwise to harden the damping action.
- Turn the adjusting screw **1** anticlockwise to soften the damping action.



Basic setting of rear-suspension damping characteristic

Turn the adjuster knob as far as it will go in the clockwise direction, then back it off 6 clicks in the counter-clockwise direction (One-up without luggage)

Turn the adjuster knob as far as it will go in the clockwise direction, then back it off 4 clicks in the counter-clockwise direction (One-up with luggage)

Turn the adjuster knob as far as it will go in the clockwise direction, then back it off 2 clicks in the counter-clockwise direction (Two-up with luggage)◀



Basic setting of rear-suspension damping characteristic

–without Dynamic ESA<sup>OE</sup>



**RIDING**

**08**

---

|                                               |            |
|-----------------------------------------------|------------|
| <b>SAFETY INFORMATION</b>                     | <b>156</b> |
| <b>REGULAR CHECK</b>                          | <b>159</b> |
| <b>STARTING</b>                               | <b>159</b> |
| <b>RUNNING IN</b>                             | <b>160</b> |
| <b>SHIFTING GEAR</b>                          | <b>161</b> |
| <b>BRAKES</b>                                 | <b>162</b> |
| <b>PARKING YOUR MOTORCYCLE</b>                | <b>165</b> |
| <b>REFUELLING</b>                             | <b>166</b> |
| <b>SECURING MOTORCYCLE FOR TRANSPORTATION</b> | <b>171</b> |

## SAFETY INFORMATION

### Rider's equipment

Do not ride without the correct clothing! Always wear:

- Helmet
- Suit
- Gloves
- Boots

This applies even to short journeys, and to every season of the year. Your authorised BMW Motorrad retailer will be happy to advise you on the correct clothing for every purpose.



### WARNING

**Loose textiles, items of luggage or straps snagged by open rotating parts of the vehicle (wheels, drive shaft)**

Risk of accident

- Make sure that loosely worn or carried textiles cannot be snagged by openly rotating parts of the vehicle.
- Keep all items of luggage and straps well clear of openly rotating parts of the vehicle.

## Load



### WARNING

**Handling adversely affected by overloading and imbalanced loads**

Risk of falling

- Do not exceed the permissible gross weight and be sure to comply with the instructions on loading.

- Adapt spring setting and damping adjustment to the total weight.
- Ensure that the case volumes on the left and right are equal.
- Make sure that the weight is uniformly distributed between right and left.
- Pack heavy items at the bottom and toward the inboard side.
- Note the maximum permissible payload and maximum permissible speed, see also the section entitled "Accessories" (131).
- with tank bag <sup>OA</sup>
- Note the maximum permissible payload of the tank bag.



Payload of tank rucksack

max. 5 kg

## Speed

If you ride at high speed, always bear in mind that various boundary conditions can adversely affect the handling of your motorcycle. They include:

- Settings of the spring-strut and shock-absorber system
- Imbalanced load
- Loose clothing
- Insufficient tyre pressure
- Poor tyre tread

## Maximum permissible speed with winter tyres



### DANGER

#### Top speed of the motorcycle higher than the permissible tyre maximum speed

Risk of accident due to tyre damage at high speed

- Do not exceed the maximum speed for which the tyres are rated.

Always bear the maximum permissible speed of the tyres in mind when riding a motorcycle fitted with winter tyres.

Affix a label stating the maximum permissible speed to the instrument panel in the rider's field of vision.

## Risk of poisoning

Exhaust fumes contain carbon monoxide, which is colourless and odourless but highly toxic.



### WARNING

#### Exhaust gases adversely affecting health

Risk of asphyxiation

- Do not inhale exhaust fumes.
- Do not run the engine in an enclosed space.



### WARNING

#### Inhalation of harmful vapours

Health hazard

- Do not inhale vapours from operating fluids and plastics.
- Use the vehicle only outdoors.

## Risk of burning



### CAUTION

**Engine and exhaust system become very hot when the vehicle is in use**

Risk of burn injury

- When you park the vehicle make sure that no-one and no objects can come into contact with the hot engine and exhaust system.



### WARNING

**Opening radiator cap**

Risk of burning

- Do not open the radiator cap when the system is hot.
- Check and, if necessary, top up the coolant in the expansion tank only.

## Catalytic converter

If misfiring causes unburned fuel to enter the catalytic converter, there is a danger of overheating and damage.

The following guidelines must be observed:

- Do not run the fuel tank dry.
- Do not attempt to start or run the engine with a spark-plug cap disconnected.
- Stop the engine immediately if it misfires.

- Use only unleaded fuel.
- Comply with all specified maintenance intervals.



### ATTENTION

**Unburned fuel in catalytic converter**

Damage to catalytic converter

- Note the points listed for protection of the catalytic converter.

## Risk of overheating



### ATTENTION

**Engine running for prolonged period with vehicle at standstill**

Overheating due to insufficient cooling; in extreme cases vehicle fire

- Do not allow the engine to idle unnecessarily.
- Ride away immediately after starting the engine.

## Tampering



### ATTENTION

#### **Tampering with the motorcycle (e.g. engine management ECU, throttle valves, clutch)**

Damage to the affected parts, failure of safety-relevant functions, voiding of warranty

- Do not tamper with the vehicle in any way that could result in tuned performance.

## REGULAR CHECK

### **Comply with checklist**

At regular intervals, use the checklist below to check your motorcycle.

#### **Always before riding off**

- Check operation of the brake system (➡ 202).
- Check operation of the lights and signalling equipment.
- Check operation of the clutch (➡ 207).
- Check the tyre tread depth (➡ 209).
- Check the tyre pressures (➡ 209).
- Check security of cases and luggage.

- without Dynamic ESA<sup>OE</sup>
- Adjust the spring preload for the rear wheel (➡ 151).
- Adjust the damping for the rear wheel (➡ 152).

#### **Every 3rd refuelling stop**

- Check the engine oil level (➡ 200).
- Check the brake pad thickness, front brakes (➡ 202).
- Check the brake pad thickness, rear brakes (➡ 203).
- Check the brake-fluid level, front brakes (➡ 205).
- Check the brake-fluid level, rear brakes (➡ 206).
- Check the coolant level (➡ 207).

## STARTING

### **Starting engine**

- Switch on the ignition. (➡ 88)
- » Pre-Ride-Check and self-diagnoses are performed. (➡ 160)
- Select neutral or, if a gear is engaged, pull the clutch lever.



You cannot start the motorcycle with the side stand extended and a gear engaged. The engine will switch itself off if you start it with the gearbox in neutral and then engage a gear before retracting the side stand.

## 160 RIDING

- Cold starts and low temperatures: Pull the clutch lever.



- Press starter button 1.

 The start attempt is automatically interrupted if battery voltage is too low. Re-charge the battery before you start the engine, or use jump leads and a donor battery to start.

See the subsection on jump starting in "Maintenance" for more details.

- » The engine starts.
- » If the engine refuses to start, consult the troubleshooting chart in the section entitled "Technical data". (➡ 250)

### Pre-Ride-Check and self-diagnosis

The instrument cluster runs a test of the instruments and the indicator and warning lights when the ignition is switched on. During the Pre-Ride-Check,

all indicator and warning lights show temporarily.

- » If the instrument cluster remains dark after the ignition is switched on, the troubleshooting chart in the Technical Data section can help. (➡ 253)
- » Self-diagnosis checks the functional readiness of the BMW Motorrad ABS and the BMW Motorrad ASC/DTC.



flashes.



slow-flashes.

- » The indicator and warning lights go out when a speed of 5 km/h is reached.
- » Self-diagnosis has completed.

If an error message appears when self-diagnosis completes:

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

---

## RUNNING IN

### Engine

- Until the running-in check, vary the throttle opening and engine-speed range frequently; avoid riding at

constant engine rpm for prolonged periods.

- Try to do most of your riding during this initial period on twisting, fairly hilly roads.
- Comply with the running-in speeds.



Running-in speeds

<5000 min<sup>-1</sup> (Odometer reading 0...1000 km)

No full load (Odometer reading 0...1000 km)

- Note the mileage after which the running-in check should be carried out.



Running-in check

500...1200 km

### Brake pads

New brake pads have to be run in before they can achieve their optimum frictional force. You can compensate for this initial reduction in braking efficiency by exerting greater pressure on the levers.



### WARNING

#### New brake pads

Longer stopping distance, risk of accident

- Apply the brakes in good time.

### Tyres

New tyres have a smooth surface. This must be roughened by riding in a restrained manner at various heel angles until the tyres are run in. This running in procedure is essential if the tyres are to achieve maximum grip.



### WARNING

#### New tyres losing grip on wet roads and at extreme bank angles

Risk of accident

- Ride carefully and avoid extremely sharp inclines.


### SHIFTING GEAR

—with shift assistant Pro<sup>OE</sup>

#### Gear Shift Assistant Pro



For more information on Shift Assistant Pro, see the section headed "Engineering details".



- You select the gear in the usual way by means of the foot-operated shift lever.
  - » The sensor **1** on the gearshift shaft registers the gearshift request and triggers shift assistance.
  - » When riding at a steady speed in a low gear at high engine rpm, an attempt to shift gear without pulling the clutch can cause a severe load-change reaction. BMW Motorrad recommends disengaging the clutch for shifts in these circumstances. It is advisable to avoid using the shift assistant at engine speeds close to the limits at which the governor cuts in to limit engine rpm.
  - » Shift assistance is not available in the following situations:
    - Clutch pulled.
    - Gearshift lever not in its initial position.
- Upshifts with the throttle valve closed (engine overrun) and when slowing.
- Downshifts with throttle valve open and when accelerating.
- After a gearshift, the shift lever has to be fully released before another gearshift with the shift assistant can take place.

---

## BRAKES

### How can stopping distance be minimised?

Each time the brakes are applied, a load distribution shift takes place with the load shifting forward from the rear to the front wheel. The sharper the motorcycle decelerates, the more load is shifted to the front wheel. The higher the wheel load, the more braking force can be transmitted without the wheel locking. To optimise stopping distance, apply the front brakes rapidly and keep on increasing the force you apply to the brake lever. This makes the best possible use of the dynamic increase in load at the front wheel. Remember to pull the clutch at the same time. In the extreme sudden-stop braking situations that are trained so

frequently, braking force is applied as rapidly as possible and with the rider's full force applied to the brake levers; under these circumstances the dynamic shift in load distribution cannot keep pace with the increase in deceleration and the tyres cannot transmit the full braking force to the surface of the road.

The BMW Motorrad full integral ABS Pro prevents the front wheel from locking up.



### **WARNING**

#### **Rear wheel lift due to severe braking**

Risk of falling

- When you brake sharply, bear in mind that ABS control cannot always be relied on to prevent the rear wheel from lifting clear of the ground.

#### **Emergency braking**

If you brake sharply from a speed in excess of >50 km/h, the brake light flashes rapidly as a warning for road users behind you.

If you brake until your speed is less than <15 km/h, the hazard warning lights start to flash as well. The hazard warning

lights switch off automatically as soon as you start to accelerate and vehicle speed reaches 20 km/h.

#### **Descending mountain passes**



### **WARNING**

#### **Braking mostly with the rear brake on mountain descents**

Brake fade, destruction of the brakes due to overheating

- Use both front and rear brakes, and make use of the engine's braking effect as well.



### **DANGER**

#### **Riding with overheated brakes**

Risk of accident due to failure of brakes

- Adapt your riding style accordingly.
- Avoid frequent braking by using the engine brake.



### **WARNING**

#### **Failure to observe service intervals**

Risk of accident

- Observe the valid service intervals for brakes.

## Wet and dirty brakes



### WARNING

#### **Wetness and dirt result in diminished braking efficiency**

Risk of accident

- Apply the brakes lightly while riding to remove wetness and dirt, or dismount and clean the brakes.
- Think ahead and brake in good time until full braking efficiency is restored.

Wetness and dirt on the brake discs and the brake pads diminish braking efficiency. Delayed braking action or poor braking efficiency must be reckoned with in the following situations:

- Riding in the rain or through puddles of water.
- After the vehicle has been washed.
- Riding on salted or gritted roads.
- After work has been carried on the brakes, due to traces of oil or grease.
- Riding on dirt-covered surfaces or off-road.

## ABS Pro

### Physical limits applicable to motorcycling



### WARNING

#### **Braking when cornering**

Risk of crash despite ABS Pro

- Invariably, it remains the rider's responsibility to adapt riding style to riding conditions.
- Do not take risks that would negate the additional safety offered by this system.

ABS Pro is available in all riding modes.

–with riding modes Pro<sup>OE</sup>

The supporting function of Dynamic Brake Control is also available.

#### **Possibility of a fall not precluded**

Although ABS Pro provides the rider with valuable assistance and constitutes a huge advance in safety for braking with the motorcycle banked for cornering, it cannot under any circumstances be considered as re-defining the physical limits that apply to motorcycling. It is still possible for these limits to be overshoot due to misjudgement

or rider error. In extreme cases this can result in a crash.

### Use on public roads

ABS Pro helps make the motorcycle even safer for riding on public roads. When the brakes are applied because of an unforeseen hazard when the motorcycle is banked for cornering, within the physical limits that apply to motorcycling the ABS Pro system prevents the wheels from locking and skidding away.

 ABS Pro was not developed to enhance individual braking performance with the motorcycle banked into corners.

—with riding modes Pro<sup>OE</sup>  
In emergency braking, Dynamic Brake Control increases the braking effect and intervenes if the throttle grip is accidentally turned during braking.

---

## PARKING YOUR MOTORCYCLE

### Side stand

- Switch off the engine.



### ATTENTION

#### Poor ground underneath the stand

Risk of damage to parts if vehicle topples

- Always check that the ground under the stand is level and firm.



### ATTENTION

#### Additional weight placing strain on the side stand

Risk of damage to parts if vehicle topples

- Do not sit or lean on the vehicle while it is propped on the side stand.

- Extend the side stand and prop the motorcycle on the stand.
- If the camber of the roadway permits, turn the handlebars all the way to the left.
- On a gradient, the motorcycle should always face uphill; select 1st gear.

### Centre stand

- Switch off the engine.

**ATTENTION****Poor ground underneath the stand**

Risk of damage to parts if vehicle topples

- Always check that the ground under the stand is level and firm.

**ATTENTION****Centre stand retracts due to severe movements**

Risk of damage to parts if vehicle topples

- Do not lean or sit on the vehicle with the centre stand extended.
- Extend the centre stand and lift the motorcycle on to the stand.
- On a gradient, the motorcycle should always face uphill; select 1st gear.

**REFUELLING****Fuel grade Requirement**

For optimum fuel consumption, fuel should be sulphur-free or as low-sulphur as possible.

**ATTENTION****Engine operation with leaded fuel**

Damage to catalytic converter

- Do not attempt to run the vehicle on leaded fuel or fuel with metallic additives (e.g. manganese or iron).

- Observe the maximum ethanol content of the fuel.



Fuel additives clean the fuel injection system and the combustion zone. It is advisable to use fuel additives when the engine is operated with low-grade fuel or if the vehicle is to be out of use for a lengthy period of time. More information is available from your authorised BMW Motorrad retailer.



Recommended fuel grade



Premium unleaded (max. 15% ethanol, E15)



95 ROZ/RON  
90 AKI



Alternative fuel grade



Regular unleaded  
(power- and consumption-related restrictions)  
(max. 15% ethanol,  
E10/E15)



91 ROZ/RON  
87 AKI

» Look for these symbols on the fuel filler cap and on the fuel pump:



## Refuelling



### WARNING

#### Fuel is highly flammable

Risk of fire and explosion

- Do not smoke. Never bring a naked flame near the fuel tank.



### WARNING

#### Escape of fuel due to heat-induced expansion if fuel tank is overfilled

Risk of falling

- Do not overfill the fuel tank.



### ATTENTION

#### Wetting of plastic surfaces by fuel

Damage to the surfaces (surfaces become unsightly or dull)

- Clean plastic surfaces immediately after contact with fuel.
- Make sure the ground is level and firm and place the motorcycle on its centre stand.



- Open the protective cap **2**.
- Unlock the cap of the fuel tank by turning vehicle key **1** clockwise in the lock and pop the cap open.

—with central locking system<sup>OE</sup>

- Press the unlocked lock barrel down and flip the cap of the fuel tank open.◁



- Refuel with fuel of the grade stated above; do not fill the tank past the bottom edge of the filler neck.

 When refuelling after running on reserve, make sure that you top up the tank to a level above reserve, so that the new level is detected and the fuel reserve indicator light is switched off.

 The "usable fuel capacity" specified in the technical data is the quantity that the fuel tank could hold if refilled after it had been run dry and the engine had cut out due to a lack of fuel.



Usable fuel capacity

approx. 25 l



Reserve fuel

approx. 4 l

- Press the fuel tank cap down firmly to close.
- Remove the ignition key and close the protective cap.

## Refuelling

—with Keyless Ride<sup>OE</sup>

## Requirement

The steering lock is disengaged.



## WARNING

### Fuel is highly flammable

Risk of fire and explosion

- Do not smoke. Never bring a naked flame near the fuel tank.



## WARNING

### Escape of fuel due to heat-induced expansion if fuel tank is overfilled

Risk of falling

- Do not overfill the fuel tank.



## ATTENTION

### Wetting of plastic surfaces by fuel

Damage to the surfaces (surfaces become unsightly or dull)

- Clean plastic surfaces immediately after contact with fuel.

- Make sure the ground is level and firm and place the motorcycle on its centre stand.  
—with Keyless Ride<sup>OE</sup>
- Switch off the ignition.  
( 91)



The fuel filler cap can be opened within the defined waiting time after the ignition has been switched off, without the radio-operated key being within range.



Waiting time for opening the fuel filler cap


2 min

- » There are **two variant ways** of opening the fuel filler cap:
- Within the waiting time.
  - After the waiting time has expired.

### Variant 1

#### Requirement

Within the waiting time



- Slowly pull tab **1** on the fuel filler cap up.
- » Fuel filler cap unlocks.
- Fully open the fuel filler cap.

### Variant 2

#### Requirement

After the waiting time has expired

- Bring the radio-operated key into range.
- Slowly pull tab **1** up.
- » The indicator light for the radio-operated key flashes while the search for the radio-operated key is in progress.
- Slowly pull tab **1** on the fuel filler cap up again.
- » Fuel filler cap unlocks.
- Fully open the fuel filler cap.



- Refuel with fuel of the grade stated above; do not fill the tank past the bottom edge of the filler neck.

 When refuelling after running on reserve, make sure that you top up the tank to a level above reserve, so that the new level is detected and the fuel reserve indicator light is switched off.

 The "usable fuel capacity" specified in the technical data is the quantity that the fuel tank could hold if refilled after it had been run dry and the engine had cut out due to a lack of fuel.



Usable fuel capacity

approx. 25 l



Reserve fuel

approx. 4 l


- Press down firmly on the filler cap of the fuel tank.
- » The fuel filler cap engages with an audible click.
- » The fuel filler cap locks automatically when the waiting time expires.
- » The engaged fuel filler cap locks immediately when you secure the steering lock or switch on the ignition.

## Opening fuel filler cap emergency release

—with Keyless Ride<sup>OE</sup>

Fuel filler cap cannot be opened.

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.



- Remove screws **1**.
- Remove emergency release **2**.
- » Fuel filler cap unlocks.
- Fully open the fuel filler cap.
- Refuel. (➡ 168)


- Close the fuel filler cap emergency release. (171)

### Closing fuel filler cap emergency release

—with Keyless Ride<sup>OE</sup>

#### Requirement

Fuel filler cap is in closed position.



- Hold emergency release **2** in position.
- Install screws **1**.

### SECURING MOTORCYCLE FOR TRANSPORTATION

- Make sure that all components that might come into contact with straps used to secure the motorcycle are adequately protected against scratching. Use adhesive tape or soft cloths, for example, for this purpose.



#### ATTENTION

#### Vehicle topples to side when being lifted on to stand

Risk of damage to parts if vehicle topples

- Secure the vehicle to prevent it toppling, preferably with the assistance of a second person.
- Push the motorcycle on to the transportation flat and hold it in position: do not place it on the side stand or centre stand.
- Have a helper hold the motorcycle to make sure that it cannot topple.



suspension should be compressed as tightly as possible front and rear.




### ATTENTION

#### Trapping of components

Component damage

- Do not trap components such as brake lines or cable legs.
- At the front, pass the straps on left and right through the fork bridge and strap the motorcycle down.



- At the rear, secure the straps to the holders for the passenger footrests on both sides and tighten the straps.
- Tighten all the straps uniformly; the vehicle's



# ENGINEERING DETAILS

09

---

|                                                     |            |
|-----------------------------------------------------|------------|
| <b>GENERAL NOTES</b>                                | <b>176</b> |
| <b>ANTILOCK BRAKE SYSTEM (ABS)</b>                  | <b>176</b> |
| <b>DYNAMIC TRACTION CONTROL (DTC)</b>               | <b>180</b> |
| <b>DYNAMIC ENGINE BRAKE CONTROL</b>                 | <b>181</b> |
| <b>DISTANCE CONTROL (ACTIVE CRUISE CONTROL ACC)</b> | <b>182</b> |
| <b>ELECTRONIC SUSPENSION ADJUSTMENT (D-ESA)</b>     | <b>185</b> |
| <b>RIDING MODE</b>                                  | <b>186</b> |
| <b>DYNAMIC BRAKE CONTROL</b>                        | <b>188</b> |
| <b>TYRE PRESSURE CONTROL (RDC)</b>                  | <b>189</b> |
| <b>GEAR SHIFT ASSISTANT</b>                         | <b>190</b> |
| <b>HILL START CONTROL (HSC)</b>                     | <b>191</b> |
| <b>SHIFTCAM</b>                                     | <b>193</b> |
| <b>ADAPTIVE HEADLIGHT</b>                           | <b>193</b> |

---

## GENERAL NOTES

To find out more about engineering, go to [bmw-motorrad.com/technik](http://bmw-motorrad.com/technik).

---

## ANTILOCK BRAKE SYSTEM (ABS)

### Fully integral brakes

Your motorcycle has fully integral brakes. With this system, when either brake lever (hand-brake or footbrake lever) is actuated both the front and the rear brakes are applied.

The BMW Motorrad fully integral ABS Pro adapts brake force distribution between front and rear brakes to suit the load on the motorcycle whenever braking requires ABS intervention.



### ATTENTION

#### Attempted burn-out despite Integral braking function

Damage to rear brake and clutch

- Do not burn out tyres.

### How does Integral ABS work?

The amount of braking force that can be transferred to the road depends on factors that include the coefficient of friction of the road surface. Loose stones, ice and snow or a wet

road all have much lower coefficients of friction than a clean and dry asphalt surface. The lower the coefficient of friction, the longer the stopping distance.

If the rider increases braking pressure to the extent that braking force exceeds the maximum transferable limit, the wheels start to lock and the vehicle loses its directional stability; a fall is imminent. Before this situation can occur, ABS intervenes and adapts braking pressure to the maximum transferable braking force. The wheels continue to turn and the driving stability is retained irrespective of the road condition.

### What are the effects of surface irregularities?

Humps and surface irregularities can cause the wheels to lose contact temporarily with the road surface; if this happens the braking force that can be transmitted to the road can drop to zero. If the brakes are applied under these circumstances the ABS has to reduce braking force to ensure that directional stability is maintained when the wheels regain contact with the road surface. At this

point, the BMW Motorrad full integral ABS Pro must act on the assumption of an extremely low coefficient of friction (gravel, ice, snow), so that the wheels will continue to rotate under all imaginable circumstances meaning that driving stability is ensured. As soon as it registers the actual circumstances, the system reacts instantly and adjusts braking force accordingly to achieve optimum braking.

### **What feedback does the rider receive from the Integral ABS?**

If ABS has to reduce braking force on account of the circumstances described above, vibration is perceptible through the handbrake lever.

When the handbrake lever is pulled, brake pressure is also built up at the rear wheel by the integral function. If the brake pedal is depressed after the handbrake lever is pulled, the brake pressure built up beforehand is perceptible as counter-pressure sooner than is the case when the brake pedal is depressed either before or at the same time as the brake lever is pulled.

### **Rear wheel lift**

Under very severe and sudden deceleration, it might be possible that the BMW Motorrad full integral ABS Pro will be unable to prevent the rear wheel from lifting clear of the ground. If this happens the outcome can be a highsiding situation in which the motorcycle can flip over.



### **WARNING**

#### **Rear wheel lift due to severe braking**

Risk of falling

- When you brake sharply, bear in mind that ABS control cannot always be relied on to prevent the rear wheel from lifting clear of the ground.

### **What is the design baseline for Integral ABS?**

Within the limits imposed by physics, the BMW Motorrad ABS ensures directional stability on any surface.

At speeds above min. 4 km/h, within the limits imposed by physics the BMW Motorrad ABS can ensure directional stability on any surface. Limitations inherent to the design

# 178      ENGINEERING DETAILS

principle mean that at lower speeds the BMW Motorrad ABS cannot provide optimum assistance on all surfaces.

The system is not optimised for special requirements that apply under extreme competitive conditions off-road or on the track.

## Special situations

The speeds of the front and rear wheels are compared as one means of detecting a wheel's incipient tendency to lock. If the system registers implausible values for a lengthy period the ABS function is deactivated for safety reasons and an ABS fault message is displayed. Self-diagnosis has to complete before fault messages can be issued.

In addition to problems with the BMW Motorrad ABS, exceptional riding conditions can lead to a fault message being issued:

- Heating up with the motorcycle on the centre stand or an auxiliary stand, engine idling or with a gear engaged.
- Rear wheel locked by the electrical machine's braking moment for a lengthy period,

for example while descending on a loose or slippery surface.

If a fault message is issued on account of exceptional riding conditions, you can reactivate the ABS function by switching the ignition off and on again.

## What significance devolves on regular servicing?



### WARNING

#### Brake system not regularly serviced.

Risk of accident

- In order to ensure that the ABS is always maintained in optimum condition, it is essential for you to comply strictly with the specified inspection intervals.

## Safety reserves

The BMW Motorrad full integral ABS Pro may not mislead the rider into a careless riding style because they can rely on shorter stopping distances. The system is primarily a means of ensuring a safety margin in genuine emergencies.



## WARNING

### Braking when cornering

Risk of accident despite ABS

- Invariably, the rider bears responsibility for assessing road and traffic conditions and adopting his or her style of riding accordingly.
- Do not take risks that would negate the additional margin of safety offered by this system.

### Evolution of ABS to ABS Pro

Until now, BMW Motorrad ABS has helped ensure a very high degree of safety for braking with the motorcycle upright and travelling in a straight line. Now ABS Pro offers enhanced safety for braking in corners as well. ABS Pro prevents the wheels from locking even under sharp braking. ABS Pro reduces abrupt changes in steering force, particularly in shock-braking situations, counteracting the vehicle's otherwise natural but undesirable tendency to straighten up.

### ABS intervention

Technically speaking, depending on the riding situation ABS Pro adapts ABS intervention to the motorcycle's bank angle. Signals for rate of roll and rate of yaw and lateral acceleration are used to calculate bank angle.

As the motorcycle is heeled over more and more as it banks into a corner, an increasingly strict limit is imposed on the brake-pressure gradient for the start of brake application. This slows the build-up of brake pressure to a corresponding degree. Additionally, pressure modulation is more uniform across the range of ABS intervention.

### Advantages for the rider

The advantages of ABS Pro for the rider are sensitive response and high braking and directional stability combined with best-case deceleration of the motorcycle, even when cornering.

## DYNAMIC TRACTION CONTROL (DTC)

### How does traction control work?

Traction control compares the front and rear wheel circumferential velocities. The differential is used to compute slip as a measure of the reserves of stability available at the rear wheel. If slip exceeds a certain limit, the electrical machine management system intervenes and adapts torque accordingly. BMW Motorrad DTC is designed as an assistant system for the rider and for use on public roads. The extent to which the rider affects DTC control can be considerable (weight shifts when cornering, items of luggage loose on the vehicle), especially when the style of riding takes rider and machine close to the limits imposed by physics.

The system is not optimised for special requirements that apply under extreme competitive conditions off-road or on the track. The BMW Motorrad DTC can be deactivated in these cases.



### WARNING

#### Risky riding

Risk of accident despite DTC

- Invariably, the rider bears responsibility for assessing road and traffic conditions and adopting his or her style of riding accordingly.
- Do not take risks that would negate the additional safety offered by this system.

#### Special situations

In accordance with the laws of physics, the ability to accelerate is restricted more and more as the angle of heel increases. Consequently, there can be a perceptible reduction in acceleration out of very tight bends.

With DTC, the speeds of the front and rear wheels are compared and the angle of heel taken into account as one means of detecting the rear wheel's incipient tendency to spin or slip sideways.

If the lean angle values are identified as implausible over an extended period of time, a substitute value is used for the lean angle or the DTC is switched off. Under these circumstances the indicator for

a DTC fault shows. Self-diagnosis has to complete before fault messages can be issued. The BMW Motorrad traction control may switch off automatically under the exceptional riding conditions outlined below.

### **Exceptional riding conditions:**

- Riding for a lengthy period with the front wheel lifted off the ground (wheelie).
- Rear wheel rotating with the vehicle held stationary by applying the front brake (burn-out).
- Warming up with the motorcycle on the centre stand, in neutral or with a gear engaged.

---

## **DYNAMIC ENGINE BRAKE CONTROL**

–with riding modes Pro<sup>OE</sup>

### **How does dynamic engine brake control work?**

The purpose of dynamic engine brake control is to prevent the unstable riding states that can be produced by excessive engine braking moment acting on the rear wheel. Depending on the road condition and riding dynamic, excessive braking torque can produce

a sharp rise in rear-wheel slip and impair directional stability. Dynamic engine brake control limits this slip at the rear wheel to a safe, mode-dependent regulated slip.

### **Causes for excessive slip at the rear wheel:**

- Riding with engine overrun on a surface with a low coefficient of friction (e.g. wet leaves).
- Rear-wheel hop when rider downshifts.
- Sharp braking during sporty riding.

In the same way as dynamic traction control BMW Motorrad DTC, engine drag torque control compares the wheel circumferential velocities of the front and rear wheels calculated from the wheel speeds and the tyre radius. Dynamic engine brake control uses this differential to compute slip as a measure of the reserve of stability available at the rear wheel.

If slip overshoots the applicable limit value, the throttle valves are opened very slightly to increase engine torque. Slip is reduced and the vehicle is stabilised.

## 182      ENGINEERING DETAILS

### **Effect of dynamic engine brake control**

- In ECO, RAIN and ROAD riding modes: Maximum stability.
- with riding modes Pro<sup>OE</sup>
- In DYNAMIC riding mode:  
Compared to ECO, RAIN and ROAD riding modes, reduced intervention.

---

### **DISTANCE CONTROL (ACTIVE CRUISE CONTROL ACC)**

- with Active Cruise Control<sup>OE</sup>

#### **What is ACC?**

BMW Motorrad ACC is a cruise control system with approach distance control. The function enables the rider to set a preferred speed and a preferred approach distance from the vehicle directly ahead in the same lane. Cruising speed remains constant as long as the distance to the vehicle directly ahead is not shorter than the approach distance pre-selected by the rider. As soon as the approach distance is less than this preset, speed is reduced until the distance between the two vehicles again matches the rider's preferred setting.

Responsibility remains with the rider, who can intervene at any time and override the ACC. The ACC function has two characteristics: *Comfortable* and *Dynamic*. They affect acceleration and deceleration while control is actively intervening.

#### **How does ACC work?**

The front-mounted radar sensor detects vehicles travelling ahead. At the same time, the radar sensor analyses yaw rate and vehicle speed to calculate what is referred to as the prospective ride path, in other words the corridor along which the motorcycle will proceed over the next approx. 100 m approximately. If one of the detected objects is in this prospective ride path the system reacts accordingly, adapting speed so that the rider's preset approach distance from the object travelling ahead is maintained.

#### **Control functions of ACC**

ACC is divided into five control functions, as follows:

- Cruise control:** Cruising speed is adapted to the setting chosen by the rider.
- Distance control:** The vehicle cruises at the speed chosen by the rider, but speed is varied to maintain the selected approach distance to be maintained behind the vehicle in front.
- Cornering control:** When the vehicle corners speed is reduced if necessary and the system attempts to achieve a comfortable bank angle (e.g. 20°). As bank angle increases, moreover, braking and acceleration dynamism is limited so that no sudden braking or acceleration takes the rider unawares. Cornering control prevents, for example, unexpected acceleration on object loss by the radar and when the rider's selected speed setting is inappropriately high. Object loss can occur when the vehicle head is only partly registered by the radar as a bend is negotiated.
- Passing assistant:** When a vehicle is present ahead, the rider can activate the passing assistant by switching on the indicators on the side appropriate for a passing manoeuvre. This causes the vehicle to pick up speed, accelerating into a fluid passing manoeuvre. If a passing manoeuvre does not take place the distance behind the vehicle ahead is closed up to some extent for a brief time.
- Passing prevention:** The ACC function prevents a vehicle for which no passing manoeuvre has been signalled from being overtaken. This would apply, for example, to a vehicle that is on the left in right-hand traffic or a vehicle on the right in left-hand traffic. When a vehicle presence is detected in these circumstances the system settles accordingly to the appropriate distance behind. Briefly opening the throttle or indicating for a passing manoeuvre on the opposite side suppresses passing prevention.

### Speed range of ACC

The ACC function can be activated in the following speed ranges:

## 184 ENGINEERING DETAILS

- 30...160 km/h
- If ACC is activated in the speed range 160...250 km/h, the maximum speed of 160 km/h is selected.

### Limits of ACC

ACC is subject to the system limits described below:

- Detected objects:** The radar sensor's object detection capability is restricted to the vehicle directly ahead in the lane.
- Radar range:** The radar has a maximum viewing range of approx. 120 m. At high speeds and with the vehicle experiencing dynamic movement on account of rider manoeuvres such as lane changes for example, object detection can be subject to restrictions.
- Adjacent-lane interference and loss of object:** In isolated cases, weaving from side to side in the lane, riding twisty sections of road or riding offset from the vehicle ahead in your lane can cause the system to assign vehicles detected ahead to the wrong lane. If this happens approach distance control is applied to the wrong vehicle and this

can lead to unexpected braking or acceleration. The system limits imposed on acceleration and deceleration, however, keep handling controllable for the rider at all times.

- Limitation of driving dynamics:** The ACC-controlled acceleration and deceleration of the motorcycle are limited. The rates of acceleration and deceleration are also limited. Consequently, abrupt, sharp acceleration or deceleration cannot occur. This limitation becomes more acute as the motorcycle's bank angle increases. On very steep climbs and with the motorcycle heavily loaded, it is possible that maximum acceleration might not be achievable in ACC-operation.
- Environmental influences:** Environmental influences can diminish the viewing range of the radar sensor. In some cases, heavy rain, snow and thick fog can severely restrict the radar's viewing range.
- Disruptive reflections:** Strong reflections at tunnel entrances for example or where crash barriers are high can hinder object detection.

## **Influence on the performance of ACC**

The rider can assist the performance of ACC by:

- Adopting a smooth style of riding.
- Staying as close as possible to the middle of lane behind the vehicle in front.
- When overtaking, making clear lane changes to the passing lane to help the system deselect the vehicle directly ahead in the original lane.
- Returning to the original lane as quickly as possible behind the next vehicle ahead, to allow the system time to select the reference object head.

---

## **ELECTRONIC SUSPENSION ADJUSTMENT (D-ESA)**

– with Dynamic ESA<sup>OE</sup>

### **Riding position equaliser**

Dynamic ESA is an electronic system that enables your motorcycle's suspension to adjust automatically to suit the load the vehicle is carrying. When spring adjustment is set to *Auto*, the rider does not have to adjust the suspension to suit the load.



BMW Motorrad recommends the *Auto* suspension setting.

When driving off and when riding, the system monitors the suspension at the rear wheel and corrects the spring setting in order to set the correct riding position. The damping is also adjusted automatically to the load.

By interpreting ride height sensor signals, Dynamic ESA detects movements in the suspension and responds by adjusting the damper valves. This enables the suspension to adapt to the terrain.

Dynamic ESA calibrates itself at regular intervals to ensure the system functions correctly.

### **Possibilities for adjustment Damping modes**

- *Road*: Damping for comfortable on-road riding
- *Dynamic*: Damping for dynamic on-road riding

### **Load settings**

- *Min*: Minimum spring setting (only to make the motorcycle easier for the rider to mount)
- *Auto*: Active ride compensation with automatic adjustment of the spring setting

and damping (recommended suspension setting)

## RIDING MODE

### Selection

To adjust the motorcycle to the road condition and the desired driving experience, the following riding modes can be selected:

- ECO
- RAIN
- ROAD
- with riding modes Pro<sup>OE</sup>
- DYNAMIC

For each of these riding modes, there is a matching setting for the DTC and engine drag torque control systems and for throttle response.

–with Dynamic ESA<sup>OE</sup>

Dynamic ESA can be parametrised independently of the selected riding mode.

DTC can be switched off in each riding mode. The explanations below always refer to the riding dynamics control systems that are switched on.

### Torque and throttle response

- In ECO riding mode: Restrained throttle response, reduced torque.
- In RAIN riding mode: Gentle throttle response, maximum torque.
- In ROAD riding mode: Optimum throttle response, maximum torque.
- with riding modes Pro<sup>OE</sup>
- In DYNAMIC riding mode: Direct throttle response, maximum torque.

### Traction control DTC

- In RAIN riding mode: Maximum stability on wet roads. Acceleration on dry roads might be reduced.
- In ECO and ROAD riding modes: High stability on dry roads. DTC intervenes later than in RAIN riding mode. This prevents the rear wheel from spinning whenever possible.
- In ECO, RAIN and ROAD riding modes, the front wheel is prevented from lifting off the ground.
- In DYNAMIC riding mode, DTC intervention is later than in ECO and ROAD riding modes. High performance on dry roads. If road conditions

are poor, optimum stability cannot be ensured.

### **Mode changes**

The riding mode can be changed while the vehicle is stationary with the ignition on. Under the following precondition, it is also possible to change modes while riding:

- No drive torque on the rear wheel.
- No brake pressure in the brake system.

The following steps must be taken to change the riding mode:

- Close the throttle twistgrip.
- Release the brake levers.
- Deactivate cruise control.

The desired riding mode is initially preselected. The mode change does not take place until the systems in question are all in the appropriate state.

The selection menu does not disappear from the display until the mode change has taken place.

### **ECO mode**

ShiftCam technology is the bridge-builder between ultra-high dynamism and maximum efficiency. The full-load cams allow full valve lift for maximum combustion-chamber charge

and high power, whereas the part-load cams considerably shorten the lift of the intake valves and open the valves to different extents. Charge-cycle losses are lessened by de-throttling, friction is reduced, the mixture is swirled more vigorously and combusted more effectively, fuel consumption goes down.

The ECO mode assists the rider with ECO indicator and engine characteristic (parametrisation of the electromotive throttle controller) to keep the engine in the operating range of the consumption-oriented part-load cam, so as to maximise the distance travelled with a given quantity of fuel.

The length of the green bar in the ECO indicator in the instrument cluster visualises whether the drive is operating in the consumption-optimised range of the part-load cam and the margin from the switch-over threshold to full-load cam operation. The length of the bar represents the load reserve left before the switch-over point for full-load cam operation is reached. The colour changes to grey when load requirement increases and the engine

switches to the full-load cam. The reading shown by the ECO indicator varies depending on the gear selected by the rider, the load requirement input via the throttle grip, and engine rpm. Even outside the operating range of the part-load cam, when the bar is grey, the ECO offers benefits for an economical style of riding by reducing maximum available torque and peak power.

 Because of the reduced acceleration ability in ECO mode, changing to a different riding mode is recommended prior to critical overtaking manoeuvres with the motorcycle heavily loaded or when riding two-up.

Rider can further reduce consumption by riding with fuel economy in mind ( 193).

---

## DYNAMIC BRAKE CONTROL

—with riding modes Pro<sup>OE</sup>

### How Dynamic Brake Control works

The Dynamic Brake Control function assists the rider in emergency braking situations.

### Detection of emergency braking

—Sudden, sharp application of the front brake is interpreted as emergency braking.

### Behaviour in emergency braking

- If emergency braking occurs at a speed in excess of min. 10 km/h, the ABS function is further assisted by Dynamic Brake Control.
- When partially integral braking at a high brake pressure gradient is initiated, Dynamic Brake Control increases the integral brake pressure at the rear wheel. The stopping distance shortens and controlled braking is possible.

### Behaviour during accidental actuation of the throttle grip

- If the throttle is accidentally opened (throttle grip position > 5 %) during emergency braking, Dynamic Brake Control ensures the desired braking effect by ignoring actuation of the throttle grip. The effectiveness of emergency braking is ensured.
- If the throttle is closed (throttle grip position < 5 %) while Dynamic Brake Control is in action, the engine torque

requested by the ABS brake system is restored.

- If hazard braking ceases and the rider still has not changed the position of the throttle grip, Dynamic Brake Control steadily ramps engine torque back to the rider's requested level.

---

## **TYRE PRESSURE CONTROL (RDC)**

- with tyre pressure control (RDC)<sup>OE</sup>

### **Function**

A sensor integrated into each tyre measures the air temperature and the air pressure inside the tyre and transmits this information to the control unit. Each sensor has a centrifugal-force tripswitch that does not enable transmission of the measured values until the motorcycle has accelerated to a defined minimum speed of min. 30 km/h for the first time. The display shows -- for each tyre until the tyre-pressure signal is received for the first time. The sensors continue to transmit the measured-value signals for min. 15 min after the vehicle comes to a stop. An error message is issued if wheels without sensors are fit-

ted to a vehicle equipped with an RDC control unit.

### **Tyre pressure ranges**

The RDC control unit distinguishes between three tyre pressure ranges matched to the vehicle:

- Tyre pressure within permitted tolerance.
- Tyre pressure close to limit of permitted tolerance.
- Tyre pressure outside permitted tolerance.

### **Temperature compensation**

Tyre pressure is a temperature-sensitive variable: pressure increases as tyre-air temperature rises and decreases as tyre-air temperature drops. Tyre air temperature depends on ambient temperature as well as on the style of riding and the duration of the ride.

The tyre-pressure readings in the multifunction display are temperature-compensated and are always referenced to a tyre-air temperature of 20 °C.

The air lines available to the public in petrol stations and motorway service areas have gauges that do not compensate for temperature; the reading shown by a gauge of this nature is the temperature-

## 190 ENGINEERING DETAILS

dependent tyre-air pressure. As a result, the values displayed there usually do not correspond to the values displayed in the display.

### Pressure adaptation

Compare the RDC value on the display with the value in the table on the back cover of the rider's manual. Then use the air-line gauge at a service station to compensate for the difference between the RDC reading and the value in the table.

|                                                                                          |
|------------------------------------------------------------------------------------------|
|  Example |
| According to the operating instructions, the tyre pressure should be:                    |
| 2.5 bar                                                                                  |
| The following value appears in the multifunction display:                                |
| 2.3 bar                                                                                  |
| So pressure is low by:                                                                   |
| 0.2 bar                                                                                  |
| The gauge on the air line shows:                                                         |
| 2.4 bar                                                                                  |
| You must now increase tyre pressure until the value is:                                  |
| 2.6 bar                                                                                  |

### GEAR SHIFT ASSISTANT

—with shift assistant Pro<sup>OE</sup>

#### Gear Shift Assistant Pro

Your vehicle is equipped with Gear Shift Assistant Pro, a system originally developed for racing and now adapted for the touring sector. It permits upshifts and downshifts without declutching or closing the throttle in virtually all load and rpm ranges.

The engine control system supports gear changes as a function of:

- Required gear
- Engine rpm
- Position of the throttle twist-grip

The rider bears responsibility for use of the shift assistant and must take the riding situation and safety and comfort aspects duly into consideration.

#### Advantages

- A large proportion of gearshifts can be carried out without using the clutch.
- Less relative movement between rider and passenger because the shift pauses are shorter.

- It is not necessary to close the throttle twistgrip when shifting under acceleration.
- When downshifting (throttle twistgrip closed), engine speed is adjusted by blipping the throttle.
- Shift time is shorter than a gearshift with clutch actuation.

The rider indicates a gearshift request by moving the gearshift lever from what was an untouched position at normal to snappy speed in the appropriate direction and following this movement through to the mechanical limit position of the gearshift operation. Once the gearshift has completed the shift lever has to be fully released before another gearshift with the Pro shift assistant can take place. In order to optimise shift quality when shifting gears with the Gear Shift Assistant Pro, the rider has to keep load state (throttle twistgrip position) constant before and during the gearshift. The Gear Shift Assistant Pro provides no assistance for gearshifts when the rider declutches.

## Downshifting

- Downshifting is assisted until maximum rpm for the target gear to be selected is reached. This prevents over-revving.



Maximum engine speed

max. 9000 min<sup>-1</sup>

## Upshifting

- Upshifting is assisted until engine speed is below idle rpm in the target gear. This prevents the engine from dropping below idle speed.
- On account of the operating principle, a certain loss of comfort and perceptibly sharper load-change reactions can be experienced if the system is used for upshifts on overrun, particularly in low gears.

## HILL START CONTROL (HSC)

### Hill Start Control function

Hill Start Control is a ride-off assistant that operates on the fully integral ABS system to prevent the vehicle from rolling back on a gradient, without the rider having to keep pressure applied to the brake lever. When Hill Start Control is ac-

## 192 ENGINEERING DETAILS

tivated, pressure is built up in the rear brake system to keep the machine at a standstill on a gradient. The brake pressure in the brake system is dependent on the gradient.

### **Effect of an incline on brake pressure and drive-off behaviour**

- If the motorcycle is stopped on a gentle incline, only low brake pressure is built up. In this case, the brakes are quickly released when driving off. The motorcycle can be moved off more gently. It is not necessary to turn the throttle grip again.
- If the motorcycle is stopped on a steep incline, high brake pressure is built up. In this case, the brakes take longer to release when driving off. More torque is required for driving off which also requires the rider to turn the throttle grip again.

### **Behaviour when the motorcycle rolls or slips**

- If the vehicle starts to roll while Hill Start Control is active, brake pressure is increased.
- If the rear wheel slips, the brake is released again after

approx. 1 m. This prevents the vehicle slipping with a locked rear wheel, for example.

### **Brake release when engine is stopped or after time-out**

Hill Start Control is deactivated if the rider stops the engine by hitting the emergency-off switch (kill switch) or when the side stand is extended, or after time-out (10 minutes).

In addition to the indicator and warning lights, the rider should be made aware that Hill Start Control has been deactivated by the following behaviour:

### **Brake warning jolt**

- The brake is released briefly and reactivated immediately.
- This creates a jolt which the rider feels.
- The full integral ABS brake system limits the speed of movement to approx. 1...2 km/h.
- The rider must brake the motorcycle manually.
- After two minutes, or when the brake is actuated, speed control is completely deactivated.



The holding pressure is released immediately without a brake warning jolt as

soon as the ignition is switched off.

—with riding modes Pro<sup>OE</sup>

### **Hill Start Control Pro**

Hill Start Control Pro enables automatic activation of the holding function.

---

## **SHIFTCAM**

### **Functional principle of ShiftCam**

The vehicle features BMW ShiftCam technology for varying valve timing and valve lift on the intake side. The heart of this technology is a one-piece shifting intake camshaft that has two lobes for each valve: a partial-load cam and a full-load cam. The partial-load cam is fine-tuned for consumption optimisation and engine smoothness. As well as adapting valve timing, the partial-load cam also reduces intake-valve lift. With the partial-load cams activated, moreover, the lobes for the cylinder's left and right intake valves produce staggered valve lift and offset angles of rotation. Consequently the two intake valves open at very slightly different times and the distance to which they open also differs. The advantage:

The fuel/air mixture flowing into the combustion chamber is swirled more thoroughly and combusted effectively - so all in all the fuel is utilised more efficiently and engine operation is perceptibly smoother. The full-load cam is designed for optimised engine power and it maximises intake valve lift. The intake camshaft is shifted axially to vary valve timing and valve lift. The pins of an electromechanical actuator engage a shift gate on the intake camshaft. This permits load-dependent and speed-dependent actuation of the intake valves and, consequently, a no-compromises combination of performance and low fuel consumption.

---

## **ADAPTIVE HEADLIGHT**

—with adaptive head light<sup>OE</sup>

### **How does the adaptive cornering headlight work?**

The low-beam unit installed as standard in the headlight consists of two reflectors that produce a low beam from an LED light source. Ride height sensors on front and rear suspension supply data for permanent beam throw adjustment. While the motor-

## 194      ENGINEERING DETAILS

cycle is moving straight ahead, pitch compensation keeps the throw of the headlight beam constantly in the optimum, preset range, regardless of ride and load state. With the Adaptive headlight function, the low-beam unit is additionally rotated about an axis to a degree that varies with the bank angle, compensating for the vehicle's angle of lean. The angle of rotation is  $70^{\circ} (\pm 35^{\circ})$ . Along with pitch compensation, therefore, the throw of the low-beam headlight also compensates for the rider's chosen bank angle through corners. The two movements are superimposed, so as the motorcycle is steered through a bend the headlight beam is directed into the bend for better illumination of the road ahead. The results are considerably better illumination of the road ahead when the vehicle corners, and a huge increase in active riding safety.



**MAINTENANCE**

**10**

---

|                             |            |
|-----------------------------|------------|
| <b>GENERAL NOTES</b>        | <b>198</b> |
| <b>TOOLKIT</b>              | <b>199</b> |
| <b>SPRING-STRUT COVER</b>   | <b>199</b> |
| <b>FRONT-WHEEL STAND</b>    | <b>200</b> |
| <b>ENGINE OIL</b>           | <b>200</b> |
| <b>BRAKE SYSTEM</b>         | <b>202</b> |
| <b>CLUTCH</b>               | <b>207</b> |
| <b>COOLANT</b>              | <b>207</b> |
| <b>TYRES</b>                | <b>209</b> |
| <b>WHEEL RIMS</b>           | <b>210</b> |
| <b>WHEELS</b>               | <b>210</b> |
| <b>SILENCER</b>             | <b>218</b> |
| <b>LIGHTING</b>             | <b>221</b> |
| <b>JUMP-STARTING</b>        | <b>221</b> |
| <b>BATTERY</b>              | <b>223</b> |
| <b>FUSES</b>                | <b>227</b> |
| <b>DIAGNOSTIC CONNECTOR</b> | <b>229</b> |

---

## GENERAL NOTES

The Maintenance chapter describes straightforward procedures for checking and replacing certain wear parts.

Special tightening torques are listed as applicable. The tightening torques for the threaded fasteners on your vehicle are listed in the section entitled "Technical data".

Some of the work calls for special tools and a thorough knowledge of the technology involved. If in doubt consult a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Microencapsulated screws

The microencapsulation is a chemical thread-locker. An adhesive compound creates a secure connection between bolt and nut or between screw and component. Consequently, microencapsulated screws are for once-only use and are not intended for re-installation after being slackened.

Regardless of whether the procedure involves removal or installation, the threaded bore always has to be cleaned. After removal of the screw, clean the

internal thread to remove all traces of thread-locking compound. Always use new microencapsulated screws when re-assembling. Prior to disassembly make sure that you have suitable tools for cleaning the threads and a new replacement for each screw to be removed. If the job is not done correctly there is no guarantee that the screw will remain secure, which means that you would be putting yourself at risk!

### Non-reusable cable ties

Non-reusable cable ties are used at some points to secure cables and lines. To prevent damage to cables and lines when these items are being removed, it is essential to use a suitable tool, for example diagonal cutting pliers, for their removal.

Cables and lines detached beforehand by the removal of non-reusable cable ties have to be re-secured with new non-reusable cable ties.

Use cable-tie clippers to clip off the excess length of the cable ties.

## TOOLKIT



- 1** Screwdriver handle
- 2** Reversible screwdriver blade  
Phillips PH1 and Torx T25  
–Removing and installing trim panel components.
- 3** Tool for oil cap  
–Topping up the engine oil. (➡ 201)  
–Remove the rear seat. (➡ 149)  
–Install the passenger seat. (➡ 150)
- 4** Open-ended spanner  
Width across flats 8/10 mm  
–Removing battery (➡ 225).

## SPRING-STRUT COVER

### Removing spring-strut cover

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Disengage spring-strut cover **1** from grommets **2**.

### Installing spring-strut cover

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Engage spring-strut cover **1** in grommets **2**.

## FRONT-WHEEL STAND

### Installing front-wheel stand



#### ATTENTION

**Use of the BMW Motorrad front-wheel stand without accompanying use of centre stand or auxiliary stand**

Risk of damage to parts if vehicle topples

- Place the motorcycle on its centre stand or another auxiliary stand before lifting the front wheel with the BMW Motorrad front-wheel stand.
- Make sure the motorcycle is standing firmly.
- Make sure the ground is level and firm and place the motorcycle on its centre stand.



- See the instructions issued with the front-wheel stand for the details of the correct procedure for installation.

- BMW Motorrad offers an auxiliary stand suitable for every vehicle. Your BMW Motorrad retailer will be happy to help you with the selection of a suitable auxiliary stand.

## ENGINE OIL

### Checking engine oil level




#### ATTENTION

**Misinterpretation of oil level reading, because oil level is temperature-dependent (the higher the temperature, the higher the oil level)**

Engine damage due to incorrect oil filling

- Check the oil level only after a lengthy ride or when the engine is at operating temperature.
  - Allow the engine to idle until the fan cuts in.
  - Switch off the engine when it is at operating temperature.
  - Make sure the ground is level and firm and place the motorcycle on its centre stand.
  - Wait five minutes for the oil to drain into the oil pan.
-  To avoid unnecessary environmental impact, BMW Motorrad recommends

checking the engine oil after riding min. 50 km.




### ATTENTION

#### Vehicle toppling sideways

Risk of damage to parts if vehicle topples

- Secure the vehicle, preferably with the assistance of a second person, so that it cannot topple sideways.
- Check the oil level in sight glass **1**.



Engine oil, specified level

Between **MIN** and **MAX** marks

If the oil level is below the **MIN** mark:

- Topping up the engine oil. (→ 201)

If the oil level is above the **MAX** mark:

- Have the oil level corrected by a specialist workshop, preferably an authorised BMW Motorrad retailer.

#### Topping up engine oil

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Wipe the area around the oil filler opening clean.
- Engage oil filler cap tool **1** in cap **2** of the oil filler opening and turn the tool anti-clockwise to remove the cap.



## ATTENTION

### Use of insufficient engine oil or too much engine oil

Engine damage due to incorrect oil filling

- Always make sure that the engine oil level is correct.
- Top up the engine oil to the specified level.



Engine oil, quantity for topping up

max. 0.8 l (Difference between **MIN** and **MAX**)

- Check the engine oil level. (III → 200)
- Install cap **2** of the oil filler opening.

## BRAKE SYSTEM

### Check operation of the brakes

- Pull the handbrake lever.
  - » The pressure point must be clearly perceptible.
- Press the footbrake lever.
  - » The pressure point must be clearly perceptible.

If pressure points are not clearly perceptible:



## ATTENTION


### Work on brake system not in compliance with correct procedure

Risk to operational reliability of the brake system


- Have all work on the brake system undertaken by trained and qualified specialists.
- Have the brakes checked by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Checking brake pad thickness, front brakes

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Visually inspect the left and right brake pads to ascertain their thickness. Viewing direction: Between wheel and front suspension toward brake pads **1**.



Brake-pad wear limit,  
front

1.0 mm (Friction pad only, without backing plate. The wear indicators (grooves) must be clearly visible.)

If the wear indicating marks are no longer clearly visible:



## WARNING

### Brake-pad thickness less than permissible minimum


Diminished braking effect, damage to the brakes

- In order to ensure the dependability of the brake system, do not permit the brake pads to wear past the minimum permissible thickness.


- Have the brake pads replaced by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Checking brake pad thickness, rear brakes

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Visually inspect the brake pads to ascertain their thickness. Viewing direction: From the rear toward brake pads **1**.



Brake-pad wear limit,  
rear

1.0 mm (Friction pad only,  
without backing plate.)

If the wear limit has been  
reached:



## WARNING

### Brake-pad thickness less than permissible minimum

Diminished braking effect,  
damage to the brakes

- In order to ensure the dependability of the brake system, do not permit the brake pads to wear past the minimum permissible thickness.

- Have the brake pads replaced by a specialist workshop, preferably an authorised BMW Motorrad retailer.

## Checking brake-fluid level, front brakes



### WARNING

#### Not enough brake fluid in brake fluid reservoir, or contaminants in brake fluid

Considerably reduced braking power due to presence of air, contaminants or water in the brake system

- Cease operation of the vehicle immediately and do not ride it until the fault has been rectified.
- Check the brake-fluid levels at regular intervals.
- Always make sure that the lid of the brake fluid reservoir and the area around the lid are cleaned before opening.
- Make sure that only fresh brake fluid from a sealed container is used.
- Make sure the ground is level and firm and place the motorcycle on its centre stand.
- Move the handlebars to the straight-ahead position.



- Check the brake fluid level in brake fluid reservoir for front wheel brake 1.



Wear of the brake pads causes the brake fluid level in the reservoir to sink.



Brake fluid level, front

#### Brake fluid, DOT4

You should never allow the brake fluid level to drop below the **MIN** mark. (Brake-fluid reservoir horizontal, motorcycle upright)

## 206 MAINTENANCE

If the brake fluid level drops below the permitted level:

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

### Checking brake-fluid level, rear brakes

#### **WARNING**

#### **Not enough brake fluid in brake fluid reservoir, or contaminants in brake fluid**

Considerably reduced braking power due to presence of air, contaminants or water in the brake system

- Cease operation of the vehicle immediately and do not ride it until the fault has been rectified.
- Check the brake-fluid levels at regular intervals.
- Always make sure that the lid of the brake fluid reservoir and the area around the lid are cleaned before opening.
- Make sure that only fresh brake fluid from a sealed container is used.
- Make sure the ground is level and firm and place the motorcycle on its centre stand.

- Remove the spring-strut cover. (► 199)



- Check the brake fluid level in brake fluid reservoir for rear wheel brake 1.

 Wear of the brake pads causes the brake fluid level in the reservoir to sink.



Brake fluid level, rear

#### Brake fluid, DOT4

You should never allow the brake fluid level to drop below the **MIN** mark. (Brake-fluid reservoir horizontal, motorcycle upright)

If the brake fluid level drops below the permitted level:

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.
- Install the spring-strut cover. (➡ 199)

## CLUTCH

### Checking operation of the clutch

- Pull the clutch lever.
- » The pressure point must be clearly perceptible.

If the pressure point is not clearly perceptible:

- Have the clutch checked by a specialist workshop, preferably an authorised BMW Motorrad retailer.

## COOLANT

### Check the coolant level

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Allow the motor to cool down.



- Check the coolant level in expansion tank **1**.



Specified coolant level

Between **MIN** and **MAX** marks on the expansion tank (Engine cold)

If the coolant drops below the permitted level:

- Top up the coolant. (➡ 208)

## 208 MAINTENANCE

### Topping up coolant



#### WARNING

#### Opening radiator cap

Risk of burning

- Do not open the radiator cap when the system is hot.
- Check and, if necessary, top up the coolant in the expansion tank only.




- Remove screws **1**.



- Ease side trim panel **1** forward and out.
  - » Retaining pins **3** are pulled out of the grommets.

- Work side panel **1** up and clear of side trim **4** and remove, noting lugs **2**.



- Open cap **1** of the coolant expansion tank and top up the coolant to the specified level.
- Check the coolant level.  
( 207)
- Close the cap of the coolant expansion tank.



- Hold side panel **1** in position with lugs **2** in place at side trim **4**.
-  Make sure that the rubber grommets are installed correctly and are not pressed out during installation.

- Pivot side panel **1** inward.
- » Retaining pins **3** are pressed into the grommets.



- Install screws **1**.

## TYRES

### Checking tyre pressures



#### WARNING

#### Incorrect tyre pressure

Impaired handling characteristics of the motorcycle, shorter useful tyre life

- Always check that the tyre pressures are correct.



#### WARNING

#### Tendency of valve inserts installed vertically to open by themselves at high riding speeds

Sudden loss of tyre pressure

- Install valve caps fitted with rubber sealing rings and tighten firmly.

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Check tyre pressures against the data below.



Before adjusting the tyre pressure, read the information on temperature compensation and adjusting pressure in the section entitled "Engineering details":



Tyre pressure, front

2.5 bar (tyre cold)



Tyre pressure, rear

2.9 bar (tyre cold)

If tyre pressure is too low:

- Correct tyre pressure.

### Check the tyre tread depth



#### WARNING

#### Riding with badly worn tyres

Risk of accident due to impaired handling

- If applicable, have the tyres changed in good time before they wear to the minimum tread depth permitted by law.

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Measure the tyre tread depth in the main tread grooves with wear marks.



Each tyre has wear indicators integrated into the main tread grooves. The tyre has reached its wear limit when the tread has worn down to the level of the wear indicators. The locations of the marks are indicated on the edge of the tyre, e.g. by the letters TI, TWI or by an arrow. If the tyre tread is worn to minimum:

- Replace tyre or tyres, as applicable.

---

### WHEEL RIMS

#### Checking rims

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Visually inspect the rims for defects.
- Have damaged rims checked and, if necessary, replaced by a specialist workshop, preferably an authorised BMW Motorrad retailer.

---

### WHEELS

#### Effect of wheel size on chassis and suspension control systems

Wheel size is very important as a parameter for the suspension control systems. In particular, the diameter and the width of a vehicle's wheels are programmed into the control unit and are fundamental to all calculations. Any change in these influencing variables, caused for example by a switch to wheels other than those installed ex-works, can have serious effects on the performance of the control systems.


The sensor rings are essential for correct road-speed calculation, and they too must match the motorcycle's control systems and consequently cannot be changed.

If you decide that you would like to fit non-standard wheels to your motorcycle, it is very important to consult a specialist workshop beforehand, preferably an authorised BMW Motorrad retailer. In some cases, the data programmed into the control units can be changed to suit the new wheel sizes.


## Removing front wheel




- Remove screws **1** on left and right.



- Disengage front-wheel cover **1** at hooks **2** and remove.
- Make sure the ground is level and firm and place the motorcycle on its centre stand.



- Disengage the cable for the wheel speed sensor from holding clips **1** and **2**.
- Remove screw **3** and remove the wheel speed sensor from its bore.
- Remove mounting bolts **4** of the left and right brake calipers.



- Force brake pads **1** slightly apart by rocking brake caliper **2** back and forth against brake disc **3**.



## ATTENTION

### Use of hard or sharp-edged objects in proximity to component

Component damage

- Take care not to scratch components; cover or mask as necessary.

- Mask off the parts of the wheel rim that could be scratched in the process of removing the brake calipers.



## ATTENTION


### Unwanted inward movement of the brake pads

Component damage on attempt to install the brake caliper or because brake pads have to be forced apart


- Do not operate the brakes with a brake caliper not correctly secured.
- Carefully pull the brake calipers back and out until clear of the brake discs.
- Make sure the ground is level and firm and place the motorcycle on its centre stand
- Raise front of motorcycle until the front wheel can turn freely. Use a suitable front-

wheel stand to lift the front of the motorcycle.


- Install the front-wheel stand. (→ 200)




- Undo right axle clamping screw **1**.



- Remove screw **1**.
- Undo left axle clamping screw **2**.
- Press quick-release axle slightly toward the inside, so as to be better able to grip it on the right-hand side.



- Withdraw quick-release axle **1**, support the front wheel when doing this.
- Set down front wheel and roll forwards out of the front suspension.



- Remove spacer bushing **1** from the wheel hub.

## Installing front wheel

### **WARNING**

#### **Use of a non-standard wheel**

Malfunctions in operation of ABS and DTC


- See the information on the effect of wheel size on the ABS and DTC systems at the start of this chapter.

### **ATTENTION**

#### **Tightening threaded fasteners to incorrect tightening torque**

Damage, or threaded fasteners work loose

- Always have the security of the fasteners checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.



- Lubricate the friction face of spacer bushing **1**

## 214 MAINTENANCE



Lubricant

Unirex N3

- Insert spacer bushing **1**, turned with the collar facing out, into the wheel hub on the left-hand side.




### ATTENTION

#### Front wheel installed wrong way round

Risk of accident

- Note direction-of-rotation arrows on tyre or rim.
- Roll the front wheel into position between the forks of the front suspension.



- Lubricate quick-release axle **1**.



Lubricant

Unirex N3




### WARNING

#### Improper installation of the quick-release axle

Loosening of the front wheel

- After securing the brake calipers and relieving the front forks, tighten the quick-release axle and the axle clamping to the specified tightening torque.
- Lift the front wheel slightly and install quick-release axle **1**.
- Remove front-wheel stand and firmly compress front forks several times. Do not operate the handbrake lever in this process.
- Install the front-wheel stand. (▶ 200)



- Install screw **1** and tighten to specified torque. In this process, counter-hold the quick-release axle on the right side.

 Quick-release axle in telescopic forks

M12 x 20


30 Nm

- Tighten left axle clamping screw **2** to specified torque.

 Clamping screw for quick-release axle in telescopic fork

M8 x 35

19 Nm



- Tighten right axle clamping screw **1** to specified torque.


 Clamping screw for quick-release axle in telescopic fork

M8 x 35

19 Nm

- Remove the front-wheel stand.

- Position left and right brake calipers on the brake discs.



- Install securing screws **4** on left and right and tighten to specified tightening torque.

 Radial brake caliper on telescopic forks

M10 x 65

38 Nm

- Remove the adhesive tape from the wheel rim.



## WARNING

### Brake pads not lying against the brake disc

Risk of accident due to delayed braking effect.

- Before driving, check that the brakes respond without delay.
- Operate the brake several times until the brake pads are bedded.

## 216 MAINTENANCE

- Seat the cable for the wheel-speed sensor in holding clips **1** and **2**.
- Insert the wheel speed sensor into the bore hole and install screw **3**.



Wheel-speed sensor to fork leg

M6 x 16

Joining compound: Micro-encapsulated or medium-strength thread-locking compound

8 Nm



- Install screws **1** on left and right.




Front-wheel cover, front, to front-wheel cover, rear

M5 x 14

Thread-locking compound: micro-encapsulated

2 Nm



- Hold front-wheel cover **1** in position, noting hooks **2**.

### Removing rear wheel

- Make sure the ground is level and firm and place the motorcycle on its centre stand.
- Engage first gear.
- Pivot the silencer outwards.  
( 218)



- Remove bolts **1** from the rear wheel, while supporting the wheel.
- Tilt the rear wheel to the side to remove.

### Installing rear wheel

#### **WARNING**

##### **Use of a non-standard wheel**

Malfunctions in operation of ABS and DTC

- See the information on the effect of wheel size on the ABS and DTC systems at the start of this chapter.

#### **ATTENTION**

##### **Tightening threaded fasteners to incorrect tightening torque**

Damage, or threaded fasteners work loose


- Always have the security of the fasteners checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.

#### **ATTENTION**

##### **Rear wheel installed with tyre's direction of rotation incorrect**

Risk of accident

- Note direction-of-rotation arrows on tyre or rim.



- Clean the contact surfaces of wheel hub **1** and wheel centring spigot **2**.
- Seat the rear wheel on the rear-wheel adapter.

## 218 MAINTENANCE



- Install wheel bolts **1** and tighten to specified torque.



Rear wheel on wheel flange

Tightening sequence: Tighten in diagonally opposite sequence

M10 x 1.25 x 40

60 Nm

- Secure the silencer. (→ 219)

### SILENCER

#### Pivoting silencer outwards




#### CAUTION


##### Hot exhaust system

Risk of burn injury

- Do not touch a hot exhaust system.
- Make sure the ground is level and firm and place the motorcycle on its stand.
- Allow the silencer to cool.




- Remove screws **1**.
- Remove screw with washer **2**.
- Remove silencer cover **3**.



- Slacken screw **1**.
- Remove screw **2** with washer **3**.
- Turn silencer **4** clockwise and out.

—with Sports silencer<sup>OE</sup>



- Slacken clamp **1**.◁

—with Sports silencer<sup>OE</sup>



- Remove screw **1** with washer **2**.
- Turn silencer **3** clockwise and out.◁

## Securing silencer




### ATTENTION

#### Tightening threaded fasteners to incorrect tightening torque

Damage, or threaded fasteners work loose

- Always have the security of the fasteners checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.



- Turn silencer **1** counter-clockwise until it is seated against the passenger-footrest bracket.
- Install washer **2** and screw **3**.




Silencer to rear frame

M8 x 35

19 Nm

## 220 MAINTENANCE

–with Sports silencer<sup>OE</sup>




- Turn silencer **3** counter-clockwise until it is seated against the passenger-footrest bracket.
- Install washer **2** and screw **1**.

 Silencer to rear frame

M8 x 35

19 Nm



- Slide the clamp with recess **1** as far forward as possible and align it with retaining lug **2**.  
» Retaining lug engages recess in the clamp.
- Tighten clamp **1**.

 Clamp to silencer and exhaust manifold

22 Nm


–with Sports silencer<sup>OE</sup>



- Tighten clamp **1**.

 Clamp to silencer and exhaust manifold

22 Nm



- Position silencer cover **3**.
- Install screws **1**.
- Install screw with washer **2**.

 Heat shield to rear silencer

5 Nm

---

## LIGHTING

### Replacing LED light sources



#### WARNING

**Vehicle overlooked in traffic due to failure of the lights on the vehicle**

Safety risk

- Always replace a faulty bulb at the earliest possible opportunity. Consult a specialist workshop, preferably an authorised BMW Motorrad Retailer.

All light sources of the vehicle are LED light sources. The service life of the LED light sources is longer than the presumed vehicle service life. If an LED light source is faulty contact a specialist workshop, preferably an authorised BMW Motorrad retailer.

---

## JUMP-STARTING



#### CAUTION

**Touching live parts of the ignition system when the engine is running**

Electric shock

- Do not touch parts of the ignition system when the engine is running.



#### ATTENTION

**Excessive current flowing when the motorcycle is jump-started**

Wiring smoulders/ignites or damage to the on-board electronics

- If the motorcycle has to be jump-started connect the leads to the battery terminals; never attempt to jump-start the engine by connecting leads to the on-board socket.

## **ATTENTION**

### **Contact between crocodile clips of jump leads and vehicle**

Risk of short-circuit


- Use jump leads fitted with fully insulated crocodile clips at both ends.

## **ATTENTION**

### **Jump-starting with a voltage greater than 12 V**

Damage to the on-board electronics

- Make sure that the battery of the donor vehicle has a voltage rating of 12 V.
- Make sure the ground is level and firm and place the motorcycle on its stand.
- Remove the battery cover. ( 225)
- When jump-starting the engine, do not disconnect the battery from the on-board electrical system.
- Remove protective cap **1**.
- Use the red jump lead to connect remote positive terminal **2** of the discharged battery to the positive terminal of the donor battery.
- Connect one end of the black jump lead to the negative terminal of the donor battery, then connect the other end to negative terminal **3** of the discharged battery.
- Run the engine of the donor vehicle during jump-starting.
- Start the engine of the vehicle with the discharged battery in the usual way; if the engine does not start, wait a few minutes before repeating the attempt in order to protect the starter motor and the donor battery.
- Allow both engines to idle for a few minutes before disconnecting the jump leads.
- Disconnect the jump lead from the negative terminals first, then disconnect the



second lead from the positive terminals.

 Do not use proprietary start-assist sprays or other products to start the engine.

- Install the protective cap.
- Install the battery cover.

( 227)

## BATTERY

### Maintenance instructions

Correct upkeep, recharging and storage will prolong the life of the battery and are essential if warranty claims are to be considered.

Compliance with the points below is important in order to maximise battery life:

- Keep the surface of the battery clean and dry.
- Do not open the battery.
- Do not top up with water.
- Be sure to read and comply with the instructions for charging the battery on the following pages.
- Do not turn the battery upside down.



Battery type

AGM (Absorbent Glass Mat), maintenance-free



### ATTENTION

#### On-board electronics (e.g. clock) draining connected battery

Battery is deep-discharged; this voids the guarantee

- Connect a float charger to the battery if the motorcycle is to remain out of use for more than four weeks.



BMW Motorrad has developed a float charger specially designed for compatibility with the electronics of your motorcycle. Using this charger, the battery can be kept charged during long periods of disuse, without having to be disconnected from the vehicle's on-board systems. For more information, consult an authorised BMW Motorrad retailer.

#### Charging battery when connected

- Disconnect devices plugged into the sockets.



## ATTENTION

### Charging the battery that is connected to the vehicle via the battery terminals

Damage to the on-board electronics

- Disconnect the battery at the battery terminals before charging.



## ATTENTION

### Recharging a fully discharged battery via the power socket or extra socket

Damage to the vehicle electronics

- If a battery has discharged to the extent that it is completely flat (battery voltage less than 12 V, indicator lights and multifunction display remain off when the ignition is switched on) always charge the **disconnected** battery with the charger connected directly to the battery terminals.



## ATTENTION

### Unsuitable chargers connected to a socket

Damage to charger and vehicle electronics

- Use suitable BMW chargers. The suitable charger is available from your authorised BMW Motorrad dealer.

- With the battery connected to the vehicle's on-board electrical system, charge via the power socket in the cockpit.



The connected battery can only be charged via the socket in the cockpit.



The motorcycle's on-board electronics know when the battery is fully charged. The on-board socket is switched off when this happens.

- Comply with the operating instructions of the charger.



If you are unable to charge the battery through the on-board socket, you may be using a charger that is not compatible with your motorcycle's electronics. If this happens, charge the battery directly at the terminals of

the battery that is disconnected from the vehicle.

### Charging battery when disconnected

- Charge the battery using a suitable charger.
- Comply with the operating instructions of the charger.
- Once the battery is fully charged, disconnect the charger's terminal clips from the battery terminals.

 The battery has to be recharged at regular intervals in the course of a lengthy period of disuse. See the instructions for caring for your battery. Always fully recharge the battery before restoring it to use.

### Removing battery




#### ATTENTION

#### Battery not disconnected in accordance with correct procedure

Risk of short-circuit


- Always proceed in compliance with the specified disconnection sequence.



- Switch off the ignition.
- Remove screws **1**.
- Remove battery cover **2**.

—with anti-theft alarm (DWA)<sup>OE</sup>

- If applicable, switch off the anti-theft alarm (DWA).◁



- Disconnect battery earth lead **1** and disengage rubber strap **2**.
- Wrap the end of negative battery cable **1** with insulating tape.

## 226 MAINTENANCE



- Pull retaining panel in position **1** outwards and remove in an upward direction.
- Slightly lift the battery and ease it clear of the holder until the battery positive terminal is accessible.



- Disconnect battery negative lead **1** and remove the battery.
- » The battery is removed.

### Installing battery



#### ATTENTION

**Battery not connected in accordance with correct procedure**

Risk of short-circuit

- Always proceed in compliance with specified installation sequence.



- Secure positive battery cable **1**.




Wiring harness to battery


M6 x 11

3.5 Nm


- Slide the battery into the holder, making sure that positive battery cable **1** is correctly routed.



- First push the retaining plate under the battery at position **2** and then seat it in mounts **1**.



- Hold battery cover **2** in position.
- Install screws **1**.
- Change the system settings.  
( 76)



- Remove the insulating tape from negative battery cable **1**.
- Secure negative battery cable **1**.



Wiring harness to battery

M6 x 11

3.5 Nm

- Secure the battery with rubber strap **2**.

## FUSES

### Replacing fuses




#### ATTENTION

#### Jumpering of blown fuses

Risk of short-circuit and fire

- Never attempt to jumper a blown fuse.
- Always replace a defective fuse with a new fuse of the same amperage.

## 228 MAINTENANCE




- Switch off the ignition.
- Remove the rider's seat.  
( 148)
- Remove fuse box 1.
- Consult the fuse assignment diagram and replace the defective fuse.

 If fuse defects recur frequently have the electric circuits checked by a specialist workshop, preferably an authorised BMW Motorrad retailer.

- Insert fuse box 1.
- Install the rider's seat.  
( 148)

### Fuse assignment



- |          |                                |
|----------|--------------------------------|
| <b>1</b> | 15 A                           |
|          | Instrument cluster             |
|          | Anti-theft alarm (DWA)         |
|          | Ignition switch                |
|          | Diagnostic socket              |
|          | Topcase lighting               |
|          | Isolating relay                |
| <b>2</b> | 7.5 A                          |
|          | Multifunction switch, left     |
|          | Tyre pressure monitoring (RDC) |
|          | Seat heating                   |
|          | Sensor group                   |
|          | Front radar                    |


## Fuse for alternator regulator



- 1** 50 A  
Alternator regulator

 Have the fuse replaced by a specialist workshop, preferably by an authorised BMW Motorrad retailer.

## Fuse for audio system



- 1** 15 A  
Fuse for audio system

 Have the fuse replaced by a specialist workshop, preferably by an authorised BMW Motorrad retailer.

## DIAGNOSTIC CONNECTOR

### Disengaging diagnostic socket



#### CAUTION


#### Incorrect disconnection of the diagnostic socket for on-board diagnosis

Malfunctions of the vehicle


- Do not disconnect the diagnostic socket or allow it to be disconnected except in the course of a BMW Motorrad service by a specialist workshop or by other authorised persons.
- Have the work carried out by appropriately trained personnel.
- Comply with the stipulations of the vehicle manufacturer.

- Remove the battery cover.  
( 225)


## 230 MAINTENANCE




- Press hook **1** and pull diagnostic socket **2** up to remove.



- Insert diagnostic socket **2** into holder **4**.
  - » Locks **3** engage on both sides.
- Seat bracket **4** on mounting **1**.



- Press locks **3** on both sides.
- Disengage diagnostic socket **2** from holder **4**.
  - » The interface to the diagnosis and information system can be connected to the diagnostic connector **2**.



- Make sure that hook **5** engages.
- Install the battery cover.  
( 227)

### Securing diagnostic socket

- Disconnect the interface for the diagnosis and information system.



# ACCESSORIES

11

---

|                             |            |
|-----------------------------|------------|
| <b>GENERAL NOTES</b>        | <b>234</b> |
| <b>POWER SOCKETS</b>        | <b>234</b> |
| <b>TOPCASE</b>              | <b>235</b> |
| <b>OPTIONAL ACCESSORIES</b> | <b>238</b> |

## GENERAL NOTES



### CAUTION

#### Use of other-make products

##### Safety risk

- BMW Motorrad cannot examine or test each product of outside origin to ensure that it can be used on or in connection with BMW vehicles without constituting a safety hazard. Country-specific official authorisation does not suffice as assurance. Tests conducted by these instances cannot make provision for all operating conditions experienced by BMW vehicles and, consequently, they are not sufficient in some circumstances.
- Use only parts and accessories approved by BMW for your vehicle.

BMW has conducted extensive testing of the parts and accessory products to establish that they are safe, functional and suitable. Consequently, BMW accepts responsibility for the products. BMW accepts no liability whatsoever for parts and accessories that it has not approved.

All modifications must be in compliance with legal requirements. Make sure that the vehicle does not infringe the national road-vehicle construction and use regulations applicable in your country. Your authorised BMW Motorrad retailer can offer expert advice on the choice of genuine BMW parts, accessories and other products. To find out more about accessories go to:

**[bmw-motorrad.com/equipment](http://bmw-motorrad.com/equipment)**

## POWER SOCKETS

### Connection of electrical devices

- You can start using electrical devices connected to the motorcycle's sockets only when the ignition is switched on.

### Cable routing

- The cables from the power sockets to the auxiliary devices must be routed in such a way that they do not impede the rider.
- The cable routing should not restrict the steering angle or obstruct handling.
- The cables must not be trapped.

### Automatic shutdown

- The sockets will be automatically switched off during the start procedure.
- The power supply to the sockets is switched off 60 seconds after the ignition is switched off, in order to prevent overloading of the on-board electrics. Low-wattage electrical accessories might not be recognised by the vehicle's electronics. In such cases, power sockets are switched off very shortly after the ignition is turned off.
- If the battery charge state is too low to maintain the motorcycle's start capability, the power sockets are switched off.
- The power sockets are also switched off when the maximum load capability as stated in the technical data is exceeded.



- Turn the key in the topcase lock to the dot position and remove the key from the lock.



- Press lock barrel **1** down.
- » Release lever **2** pops up.
- Pull release lever **2** all the way up and open the lid of the topcase.

---

### TOPCASE

- with topcase<sup>OA</sup>

#### Opening topcase

- with central locking system<sup>OE</sup>
- If necessary, unlock the central locking system.<

## 236 ACCESSORIES

### Closing topcase




- Pull release lever **2** all the way up.
- Close the lid of the topcase and hold it down. Check that nothing is trapped between the lid and the case.

 The topcase can also be closed when the lock is in the **LOCK** position. Make sure that the vehicle key is not left inside the topcase.

- Push release lever **2** down until it engages.
- Turn the key in the topcase lock to the **LOCK** position and remove the key from the lock.

### Removing topcase

- Remove the rider's seat.  
( 148)
- Remove the rear seat.  
( 149)



- Disconnect plug connection **1**.
- Work the plug of the topcase through to the rear.
- Open the topcase.
- If applicable, empty the topcase and lift out the bottom mat.



- Push slide latch **2** toward the outside and hold it in this position.
- Turn rotary latch **3** in the direction indicated by the **RELEASE** arrow.
  - » Release warning **4** is visible.
- Close the topcase.



- Lift the topcase at the rear and remove it from the luggage carrier.
- Install the passenger seat.  
(▶▶▶ 150)
- Install the rider's seat.  
(▶▶▶ 148)

### Installing topcase

- Remove the rider's seat.  
(▶▶▶ 148)
- Remove the rear seat.  
(▶▶▶ 149)
- If applicable, empty the topcase and lift out the bottom mat.



- Set the topcase on the luggage carrier.


- Open the topcase. (▶▶▶ 235)




- Turn rotary latch **3** as far as it will go in the direction indicated by the **LOCK** while pressing down on the back edge of the topcase.
- » Release warning **4** is no longer visible.

If the release warning is still visible the topcase is not correctly secured.

- Make sure that the topcase is correctly seated on the luggage carrier.



- Seat the connecting cable in holders **5** and route it forward.



- Work the cable into place at positions **6**.
- Close plug connection **1**.
- Install the passenger seat.  
( 150)
- Install the rider's seat.  
( 148)

## Maximum payload and maximum speed

Note the maximum payload and the maximum permissible speed.

The values for the combination described here are as follows:

|                                                                                    |                                                 |
|------------------------------------------------------------------------------------|-------------------------------------------------|
|   | Maximum speed for riding with a loaded top-case |
|                                                                                    | max. 180 km/h                                   |
|  | Payload of topcase                              |
|                                                                                    | max. 5 kg                                       |

## OPTIONAL ACCESSORIES

Available optional accessories



Your authorised BMW Motorrad retailer can offer expert advice on the choice of genuine BMW parts, accessories and other products such as luggage systems or windscreens.

You can examine all the optional accessories from BMW Motorrad by visiting: **[bmw-motorrad.com](http://bmw-motorrad.com)**.



**CARE**

**12**

---

|                                           |            |
|-------------------------------------------|------------|
| <b>CARE PRODUCTS</b>                      | <b>242</b> |
| <b>WASHING THE VEHICLE</b>                | <b>242</b> |
| <b>CLEANING EASILY DAMAGED COMPONENTS</b> | <b>243</b> |
| <b>CARE OF PAINTWORK</b>                  | <b>245</b> |
| <b>PAINT PRESERVATION</b>                 | <b>245</b> |
| <b>LAYING UP MOTORCYCLE</b>               | <b>245</b> |
| <b>RESTORING MOTORCYCLE TO USE</b>        | <b>246</b> |

## CARE PRODUCTS



### ATTENTION

#### Use of unsuitable cleaning and care products

Damage to vehicle parts

- Do not use solvents such as cellulose thinners, cold cleaners, fuel or the like, and do not use cleaning products that contain alcohol.



### ATTENTION

#### Use of strongly acidic or strongly alkaline cleaning agents

Damage to vehicle parts

- Dilute in accordance with the dilution ratio stated on the packaging of the cleaning agent.
- Do not use strongly acidic or strongly alkaline cleaning agents.

BMW Motorrad recommends that you use the cleaning and care products you can obtain from your authorised BMW Motorrad retailer. The substances in BMW Care Products have been tested in laboratories and in practice;

they provide optimised care and protection for the materials used in your vehicle.

## WASHING THE VEHICLE



### WARNING

#### Wet brake discs and brake pads after vehicle wash, after riding through water and in rainy conditions

Diminished braking effect, risk of accident

- Apply the brakes in good time to allow the friction and heat to dry the brake discs and brake pads.



### ATTENTION

#### Damage due to high water pressure from high pressure cleaners or steam cleaners

Corrosion or short circuit, damage to labels, seals, hydraulic brake system, electrical system and the motorcycle seat

- Exercise restraint when using a steam jet or high pressure cleaning equipment.

BMW Motorrad recommends that you use BMW insect remover to soften and wash off insects and stubborn dirt on

painted parts prior to washing the vehicle.

To prevent stains, do not wash the vehicle immediately after it has been exposed to strong sunlight and do not wash it in the sun.

Remove dirt from the fork legs at regular intervals.

Make sure that the vehicle is washed frequently, especially during the winter months or if it is ridden on salted roads.



### ATTENTION

#### Effect of road salt intensified by warm water

Corrosion

- Use only cold water to remove road salt deposits.

To remove road salt deposits, clean the vehicle and mounted parts, as applicable, with cold water immediately after every trip.



After a ride in the rain, when humidity is high or after the vehicle has been washed, condensation might form inside the headlight. This can cause temporary fogging on the headlight lens. If moisture is constantly present inside the headlight consult a specialist workshop, preferably an

authorised BMW Motorrad retailer.

## CLEANING EASILY DAMAGED COMPONENTS

### Plastics



### ATTENTION

#### Use of unsuitable cleaning agents

Damage to plastic surfaces

- Do not use cleaning agents that contain alcohol, solvents or abrasives.
- Do not use insect-remover pads or cleaning pads with hard, scouring surfaces.

Clean the plastic parts with water and BMW plastic care product. This includes in particular:

- Windscreen and slipstream deflectors
- Headlight lens made of plastic
- Glass cover of the instrument cluster
- Black, unpainted parts



Soften stubborn dirt and insects by covering the affected areas with a wet cloth.

## 244 CARE

### Instrument cluster

Clean the instrument cluster with warm water and washing-up liquid. Then dry it with a clean cloth, e.g. a paper towel.

### Chrome

Carefully clean chrome parts with plenty of water and motorcycle cleaner from the BMW Care Products range. This is particularly important to counter the effects of salt. Use BMW Motorrad high-gloss polish for additional treatment.

### Radiator

Clean the radiator regularly to prevent overheating of the engine due to inadequate cooling. For example, use a garden hose with low water pressure.



### ATTENTION

#### Bending of radiator fins

Damage to radiator fins

- Take care not to bend the radiator fins when cleaning.

### Rubber



### ATTENTION

#### Application of silicone sprays to rubber seals

Damage to the rubber seals

- Do not use silicone sprays or care products that contain silicon.

Treat rubber components with water or BMW rubber-care products.

### Radar sensor

—with Active Cruise Control<sup>OE</sup>



Clean radar sensor **1** with a cloth moistened with a proprietary glass cleaner.

---

## CARE OF PAINTWORK



### ATTENTION

#### Damage to paintwork due to metal polish

Risk of damage

- Do not treat painted surfaces and chrome-painted surfaces with metal polish.

Washing the vehicle regularly will help counteract the long-term effects of substances that can damage the paint, especially if your vehicle is ridden in areas with high air pollution or natural sources of dirt, for example tree resin or pollen.

Remove particularly aggressive substances immediately, however, as otherwise the paint can be affected or become discoloured. Substances of this nature include spilt fuel, oil, grease, brake fluid and bird droppings. For this, we recommend BMW Motorrad solvent cleaner followed by BMW Motorrad gloss polish for preservation.

Marks on the paintwork are particularly easy to see after the vehicle has been washed. Remove stains of this kind at the earliest possible opportu-

ity, using benzine or petroleum spirit on a clean cloth or ball of cotton wool. BMW Motorrad recommends using BMW tar remover for removing specks of tar. Then apply preserving agent to the areas treated in this way.

---

## PAINT PRESERVATION

If water no longer rolls off the paint, the paint must be preserved.

For paint preservation, BMW Motorrad recommends the use of BMW Motorrad gloss polish or agents containing carnauba wax or synthetic wax.



Do not use chrome polish to preserve chrome paints. Use only the agents recommended by BMW Motorrad.

---

## LAYING UP MOTORCYCLE

- Fill the motorcycle's fuel tank.



Fuel additives clean the fuel injection system and the combustion zone. It is advisable to use fuel additives when the engine is operated with low-grade fuel or if the vehicle is to be out of use for a lengthy period of time. More information is available from

your authorised BMW Motorrad  
retailer.

- Clean the motorcycle.
- Remove the battery. (▶▶▶ 225)
- Spray the brake and clutch lever pivots and the side-stand and centre-stand pivot mounts with a suitable lubricant.
- Coat bright metal and chrome-plated parts with an acid-free grease (e.g. Vaseline).
- Stand the motorcycle in a dry room in such a way that there is no load on either wheel.

## RESTORING MOTORCYCLE TO USE

- Remove the protective wax coating.
- Clean the motorcycle.
- Install the battery. (➡ 226)
- Note the checklist (➡ 159).



# TECHNICAL DATA

13

---

|                                     |            |
|-------------------------------------|------------|
| <b>TROUBLESHOOTING CHART</b>        | <b>250</b> |
| <b>THREADED FASTENERS</b>           | <b>254</b> |
| <b>FUEL</b>                         | <b>256</b> |
| <b>ENGINE OIL</b>                   | <b>257</b> |
| <b>ENGINE</b>                       | <b>257</b> |
| <b>CLUTCH</b>                       | <b>258</b> |
| <b>TRANSMISSION</b>                 | <b>258</b> |
| <b>FINAL DRIVE</b>                  | <b>258</b> |
| <b>FRAME</b>                        | <b>258</b> |
| <b>CHASSIS AND SUSPENSION</b>       | <b>258</b> |
| <b>BRAKES</b>                       | <b>259</b> |
| <b>WHEELS AND TYRES</b>             | <b>259</b> |
| <b>ELECTRICAL SYSTEM</b>            | <b>260</b> |
| <b>DIMENSIONS</b>                   | <b>261</b> |
| <b>WEIGHTS</b>                      | <b>262</b> |
| <b>PERFORMANCE FIGURES</b>          | <b>262</b> |
| <b>RADIO</b>                        | <b>262</b> |
| <b>SPEAKERS (VEHICLE-DEPENDENT)</b> | <b>263</b> |

## TROUBLESHOOTING CHART

The engine does not start.

| Possible cause                                                                                               | Rectification                                                                                                               |
|--------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| Side stand extended and gear engaged                                                                         | Retract the side stand.                                                                                                     |
| Gear engaged and clutch not disengaged                                                                       | Select neutral or pull the clutch lever.                                                                                    |
| No fuel in tank                                                                                              | Refuel. (  167)                            |
| Battery flat                                                                                                 | Charge the battery when connected. (  223) |
| Starter motor overheating protection has tripped. The starter motor can be operated for a limited time only. | Allow the starter motor to cool down for approximately 1 minute before trying again.                                        |

The Bluetooth connection is not established.

| Possible cause                                                                       | Rectification                                                                                        |
|--------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------|
| The steps required for pairing were not carried out.                                 | Check the necessary steps for pairing in the operating instructions for the communication system.    |
| The communication system was not connected automatically despite successful pairing. | Switch off the helmet's communication system and reconnect it after a minute or two.                 |
| Too many Bluetooth devices are saved on the helmet.                                  | All pairing entries on the helmet are deleted (see the communication system operating instructions). |
| There are other vehicles with Bluetooth-capable devices in the vicinity.             | Avoid simultaneously pairing with more vehicles.                                                     |

Bluetooth connection is interrupted.

| Possible cause                                                | Rectification                                                                                                                                                                                                       |
|---------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The Bluetooth connection to the mobile device is interrupted. | Switch off energy saving mode.                                                                                                                                                                                      |
| The Bluetooth connection to the helmet is interrupted.        | Switch off the helmet's communication system and reconnect it after a minute or two.                                                                                                                                |
| Bluetooth connection interrupted.                             | The temperature of the display is too high. Bluetooth is deactivated. The brightness of the display is reduced. Keep direct sunlight off the display. Interrupt your journey until the components have cooled down. |
| The volume in the helmet cannot be adjusted.                  | Switch off the helmet's communication system and reconnect it after a minute or two.                                                                                                                                |
| In-helmet volume is too low.                                  | Set the mobile device's volume for media and calls to maximum.                                                                                                                                                      |

Display faulty.

| Possible cause              | Rectification                                                                                                                                                                             |
|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Display brightness reduced. | The temperature of the display is too high. The brightness of the display is reduced. Keep direct sunlight off the display. Interrupt your journey until the components have cooled down. |

## 252 TECHNICAL DATA

Phonebook is not displayed in the instrument cluster.

| Possible cause                                    | Rectification                                                                                                                                        |
|---------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| The phonebook was not transmitted to the vehicle. | Confirm transmission of the phone data (📶 84) when pairing the mobile device.                                                                        |
| Not all contacts are shown.                       | The number of phonebook entries that can be saved in the instrument cluster is limited. Reduce the number of phonebook entries on the mobile device. |

Active route guidance is not displayed in the instrument cluster.

| Possible cause                                                      | Rectification                                                                                       |
|---------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| Navigation from the BMW Motorrad Connected app was not transmitted. | Call up the BMW Motorrad Connected app on the paired mobile device prior to departure.              |
| The route guidance cannot be started.                               | Make sure that the mobile device has a data connection and check the map data on the mobile device. |

Playlist not shown on the display.

| Possible cause                                        | Rectification                                                     |
|-------------------------------------------------------|-------------------------------------------------------------------|
| Too many tracks in the playlist on the mobile device. | Reduce the number of tracks in the playlist on the mobile device. |

The instrument cluster remains dark after the ignition is switched on.

| Possible cause                                                                         | Rectification                                                                                                             |
|----------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|
| There is a software error which leads to a function failure of the instrument cluster. | Switch ignition off and on again.                                                                                         |
| The instrument cluster is damaged.                                                     | Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer. |

## 254 TECHNICAL DATA

### THREADED FASTENERS

| Front wheel                                                              | Value                                                                                | Valid |
|--------------------------------------------------------------------------|--------------------------------------------------------------------------------------|-------|
| <b>Radial brake caliper on telescopic forks</b>                          |                                                                                      |       |
| M10 x 65                                                                 | 38 Nm                                                                                |       |
| <b>Bottom fork bridge to slider tube</b>                                 |                                                                                      |       |
| M8 x 35                                                                  | <b>Tightening sequence:</b><br><b>Tighten screws six times in alternate sequence</b> |       |
|                                                                          | 19 Nm                                                                                |       |
| <b>Wheel-speed sensor to fork leg</b>                                    |                                                                                      |       |
| M6 x 16<br>Micro-encapsulated or medium-strength thread-locking compound | 8 Nm                                                                                 |       |
| <b>Quick-release axle in telescopic forks</b>                            |                                                                                      |       |
| M12 x 20                                                                 | 30 Nm                                                                                |       |
| Rear wheel                                                               | Value                                                                                | Valid |
| <b>Rear wheel on wheel flange</b>                                        |                                                                                      |       |
| M10 x 1.25 x 40                                                          | <b>Tightening sequence:</b><br><b>Tighten in diagonally opposite sequence</b>        |       |
|                                                                          | 60 Nm                                                                                |       |

| Exhaust system                                | Value | Valid |
|-----------------------------------------------|-------|-------|
| <b>Silencer to rear frame</b>                 |       |       |
| M8 x 35                                       | 19 Nm |       |
| <b>Clamp to silencer and exhaust manifold</b> |       |       |
|                                               | 22 Nm |       |

| Mirror arm              | Value | Valid |
|-------------------------|-------|-------|
| <b>Mirror to holder</b> |       |       |
| M6 x 50                 | 8 Nm  |       |

## 256 TECHNICAL DATA

### FUEL

|                                     |                                                                                                                                                                                                                                                                                        |
|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Recommended fuel grade              |  Premium unleaded (max. 15% ethanol, E15)<br> 95 ROZ/RON<br>90 AKI                                                   |
| Alternative fuel grade              |  Regular unleaded (power- and consumption-related restrictions) (max. 15% ethanol, E10/E15)<br> 91 ROZ/RON<br>87 AKI |
| Usable fuel capacity                | approx. 25 l                                                                                                                                                                                                                                                                           |
| Reserve fuel                        | approx. 4 l                                                                                                                                                                                                                                                                            |
| Fuel consumption                    | 4.8 l/100 km, in accordance with WMTC                                                                                                                                                                                                                                                  |
| —with power reduction <sup>OE</sup> | 4.9 l/100 km, in accordance with WMTC                                                                                                                                                                                                                                                  |
| CO2 emission                        | 110 g/km, in accordance with WMTC                                                                                                                                                                                                                                                      |
| —with power reduction <sup>OE</sup> | 113 g/km, in accordance with WMTC                                                                                                                                                                                                                                                      |
| Exhaust emissions standard          | EU 5                                                                                                                                                                                                                                                                                   |
| —with Canada export <sup>NV</sup>   | TIER 2, measured in accordance with FTP75                                                                                                                                                                                                                                              |

## ENGINE OIL

|                                     |                                                                                                                                                                                                          |
|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Engine oil, capacity                | max. 4 l, with filter change                                                                                                                                                                             |
| Specification                       | SAE 5W-40, API SL / JASO MA2, Additives (e.g. molybdenum-based) are not permissible because they can attack coated components of the engine, BMW Motorrad recommends BMW Motorrad ADVANTEC Ultimate oil. |
| Engine oil, quantity for topping up | max. 0.8 l, Difference between <b>MIN</b> and <b>MAX</b>                                                                                                                                                 |

**BMW recommends** **ADVANTEC**  
ORIGINAL BMW ENGINE OIL

## ENGINE

|                                     |                                                                                                                                                                                    |
|-------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Engine number location              | Crankcase, bottom right, below starter motor                                                                                                                                       |
| Engine type                         | A74B12M                                                                                                                                                                            |
| Engine design                       | Air-/liquid-cooled, two-cylinder four-stroke boxer engine with two overlying, spur-gear-driven camshafts, a counterbalance shaft and variable intake camshaft control BMW ShiftCam |
| Displacement                        | 1254 cm <sup>3</sup>                                                                                                                                                               |
| Compression ratio                   | 12.5:1                                                                                                                                                                             |
| Nominal capacity                    | 100 kW, at rpm: 7750 min <sup>-1</sup>                                                                                                                                             |
| –with power reduction <sup>OE</sup> | 79 kW, at rpm: 7750 min <sup>-1</sup>                                                                                                                                              |
| Torque                              | 143 Nm, at rpm: 6250 min <sup>-1</sup>                                                                                                                                             |
| –with power reduction <sup>OE</sup> | 140 Nm, at rpm: 5000 min <sup>-1</sup>                                                                                                                                             |
| Maximum engine speed                | max. 9000 min <sup>-1</sup>                                                                                                                                                        |

## 258 TECHNICAL DATA

|            |                                                                  |
|------------|------------------------------------------------------------------|
| Idle speed | 1050 min <sup>-1</sup> , Engine at regular operating temperature |
|------------|------------------------------------------------------------------|

### CLUTCH

|             |                                           |
|-------------|-------------------------------------------|
| Clutch type | Multi-plate oil-bath clutch, anti-hopping |
|-------------|-------------------------------------------|

### TRANSMISSION

|                      |                                                 |
|----------------------|-------------------------------------------------|
| Type of transmission | Claw-shift 6-speed gearbox with helical gearing |
|----------------------|-------------------------------------------------|

### FINAL DRIVE

|                                       |                                       |
|---------------------------------------|---------------------------------------|
| Gear ratio of final drive             | 2.75 (33/12 teeth)                    |
| —with alternative ratio <sup>OE</sup> | 2.82 (31/11 teeth)                    |
| Rear axle differential oil            | SAE 70W-80, above 5 °C and below 5 °C |

### FRAME

|                                               |                                        |
|-----------------------------------------------|----------------------------------------|
| Type plate location                           | Frame, front left at steering head     |
| Position of the vehicle identification number | Frame, front right below steering head |

### CHASSIS AND SUSPENSION

#### Front wheel

|                          |                                                                                                                                                               |
|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Type of front suspension | BMW Telelever, anti-dive top fork bridge, trailing arm pivot-mounted on engine and telescopic forks, central spring strut supported by training arm and frame |
| Spring travel, front     | 120 mm, at wheel                                                                                                                                              |

**Rear wheel**

|                             |                                                                |
|-----------------------------|----------------------------------------------------------------|
| Type of rear suspension     | Cast aluminium single swinging arm with BMW Motorrad Paralever |
| Spring travel at rear wheel | 136 mm, at wheel                                               |

**BRAKES****Front wheel**

|                             |                                                                                                     |
|-----------------------------|-----------------------------------------------------------------------------------------------------|
| Type of front brake         | Hydraulically operated twin disc brake with 4-piston radial brake calipers and floating brake discs |
| Brake-pad material, front   | Sintered metal                                                                                      |
| Brake disc thickness, front | 4.5 mm, When new<br>4 mm, Wear limit                                                                |

**Rear wheel**

|                            |                                                                                 |
|----------------------------|---------------------------------------------------------------------------------|
| Type of rear brake         | Hydraulically actuated disc brake with 2-piston floating caliper and fixed disc |
| Brake-pad material, rear   | Sintered metal                                                                  |
| Brake disc thickness, rear | 5 mm, When new<br>min. 4.5 mm, Wear limit                                       |

**WHEELS AND TYRES**

|                                  |                                |
|----------------------------------|--------------------------------|
| Speed category, front/rear tyres | W, required at least: 270 km/h |
|----------------------------------|--------------------------------|

**Front wheel**

|                         |               |
|-------------------------|---------------|
| Front-wheel rim size    | 3.50" x 17"   |
| Tyre designation, front | 120/70 - ZR17 |
| Load index, front tyre  | min. 58       |

## 260 TECHNICAL DATA

### Rear wheel

|                        |               |
|------------------------|---------------|
| Rear wheel rim size    | 5.50" x 17"   |
| Tyre designation, rear | 180/55 - ZR17 |
| Load index, rear tyre  | min. 73       |

### Tyre pressures

|                      |                    |
|----------------------|--------------------|
| Tyre pressure, front | 2.5 bar, tyre cold |
| Tyre pressure, rear  | 2.9 bar, tyre cold |

## ELECTRICAL SYSTEM

|                                       |                                                                                                                      |
|---------------------------------------|----------------------------------------------------------------------------------------------------------------------|
| Electrical rating of on-board sockets | max. 12 A, Total for all sockets                                                                                     |
| Main fuse                             | 50 A, Voltage regulator                                                                                              |
| Fuse 1                                | 15 A, Instrument cluster, anti-theft alarm (DWA), ignition lock, diagnostic socket, top-case lighting, cut-off relay |
| Fuse 2                                | 7.5 A, Multifunction switch left, tyre pressure control (RDC), seat heating, sensor group, front radar               |
| Fuse 3                                | 15 A, Audio system                                                                                                   |

### Battery

|                                                      |                                             |
|------------------------------------------------------|---------------------------------------------|
| Battery type                                         | AGM (Absorbent Glass Mat), maintenance-free |
| Battery rated voltage                                | 12 V                                        |
| Battery rated capacity                               | 16 Ah                                       |
| Battery type (For Keyless Ride radio-operated key)   | CR 2032                                     |
| Battery type (For remote control of central locking) | CR 1632                                     |

**Spark plugs**

|                                           |                |
|-------------------------------------------|----------------|
| Spark plugs, manufacturer and designation | NGK LMAR8AI-10 |
|-------------------------------------------|----------------|

**Lighting**

|                   |     |
|-------------------|-----|
| All light sources | LED |
|-------------------|-----|

**DIMENSIONS**

|                                        |                                                         |
|----------------------------------------|---------------------------------------------------------|
| Length of motorcycle                   | 2215 mm, over spray guard                               |
| Height of motorcycle                   | 1415...1575 mm, over wind-screen, at DIN unladen weight |
| —with windscreen, high <sup>OE</sup>   | 1440...1609 mm, over wind-screen, at DIN unladen weight |
| —with Sport windscreen <sup>OE</sup>   | 1354...1485 mm, over wind-screen, at DIN unladen weight |
| Width of motorcycle                    | 990 mm, with cases<br>990 mm, with mirrors              |
| Height of rider's seat                 | 805...825 mm, without rider, at DIN unladen weight      |
| —with rider's seat, low <sup>OE</sup>  | 760...780 mm, without rider, at DIN unladen weight      |
| —with rider's seat, high <sup>OE</sup> | 830...850 mm, without rider, at DIN unladen weight      |
| Rider's inside-leg arc, heel to heel   | 1810...1850 mm, without rider, at DIN unladen weight    |
| —with rider's seat, low <sup>OE</sup>  | 1740...1780 mm, without rider, at DIN unladen weight    |
| —with rider's seat, high <sup>OE</sup> | 1875...1915 mm, without rider, at DIN unladen weight    |

## 262 TECHNICAL DATA

### WEIGHTS

|                                  |                                                                                             |
|----------------------------------|---------------------------------------------------------------------------------------------|
| Vehicle kerb weight              | 279 kg, DIN unladen weight, ready for road, 90 % load of fuel, without optional extras (OE) |
| Permissible gross vehicle weight | 505 kg                                                                                      |
| Maximum payload                  | 226 kg                                                                                      |
| Payload per case                 | max. 10 kg                                                                                  |
| Payload of topcase               | max. 5 kg                                                                                   |

### PERFORMANCE FIGURES

|                                                |               |
|------------------------------------------------|---------------|
| Top speed                                      | >200 km/h     |
| —with power reduction <sup>OE</sup>            | >200 km/h     |
| Maximum speed for riding with a loaded case    | max. 180 km/h |
| Maximum speed for riding with a loaded topcase | max. 180 km/h |

### RADIO

|           |                                          |
|-----------|------------------------------------------|
| Wavebands | FM, AM and DAB, depending on the country |
|-----------|------------------------------------------|

#### Wavebands

|    |                  |
|----|------------------|
| FM | 87.5...108.0 MHz |
| AM | 531...1602 kHz   |

---

**SPEAKERS (VEHICLE-DEPENDENT)**

---

|                 |                             |
|-----------------|-----------------------------|
| Impedance       | 4 $\Omega$                  |
| Output power    | 15 W, RMS, per speaker unit |
| Frequency range | 0.02...20 kHz               |

---

**SERVICE**

**14**

---

|                                          |            |
|------------------------------------------|------------|
| <b>REPORTING SAFETY-RELEVANT DEFECTS</b> | <b>266</b> |
| <b>RECYCLING</b>                         | <b>267</b> |
| <b>BMW MOTORRAD SERVICE</b>              | <b>267</b> |
| <b>BMW MOTORRAD SERVICE HISTORY</b>      | <b>268</b> |
| <b>BMW MOTORRAD MOBILITY SERVICES</b>    | <b>269</b> |
| <b>MAINTENANCE WORK</b>                  | <b>269</b> |
| <b>MAINTENANCE SCHEDULE</b>              | <b>271</b> |
| <b>BMW MOTORRAD RUNNING-IN CHECK</b>     | <b>272</b> |
| <b>MAINTENANCE CONFIRMATIONS</b>         | <b>273</b> |
| <b>SERVICE CONFIRMATIONS</b>             | <b>285</b> |

---

### REPORTING SAFETY-RELEVANT DEFECTS

—with Canada export<sup>NV</sup>

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the NHTSA (National Highway Traffic Safety Administration) in addition to notifying the BMW of North America, LLC.

If the NHTSA receives other, similar complaints, it may open an investigation. If it finds that a safety defect exists in a group of vehicles, the NHTSA it may order a recall and remedy campaign. However, the NHTSA cannot become involved in individual problems between you, your retailer, or BMW of North America, LLC. You can contact the NHTSA by calling the Vehicle Safety Hotline on 1-888-327-4236 (teletypewriter TTY for the hearing impaired: 1-800-424-9153) toll-free, by visiting the website at <http://www.safercar.gov> or by writing to Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590. Further information on vehicle safety is available at <http://www.safercar.gov>.

Canadian customers who wish to report a safety-related defect to Transport Canada, Defect Investigations and Recalls can call the toll-free hotline 1-800-333-0510. You can obtain further information about motor vehicle safety from <http://www.tc.gc.ca/roadsafety>.

---

## RECYCLING

### Disposal of an EOL vehicle

BMW Motorrad recommends disposing of a vehicle that has reached the end of its useful life by taking it to a manufacturer-designated receiving centre for EOL vehicles.

In general, the laws of the country in question apply for receiving and recycling of EOL vehicles. Information about recycling and sustainability can be viewed on the country-specific websites of the manufacturer. Additional information can be obtained on request from your authorised BMW Motorrad retailer or another qualified service partner, or from a specialist workshop.

### Disposal of the rider's manual

—with France export<sup>NV</sup>



Dispose of this rider's manual by depositing it in the container provided for the purpose.

---

## BMW MOTORRAD SERVICE

BMW Motorrad has an extensive network of retailers in place to look after you and your motorcycle in more than 100 countries. Authorised BMW Motorrad retailers have the technical information and the technical know-how to carry out reliably all preventive maintenance and repair work on your BMW.

You can locate the nearest authorised BMW Motorrad retailer by visiting our website: **[bmw-motorrad.com](http://bmw-motorrad.com)**.



## WARNING

### **Maintenance and repair work not in compliance with correct procedure**

Risk of accident due to consequential damage

- BMW Motorrad recommends having work of this nature carried out on the vehicle by a specialist workshop, preferably an authorised BMW Motorrad dealer.

In order to help ensure that your BMW is always in optimum condition, BMW Motorrad recommends compliance with the maintenance intervals specified for your motorcycle.

Have all maintenance and repair work carried out confirmed in the "Service" chapter in this manual. Evidence of regular preventive maintenance is essential for generous treatment of claims submitted after the warranty period has expired.

Your authorised BMW Motorrad retailer can provide information on BMW Motorrad services and the work undertaken as part of each service.

## **BMW MOTORRAD SERVICE HISTORY**

### **Entries**

Maintenance work that has been carried out is entered in the proof of maintenance. The entries are like a Service Booklet and provide proof of regular maintenance.

When an entry is made in the electronic service booklet of the vehicle, service-relevant data is saved in the central IT systems of BMW AG, Munich, Germany.

If there is a change in vehicle ownership, the data saved in the electronic service booklet can also be viewed by the new vehicle owner. An authorised BMW Motorrad retailer or a specialist workshop can also view data that is stored in the electronic service booklet.

## Objection

The vehicle owner can object to entries being made by the authorised BMW Motorrad retailer or a specialist workshop in the electronic service booklet along with the corresponding storage of data in the vehicle and transfer of data to the vehicle manufacturer for the period of time that they are the vehicle owner. In this instance, no entry is made in the electronic service booklet of the vehicle.

---

## BMW MOTORRAD MOBILITY SERVICES

As owner of a new BMW vehicle, in circumstances in which assistance is required you can benefit from the protection afforded by the various BMW Motorrad mobility services (e.g. Mobile Service, breakdown service, vehicle recovery service). Your authorised BMW Motorrad retailer will be happy to provide information about the mobility services available to you.

---

## MAINTENANCE WORK

### BMW Motorrad pre-delivery check

The BMW Motorrad pre-delivery check is performed by your authorised BMW Motorrad retailer before the vehicle is handed over to you.

### BMW Motorrad Running-in check

The BMW Motorrad running-in check has to be performed when the vehicle has covered between 500 km and 1200 km.

### BMW Motorrad Service

The BMW Motorrad Service is carried out once a year; the extent of servicing can vary, depending on the age of the vehicle and the distance it has covered. Your authorised BMW Motorrad retailer confirms that the service work has been carried out and enters the date when the next service will be due.

Riders who cover long distances in a year might have to bring in their vehicles for service before the next scheduled date. It is to allow for these cases that a maximum odometer reading is entered as well in the confirmation of

## 270 SERVICE

service. Servicing has to be brought forward if this odometer reading is reached before the next scheduled date for the service.

The service-due indicator in the display reminds you about one month or 1000 km in advance when the time for a service is approaching.

To find out more about service go to:

**[bmw-motorrad.com/service](http://bmw-motorrad.com/service)**

The maintenance tasks necessary for your vehicle are set out in the maintenance schedule below. The tasks listed are due either when the vehicle has covered the stated distances, or periodically at the stated times.

## MAINTENANCE SCHEDULE

|    | 500 -1200 km<br>300 - 750 mls | 10 000 km<br>6 000 mls | 20 000 km<br>12 000 mls | 30 000 km<br>18 000 mls | 40 000 km<br>24 000 mls | 50 000 km<br>30 000 mls | 60 000 km<br>36 000 mls | 70 000 km<br>42 000 mls | 80 000 km<br>48 000 mls | 90 000 km<br>54 000 mls | 100 000 km<br>60 000 mls | 12 months      | 24 months      |
|----|-------------------------------|------------------------|-------------------------|-------------------------|-------------------------|-------------------------|-------------------------|-------------------------|-------------------------|-------------------------|--------------------------|----------------|----------------|
| 1  | X                             |                        |                         |                         |                         |                         |                         |                         |                         |                         |                          |                |                |
| 2  |                               | X                      | X                       | X                       | X                       | X                       | X                       | X                       | X                       | X                       | X                        | X <sup>a</sup> |                |
| 3  |                               | X                      | X                       | X                       | X                       | X                       | X                       | X                       | X                       | X                       | X                        | X <sup>a</sup> |                |
| 4  |                               |                        | X                       |                         | X                       |                         | X                       |                         | X                       |                         | X                        |                | X <sup>b</sup> |
| 5  |                               |                        | X                       |                         | X                       |                         | X                       |                         | X                       |                         | X                        |                |                |
| 6  |                               |                        | X                       |                         | X                       |                         | X                       |                         | X                       |                         | X                        |                |                |
| 7  |                               |                        | X                       |                         | X                       |                         | X                       |                         | X                       |                         | X                        |                |                |
| 8  |                               |                        | X                       |                         | X                       |                         | X                       |                         | X                       |                         | X                        |                |                |
| 9  |                               |                        | X                       |                         | X                       |                         | X                       |                         | X                       |                         | X                        |                |                |
| 10 |                               |                        |                         |                         |                         |                         | X <sup>e</sup>          |                         |                         |                         |                          |                |                |
| 11 |                               |                        |                         |                         |                         |                         |                         |                         |                         |                         |                          | X <sup>d</sup> | X <sup>d</sup> |

**1** BMW Motorrad running-in check (including oil change and oil filter change)

**2** BMW Motorrad Service, standard scope

**3** Engine-oil change, with filter

**4** Oil change in bevel gears rear

**5** Check valve clearances

**6** Replace all spark plugs

**7** Replace air-filter element

**8** Recommended: Check Cardan shaft

**9** Recommended: Lubricate Cardan shaft

**10** Replace Cardan shaft

**11** Change brake fluid, entire system

<sup>a</sup> annually or every 10000 km (whichever comes first)

<sup>b</sup> every two years or every 20000 km (whichever comes first)

<sup>d</sup> for the first time after one year, then every two years

<sup>e</sup> referenced to the distance over which the component was in use

### **BMW MOTORRAD RUNNING-IN CHECK**

#### **BMW Motorrad running-in check**

The tasks included in the BMW Motorrad running-in check are listed below. The actual scope of work applicable for your vehicle may vary.

- Setting service-due date and countdown distance
- Performing vehicle test with BMW Motorrad diagnostic system
- Engine-oil change, with filter
- Changing oil in bevel gears
- Check the brake-fluid level, front wheel brake
- Check the brake-fluid level, rear wheel brake
- Check the coolant level
- Checking tyre tread depth and tyre pressures
- Checking lighting and signalling system
- Function test, engine start suppression
- Final inspection and check of roadworthiness
- Performing vehicle test with BMW Motorrad diagnostic system
- Confirm the BMW Motorrad service in the on-board literature

---

## MAINTENANCE CONFIRMATIONS

### **BMW Motorrad Service standard scope**

The tasks included in the BMW Motorrad Service standard scope are listed below. The actual scope of maintenance work applicable for your vehicle may vary.

- Performing vehicle test with BMW Motorrad diagnostic system
- Visual inspection of clutch system
- Visual inspection of the brake lines, brake hoses and connections
- Check the front brake pads and brake discs for wear
- Check the brake-fluid level, front wheel brake
- Check the rear brake pads and brake disc for wear
- Check the brake-fluid level, rear wheel brake
- Check the coolant level
- Check the side stand's ease of movement
- Check the ease of movement of the centre stand
- Check the tyre pressures and tread depth
- Checking lighting and signalling system
- Function test, engine start suppression
- Final inspection and check of roadworthiness
- Performing vehicle test with BMW Motorrad diagnostic system
- Setting service-due date and countdown distance with BMW Motorrad diagnostic system
- Checking battery state of charge
- Confirm the BMW service in the on-board literature

## 274 SERVICE

### **BMW Motorrad pre-delivery check**

carried out

on \_\_\_\_\_

Stamp, signature

### **BMW Motorrad running-in check**

carried out

on \_\_\_\_\_

odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, when reached earlier

odometer reading \_\_\_\_\_

Stamp, signature

**BMW Motorrad service**

carried out

on \_\_\_\_\_

odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, when reached earlier

odometer reading \_\_\_\_\_

**Work performed**

|                                                      | Yes                      | No                       |
|------------------------------------------------------|--------------------------|--------------------------|
| BMW Motorrad service                                 | <input type="checkbox"/> | <input type="checkbox"/> |
| Engine oil change with filter                        | <input type="checkbox"/> | <input type="checkbox"/> |
| Oil change in rear angular gearbox                   | <input type="checkbox"/> | <input type="checkbox"/> |
| Checking valve clearance                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Renewing all spark plugs                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing the air filter element                     | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Checking Cardan shaft (during service)  | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Lubricate Cardan shaft (during service) | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing Cardan shaft (during service)              | <input type="checkbox"/> | <input type="checkbox"/> |
| Changing the brake fluid in the entire system        | <input type="checkbox"/> | <input type="checkbox"/> |

Notes

Stamp, signature

## BMW Motorrad service

carried out

on \_\_\_\_\_

odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, when reached earlier

odometer reading \_\_\_\_\_

## Work performed

|                                                      | Yes                      | No                       |
|------------------------------------------------------|--------------------------|--------------------------|
| BMW Motorrad service                                 | <input type="checkbox"/> | <input type="checkbox"/> |
| Engine oil change with filter                        | <input type="checkbox"/> | <input type="checkbox"/> |
| Oil change in rear angular gearbox                   | <input type="checkbox"/> | <input type="checkbox"/> |
| Checking valve clearance                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Renewing all spark plugs                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing the air filter element                     | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Checking Cardan shaft (during service)  | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Lubricate Cardan shaft (during service) | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing Cardan shaft (during service)              | <input type="checkbox"/> | <input type="checkbox"/> |
| Changing the brake fluid in the entire system        | <input type="checkbox"/> | <input type="checkbox"/> |

Notes

Stamp, signature

**BMW Motorrad service**

carried out

on \_\_\_\_\_

odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, when reached earlier

odometer reading \_\_\_\_\_

**Work performed**

|                                                      | Yes                      | No                       |
|------------------------------------------------------|--------------------------|--------------------------|
| BMW Motorrad service                                 | <input type="checkbox"/> | <input type="checkbox"/> |
| Engine oil change with filter                        | <input type="checkbox"/> | <input type="checkbox"/> |
| Oil change in rear angular gearbox                   | <input type="checkbox"/> | <input type="checkbox"/> |
| Checking valve clearance                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Renewing all spark plugs                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing the air filter element                     | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Checking Cardan shaft (during service)  | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Lubricate Cardan shaft (during service) | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing Cardan shaft (during service)              | <input type="checkbox"/> | <input type="checkbox"/> |
| Changing the brake fluid in the entire system        | <input type="checkbox"/> | <input type="checkbox"/> |

Notes

Stamp, signature

## BMW Motorrad service

carried out

on \_\_\_\_\_

odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, when reached earlier

odometer reading \_\_\_\_\_

## Work performed

|                                                      | Yes                      | No                       |
|------------------------------------------------------|--------------------------|--------------------------|
| BMW Motorrad service                                 | <input type="checkbox"/> | <input type="checkbox"/> |
| Engine oil change with filter                        | <input type="checkbox"/> | <input type="checkbox"/> |
| Oil change in rear angular gearbox                   | <input type="checkbox"/> | <input type="checkbox"/> |
| Checking valve clearance                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Renewing all spark plugs                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing the air filter element                     | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Checking Cardan shaft (during service)  | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Lubricate Cardan shaft (during service) | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing Cardan shaft (during service)              | <input type="checkbox"/> | <input type="checkbox"/> |
| Changing the brake fluid in the entire system        | <input type="checkbox"/> | <input type="checkbox"/> |

Notes

Stamp, signature

**BMW Motorrad service**

carried out

on \_\_\_\_\_

odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, when reached earlier

odometer reading \_\_\_\_\_

**Work performed**

|                                                      | Yes                      | No                       |
|------------------------------------------------------|--------------------------|--------------------------|
| BMW Motorrad service                                 | <input type="checkbox"/> | <input type="checkbox"/> |
| Engine oil change with filter                        | <input type="checkbox"/> | <input type="checkbox"/> |
| Oil change in rear angular gearbox                   | <input type="checkbox"/> | <input type="checkbox"/> |
| Checking valve clearance                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Renewing all spark plugs                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing the air filter element                     | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Checking Cardan shaft (during service)  | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Lubricate Cardan shaft (during service) | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing Cardan shaft (during service)              | <input type="checkbox"/> | <input type="checkbox"/> |
| Changing the brake fluid in the entire system        | <input type="checkbox"/> | <input type="checkbox"/> |

Notes

Stamp, signature

## BMW Motorrad service

carried out

on \_\_\_\_\_

odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, when reached earlier

odometer reading \_\_\_\_\_

## Work performed

|                                                      | Yes                      | No                       |
|------------------------------------------------------|--------------------------|--------------------------|
| BMW Motorrad service                                 | <input type="checkbox"/> | <input type="checkbox"/> |
| Engine oil change with filter                        | <input type="checkbox"/> | <input type="checkbox"/> |
| Oil change in rear angular gearbox                   | <input type="checkbox"/> | <input type="checkbox"/> |
| Checking valve clearance                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Renewing all spark plugs                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing the air filter element                     | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Checking Cardan shaft (during service)  | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Lubricate Cardan shaft (during service) | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing Cardan shaft (during service)              | <input type="checkbox"/> | <input type="checkbox"/> |
| Changing the brake fluid in the entire system        | <input type="checkbox"/> | <input type="checkbox"/> |

Notes

Stamp, signature

**BMW Motorrad service**

carried out

on \_\_\_\_\_

odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, when reached earlier

odometer reading \_\_\_\_\_

**Work performed**

|                                                      | Yes                      | No                       |
|------------------------------------------------------|--------------------------|--------------------------|
| BMW Motorrad service                                 | <input type="checkbox"/> | <input type="checkbox"/> |
| Engine oil change with filter                        | <input type="checkbox"/> | <input type="checkbox"/> |
| Oil change in rear angular gearbox                   | <input type="checkbox"/> | <input type="checkbox"/> |
| Checking valve clearance                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Renewing all spark plugs                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing the air filter element                     | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Checking Cardan shaft (during service)  | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Lubricate Cardan shaft (during service) | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing Cardan shaft (during service)              | <input type="checkbox"/> | <input type="checkbox"/> |
| Changing the brake fluid in the entire system        | <input type="checkbox"/> | <input type="checkbox"/> |

Notes

Stamp, signature

## BMW Motorrad service

carried out

on \_\_\_\_\_

odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, when reached earlier

odometer reading \_\_\_\_\_

## Work performed

|                                                      | Yes                      | No                       |
|------------------------------------------------------|--------------------------|--------------------------|
| BMW Motorrad service                                 | <input type="checkbox"/> | <input type="checkbox"/> |
| Engine oil change with filter                        | <input type="checkbox"/> | <input type="checkbox"/> |
| Oil change in rear angular gearbox                   | <input type="checkbox"/> | <input type="checkbox"/> |
| Checking valve clearance                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Renewing all spark plugs                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing the air filter element                     | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Checking Cardan shaft (during service)  | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Lubricate Cardan shaft (during service) | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing Cardan shaft (during service)              | <input type="checkbox"/> | <input type="checkbox"/> |
| Changing the brake fluid in the entire system        | <input type="checkbox"/> | <input type="checkbox"/> |

Notes

Stamp, signature

**BMW Motorrad service**

carried out

on \_\_\_\_\_

odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, when reached earlier

odometer reading \_\_\_\_\_

**Work performed**

|                                                      | Yes                      | No                       |
|------------------------------------------------------|--------------------------|--------------------------|
| BMW Motorrad service                                 | <input type="checkbox"/> | <input type="checkbox"/> |
| Engine oil change with filter                        | <input type="checkbox"/> | <input type="checkbox"/> |
| Oil change in rear angular gearbox                   | <input type="checkbox"/> | <input type="checkbox"/> |
| Checking valve clearance                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Renewing all spark plugs                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing the air filter element                     | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Checking Cardan shaft (during service)  | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Lubricate Cardan shaft (during service) | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing Cardan shaft (during service)              | <input type="checkbox"/> | <input type="checkbox"/> |
| Changing the brake fluid in the entire system        | <input type="checkbox"/> | <input type="checkbox"/> |

Notes

Stamp, signature

## BMW Motorrad service

carried out

on \_\_\_\_\_

odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, when reached earlier

odometer reading \_\_\_\_\_

## Work performed

|                                                      | Yes                      | No                       |
|------------------------------------------------------|--------------------------|--------------------------|
| BMW Motorrad service                                 | <input type="checkbox"/> | <input type="checkbox"/> |
| Engine oil change with filter                        | <input type="checkbox"/> | <input type="checkbox"/> |
| Oil change in rear angular gearbox                   | <input type="checkbox"/> | <input type="checkbox"/> |
| Checking valve clearance                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Renewing all spark plugs                             | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing the air filter element                     | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Checking Cardan shaft (during service)  | <input type="checkbox"/> | <input type="checkbox"/> |
| Recommended: Lubricate Cardan shaft (during service) | <input type="checkbox"/> | <input type="checkbox"/> |
| Replacing Cardan shaft (during service)              | <input type="checkbox"/> | <input type="checkbox"/> |
| Changing the brake fluid in the entire system        | <input type="checkbox"/> | <input type="checkbox"/> |

Notes

Stamp, signature







|                                                   |            |
|---------------------------------------------------|------------|
| <b>DECLARATION OF CONFORMITY</b>                  | <b>289</b> |
| <b>BATTERY DIRECTIVE</b>                          | <b>292</b> |
| <b>MID RANGE RADAR</b>                            | <b>294</b> |
| <b>RADIO EQUIPMENT WIRELESS CHARGING DEVICE</b>   | <b>297</b> |
| <b>RADIO EQUIPMENT TFT INSTRUMENT CLUSTER</b>     | <b>297</b> |
| <b>RADIO EQUIPMENT ELECTRONIC IMMOBILISER</b>     | <b>299</b> |
| <b>KEYLESS RIDE KEY</b>                           | <b>302</b> |
| <b>KEYLESS RIDE ECU</b>                           | <b>304</b> |
| <b>CERTIFICATION TIRE PRESSURE CONTROL</b>        | <b>306</b> |
| <b>RADIO EQUIPMENT AUDIO SYSTEM</b>               | <b>306</b> |
| <b>RADIO EQUIPMENT INTELLIGENT EMERGENCY CALL</b> | <b>307</b> |

## DECLARATION OF CONFORMITY

### Manufacturer

Bayerische Motoren Werke Aktiengesellschaft  
Petuelring 130, 80809 Munich, Germany

**Simplified EU Declaration of Conformity according to EU RED (2014/53/EU).**



**Simplified UK Declaration of Conformity according to Radio Equipment Regulations 2017 of the United Kingdom.**



Hereby, BMW AG declares that the radio equipment components listed below are in compliance with Directive 2014/53/EU and with Radio Equipment Regulations 2017 of the United Kingdom. The full text of the EU/UK declarations of conformity are available at the following internet address: **[bmw-motorrad.com/certification](http://bmw-motorrad.com/certification)**

### Technical information

| Radio equipment | Component    | Frequency band | Output/Transmission Power            |
|-----------------|--------------|----------------|--------------------------------------|
| EWS4            | EWS          | 134 kHz        | 50 dB $\mu$ V/m                      |
| HUF5794         | Keyless Ride | 433.92 MHz     | 10 mW                                |
| HUF8485         | Keyless Ride | 134.45 kHz     | 42 dB $\mu$ V/m                      |
| ZB001           | Keyless Ride | 134.5 kHz      | allowed<br>66 dB $\mu$ A/<br>m @ 10m |

| Radio equipment             | Component            | Frequency band                                              | Output/Transmission Power                  |
|-----------------------------|----------------------|-------------------------------------------------------------|--------------------------------------------|
| ZB002                       | Keyless Ride         | 433.92 MHz                                                  | max.<br>10 dBm<br>e.r.p                    |
| TXBM-WMR                    | DWA 8                | 433.05 MHz - 434.79 MHz                                     | 18.8 dBm                                   |
| RDC3                        | RDC                  | 433.92 MHz                                                  | < 13 mW                                    |
| Wus Moto gen 3              | RDC                  | 433.05 MHz - 434.79 MHz                                     | < 10 mW<br>e.r.p.                          |
| MC24-MA4                    | RDC                  |                                                             |                                            |
| WCA Motor-rad-Ladestaurauch | Charging compartment | 110 kHz - 115 kHz                                           | < 6 W                                      |
| ICC6.5in                    | Instrument Cluster   | Bluetooth: 2402 MHz - 2480 MHz<br>WLAN: 2412 MHz - 2462 MHz | Bluetooth:<br>< 4 dBm<br>WLAN:<br>< 20 dBm |
| ICC65V2                     | Instrument Cluster   | Bluetooth: 2400 MHz - 2480 MHz<br>WLAN: 2400 MHz - 2480 MHz | Bluetooth:<br>< 10 mW<br>WLAN:<br>< 100 mW |
| ICC10in                     | Instrument Cluster   | Bluetooth: 2402 MHz - 2480 MHz<br>WLAN: 2402 MHz - 2472 MHz | Bluetooth:<br>< 4 dBm<br>WLAN:<br>< 14 dBm |
| MR-Re14FCR                  | ACC                  | 76 - 77 GHz                                                 | Peak max.<br>32 dBm<br>Nom max.<br>27 dBm  |

| <b>Radio equipment</b> | <b>Component</b>           | <b>Frequency band</b>                                                                                                                                                                                       | <b>Output/Transmission Power</b>                                             |
|------------------------|----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------|
| ARS513                 | Front radar                | 77 GHz                                                                                                                                                                                                      | Peak max.<br>30 dBm                                                          |
| SRR521                 | Rear radar                 | 77 GHz                                                                                                                                                                                                      | Peak max.<br>30 dBm                                                          |
| TL1P22                 | Intelligent emergency call | 832 MHz - 862 MHz<br>880 MHz - 915 MHz<br>1710 MHz - 1785 MHz<br>1920 MHz - 1980 MHz<br>2500 MHz - 2570 MHz<br>2570 MHz - 2620 MHz<br>GNSS: 1559 MHz - 1610 MHz                                             | 23 dBm<br>33 dBm<br>30 dBm<br>24 dBm<br>23 dBm<br>23 dBm                     |
| TL1M-23NE              | Intelligent emergency call | 703 MHz - 748 MHz<br>832 MHz - 862 MHz<br>880 MHz - 915 MHz<br>1710 MHz - 1785 MHz<br>1920 MHz - 1980 MHz<br>2300 MHz - 2400 MHz<br>2500 MHz - 2570 MHz<br>2570 MHz - 2620 MHz<br>GNSS: 1559 MHz - 1610 MHz | 23 dBm<br>23 dBm<br>33 dBm<br>30 dBm<br>24 dBm<br>23 dBm<br>23 dBm<br>23 dBm |
| MCR001                 | Audio system               |                                                                                                                                                                                                             |                                                                              |
| ZB005                  | Keyless Ride Main Unit     | 134.5 kHz<br>433.92 MHz                                                                                                                                                                                     | < 66 dBμA/m                                                                  |
| ZB006                  | Keyless Ride Active Key    | 134.5 kHz<br>433.92 MHz                                                                                                                                                                                     | < 10 mW<br>e.r.p.                                                            |
| LIN2BTLE Gateway       | Instrument Cluster         | 2400 MHz - 2483.5 MHz                                                                                                                                                                                       | < 3 dBm                                                                      |

## 292 APPENDIX

### BATTERY DIRECTIVE

Batteries are generally subject to the battery directive 2023/1542/EU. Consumer information on the batteries can be found in the relevant sections of this manual.

Batteries are integrated in the following components:

#### Technical information

| Component  | Type    | Contact                                                                                                                                                                                                                   |
|------------|---------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RDC sensor | 17109   | LID TECHNOLOGIES, 3 rue Giotto,<br>31520 Ramonville, Saint Agne, France<br>E-mail: <a href="mailto:contact@lid.tech">contact@lid.tech</a><br><b><a href="http://www.lid.tech">www.lid.tech</a></b>                        |
| KLR Key    | HUF5794 | Huf Hülsbeck & Fürst GmbH & Co.<br>KG, Steeger Str.17, 42551 Velbert,<br>Germany<br>E-mail: <a href="mailto:info@huf-group.com">info@huf-group.com</a><br><b><a href="http://www.huf-group.com">www.huf-group.com</a></b> |
| KLR Key    | ZB002   | ZADI S.p.A., Via Carlo Marx 138,<br>41012 Carpi (MO), Italy<br>E-mail: <a href="mailto:info@zadi.com">info@zadi.com</a><br><b><a href="http://www.zadi.com">www.zadi.com</a></b>                                          |
| KLR Key    | ZB006   | ZADI S.p.A., Via Carlo Marx, 138<br>41012 Carpi (MO), Italy<br>E-mail: <a href="mailto:info@zadi.com">info@zadi.com</a><br><b><a href="http://www.zadi.com">www.zadi.com</a></b>                                          |
| DWA8 ECU   | DWA8    | Meta System S.p.A, Via Tancredi<br>Galimberti 5, 42124 Reggio Emilia,<br>Italy<br><b><a href="http://www.metasystemcorporation.com">www.metasystemcorporation.com</a></b>                                                 |
| DWA8 RC    | TXBMWMR | Meta System S.p.A, Via Tancredi<br>Galimberti 5, 42124 Reggio Emilia,<br>Italy<br><b><a href="http://www.metasystemcorporation.com">www.metasystemcorporation.com</a></b>                                                 |

| Component | Type | Contact                                                                                                           |
|-----------|------|-------------------------------------------------------------------------------------------------------------------|
| DWA9      | DWA9 | Bury Sp. z o.o., ul. Wojska Polskiego<br>4, 39-300 Mielec, Poland<br>E-mail: info@bury.com<br><b>www.bury.com</b> |

## 294 APPENDIX

### MID RANGE RADAR

For all countries without EU

#### **Model name: MRRe14FCR Manufacturer**

Robert Bosch GmbH  
Robert-Bosch-Platz 1, 70839  
Gerlingen, Germany

#### **Technical information**

Frequency band: 76 - 77 GHz  
Nominal radiated power:  
e.i.r.p. (peak detector): 32 dBm  
Nominal radiated power:  
e.i.r.p. (RMS detector): 27 dBm

#### **Country**

#### **Argentina**



COMISIÓN NACIONAL DE CO-  
MUNICACIONES

C-20030

#### **Australia**



#### **Canada**

#### **NOTICE:**

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference.

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Radiofrequency radiation exposure Information: This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage;

(2) l'utilisateur de l'appareil doit accepter tout brouillage

radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Informations sur l'exposition aux radiofréquences: Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps. Ce transmetteur ne doit pas être placé au même endroit ou utilisé simultanément avec un autre transmetteur ou antenne.

### **Hong Kong**

HKCA 1035: automotive radar: radio equipment exempted from licensing!

### **Indonesia**

72726/SDPPI/2021  
13349

### **Israel**

10. תנאים מיוחדים והערות המשרד:  
Mid-range Radar Sensor לפני השיווק ידאג היבואן שעל אריזה חיצונית של המוצר יודבק מדבקה, בה יהיה רשום כי: א. השימוש במכשיר הינו על בסיס "משני" ופטור מרשיון הפעלה אלחוטי. כלומר - לא מוגן מהפרעות וללא הפרעה למערכות

אחרות הפועלות כדין. ב. רק "בפעולת בזק" לשימוש עצמי של הלקוח בלבד, הצידוד פטור מרשיון הפעלה אלחוטי. מתן "שרות בזק" לצד ג' מחייב רשיון מיוחד ממשרד התקשורת. ג. אסור להחליף את האנטנה המקורית של המכשיר ולא לעשות בו כל שינוי טכני אחר.

### **Jordan**

TRC No. TRC/LPD/2017/254

### **Malaysia**



CIDF 15000490

### **Mexico**

IFETEL: RCPBOMR17-0598

La operación de este equipo está sujeta a las siguientes dos condiciones:

- (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y
- (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

## 296 APPENDIX

### Morocco

AGREE PAR L'ANRT MAROC

Numéro d'agrément :

MR 13900 ANRT 2017

### Paraguay



2017-06-I-0000162

### Philippines



NTC

Type Approved

No. ESD-1716172C

### Serbia



U00517

### Singapore

Complies with

IMDA Standards

DB03227

Complies with

IMDA Standards

DB105658

### South Africa



TA-2017/2013

APPROVED

### Sultanate of Oman

OMAN TRA

TA-R/4353/17

D080134

### Taiwan



CCAF22LP1960T0

注意!

依據低功率電波輻射性電機管理辦法

第十二條經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信，指依

電信規定作業之無線電 信。低功率射頻電機須忍受合法通信 或工業、科學及醫療用電波輻射性電機設備之干擾。

## **RADIO EQUIPMENT WIRELESS CHARGING DEVICE**

For all Countries without EU

**Model name: WCA**  
**Motorrad-Ladestaufach**  
**Manufacturer**

Bury Sp. z o.o.  
 ul. Wojska Polskiego 4, 39-300  
 Mielec, Poland

### **Technical Information**

Wireless charging operates in the frequency range from 110 kHz to 115 kHz with a maximum power of 6 W.

### **Country**

**Argentina**



H-25468

### **Morocco**

AGREE PAR L'ANRT MAROC  
 Numéro d'agrément :  
 MR 00025359 ANRT 2020  
 Date d'agrément :  
 01/09/2020

## **Singapore**

Complies with  
 IMDA Standards  
 DA103787

## **RADIO EQUIPMENT TFT INSTRUMENT CLUSTER**

For all Countries without EU

**Model name: ICC10in**  
**Manufacturer**

Robert Bosch GmbH  
 Robert-Bosch-Platz 1, 70839  
 Gerlingen, Germany

### **Technical information**

The ICC10in can operate in one of two operating modes:

1. Normal mode, with Bluetooth and WLAN on, and
2. Radio off mode (only available during vehicle manufacturing).

BT operating frq. Range:

2402 - 2480 MHz

BT version: 4.2 (no BTLE)

BT output power:

< +4 dBm (internal antenna)

WLAN operating frq. Range:

2402 - 2472 MHz

WLAN standards:

IEEE 802.11 b/g/n

WLAN output power:

< +14 dBm (internal antenna)

## Country

### Argentina



C-25636

### Canada

This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Radiofrequency radiation exposure Information: This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 centimeters between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Informations sur l'exposition aux radiofréquences: Cet équipement est conforme aux limites d'exposition aux radiations fixées par le Canada pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 centimètres entre le radiateur et votre corps. Cet émetteur ne doit pas être colocalisée ou opérant en conjonction avec autre antenne ou émetteur.

### Mexico

La operación de este equipo está sujeta a las siguientes dos condiciones:

(1) es posible que este equipo o dispositivo no cause interferencia perjudicial y

(2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.



**Serbia**



N011 20

**Taiwan**

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法

通信或工業、科學及醫療用電波輻射性電機設備之干擾。

## **RADIO EQUIPMENT ELECTRONIC IMMOBILISER**

For all countries without EU

**Model name: EWS 4**

**Manufacturer**

BECOM Electronics GmbH  
Technikerstraße 1, A-7442  
Hochstraße, Austria

### **Technical information**

Frequency Band: 134 kHz  
Transponder: TMS37145/Type  
DST80, TMS3705 Transponder  
Base Station IC  
Output Power: 50 dBμV/m

**Country**

**Argentina**



H-25246

**Australia/New Zealand**



R-NZ

## 300 APPENDIX

### Brunei



TA No: DTA-007061

### Canada

Contains IC:

10430A-MREWS5012

This device complies with part 15 of the FCC Rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### India

ETA-SD-20200905860

### Israel

מספר אישור אלחוטית של משרד

התקשורת הוא

74908-51

אסור להחליף את האנטנה המקורית של

המכשיר ולא לעשות בו כל שינוי טכני

אחר

### Malaysia



RFCL/47A/0920/S(20-3358)

### Indonesia



78578/SDPPI/2023

2651

Dilarang melakukan perubahan Spesifikasi yang dapat Menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya

**Paraguay**

NR: 2020-11-I-0834

**Philippines**

Type Approved

No.: ESD-RCE-2023298

**Serbia**

P1620118300

**Singapore**

Complies with  
IMDA Standards  
N3504-20

**South Africa**

TA-2020/6131

APPROVED

**Taiwan**

低功 電波 射性電機管 辦法 第十二條 經型式認證合格之低 功率射頻電 機，非經許可，公 司、商號或使用者均不得擅 自變 更頻率、加大功率或變更原設計 之特性及功能。第十四條 低功 率射頻電機之使用不 得影響飛航 安全及干擾合法通信；經發現有 干 擾現象時，應立即停用，並改 善至無干擾時方 得繼續使用。前 項合法通信，指依電信法規定作 業之無線電 通信。

**Vietnam**

## 302 APPENDIX

A1109091120AF04A3

### KEYLESS RIDE KEY

For all Countries without EU

**Model name: HUF5794**

#### Manufacturer

Huf Hüsbeck & Fürst GmbH &  
Co. KG  
Steeger Str. 17, 42551 Velbert,  
Germany

#### Technical information

Frequenzy band: 433,92 MHz  
Output/Transmission Power:  
10 mW

#### Country

##### Canada

This device complies with  
part 15 of the FCC Rules and  
Industry Canada licence-exempt  
RSS standard(s). Operation  
is subject to the following two  
conditions:

- (1) This device may not cause  
interference.
- (2) This device must accept any  
interference, including interfe-  
rence that may cause undesired  
operation of the device.

Le présent appareil est conforme  
aux CNR d'Industrie Canada ap-  
plicables aux appareils radio ex-  
empts de licence. L'exploitation

est autorisée aux deux condi-  
tions suivantes :

- (1) L'appareil ne doit pas pro-  
duire de brouillage;
- (2) L'utilisateur de l'appareil  
doit accepter tout brouillage  
radioélectrique subi, même si le  
brouillage est susceptible d'en  
compromettre le fonctionne-  
ment.

##### Indonesia

81598/SDPPI/2022  
13349

##### Malaysia



HIDF17000037

##### Morocco

AGREE PAR L'ANRT MAROC  
Numéro d'agrément :  
MR00031289ANRT2022  
Date d'agrément :  
06/01/2022

##### Nigeria

Connection and use of this com-  
munications equipment is per-  
mitted by the Nigerian Commu-  
nications Commission

**Pakistan**

TAC NO: 9.140/2022

**Paraguay**

2022-01-I-0051

**Philippines**

Type Approved

No. ESD-RCE-2228693

**Serbia**

I005 22

**Singapore**

Complies with  
IMDA Standards  
DA105282

**South Africa**

TA-2022/0252  
APPROVED

**Sultanate of Oman**

OMAN - TRA  
R/13021/22  
D100428

**Taiwan**

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

# 304 APPENDIX

## Vietnam



THACO AUTO  
C900248

### KEYLESS RIDE ECU

For all Countries without EU

**Model name: HUF8485**

#### Manufacturer

Huf Hülsbeck & Fürst GmbH &  
Co. KG  
Steeger Str. 17, 42551 Velbert,  
Germany

#### Technical information

Frequenzy band: 134,45 kHz  
Output/Transmission Power:  
42 dBμV/m

#### Country

##### Canada

This device complies with  
part 15 of the FCC Rules and  
Industry Canada licence-exempt  
RSS standard(s). Operation  
is subject to the following two  
conditions:

(1) This device may not cause  
interference.

(2) This device must accept any  
interference, including interfe-  
rence that may cause undesired  
operation of the device.

Le présent appareil est conforme  
aux CNR d'Industrie Canada ap-  
plicables aux appareils radio ex-  
empts de licence. L'exploitation  
est autorisée aux deux conditi-  
ons suivantes :

(1) L'appareil ne doit pas pro-  
duire de brouillage;

(2) L'utilisateur de l'appareil  
doit accepter tout brouillage  
radioélectrique subi, même si le  
brouillage est susceptible d'en  
compromettre le fonctionne-  
ment.

##### Indonesia

81597/SDPPI/2022  
13349

##### Malaysia



HIDF17000037

##### Morocco

AGREE PAR L'ANRT MAROC  
Numéro d'agrément :  
MR00031290ANRT2022

Date d'agrément :

06/01/2022

### **Nigeria**

Connection and use of this communications equipment is permitted by the Nigerian Communications Commission

### **Pakistan**



TAC NO: 9.122/2022

### **Paraguay**



2022-01-I-0052

### **Philippines**



Type Approved

No. ESD-RCE-2228692

### **Singapore**

Complies with  
IMDA Standards  
DA105282

### **South Africa**



TA-2022/0251  
APPROVES

### **Sultanate of Oman**

OMAN - TRA  
R/13020/22  
D100428

### **Vietnam**



THACO AUTO  
C900248

## 306 APPENDIX

### CERTIFICATION TIRE PRESSURE CONTROL TPC

#### Canada

IC: 2546A-BC5A4

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

**WARNING:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

### RADIO EQUIPMENT AUDIO SYSTEM

**Model name: MCR001**

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Cet appareil est conforme à la partie 15 des règles FCC. Son fonctionnement est soumis aux deux conditions suivantes :

- (1) Cet appareil ne doit pas causer d'interférences nuisibles, et
- (2) cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant entraîner un fonctionnement indésirable.

#### ATTENTION FCC

Les changements ou modifications non expressément approuvés par la partie responsable de la conformité peuvent annuler le

droit de l'utilisateur à faire fonctionner l'équipement.

## **RADIO EQUIPMENT INTELLIGENT EMERGENCY CALL**

For all countries without EU

**Model name: TL1P22**

### **Manufacturer**

LG ELECTRONICS INC.  
10, Magokjungang 10-ro,  
Gangseo-gu Seoul, Republic of  
Korea

### **Country**

#### **Canada**

IC: 2703H-TM04ANNABM1

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 3.5 cm between the radiator & your body. Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment.

Such modifications could void the user's authority to operate the equipment.

Avis d'Industrie Canada sur l'exposition aux rayonnements

Cet appareil est conforme aux limites d'exposition aux rayonnements d'Industrie Canada pour un environnement non contrôlé. Il doit être installé de façon à garder une distance minimale de 3.5 centimètres entre la source de rayonnements et votre corps. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Le fabricant n'est pas responsable des interférences radioélectriques causées par des modifications non autorisées apportées à cet appareil. de telles modifications pourrait annuler l'autorisation accordée à l'utilisateur de faire fonctionner l'appareil.

## 308 INDEX

### A

Abbreviations and symbols, 4

ABS

Engineering details, 176

Status indicators, 59

Warning indicators, 59, 60, 61

ACC

Activating, 110

Control, 22

Deactivating, 110

Engineering details, 182

Operating, 110

Safety information, 106

Status indicators, 111

Warning light, 66

Active cruise control

Warning light, 66

Adaptive Headlight, 193

Ambient temperature, 44

Anti-theft alarm

Indicator light, 25

Operating, 115

Audio system

Switching on and off, 134

Warning light, 67

Auxiliary headlights

Operating, 98

### B

Battery

Charging battery when connected, 223

Charging battery when disconnected, 225

Installing, 226

Maintenance instructions, 223

Removing, 225

Technical data, 260

Warning indicators, 45, 46

Bluetooth, 77

Helmet, 141

Pairing, 77

Brake fluid

Checking fluid level,

front, 205

Checking fluid level, rear, 206

Reservoir, front, 19

Reservoir, rear, 19

Brake pads

Checking front, 202

Checking rear, 203

Running in, 161

Brake temperature

Warning light, 64, 65

Brakes

ABS Pro in detail, 179

ABS Pro depending on riding mode, 164

Adjusting handlebar levers, 147

Checking operation, 202

Safety information, 162

Technical data, 259

### C

Care

Care products, 242

Chrome, 244

Paintwork preservation, 245

Radar sensor, 244

Washing the vehicle, 242

Cases

Operating, 129

Central locking

Operating, 125

Chassis and suspension  
Technical data, 258

Check control  
Dialogue, 35  
Display, 35

Clutch  
Adjusting handlebar  
levers, 145  
Fluid reservoir, 18  
Technical data, 258

Communication systems  
Helmet, 141

Coolant  
Checking fill level, 207  
Fill-level indicator, 19  
Topping up, 208

Cruise control  
Control, 22  
Operating, 103

Currency, 6

## D

Daytime riding lights  
Automatic daytime riding  
light, 99

Diagnostic connector  
Disengaging, 229  
Securing, 230

Dimensions  
Technical data, 261

Drop sensor  
Warning light, 58

DTC, 100  
Engineering details, 180  
Warning indicators, 61, 62

DWA  
Warning indicator lights, 49  
Warning indicators, 48, 49

Dynamic Brake Control, 188  
Engineering details, 188  
Dynamic engine brake  
control, 181

## E

Electrical system  
Technical data, 260

Emergency call  
Automatically in the event of a  
light fall, 96  
Automatically in the event of a  
severe fall, 97  
Language, 95  
Notes, 11  
Warning indicators, 58

Emergency off switch (kill  
switch), 23, 24  
Operating, 94

Engine  
Starting, 159  
Technical data, 257  
Warning indicator lights, 52  
Warning indicators, 52, 53

Engine oil  
Checking fill level, 200  
Electronic oil-level check, 49  
Filler neck, 19  
Indicator light for engine oil  
level, 50  
Oil dipstick, 19  
Technical data, 257  
Topping up, 201

Engine temperature, 50, 51

Equipment, 5

## ESA

Engineering details, 185  
Operating, 101

# 310 INDEX

## F

- Favourites buttons, 124
  - Assigning functions, 125
- Final drive
  - Technical data, 258
- Frame
  - Technical data, 258
- Front-wheel stand
  - Installing, 200
- Fuel
  - Filler neck, 20
  - Fuel grade, 166
  - Refuelling, 167
  - Refuelling with Keyless Ride, 168, 169
  - Technical data, 256
- Fuel filler cap emergency release, 170, 171
- Fuel reserve
  - Range, 32
  - Warning indicators, 67
- Fuses
  - Position on the vehicle, 21
  - Replacing, 227

## G

- General views
  - Indicator and warning lights, 28
  - Instrument cluster, 25, 29, 30
  - Left multifunction switch, 22
  - Left side of vehicle, 18
  - My vehicle, 33
  - Right multifunction switch, 23, 24
  - Right side of vehicle, 19
  - Underneath the seat, 21

## H

- Hazard warning flashers
  - Control, 22
  - Operating, 100
- Headlight
  - Headlight beam throw, 144
- Headlight courtesy delay feature, 98
- Heated handlebar grips
  - Operating, 118
- Hill Start Control
  - Automatically deactivated, 64
  - Cannot be activated, 64
  - Engineering details, 191
  - Hill Start Control, 112
  - Indicator and warning lights, 64
  - Operating, 113
  - Switching on and off, 112
- Hill Start Control Pro
  - Engineering details, 191
  - Operating, 113
- Horn, 22

## I

- Ignition
  - Switching off, 88
  - Switching on, 88
- Immobiliser
  - Emergency key, 91
- Indicator lights, 25
  - Overview, 28
- Instrument cluster
  - Ambient-light brightness sensor, 25
  - Overview, 25

- Instrument panel
  - Control, 22
  - Operating, 70, 74, 75, 79
  - Overview, 29, 30
  - Selecting display, 72

**J**

- Jump-starting, 221

**K**

- Keyless Ride
  - Battery of the radio-operated key is empty or loss of the radio-operated key, 92
  - Engaging steering lock, 89
  - Fuel filler cap, unlocking, 168, 169
  - Switching off ignition, 91
  - Switching on ignition, 90
  - Warning indicators, 44, 45
- Keys, 88, 89

**L**

- Lighting
  - Replacing LED light sources, 221
  - Technical data, 261
  - Warning indicators, 47
- Lights
  - Automatic daytime riding light, 99
  - Control, 22
  - Headlight courtesy delay feature, 98
  - Headlight flasher, 97
  - High-beam headlight, 97
  - Low-beam headlight, 97
  - Parking lights, 98
  - Side light, 97

- Loudspeaker
  - Relationship with Bluetooth, 136
  - Switching off, 137
- Luggage
  - Instructions for loading, 156

**M**

- Maintenance
  - Maintenance schedule, 271
- Maintenance confirmations, 273
- Maintenance intervals, 269
- Media
  - Operating, 82
- Menu
  - Calling up, 74
- Mirrors
  - Adjusting, 144
- Mobility services, 269
- Motorcycle
  - Care, 240
  - Cleaning, 240
  - Lashing, 171
  - Laying up, 245
  - Parking, 165
  - Restoring to use, 246
- Multifunction switch
  - Overview, left side, 22
  - Overview, right side, 23, 24

**N**

- Navigation
  - Operating, 79

**O**

- On-board voltage, 45, 46

# 312 INDEX

## P

- Pairing, 77
- Parking, 165
- Passenger seat
  - Installing, 148, 150
  - Removing, 148
- Performance figures
  - Technical data, 262
- Phone
  - Operating, 83
- Power socket
  - Notes on use, 234
  - Position on the vehicle, 20
- Pre-Ride-Check, 160
- Pure Ride
  - Overview, 30

## R

- Radio
  - Adding favourite, 136
  - Selecting source, 134
- Radio-operated key
  - Warning indicators, 44, 45
- RDC
  - Engineering details, 189
  - Warning indicators, 55, 56, 57
- Recycling, 267
- Refuelling, 167
  - Fuel grade, 166
  - with Keyless Ride, 168, 169
- Remote control
  - Registration, 126
  - Replacing battery, 92, 128
  - Synchronising, 127
- Rev. counter
  - Rev. counter, 31

- Rider's seat
  - Adjusting seat height, 148
  - Height adjustment, 21
  - Installing, 148
  - Lock, 18
  - Removing, 148
- Riding mode
  - Adjusting, 102
  - Engineering details, 186
- Running in, 160

## S

- Safety instructions
  - For brakes, 162
  - For riding, 156
- Satellite radio
  - Availability, 138
  - Calling up channel saved in memory, 140
  - Saving channel, 139
  - Selecting category and channel, 139
  - Signal strength, 139
  - Subscribing to channel, 139
  - System messages, 140
- Screw connections, 254
- Seat heating
  - Control, 18
  - Operating, 118
- Service, 267
  - Reporting safety-relevant defects, 266
  - Service history, 268
  - Warning indicators, 68, 69
- Service-due indicator, 68

- Shift assistant, 161, 190
  - Engineering details, 190
  - Gear not taught, 67
  - Riding, 161
- ShiftCam, 193
  - Engineering details, 193
- Shifting gear
  - Recommendation to upshift, 32
- Silencer
  - Pivoting silencer outwards, 218
  - Securing silencer, 219
- Spark plugs
  - Technical data, 261
- Speed Limit Info, 82
- Splitscreen, 79
  - Selecting display, 79
  - Switching off, 79
  - Switching on, 79
- Spring preload
  - Adjusting, 150
- Starting, 159
  - Control, 23, 24
- Status line, top, 76
  - Adjusting, 75
- Steering lock
  - Locking, 88
- Stowage compartment
  - Operating, 121
  - Position on the vehicle, 20

## T

- Technical data, 261
  - Battery, 260
  - Brakes, 259
  - Chassis and suspension, 258
  - Clutch, 258
  - Dimensions, 261
  - Electrical system, 260
  - Engine, 257
  - Engine oil, 257
  - Final drive, 258
  - Frame, 258
  - Fuel, 256
  - General notes, 5
  - Performance figures, 262
  - Spark plugs, 261
  - Standards, 5
  - Transmission, 258
  - Weights, 262
  - Wheels and tyres, 259
- Tone settings, 137
- Toolkit
  - Contents, 199
  - Position on the vehicle, 21
- Topcase
  - Installing, 237
  - Operating, 235
  - Removing, 236
- Torques, 254
- Traction control
  - DTC, 180
- Transmission
  - Technical data, 258
- Trim panels, 199
- Troubleshooting chart, 250
- Turn indicators
  - Control, 22
  - Operating, 100
- Type plate
  - Position on the vehicle, 19
- Tyre pressure monitoring RDC
  - Display, 54
- Tyres, 210
  - Checking tread depth, 209
  - Checking tyre pressure, 209

## 314 INDEX

- Pressures, 260
- Running in, 161
- Technical data, 259
- Top speed, 157

### V

- Value
  - Display, 35
- Vehicle identification number
  - Position on the vehicle, 19
- Volume
  - Adapt to speed, 138
  - Adjusting, 137

### W

- Warning indicator lights
  - ABS, 59, 60, 61
  - Anti-theft alarm, 49
  - Audio system, 67
  - Brake temperature, 64, 65
  - Bulb faulty, 47
  - Cruise control, 66
  - Distance control (Active Cruise Control ACC), 66
  - DTC, 61, 62
  - DWA, 48, 49
  - Electrical machine control unit, 52, 53
  - Electrical machine temperature, 50, 51
  - Emergency call, 58
  - Engine, 52
  - Engine electronics, 52
  - Engine oil level, 50
  - Fall sensor, 58
  - Fuel reserve, 67
  - Gear not taught, 67
  - Hill Start Control, 64
  - Keyless Ride, 44, 45

- Light control failed, 48
- Mode of presentation, 35
- My vehicle, 33
- On-board voltage, 45, 46
- Outside temperature
  - warning, 44
- RDC, 55
- Service, 68, 69
- Side stand, 59
- TPM, 55, 56, 57
- Warning light, drive malfunction, 51
- Warning light, drive malfunction, 51, 52
- Warning lights, 25
  - Overview, 28
- Warnings, overview, 37
- Weights
  - Technical data, 262
- Wheels
  - Change of size, 210
  - Checking rims, 210
  - Installing front wheel, 213
  - Installing rear wheel, 217
  - Removing front wheel, 211
  - Removing rear wheel, 216
  - Technical data, 259
- Windscreen
  - Adjusting, 144
  - Control, 22

Details described or illustrated in this booklet may differ from the vehicle's actual specification as purchased, the accessories fitted or the national-market specification. No claims will be entertained as a result of such discrepancies.

Dimensions, weights, fuel consumption and performance data are quoted to the customary tolerances.

The right to modify designs, equipment and accessories is reserved.

Errors and omissions excepted.

© 2024 Bayerische Motoren  
Werke Aktiengesellschaft  
80788 Munich, Germany

Not to be reproduced by any means whatsoever, wholly or in part, without the written permission of BMW Motorrad, After-sales.

Original rider's manual, printed in Germany.

## Important data for refuelling:

### Fuel

|                        |                                                                                                                                                                                                                                                                                        |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Recommended fuel grade |  Premium unleaded (max. 15% ethanol, E15)<br> 95 ROZ/RON<br>90 AKI                                                   |
| Alternative fuel grade |  Regular unleaded (power- and consumption-related restrictions) (max. 15% ethanol, E10/E15)<br> 91 ROZ/RON<br>87 AKI |
| Usable fuel capacity   | approx. 25 l                                                                                                                                                                                                                                                                           |
| Reserve fuel           | approx. 4 l                                                                                                                                                                                                                                                                            |
| <b>Tyre pressures</b>  |                                                                                                                                                                                                                                                                                        |
| Tyre pressure, front   | 2.5 bar, tyre cold                                                                                                                                                                                                                                                                     |
| Tyre pressure, rear    | 2.9 bar, tyre cold                                                                                                                                                                                                                                                                     |

For further information on all aspects of your vehicle, visit: [bmw-motorrad.com](https://bmw-motorrad.com)

