



**BMW
MOTORRAD**

RIDER'S MANUAL

R nineT



MAKE LIFE A RIDE

Vehicle data

Model

Vehicle Identification Number

Colour code

Date of first registration

Registration number

Dealership details

Person to contact in Service department

Ms/Mr

Phone number

Dealership address/phone number (company stamp)

YOUR BMW.

We congratulate you on your choice of a vehicle from BMW Motorrad and welcome you to the community of BMW riders. Familiarise yourself with your new vehicle so that you can ride it safely and confidently in all traffic situations.

About this rider's manual

Read this rider's manual carefully before starting to use your new BMW. It contains important information on how to operate the controls and how to make the best possible use of all your BMW's technical features.

In addition, it contains information on maintenance and care to help you maintain your vehicle's reliability and safety, as well as its value.

If the time comes to sell your BMW, please remember to hand over this rider's manual to the new owner. It is an important part of the vehicle.

We hope you will enjoy riding your BMW and that all your journeys will be pleasant and safe

BMW Motorrad.

01 GENERAL INSTRUCTIONS	2	04 OPERATION	36
Quick & easy reference	4	Ignition switch/steering lock	38
Abbreviations and symbols	4	Emergency-off switch (kill switch)	40
Equipment	5	Lights	40
Technical data	5	Hazard warning lights	43
Currency	6	Turn indicators	43
Additional sources of information	6	Reading	45
Certificates and operating licences	6	Settings in the instrument cluster	49
Data memory	6	Anti-theft alarm (DWA)	53
		Traction control (ASC/DTC)	55
02 GENERAL VIEWS	12	Riding mode	56
General view, left side	14	Adaptive cruise control	57
General view, right side	15	Heated handlebar grips	59
Underneath the seat	16	Front and rear seats	60
Multifunction switch, left	17		
Multifunction switch, right	18	05 ADJUSTMENT	62
Instrument cluster	19	Mirrors	64
		Headlight	65
03 STATUS INDICATORS	20	Clutch	66
Indicator and warning lights	22	Brakes	67
Multifunction displays	23	Spring preload	68
Warning indicators	24	Damping	70
Service-due indicator	33	Footrest system	72
		06 RIDING	78
		Safety instructions	80
		Regular check	82
		Starting	83
		Running in	86
		Brakes	87

Parking your motorcycle	90	Diagnostic connector	135
Refuelling	91		
Securing motorcycle for transportation	93	09 ACCESSORIES	138
		General instructions	140
07 ENGINEERING DETAILS	96	USB charging socket	140
General instructions	98	Luggage	141
Antilock Brake System (ABS)	98	Passenger frame	142
Dynamic Brake Control	101	Tail-hump cover	147
Traction control (ASC/DTC)	102	Optional accessories	149
Riding mode	103		
Dynamic engine brake control	105	10 CARE	150
Adaptive Headlight	106	Care products	152
		Washing the vehicle	152
08 MAINTENANCE	108	Cleaning easily damaged components	153
General notes	110	Care of paintwork	154
Toolkit	111	Paint preservation	155
Front-wheel stand	111	Laying up motorcycle	155
Rear-wheel stand	112	Restoring motorcycle to use	155
Engine oil	112		
Brake system	114	11 TECHNICAL DATA	156
Clutch	119	Troubleshooting chart	158
Tyres	119	Screw connections	159
Wheel rims	120	Fuel	162
Wheels	120	Engine oil	162
Lighting	129	Engine	163
Jump-starting	130	Clutch	163
Battery	132	Transmission	164
Fuses	134	Final drive	164
		Frame	164
		Chassis and suspension	165
		Brakes	166
		Wheels and tyres	166

Electrical system	167
Dimensions	168
Weights	168
Performance figures	169

12 SERVICE	170
-------------------	------------

Reporting safety-relevant defects	172
BMW Motorrad Service	173
BMW Motorrad Service history	173
BMW Motorrad mobility services	174
Maintenance work	174
Maintenance schedule	176
Maintenance confirmations	177
Service confirmations	191

APPENDIX	194
-----------------	------------

Declaration of conformity for electronic immobiliser	195
Certificate for electronic immobiliser	201
Declaration of conformity for anti-theft alarm system	203

INDEX	208
--------------	------------

GENERAL IN- STRUCTIONS

01

QUICK & EASY REFERENCE	4
ABBREVIATIONS AND SYMBOLS	4
EQUIPMENT	5
TECHNICAL DATA	5
CURRENCY	6
ADDITIONAL SOURCES OF INFORMATION	6
CERTIFICATES AND OPERATING LICENCES	6
DATA MEMORY	6

4 GENERAL INSTRUCTIONS

QUICK & EASY REFERENCE

Chapter 2 of these operating instructions will provide you with an initial overview of your motorcycle. All maintenance and servicing work on the motorcycle is documented in the "Service" section. The record of the maintenance work you have had performed on your vehicle is a precondition for generous treatment of goodwill claims. If the time comes to sell your BMW, please remember to hand over these operating instructions to the new owner. They are an important part of the motorcycle.

ABBREVIATIONS AND SYMBOLS

 **CAUTION** Low-risk hazard. Non-avoidance can lead to slight or moderate injury.

 **WARNING** Medium-risk hazard. Non-avoidance can lead to fatal or severe injury.

 **DANGER** High-risk hazard. Non-avoidance leads to fatal or severe injury.

 **ATTENTION** Special notes and precautionary measures. Non-compliance can lead

to damage to the vehicle or accessory and, consequently, to voiding of the warranty.



NOTICE Specific instructions on how to operate, control, adjust or look after items of equipment on the vehicle.

- Instruction.
- » Result of an activity.
-  Reference to a page with more detailed information.
- < Indicates the end of a passage relating to specific accessories or items of equipment.



Tightening torque.



Technical data.

OE Optional equipment. The vehicles are assembled complete with all the BMW Motorrad optional equipment originally ordered.

OA	Optional accessories. You can obtain BMW Motorrad optional accessories through your authorised BMW Motorrad dealer; optional accessories have to be retrofitted to the vehicle.
ABS	Anti-lock brake system.
ASC	Automatic Stability Control.
DTC	Dynamic Traction Control.
DWA	Anti-theft alarm.
EWS	Electronic immobiliser.
MSR	Dynamic engine brake control.

EQUIPMENT

When you ordered your BMW Motorrad, you chose various items of custom equipment. These operating instructions describe the optional equipment (OE) offered by BMW and selected optional accessories (OA). This explains why the manual may also contain descriptions of equipment that you might

not have selected. Please note, too, that on account of country-specific differences, your motorcycle might not be exactly as illustrated. If your motorcycle contains equipment that has not been described, its description can be found in a separate manual.

TECHNICAL DATA

All dimensions, weights and power ratings stated in the operating instructions are quoted to the standards and comply with the tolerance requirements of the Deutsches Institut für Normung e.V. (DIN). Technical data and specifications in this rider's manual serve as reference points. The vehicle-specific data may deviate from these, for example as a result of selected optional equipment, the national-market version or country-specific measuring procedures. Detailed values can be taken from the vehicle registration documents, or can be obtained from your authorised BMW Motorrad retailer or another qualified service partner or specialist workshop. The specifications in the vehicle documents always have priority over the inform-

6 GENERAL INSTRUCTIONS

ation provided in this rider's manual.

CURRENCY

The high safety and quality standards of BMW motorcycles are maintained by constant development work on designs, equipment and accessories. Because of this, your motorcycle may differ from the information supplied in the Rider's Manual. Nor can BMW Motorrad entirely rule out errors and omissions. We hope you will appreciate that no claims can be entertained on the basis of the data, illustrations or descriptions in these operating instructions.

ADDITIONAL SOURCES OF INFORMATION

Authorised BMW Motorrad retailer

Your authorised BMW Motorrad retailer will be happy to answer any questions you may have.

Internet

The operating instructions for your vehicle, operating and installation instructions for accessories and general information about BMW Motorrad, in relation to

technology, for example, are available for download from www.bmw-motorrad.com/manuals.

CERTIFICATES AND OPERATING LICENCES

The certificates for the vehicle and the official operating licences for accessories can be downloaded from bmw-motorrad.com/certification.

DATA MEMORY

General

Control units are installed in the vehicle. Control units process data that they receive, for example, from vehicle sensors, or that they generate themselves or exchange between each other. Some control units are required for the vehicle to function safely or provide assistance during riding, for example assistance systems. In addition, control units enable comfort or infotainment functions.

Information on data that has been stored or exchanged can be obtained from the manufacturer of the vehicle, for example via a separate booklet.

Personal reference

Each vehicle is identified with a clear vehicle identification number. Depending on the country, the vehicle identification number, the number plate and the corresponding authorities can be referenced to ascertain the vehicle owner. There are also other ways to use data obtained from the vehicle to trace the rider or vehicle owner, for example using the Connected-Drive user account.

Data protection rights

In accordance with applicable data protection laws, vehicle users have certain rights in relation to the manufacturer of the vehicle or in relation to companies which collect or process personal data. Vehicle users have the right to obtain full information at no cost from persons or entities storing personal data of the vehicle user.

These entities may include:

- Manufacturer of the vehicle
- Qualified service partners
- Specialist workshops
- Service providers

Vehicle users have the right to request information on what personal data has been stored, for what purpose the data

is used, and where the data comes from. To obtain this information, proof of ownership or use is required.

The right to information also includes information about data that has been shared with other companies or entities. The website of the vehicle manufacturer contains the applicable data protection information. This data protection information includes information on the right to have data deleted or corrected. The manufacturer of the vehicle also provides their contact details and those of the data protection officer on their website.

The vehicle owner can also request that a BMW Motorrad retailer or another qualified service partner or specialist workshop read out the data that is stored in the vehicle for a charge.

The vehicle data is read out using the legally prescribed socket for on-board diagnosis (OBD) in the vehicle.

8 GENERAL INSTRUCTIONS

Legal requirements for the disclosure of data

As part of its legal responsibilities, the manufacturer of the vehicle is obligated to make its stored data available to the relevant authorities. This data is provided in the required scope in individual cases, for example to clarify a criminal offence. In the context of applicable laws, public agencies are entitled in individual cases to read out data from the vehicle themselves.

Operating data in the vehicle

Control units process data to operate the vehicle.

This includes, for example:

- Status reports of the vehicle and its individual components, for example wheel revolutions, wheel speed, deceleration
- Environmental conditions, for example temperature

The data is only processed in the vehicle itself and is generally non-permanent. The data is not stored beyond the operating period.

Electronic components, for example control units, contain components for storing technical information. Information can be temporarily or permanently stored on the vehicle con-

dition, component loads, incidents or errors.

This information is generally used to document the condition of a component, a module, a system or the surrounding area, for example:

- Operating conditions of system components, for example filling levels, tyre pressure
- Malfunctions and faults in important system components, for example light and brakes
- Response of the vehicle in special riding situations, for example engagement of the driving dynamics systems
- Information on incidents resulting in damage to the vehicle

The data is necessary for the provision of control unit functions. Furthermore, the data is used to detect and rectify malfunctions and to enable the vehicle manufacturer to optimise vehicle functions.

The vast majority of this data is non-permanent and is only processed in the vehicle itself. Only a small amount of the data is stored in incident or fault memories as required by events.

If services are accessed, for example repairs, service pro-

cesses, warranty cases and quality assurance measures, this technical information can be read out of the vehicle together with the vehicle identification number.

The information can be read out by a BMW Motorrad retailer or another qualified service partner or specialist workshop. The legally stipulated socket for on-board diagnosis (OBD) in the vehicle is used to read out the data. The data is obtained, processed and used by the relevant parts of the retailer network. The data is used to document the technical conditions of the vehicle, to help with error localization, to comply with warranty obligations and to improve quality.

In addition, the manufacturer has various product monitoring obligations arising from product liability legislation. To meet these obligations, the vehicle manufacturer requires technical data from the vehicle. The data from the vehicle can also be used to check warranty claims from the customer. Error and incident memories in the vehicle can be reset during

servicing or repair work by a BMW Motorrad retailer or another qualified service partner or specialist workshop.

Data input and data transfer in the vehicle

General

Depending on the equipment, comfort and customised settings can be stored in the vehicle and can be changed or reset at any time.

This includes, for example:

- Settings of the windscreen position
- Chassis and suspension settings

If required, data can be entered in the entertainment and communication system of the vehicle, for example using a smartphone.

Depending on the individual equipment, this includes:

- Multimedia data, such as music for playback
- Contacts data for use in connection with a communication system or an integrated navigation system
- Entered destinations
- Data on the use of internet services. This data can be stored locally in the vehicle or is located on a device that is connected to the vehicle,

10 GENERAL INSTRUCTIONS

for example smartphone, USB stick, MP3 player. If this data is stored in the vehicle, the data can be deleted at any time.

This data is transferred to third parties only if personally requested within the context of using online services. This depends on the selected settings when using the services.

Incorporation of mobile devices

Depending on the equipment, mobile devices connected to the vehicle, for example smartphones, can be controlled using the operating elements of the vehicle.

The image and sound of the mobile device can then be output via the multimedia system. At the same time, specific information is transferred to the mobile device. Depending on the type of integration, this includes, for example, position data and additional general vehicle information. This enables optimal use of the selected apps, for example navigation or music playback.

The type of additional data processing is determined by the provider of the respective app. The scope of the possible set-

tings depends on the corresponding app and the operating system of the mobile device.

Services

General

If the vehicle has a wireless connection, this enables the exchange of data between the vehicle and other systems. The wireless connection is enabled by the vehicle's own transmitter and receiver unit or using personally integrated mobile devices, for example smartphones. Online functions can be used using this wireless connection. These include online services and apps that are provided by the vehicle manufacturer or by other providers.

Services of the vehicle manufacturer

For online services of the vehicle manufacturer, the individual functions are described at suitable points, for example rider's manual, website of the manufacturer. At the same time, information is also provided on the relevant data protection law. Personal data may be used to provide online services. Data is exchanged using a secure connection, for example with

the IT systems provided by the vehicle manufacturer.

Obtaining, processing and using personal data outside of the normal provision of services requires legal permission, contractual agreement or consent. It is also possible to have the entire data connection activated or deactivated. Statutory functions are excluded from this.

Services from other providers

When using online services from other providers, these services are subject to the responsibility and the data protection and operating conditions of the individual provider. The vehicle manufacturer has no influence on the content that is exchanged in this instance. Information on the type, scope and purpose of the data capture and use of personal data as part of the services of third parties can be ascertained from the individual provider.


GENERAL VIEWS

02


GENERAL VIEW, LEFT SIDE	14
GENERAL VIEW, RIGHT SIDE	15
UNDERNEATH THE SEAT	16
MULTIFUNCTION SWITCH, LEFT	17
MULTIFUNCTION SWITCH, RIGHT	18
INSTRUMENT CLUSTER	19

14 GENERAL VIEWS

GENERAL VIEW, LEFT SIDE




- 1** Adjusting damping for front wheel (▮▮▮➔ 70)
- 2** Checking operation of the clutch (▮▮▮➔ 119)
- 3** Fuel filler neck (▮▮▮➔ 91)
- 4** Loading correctly (▮▮▮➔ 141)
- 5** Adjusting damping for rear wheel (▮▮▮➔ 71)
- 6** USB charging socket (▮▮▮➔ 140)
- 7** Checking engine oil level (▮▮▮➔ 112)
- 8** Type plate (on the steering-head bearing)

GENERAL VIEW, RIGHT SIDE


- 1** Checking brake-fluid level, front brakes (➡ 117)
- 2** Topping up engine oil (➡ 113)
- 3** Vehicle identification number (front right at the bottom on the rear frame)
- 4** Checking brake-fluid level, rear brakes (➡ 118)
- 5** Adjusting spring preload (➡ 69)
- 6** Removing passenger seat (➡ 60)

16 GENERAL VIEWS

UNDERNEATH THE SEAT




- 1** Diagnostic connector
(135)
- 2** Toolkit (111)
- 3** Payload table
- 4** Tyre pressures table
- 5** Fuse box (134)
- 6** Remote positive terminal
(130)

MULTIFUNCTION SWITCH, LEFT


- 1 High-beam headlight and headlight flasher (▮▮▮▮ 41)
- 2 Adaptive cruise control (▮▮▮▮ 57)
- 3 Hazard warning lights (▮▮▮▮ 43)
- 4 Traction control (ASC/DTC) (▮▮▮▮ 55)
- 5 Turn indicators (▮▮▮▮ 43)
- 6 Horn
- 7 MENU rocker button (▮▮▮▮ 45)

18 GENERAL VIEWS

MULTIFUNCTION SWITCH, RIGHT



- 1** Operating heated handle-bar grips (➡ 59)
- 2** Selecting riding mode (➡ 56)
- 3** Emergency-off switch (kill switch) (➡ 40)
- 4** Starter button (➡ 83)

INSTRUMENT CLUSTER

- 1 Speedometer
- 2 Indicator and warning lights (▮▮▮ 22)
- 3 Photosensor for the brightness control in the multi-function display
—with anti-theft alarm
(DWA)^{OE}
DWA light-emitting diode
(▮▮▮ 53)
- 4 Rev. counter
- 5 Multifunction displays
(▮▮▮ 23)

STATUS INDICAT- ORS

03

INDICATOR AND WARNING LIGHTS	22
MULTIFUNCTION DISPLAYS	23
WARNING INDICATORS	24
SERVICE-DUE INDICATOR	33


22 STATUS INDICATORS

INDICATOR AND WARNING LIGHTS



- 1 Warning light, drive malfunction (► 28)
- 2 High beam indicator light (► 41)
- 3 General warning light
Displayed in combination with warning symbols in the multifunction display (► 24)
- 4 Neutral indicator light
- 5 ASC/DTC indicator and warning light (► 30)
- 6 Turn signal indicator light (► 43)
- 7 ABS indicator and warning light

MULTIFUNCTION DISPLAYS



- 1 Selecting riding mode
(56)
- 2 On-board computer
Selecting display in
speedometer (45)
Unit of selected display
- 3 Status
Warning symbol (24)
- 4 On-board computer
Selecting display in rev.
counter (47)
- 5 Unit of selected display
- 6 Gear indicator
- 7 Value

24 STATUS INDICATORS

WARNING INDICATORS

Mode of presentation

Warnings are indicated by the corresponding warning lights. If two or more warnings occur at the same time, all the appropriate warning lights show. Warning symbols corresponding to the warnings appear in alternate sequence. The possible warnings are listed on the next pages.



Warnings that do not have warning lights of their own are indicated by a warning symbol **1** appearing in the multifunction display in combination with 'General' warning light **2**. The 'General' warning light either shows steadily or flashes, depending on the urgency of the warning.

Warnings, overview

Indicator and warning lights	Display text	Meaning
 lights up.	 is displayed.	Electronic immobiliser active (▮▮▮ 27)
 lights up.	 is displayed.	Engine in emergency-operation mode (▮▮▮ 27)
 flashes.	 is displayed.	Engine warning (▮▮▮ 27)
 lights up.		Drive malfunction (▮▮▮ 28)
 flashes.	 is displayed.	Serious drive malfunction (▮▮▮ 28)
 flashes.		
 lights up.	 is displayed.	Voltage of the vehicle electrical system critical (▮▮▮ 28)
 lights up.	 is displayed.	Vehicle voltage too low (▮▮▮ 29)
	 is displayed.	Outside temperature warning (▮▮▮ 29)
 lights up.	 is displayed.	Bulb faulty (▮▮▮ 29)
 flashes.		ABS self-diagnosis not completed (▮▮▮ 30)
 lights up.		ABS fault (▮▮▮ 30)

26 STATUS INDICATORS

Indicator and warning lights	Display text	Meaning
 quick-flashes.		ASC/DTC intervention (▮▮▮▮▶ 30)
 flashes.		ASC/DTC self-diagnosis not completed (▮▮▮▮▶ 31)
 lights up.		ASC/DTC switched off (▮▮▮▮▶ 31)
 lights up.		ASC/DTC fault (▮▮▮▮▶ 31)
	 is displayed.	Anti-theft alarm battery flat (▮▮▮▮▶ 31)
 lights up.	 and distance recorder KM R or, as applicable, MI R are displayed.	Fuel down to reserve (▮▮▮▶ 32)
	 is displayed.	Service due (▮▮▮▶ 32)
 lights up.	 is displayed.	Service overdue (▮▮▮▶ 33)

Electronic immobiliser active

lights up.



is displayed.

Possible cause:

The key being used is not authorised for starting, or communication between key and engine electronics is disrupted.

- Remove all other vehicle keys from the same ring as the vehicle key being used.
- Have the faulty ignition key replaced, preferably by an authorised BMW Motorrad retailer.

Engine in emergency-operation mode

lights up.



is displayed.

**WARNING****Unusual ride characteristics when engine running in emergency-operation mode**

Risk of accident

- Avoid accelerating sharply and overtaking.

Possible cause:

The engine control unit has diagnosed a fault. In exceptional cases, the engine stops and refuses to start. Otherwise, the engine runs in emergency operating mode.

- You can continue to ride, but bear in mind that the usual engine performance might not be available.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Engine warning

flashes.



is displayed.

**WARNING****Engine damage when running in emergency-operation mode**

Risk of accident

- Ride slowly, avoid accelerating sharply and overtaking.
- If possible, have the vehicle picked up and have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad Retailer.

28 STATUS INDICATORS

Possible cause:

The engine control unit has diagnosed a fault which may cause severe secondary faults. The engine is in emergency-operation mode.

- Avoid high load and rpm ranges if possible.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

» It is possible to continue to ride but not recommended.

Drive malfunction



lights up.

Possible cause:

The engine control unit has diagnosed a fault that affects pollutant emissions and/or reduces power.

- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad retailer.
- » You can continue riding; pollutant emissions are higher than the threshold values.

Serious drive malfunction



flashes.



flashes.



is displayed.

Possible cause:

The engine control unit has diagnosed a fault that can lead to damage to the exhaust system.

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

» It is possible to continue to ride but not recommended.

Voltage of the vehicle electrical system critical



lights up.



is displayed.

Generator power is no longer sufficient to supply all consumers and charge the battery. In order to ensure that the engine can be started and the motorcycle ridden, the on-board electronics switch off the electricity supply to individual consumers.

Possible cause:

Too many consumers are switched on. On-board system voltage tends to drop particularly at low engine rpm and when the engine is idling.

- When riding at low engine rpm, switch off all consumers that are not necessary for road safety (e.g. heated body warmers).

Vehicle voltage too low



lights up.



is displayed.



WARNING

Failure of the vehicle systems

Risk of accident

- Do not continue your journey.

Possible cause:

Alternator or alternator belt faulty.

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Outside temperature warning



is displayed.

Possible cause:

The air temperature measured at the motorcycle is lower than 3 °C.



WARNING

Risk of black ice also applicable at over 3 °C

Risk of accident

- Always take extra care when temperatures are low; remember that there is particular danger of black ice forming on bridges and where the road is in shade.

- Ride carefully and think well ahead.

Bulb faulty



lights up.



is displayed.

30 STATUS INDICATORS



WARNING

Vehicle overlooked in traffic due to failure of the lights on the vehicle

Safety risk

- Always replace a faulty bulb at the earliest possible opportunity. Consult a specialist workshop, preferably an authorised BMW Motorrad Retailer.

ABS self-diagnosis not completed



flashes.

Possible cause:

The ABS function is not available, because self-diagnosis did not complete. The motorcycle has to move forward a few metres for the wheel sensors to be tested.

- Pull away slowly. Bear in mind that the ABS function is not available until self-diagnosis has completed.

ABS fault



lights up.

Possible cause:

The ABS control unit has detected a fault. The ABS function is not available.

- You can continue to ride the vehicle, but make due provision for the fact that the ABS function is not available. Bear in mind the more detailed information on situations that can lead to an ABS fault (► 99).
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

ASC/DTC intervention



quick-flashes.

The ASC/DTC has detected a degree of instability at the rear wheel and has intervened to reduce torque. The ASC/DTC indicator and warning light flashes for longer than ASC/DTC intervention lasts. This affords the rider visual feedback on control intervention even after the critical situation has been dealt with.

ASC/DTC self-diagnosis not completed



flashes.

Possible cause:



ASC/DTC self-diagnosis not completed

The ASC/DTC function is not available, because self-diagnosis did not complete. (The motorcycle has to reach a defined minimum speed with the engine running for the wheel-speed sensors to be checked: min 5 km/h)

- Pull away slowly. Bear in mind that the ASC/DTC function and dynamic engine brake control are not available until self-diagnosis has completed.

ASC/DTC switched off



lights up.

Possible cause:

The rider has switched off the ASC/DTC system.

- Switch on the ASC/DTC function (➡ 55).

ASC/DTC fault



lights up.

Possible cause:

The ASC/DTC control unit has detected a fault. The ASC/DTC function and dynamic engine brake control are not available or their functionality is subject to certain restrictions.

- You can continue to ride. Bear in mind that the ASC/DTC function and dynamic engine brake control are not available or are restricted. Bear in mind the more detailed information on situations that can lead to an ASC/DTC fault (➡ 102).
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

Anti-theft alarm battery flat

—with anti-theft alarm (DWA)^{OE}



is displayed.



This error message shows briefly only after the Pre-Ride-Check completes.

Possible cause:

The integral battery in the anti-theft alarm (DWA) has lost its entire original capacity. There is no assurance that the DWA anti-theft alarm will be opera-

32 STATUS INDICATORS

tional if the vehicle's battery is disconnected.

- Consult a specialist workshop, preferably an authorised BMW Motorrad dealer.

Fuel reserve

The amount of fuel remaining in the fuel tank when the low-fuel warning light comes on depends on riding dynamics. The more the fuel moves inside the fuel tank (due to frequent changes in angle of lean, frequent braking and acceleration), the more difficult it becomes to determine the reserve volume of fuel remaining in the tank. For this reason, the reserve volume of fuel cannot be displayed exactly.

 As soon as the low-fuel warning light comes on, the KM R or, as applicable, the MI R reading for the distance that can potentially be covered with the fuel still on board appears and counts down. The distance that can still be travelled using the reserve volume of fuel depends on the style of riding (fuel consumption) and the amount of fuel left in the tank. After a refuelling stop, the distance counter for reserve fuel

is reset if the amount of fuel in the tank is greater than the reserve quantity.

Fuel down to reserve



lights up.



and distance recorder KM R or, as applicable, MI R are displayed.



WARNING

Irregular engine operation or engine shutdown due to lack of fuel

Risk of accident, damage to catalytic converter

- Do not run the fuel tank dry.

Possible cause:

The fuel tank contains no more than the reserve quantity of fuel.



Reserve fuel

approx. 3.5 l

- Refuelling (91).

Service due



is displayed.

Possible cause:

Service is due, because of either distance covered or time expired.

- Have your motorcycle serviced regularly by a specialist workshop, preferably an authorised BMW Motorrad retailer.
- » The vehicle remains operationally reliable and road-worthy.
- » The vehicle retains its value.

Service overdue



lights up.




is displayed.

Possible cause:


Service is overdue because of the driving performance or the date.

- Have your motorcycle serviced regularly by a specialist workshop, preferably an authorised BMW Motorrad retailer.
- » The vehicle remains operationally reliable and road-worthy.
- » The vehicle retains its value.

SERVICE-DUE INDICATOR



When a service is due within one month, symbol for service due **3** and service due date **1** are displayed. **SERV 2** appears briefly on the display after the Pre-Ride-Check or when called up by the rider for display in the on-board computer.



When a service is due within 1000 km, symbol for service due **3** and countdown distance **1** are displayed and the countdown proceeds in steps of 100 km. **SERV 2** appears briefly on the display after the Pre-Ride-Check or when called

34 STATUS INDICATORS

up by the rider for display in the on-board computer.

 The date saved in the instrument cluster must be adjusted if the service display appears more than one month prior to the service date. This situation may occur if the battery has been disconnected from the vehicle.

OPERATION

04

IGNITION SWITCH/STEERING LOCK	38
EMERGENCY-OFF SWITCH (KILL SWITCH)	40
LIGHTS	40
HAZARD WARNING LIGHTS	43
TURN INDICATORS	43
READING	45
SETTINGS IN THE INSTRUMENT CLUSTER	49
ANTI-THEFT ALARM (DWA)	53
TRACTION CONTROL (ASC/DTC)	55
RIDING MODE	56
ADAPTIVE CRUISE CONTROL	57
HEATED HANDLEBAR GRIPS	59
FRONT AND REAR SEATS	60

38 OPERATION

IGNITION SWITCH/STEERING LOCK

Keys

You receive 2 ignition keys and a special key for removing the passenger seat (► 60).

If a key is lost or mislaid, consult the information on the electronic immobiliser (EWS) (► 39).

Ignition switch/steering lock and the fuel filler cap lock are operated with the ignition key.

Engaging steering lock



ATTENTION

Handlebars turned in wrong direction when motorcycle propped on side stand

Risk of damage to parts if vehicle topples

- On level ground, always turn the handlebars to the left to set the steering lock.
 - In all other cases it is the lie of the ground that determines the direction in which the handlebars should be turned.
- Turn the handlebars to the full left or right lock position.



- Turn the ignition key to position **1**, while moving the handlebars slightly.
 - » Ignition, lights and all function circuits switched off.
 - » Steering lock engaged.
 - » Vehicle key can be removed.


Switching on ignition



- Turn the ignition key to position **1**.
 - » Side lights and all function circuits switched on.
 - » Engine can be started.
 - » Pre-Ride-Check is performed. (► 83)
 - » ABS self-diagnosis is in progress. (► 84)

- with riding modes Pro^{OE}
- » DTC self-diagnosis is in progress. (➡ 86)◀

Switching off ignition



- Turn the ignition key to position **1**.
 - » Lights switched off.
 - » Handlebars not locked.
 - » Vehicle key can be removed.
 - » Electrically powered accessories remain operational for a limited period of time.
 - » The battery can be recharged via the socket.

Electronic immobiliser (EWS)

The on-board electronics access the data saved in the ignition key via a ring aerial in the ignition lock. The engine control unit will not permit the engine to be started unless the key is identified as "authorised".

 Another vehicle key attached to the same ring as the vehicle key used to start the engine could "irritate" the electronics, in which case the

enabling signal for starting is not issued. The warning with the key symbol appears in the multifunction display. Always keep other vehicle keys separate from the vehicle key used to start the engine.

If you lose an ignition key, you can have it barred by your authorised BMW Motorrad retailer.

If you wish to do this, you will need to bring all other keys for the motorcycle with you. The engine cannot be started by a barred key, but a key that has been barred can subsequently be reactivated.

You can obtain extra keys only through an authorised BMW Motorrad retailer. The keys are part of an integrated security system, so the retailer is under an obligation to check the legitimacy of all applications for replacement/extra keys.

40 OPERATION

EMERGENCY-OFF SWITCH (KILL SWITCH)



- 1 Emergency-off switch (kill switch)



WARNING

Operation of the kill switch while riding

Risk of fall due to rear wheel locking

- Do not operate the kill switch when riding.

The emergency off switch is a kill switch for switching off the engine quickly and easily.



- A Engine switched off
B Normal operating position (run)




You cannot start the engine unless the kill switch is in the run position.

LIGHTS

Switching on low-beam headlight

- Switch on the ignition (➡ 38).
- Start the engine (➡ 83).



- Alternatively: pull switch 1 when ignition switched on.


Side light

The side lights switch on automatically when the ignition is switched on.

 The side lights place a strain on the battery. Do not switch the ignition on for longer than absolutely necessary.

High-beam headlight and headlight flasher


- Switch on the ignition (➡ 38).



- Push switch **1** forward to switch on the high-beam headlight.
- Pull switch **1** back to operate the headlight flasher.

Headlight courtesy delay feature

- Switch off the ignition (➡ 39).



- Immediately after switching off the ignition, pull switch **1** back and hold it in that position until the headlight courtesy delay feature comes on.
- » The vehicle's lights come on for one minute and then switch off automatically.
- This can be used to light up the path to the house door after the vehicle has been parked, for example.

Parking lights

- Switch off the ignition (➡ 39).



- Immediately after switching off the ignition, push button **1** to the left and hold it

42 OPERATION

in that position until the parking lights come on.

- Switch the ignition on and off again to switch off the parking lights.

Automatic daytime riding light

 The changeover between daytime riding light and low-beam headlight including front side lights can be effected automatically.



WARNING

The automatic daytime riding light is not a substitute for the rider's personal judgement of the light conditions

Risk of accident

- Switch off the automatic daytime riding light in poor light conditions.
- Switch on the ignition (III 38).



- Repeatedly short-press button **1** until SETUP ENTER is displayed.
 - Long-press button **1** to open SETUP.
- » SET DRL A is displayed.



- Short-press button **2** to change the set value.
- The following settings are available:
- DRL A ON: automatic daytime riding light is activated.
 - DRL A OFF: automatic daytime riding light is deactivated.
- Long-press button **1** to exit SET DRL A.
- » SETUP ENTER is displayed.

» If the ambient brightness decreases below a certain value (e.g. in a tunnel) while the daytime riding light function is active, the low-beam headlight is automatically switched on. When sufficient ambient brightness is detected, the daytime riding light is switched back on.

HAZARD WARNING LIGHTS

Operating hazard warning flashers

 The hazard warning flashers place a strain on the battery. Do not use the hazard warning flashers for longer than absolutely necessary.

 If you press a turn-indicator button while the hazard warning lights are switched on, the turn-indicator function is activated instead of the hazard warning flashers and remains active until you release the button. The hazard warning flashers recommence flashing as soon as the button is released.

- Switch on the ignition (➡ 38).



- Press button **1** to switch on the hazard warning lights system.
- » Ignition can be switched off.
- To switch off the hazard warning flashers, switch on the ignition and press button **1** again.

TURN INDICATORS

Operating turn indicators

- Switch on the ignition (➡ 38).



- Push button **1** to the left to switch on the left turn indicators.
- Push button **1** to the right to switch on the right turn indicators.

44 OPERATION

- Centre button **1** to cancel the turn indicators.

Comfort turn indicator



If button **1** has been pressed to the right or left, the turn indicators are automatically switched off under the following circumstances:

- Speed below 30 km/h: after 50 m distance covered.
- Speed between 30 km/h and 100 km/h: after a speed-dependent distance covered or in case of acceleration.
- Speed over 100 km/h: after flashing five times.

If button **1** is pressed to the right or left slightly longer, the turn indicators only switch off automatically once the speed-dependent distance covered is reached.

READING**Selecting display in speedometer****WARNING****Distraction from the road and loss of control**

Operating the integrated information system and communication devices while driving results in a risk of accident

- Operate those systems or devices only when the traffic situation allows for it.
- If necessary, stop and operate the systems or devices when stationary.

46 OPERATION

- Switch on the ignition (▣▶ 38).
 - » The on-board computer readings appear on the display.
- Repeatedly short-press button **1** until the desired value is displayed.

Possible displays:

- Total distance travelled: KM
- Trip distance 1: KM 1
- Automatic trip recorders:
KM A is reset automatically when 6 hours have elapsed after the ignition was switched off and the date has changed.
- Distance ridden after fuel down to reserve: KM R, selectable only after the fuel level has dropped to the reserve volume.
- Outside temperature: °C
- Clock: H:M
- Service due date: SERV, selectable only when next service is due within one month or service is overdue.
- Countdown distance to next service due: SERV, selectable only when next service due within 1000 km or service is overdue.
- Call up the menu for settings: SETUP ENTER, selectable only when the vehicle is at a standstill.

Selecting display in rev. counter



- Switch on the ignition (☛ 38).
» The on-board computer readings appear on the display.
- Repeatedly short-press button **1** until the desired value is displayed.

Possible displays:

- Engine temperature: Bar indicator
- Average speed: ØKM/H
- Vehicle voltage: V
- Average fuel consumption: ØL/100
- Current fuel consumption: L/100, when vehicle at standstill: L/H

48 OPERATION

Resetting trip recorder

- Switch on the ignition (▮▮▮▮▶ 38).



- Repeatedly short-press button **1** until the trip recorder you want to reset **2** is displayed.
- Press and hold down button **1** until trip recorder **2** is reset.

Resetting average values

- Switch on the ignition (▮▮▮▮▶ 38).



- Repeatedly short-press button **1** until the average value you want **2** is displayed.
- Press and hold down button **1** until the average value you want **2** is reset.

SETTINGS IN THE INSTRUMENT CLUSTER

Selecting **SETUP** Requirement

The vehicle is at a standstill.



- Repeatedly short-press button **1** until **SETUP ENTER** is displayed.
- Long-press button **1** to start **SETUP**.
- Short-press button **1** to step through the sequence of parameters in **SETUP** as follows:
 - Activate **DRL A ON** or deactivate **DRL A OFF** automatic daytime riding light.
 - Adjust the brightness of the backlighting in the instrument cluster **BRIGHT**.
 - with anti-theft alarm (DWA)^{OE}
 - Automatically activate anti-theft alarm function when the ignition is switched off **DWA ON** or leave the automatic function switched off **DWA OFF**.◀

- Set the time **CLOCK**.
- Set the date **DATE**.
- Set units **UNIT**.
- Reset displays **RESET**.
- Exit **SETUP** menu **SETUP EXIT**.

Adjusting display brightness

- Switch on the ignition (▶▶▶ 38).
- Select **SETUP** (▶▶▶ 49).



- Repeatedly short-press button **1** until **SET BRIGHT** is displayed.
- Repeatedly short-press button **2** until the desired value for display brightness **3** is set.
 - » A display brightness value in the range 1 ... 5 (dark ... bright) is set.
- Long-press button **1** to exit **SET BRIGHT**.
 - » **SETUP ENTER** is displayed.

Setting clock

- Switch on the ignition (▶▶▶ 38).
- Select **SETUP** (▶▶▶ 49).



- Short-press button **1** to increase year number **5** by one.
- Short-press button **2** to reduce year number **5** by one.
- Press and hold down button **2** until the year stops flashing.
» The year is set.
- Long-press button **1** to exit SET YEAR.
» The date is set.
- » SETUP ENTER is displayed.

Setting units

Requirement


The vehicle is at a standstill.

- Switch on the ignition (III 38).
- Select SETUP (III 49).



- Repeatedly short-press button **1** until SET UNIT ENTER is displayed.
- Long-press button **2** to activate SET UNIT.
» UNIT SPEED is displayed.
- Short-press button **1** to step through the sequence of parameters in SET UNIT as follows:
 - without Canada export^{NV}
 - Change speedometer unit between KM/H and MPH<
 - without Canada export^{NV}
 - Change distance recorder unit between KM and MI<
 - Change fuel consumption display between L/100, MPG and KM/L
 - Change temperature display unit between °C and °F
 - Change clock display between 24H and 12H
 - Change date format between DMY and MDY

52 OPERATION



- Repeatedly short-press button **2** until the unit you want **3** is selected.
 - If you want to exit setup, repeatedly press button **1** until SET UNIT EXIT is displayed.
 - Long-press button **2** to exit SET UNIT.
- » SETUP RESET is displayed.



- If you want to restore the factory defaults, repeatedly short-press button **1** until SET UNIT RESET is displayed.
 - Long-press button **2** until RE-SET **3** flashes.
- » Units have been reset to the factory setting.

» SET UNIT EXIT is displayed.

- Long-press button **2** to exit SET UNIT.

» SETUP RESET is displayed.

Resetting SETUP

- Switch on the ignition.
- Select SETUP (▶▶ 49).



- Repeatedly short-press button **1** until SETUP RESET is displayed.
- Press and hold down button **2** until RESET **3** flashes.

 Date and time can also be reset to a default value by using the SETUP RESET function.


» SETUP EXIT is displayed.

- Exit SETUP (▶▶ 52).

Exiting SETUP

Requirement

There are four ways of exiting SETUP.



- Press and hold button **1**.
 - » **SETUP ENTER** is displayed.
 - » Settings were saved.
- Alternatively: Repeatedly short-press button **1** until **SETUP EXIT** is displayed.
- Long-press button **2**.
 - » **SETUP ENTER** is displayed.
 - » Settings were saved.
- Alternatively: Switch the ignition off and then on again.
 - » **SETUP** exited and settings not saved.
- Alternatively, ride away.



Speed for operation in
SETUP mode

max 10 km/h

- » If permissible maximum speed for operation is exceeded, **SETUP** is exited and the settings are not saved.
- » **KM** is displayed.

ANTI-THEFT ALARM (DWA)

—with anti-theft alarm (DWA) ^{OE}

Activating DWA

- Switch on the ignition (➡ 38).
- Adjust the DWA settings (➡ 54).
- Switch off the ignition.
 - » If the alarm system (DWA) is activated, the DWA will be armed automatically when you switch off the ignition.
- » Activation takes approximately 30 seconds to complete.
- Turn indicators flash twice.
- » Anti-theft alarm (DWA) is active.

Alarm signal

A DWA alarm can be triggered by:

- motion sensor
- an attempt to use an unauthorised vehicle key to switch on the ignition.
- disconnection of the DWA anti-theft alarm from the motorcycle's battery (DWA internal battery in the anti-theft alarm provides power - alarm tone only, the turn indicators do not flash).

54 OPERATION

All functions are sustained even if the internal battery of the DWA anti-theft alarm system is flat; the only difference is that an alarm cannot be triggered if the system is disconnected from the motorcycle's battery.

The alarm signal continues for approx. 26 seconds. While a DWA alarm is in progress an alarm tone sounds and the turn indicators flash. The type of alarm tone can be set by an authorised BMW Motorrad dealer.

If a DWA alarm was triggered while the motorcycle was unattended, the rider is notified accordingly by an alarm tone sounding once when the ignition is switched on. The DWA LED then indicates the reason for the DWA alarm for one minute.

Light signals issued by the DWA LED:

- Flashes 1x: Motion sensor 1
- Flashes 2x: Motion sensor 2
- Flashes 3x: Ignition switched on with unauthorised vehicle key
- Flashes 4x: Disconnection of the DWA anti-theft alarm from the motorcycle's battery
- Flashes 5x: Motion sensor 3

Deactivating DWA

- Switch on the ignition (▮▮▮▮ 38).
- » Turn indicators flash once.
- » DWA is switched off.

Adjusting DWA settings

- Switch on the ignition (▮▮▮▮ 38).
- Select SETUP (▮▮▮▮ 49).



- Repeatedly short-press button 1 until SET DWA is displayed.
 - Short-press button 2 to change the set value.
- The following settings are available:
- DWA ON: The DWA anti-theft alarm is active and will be armed automatically when the ignition is switched off.
 - DWA OFF: The DWA anti-theft alarm is deactivated.
 - Long-press button 1 to exit SET DWA.
 - » SETUP ENTER is displayed.

TRACTION CONTROL (ASC/DTC)

Switch off the ASC/DTC function

- Switch on the ignition (III 38).

 You have the option of deactivating the ASC/DTC function while the motorcycle is on the move.



- Press and hold down button **1** until ASC/DTC indicator and warning light **2** changes its status.



starts to show.

» The ASC/DTC function is switched off.

Switch on the ASC/DTC function



- Press and hold down button **1** until ASC/DTC indicator and warning light **2** changes its status.



goes out; if self-diagnosis has not completed it starts flashing.

- » The ASC/DTC function is switched on.
- You also have the option of switching the ignition off and then on again.



If the ASC/DTC indicator and warning light remains on even though the vehicle has accelerated past the minimum speed stated below after the ignition was switched off and then on again, an ASC/DTC fault has occurred.

min 5 km/h

- For more information on ASC/DTC traction control, see the

56 OPERATION

section entitled "Engineering details" (102).

RIDING MODE

Using riding modes

BMW Motorrad has developed operational scenarios for your motorcycle from which you can select the scenario suitable for your situation:

Standard

- RAIN: Riding on a rain-wet road surface.
 - ROAD: Riding on a dry road surface.
 - with riding modes Pro^{OE}
- With riding modes Pro additionally**
- DYNA: Dynamic riding on a dry road surface.

The respective optimum interplay of engine characteristic, ABS control and ASC/DTC control is provided for each of these scenarios.

For more information on the riding modes, see the section entitled "Engineering details" (103).

Selecting riding mode

- Switch on the ignition (38).



- Press button **1**.
 - » The current riding mode **2** is displayed.



- Repeatedly press button **1** until the riding mode you want **2** is displayed.
 - » With the motorcycle at a standstill, the selected mode is activated after approximately two seconds.
 - » The following conditions must be satisfied for activation of a new riding mode while riding:
 - Throttle grip is in idle position.
 - Brake is not applied.

- with cruise control^{OE}
- » additionally on vehicles with adaptive cruise control:
- Adaptive cruise control is deactivated.◀
- » The riding mode selected in this way is retained, with the engine-characteristic and, ABS control and ASC/DTC control adaptation settings, even after the ignition has been switched off.

ADAPTIVE CRUISE CONTROL

- with cruise control^{OE}

Switching on adaptive cruise control



- Slide switch **1** to the right.
- » Button **2** is enabled for operation.

Setting road speed



- Briefly push button **1** forward.



Adjustment range for adaptive cruise control (gear-dependent)


20...210 km/h



Symbol for adaptive cruise control is displayed.

- » The motorcycle maintains your current cruising speed and the setting is saved.

Accelerating




- Briefly push button **1** forward.
- » Speed is increased by approx. 1 km/h each time you push the button.

58 OPERATION

- Push button **1** forward and hold it in this position.
 - » The motorcycle accelerates smoothly.
 - » The current speed is maintained and saved if button **1** is not pushed again.

Decelerating



- Briefly push button **1** back.
 - » Speed is reduced by 1 km/h each time you push the button.
- Push button **1** back and hold it in this position.
 - » The motorcycle decelerates smoothly.
 - » The current speed is maintained and saved if button **1** is not pushed again.

Deactivating adaptive cruise control

- Brake, pull the clutch lever or turn the throttle grip (close the throttle by turning the grip back past the idle position) to deactivate adaptive cruise control.

 For safety reasons, adaptive cruise control is automatically deactivated whenever ASC/DTC intervention occurs.

- » Symbol for adaptive cruise control disappears.

Resuming former cruising speed




- Briefly push button **1** back to return to the speed saved beforehand.

 Opening the throttle does not deactivate cruise control. When the twistgrip is released the motorcycle decelerates only to the speed saved in memory, even if the rider intended slowing to a lower speed.



Symbol for adaptive cruise control is displayed.

Switching off adaptive cruise control



- Slide switch **1** to the left.
» The system is deactivated.
» Button **2** is disabled.

HEATED HANDLEBAR GRIPS

—with heated grips^{OE}

Operating heated handlebar grips

 The heating in the heated handlebar grips can be activated only when the engine is running.

 The increase in power consumption caused by having the heated handlebar grips switched on can drain the battery if you are riding at low engine speeds. If the charge level is low, the heated handlebar grips are switched off to ensure the battery's starting capability.

- Start the engine ( 83).



- Repeatedly press button **1** until desired heating stage **2** is displayed.

The following settings are available:



Heating off



Low heating power



High heating power


- » High heating power is for heating the grips quickly: it is advisable to switch back to a lower heating power as soon as the grips are warm.
- » If you allow a certain length of time to pass without making further changes, the selected heating stage is saved and the grip-heating symbol disappears.

60 OPERATION

FRONT AND REAR SEATS


Removing rider's seat

- Remove the passenger seat (➡ 60).




- Pull lock **1** up.
- Pull rider's seat **2** to the rear and remove.

Installing rider's seat




- Insert rider's seat **1** into lugs **2**.
- Push down on rider's seat **1**, applying pressure to the rear of the seat.
 - » The rider's seat engages with an audible click.
- Install the passenger seat (➡ 60).

Removing passenger seat



- Remove screw **1** with motorcycle seat key **2**.
- Pull grab strap **3** toward the rider's seat and work passenger seat **4** to the rear to remove.

Installing passenger seat



- Insert passenger seat **2** into the rear frame, making sure that lug **5** of the passenger seat is seated in the rear frame.
- Tighten screw **3** until hand-tight with motorcycle seat key **4**.
- Pull grab strap **1** over the passenger seat.

ADJUSTMENT

05

MIRRORS	64
HEADLIGHT	65
CLUTCH	66
BRAKES	67
SPRING PRELOAD	68
DAMPING	70
FOOTREST SYSTEM	72

64 ADJUSTMENT

MIRRORS

Adjusting mirrors



- Turn the mirror to the correct position.

—with Option 719 milled parts package Classic II^{OE}

or

—with Option 719 milled parts package Shadow II^{OE}



DANGER

Functional restriction due to incorrect installation position

Risk of crash and accident

- Do not change the installation position of the mirror.

- Turn the mirror head to the desired position.◁

Adjusting mirror arm



- Push the protective cap up to expose the threaded fastener on the mirror arm.
- Use the tool from the on-board toolkit to slacken nut **1**.
- Turn the mirror arm to the appropriate position.
- Tighten nut **1**, while holding the mirror arm to ensure that it does not move out of position.



Mirror (locknut) to adapter

22 Nm (Left-hand thread)

- Push the protective cap over the threaded fastener.

HEADLIGHT

Headlight adjustment for right- or left-hand traffic

This motorcycle has a symmetric-beam low-beam headlight. If the motorcycle is ridden in a country where the opposite rule of the road applies, its symmetric low-beam headlight means that no measures are necessary to prevent the headlight beam from dazzling oncoming traffic.

Headlight beam throw and spring preload

Headlight beam throw is generally kept constant when spring preload is adjusted to suit load.


However, a spring preload adjustment might not suffice if the motorcycle is very heavily loaded. Under these circumstances, headlight beam throw has to be adjusted to suit the weight carried by the motorcycle.

 If there are doubts about the correct headlight beam throw, have the setting checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Adjusting headlight beam throw

Requirement

Even with spring preload correctly adjusted, oncoming traffic is dazzled if the motorcycle is heavily loaded.



- Loosen screws **1**.
- Swivel the headlight to adjust beam throw.
- Tighten screws **1** while holding the headlight so that it cannot move out of position.



Headlight to bracket

19 Nm

When the motorcycle is again ridden with a lower load:

- Have the basic settings of the headlight restored by a specialist workshop, preferably an authorised BMW Motorrad retailer.

66 ADJUSTMENT

CLUTCH

Adjusting clutch lever



WARNING

Relocated clutch-fluid reservoir

Air in the clutch system

- Do not turn the handlebars or the handlebar fitting on the handlebar.



WARNING

Adjusting the clutch lever while riding

Risk of accident

- Adjust the clutch lever only when the motorcycle is at a standstill.

» Adjustment options:


– From position 1: narrowest span between handlebar grip and clutch lever

– To position 5: widest span between handlebar grip and clutch lever

– with Option 719 milled parts package Classic II^{OE}

or

– with Option 719 milled parts package Shadow II^{OE}




- Turn adjustment lever **1** to the desired position.

» Adjustment options:

– From position **A**: narrowest span between handlebar grip and clutch lever.

– In 5 steps toward position **B** to increase the span between handlebar grip and clutch lever.◀



- Applying light pressure from behind, turn adjusting screw **1** to the desired position.



The adjusting screw can be turned more easily if the clutch lever is pushed forward.

BRAKES

Adjusting handbrake lever



WARNING

Relocated brake fluid tank

Air in the brake system

- Do not turn the handlebars or the handlebar fitting on the handlebar.




WARNING

Adjusting the handbrake lever while riding

Risk of accident

- Do not attempt to adjust the handbrake lever unless the motorcycle is at a standstill.



- Applying light pressure from behind, turn adjusting screw **1** to the desired position.


 The adjusting screw is easier to turn when the handbrake lever is pushed forward.

» Adjustment options:

- From position **1**: narrowest span between handlebar grip and handbrake lever
- To position **5**: widest span between handlebar grip and handbrake lever

– with Option 719 milled parts package Classic II^{OE} or

– with Option 719 milled parts package Shadow II^{OE}



- Turn adjustment lever **1** to the desired position.

» Adjustment options:

- From position **A**: narrowest span between handlebar grip and handbrake lever.
- In 5 steps toward position **B** to increase the span between handlebar grip and handbrake lever.◀

68 ADJUSTMENT


SPRING PRELOAD

Setting on the front wheel

Front spring preload has to be adjusted to suit the rider's weight. Increase spring preload for heavier loads, decrease spring preload for lighter loads.

Adjusting spring preload for front wheel

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Make sure there is no load on the motorcycle; remove all items of luggage, if carried.



- Hold the motorcycle upright and measure distance **D** from bottom edge **1** of the slider tube to point **2**.
- Apply the rider's weight to the motorcycle.
- With the assistance of a second person, measure the distance **D** between the points **1** and **2** again and calculate the difference


(compression) between the measured values.



Load-dependent adjustment of spring preload

Negative spring displacement of front wheel

6...10 mm (including rider 85 kg)



- Push plastic adapters **1** from the on-board toolkit on to adjusting screws **2**.



WARNING

Spring preload setting and spring-strut damping setting not matched.

Impaired handling.

- Adjust spring-strut damping to suit spring preload.
- To reduce negative spring displacement (increase spring preload), use the tool from the on-board toolkit to turn adjusting screws **2** in direction **A**.


- To increase negative spring displacement (reduce spring preload), use the tool from the on-board toolkit to turn adjusting screws **2** in direction **B**.
- Make sure that the settings are identical on left and right.

Adjustment for rear suspension

It is essential to set spring preload of the rear suspension to suit the load carried by the motorcycle. Increase spring preload when the motorcycle is heavily loaded and reduce spring preload accordingly when the motorcycle is lightly loaded.

Adjusting spring preload for rear wheel

- Make sure the ground is level and firm and place the motorcycle on its stand.



WARNING

Spring preload setting and spring-strut damping setting not matched.

Impaired handling.

- Adjust spring-strut damping to suit spring preload.

- If you want to increase spring preload, turn knob **1** clockwise.
- If you want to reduce spring preload, turn knob **1** counter-clockwise.
- Adjust the damping characteristic to suit spring preload.



See the section on suspension in "Technical data" for a recommendation on how to set up the suspension.

- Adjust the damping for rear wheel (71).

70 ADJUSTMENT


DAMPING

Adjustment

Damping must be adapted to suit the condition of the surface on which the motorcycle is ridden and to suit spring preload.

- An uneven surface requires softer damping than a smooth surface.
- An increase in spring preload requires firmer damping, a reduction in spring preload requires softer damping.

Adjusting compression-stage damping for front wheel



- Adjust compression-stage damping by turning adjusting screw **1** on the left fork leg.



- To increase damping: Use the tool from the on-board toolkit to turn the adjusting screw so that mark **1** points to a higher value on the scale.
- To reduce damping: Use the tool from the on-board toolkit to turn the adjusting screw so that mark **1** points to a lower value on the scale.



Compression stage, basic setting, front

Position 1 (comfortable setting with rider 85 kg)

Position 3 (normal setting with rider 85 kg)

Position 7 (sports setting with rider 85 kg)

Adjusting rebound-stage damping for front wheel



- Adjust rebound-stage damping by turning adjusting screw **1** on the right fork leg.



- To increase damping: Use the tool from the on-board toolkit to turn the adjusting screw so that mark **1** points to a higher value on the scale.
- To reduce damping: Use the tool from the on-board toolkit to turn the adjusting screw so that mark **1** points to a lower value on the scale.



Rebound stage, basic setting, front

Position 1 (comfortable setting with rider 85 kg)

Position 3 (normal setting with rider 85 kg)

Position 7 (sports setting with rider 85 kg)

Factory default settings, front wheel

- Reset the factory defaults as stated below.



Factory default settings for compression/rebound stages, front

Position 3

Adjusting damping for rear wheel

- Make sure the ground is level and firm and place the motorcycle on its stand.

72 ADJUSTMENT



CAUTION

Adjusting the spring-strut damping when the silencer is hot

Risk of burn injury

- Allow the silencer to cool.




CAUTION

Working with hot components

Risk of burn injury

- Wear protective gloves.

- Adjust the damping characteristic, using the tool from the on-board toolkit to turn adjusting screw **1**.



- Turn the adjusting screw **1** clockwise to harden the damping action.
- Turn the adjusting screw **1** anticlockwise to soften the damping action.



See the section on suspension in "Technical data" for a recommendation on how to set up the suspension.

FOOTREST SYSTEM

- with Option 719 milled parts package Classic II^{OE}
- or
- with Option 719 milled parts package Shadow II^{OE}

Adjusting rotor




WARNING

Steep bank angles can lead to hard components striking the roadway during cornering.

Risk of falling


- Do not use footrests as an indicator of critical bank angles.

- Setting of the rotor is the same on the right and left.
- The position of the rotor must be set identically on the right and left.



- You can adjust foot clearance and set the footrest for a higher foot position by turning rotor **2**.
- Slacken screw **1** until rotor **2** can be pulled out.
- Rotor **2** is adjustable to any of 12 positions. To set the footrest to the highest position, turn rotor **2** through

180° clockwise or counter-clockwise.



- Install rotor **1** in the desired position and tighten screw **2**.



Rotor to base plate

20 Nm



WARNING

Incorrectly adjusted footrest as a result of movement of the rotor.

Risk of falling


- The footrest setting must be adjusted accordingly if the rotor has moved.

- The footrest may only fold upwards and slightly towards the rear.


Adjusting footrest hinge

- Setting of the footrest joint is the same on the right and left.


74 ADJUSTMENT



- Remove screw **1** and pin **2**.
- Fold footrest body **3** in the direction indicated by the arrow.
- » The spring is relieved.
- Disengage spring **4** from footrest joint **5**.



- Remove screw **1**.
- Pull footrest joint **2** off rotor **3**.
- Change the position of footrest joint **2** by turning counter-clockwise or clockwise.




- When fitted, footrest joint **1** **must** be seated on rotor **2** in a position in which the opening **arrow** is pointing either upward or up and slightly to the rear.
- Install screw **3**.
- Remove and refit the footrest hinge on the shifting unit side in the same way.




Positioning joint to rotor

20 Nm



- Hook spring **1** into the eye of footrest joint **3**.
- Fold footrest body **2** up in footrest joint **3**.




- Install pin **1** with head flattened on one side **2** flush in the footrest joint and footrest body **3**.
- Install screw **4**.
- Remove and refit the footrest body on the shifting unit side in the same way.




Footrest body to positioning joint

3 Nm

Adjusting footbrake lever peg



- Foot clearance and height relative to peg **1** can be adjusted by turning to different positions.
- Remove screw **2**.



- Clean the threads.
- Turn peg **1** to the desired position.
- Install **new** screw **2**.




Foot piece on footbrake lever

Thread-locking compound: micro-encapsulated


10 Nm

Adjusting gearshift lever peg



- Foot clearance and height relative to peg **1** can be adjusted by turning to different positions.
- Remove screw **2**.

76 ADJUSTMENT



- Clean the threads.
- Turn peg **1** to the desired position.
- Install **new** screw **2**.



Foot piece on gearshift
lever

Thread-locking compound:
micro-encapsulated

10 Nm

RIDING

06

SAFETY INSTRUCTIONS	80
REGULAR CHECK	82
STARTING	83
RUNNING IN	86
BRAKES	87
PARKING YOUR MOTORCYCLE	90
REFUELLING	91
SECURING MOTORCYCLE FOR TRANSPORTATION	93

SAFETY INSTRUCTIONS

Rider's equipment

Do not ride without the correct clothing! Always wear

- Helmet
- Suit
- Gloves
- Boots

This applies even to short journeys, and to every season of the year. Your authorised BMW Motorrad retailer will be happy to advise you on the correct clothing for every purpose.



WARNING

Loose textiles, items of luggage or straps snagged by open rotating parts of the vehicle (wheels, drive shaft)

Risk of accident

- Make sure that loosely worn or carried textiles cannot be snagged by openly rotating parts of the vehicle.
- Keep all items of luggage and straps well clear of openly rotating parts of the vehicle.

Load correctly



WARNING

Handling adversely affected by overloading and imbalanced loads

Risk of falling

- Do not exceed the permissible gross weight and be sure to comply with the instructions on loading.

- Set spring preload, damping characteristic and tyre pressures to suit total weight.
- Pack heavy items at the bottom and toward the inboard side.

–with tank bag^{OA}

- Note the maximum permissible payload of the tank rucksack.



Payload of tank rucksack

≤5 kg<

–with rear softbag^{OA}

- Note the maximum payload of the rear softbag.



Payload of rear softbag

max 10 kg<

Speed

If you ride at high speed, always bear in mind that various boundary conditions can adversely affect the handling of your motorcycle, e.g.:

- Spring-strut and shock-absorber system not set up correctly
- Imbalanced load
- Loose clothing
- Insufficient tyre pressure
- Poor tyre tread
- On-board luggage systems such as a tank bag or rear softbag.

Risk of poisoning

Exhaust fumes contain carbon monoxide, which is colourless and odourless but highly toxic.



WARNING

Exhaust gases adversely affecting health

Risk of asphyxiation

- Do not inhale exhaust fumes.
- Do not run the engine in an enclosed space.



WARNING

Inhalation of harmful vapours

Health hazard

- Do not inhale vapours from operating fluid and plastics.
- Use the vehicle only outdoors.

Risk of burn injury



CAUTION

Engine and exhaust system become very hot when the vehicle is in use

Risk of burn injury

- When you park the vehicle make sure that no-one and no objects can come into contact with the hot engine and exhaust system.

Catalytic converter

If misfiring causes unburned fuel to enter the catalytic converter, there is a danger of overheating and damage.

The following guidelines must be observed:

- Do not run the fuel tank dry.
- Do not attempt to start or run the engine with a spark-plug cap disconnected.
- Stop the engine immediately if it misfires.

82 RIDING

- Use only unleaded fuel.
- Comply with all specified maintenance intervals.



ATTENTION

Unburned fuel in catalytic converter

Damage to catalytic converter

- Note the points listed for protection of the catalytic converter.

Risk of overheating



ATTENTION

Engine running for prolonged period with vehicle at standstill

Overheating due to insufficient cooling; in extreme cases vehicle fire

- Do not allow the engine to idle unnecessarily.
- Ride away immediately after starting the engine.

Tampering



ATTENTION

Tampering with the motorcycle (e.g. engine management ECU, throttle valves, clutch)

Damage to the affected parts, failure of safety-relevant functions, voiding of warranty

- Do not tamper with the vehicle in any way that could result in tuned performance.

REGULAR CHECK

Checklist

- At regular intervals, use the checklist below to check your motorcycle.

Always before riding off

- Checking function of brakes (114).
- Check operation of the lights and signalling equipment.
- Checking clutch function (119).
- Checking tyre tread depth (120).
- Checking tyre pressure (119).
- Check security of luggage systems and luggage.

Every 3rd refuelling stop

- Check the engine oil level (112).
- Check the brake pad thickness, front brakes (114).
- Check the brake pad thickness, rear brakes (115).
- Check the brake-fluid level, front brakes (117).
- Check the brake-fluid level, rear brakes (118).

STARTING

Starting engine

- Switch on the ignition (38).
 - » Pre-Ride-Check is performed. (83)
 - » ABS self-diagnosis is in progress. (84)
- Select neutral or, if a gear is engaged, pull the clutch lever.

 You cannot start the motorcycle with the side stand extended and a gear engaged. The engine will switch itself off if you start it with the gearbox in neutral and then engage a gear before retracting the side stand.

- Cold starts and low temperatures:
 - » Pull the clutch lever.



- Press the starter button **1**.

 The start attempt is automatically interrupted if battery voltage is too low. Re-charge the battery before you start the engine, or use jump leads and a donor battery to start.

See the subsection on jump starting in "Maintenance" for more details.


- » The engine starts.
- » Consult the troubleshooting chart below if the engine refuses to start. (158)

Pre-Ride-Check

When the ignition is switched on, the instrument cluster carries out a test of the instruments, the warning and indicator lights and the display, the "Pre-Ride-Check". The check is aborted if you start the engine before it completes.

84 RIDING

Phase 1



All the segments in displays **1** light up.
At the same time, all the indicator and warning lights **3** are switched on.

Phase 2

'General' warning light **2** changes from ON to flashing.
The needle **4** for the speed indicator moves to maximum speed.

Rev. counter needle **5** swings to the maximum rpm position.

Phase 3

Speedometer needle **4** moves to the zero position.

Rev. counter needle **5** moves to the zero position.
The indicator and warning lights go out or assume operational status, as applicable.

The malfunction indicator lamp (MIL) does not go out until 15 seconds have elapsed.

The display switches to its ordinary display mode. The on-board computer readings appear on the display.

If the needles did not move, an indicator or warning light did not show or segments in the display failed to light up:

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

ABS self-diagnosis

BMW Motorrad ABS performs self-diagnosis to ensure its operability. Self-diagnosis starts automatically when you switch on the ignition.

Phase 1

- » Test of the diagnosis-compatible system components with the vehicle at a standstill.



flashes.

Phase 2

- » Test of the wheel-speed sensors as the vehicle pulls away from rest.



flashes.

ABS self-diagnosis completed

» The ABS indicator and warning light goes out.



ABS self-diagnosis not completed

The ABS function is not available, because self-diagnosis did not complete. (The motorcycle has to reach a defined minimum speed for the wheel speed sensors to be checked: 5 km/h)

If an indicator showing an ABS fault appears when ABS self-diagnosis completes:

- You can continue to ride. Bear in mind that the ABS function is not available.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

ASC self-diagnosis

BMW Motorrad ASC performs self-diagnosis to ensure its operability. Self-diagnosis is performed automatically when you switch on the ignition.

Phase 1

» Test of the diagnosable system components with the vehicle at a standstill.



flashes.

Phase 2

» Test of the diagnosis-compatible system components while the motorcycle is on the move.



flashes.

ASC self-diagnosis completed

» The ASC telltale and warning light goes out.

- Check all the indicator and warning lights.



ASC self-diagnosis not completed

The ASC function is not available, because self-diagnosis did not complete. (The motorcycle has to reach a defined minimum speed for the wheel sensors to be checked: min 5 km/h)

If an indicator showing an ASC fault appears when ASC self-diagnosis completes:

- You can continue to ride. Bear in mind that the ASC function is not available.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

86 RIDING

DTC self-diagnosis

—with riding modes Pro^{OE}

BMW Motorrad DTC performs self-diagnosis to ensure its operability. Self-diagnosis is performed automatically when you switch on the ignition.

Phase 1

» Test of the diagnosis-compatible system components with the vehicle at a standstill.



DTC indicator and warning light slow-flashes.

Phase 2

» Pullaway test of the diagnosis-compatible system components.



DTC indicator and warning light slow-flashes.

DTC self-diagnosis completed

» The DTC symbol no longer shows.

- Observe all the indicator and warning lights.



DTC self-diagnosis not completed

The DTC function is not available, because self-diagnosis did not complete. (The motorcycle has to reach a defined minimum speed with the engine running for the wheel-speed sensors to be checked: min 5 km/h)

If an indicator showing a DTC fault appears when DTC self-diagnosis completes:

- You can continue to ride.
Bear in mind that the DTC function is not available or the functionality might be subject to certain restrictions.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

RUNNING IN

Engine

- Until the first running-in check, vary the throttle opening and engine-speed range frequently; avoid riding at constant engine rpm for prolonged periods.
- Try to do most of your riding during this initial period on twisting, fairly hilly roads.

- Comply with the rpm limits for running in.



Running-in speed

<5000 min⁻¹ (Odometer reading 0...1000 km)

- Note the mileage after which the running-in check should be carried out.



Mileage until the first running-in check

500...1200 km

Brake pads

New brake pads have to be run in before they can achieve their optimum frictional force. You can compensate for this initial reduction in braking efficiency by exerting greater pressure on the levers.



WARNING

New brake pads

Longer stopping distance, risk of accident

- Apply the brakes in good time.

Tyres

New tyres have a smooth surface. This must be roughened by riding in a restrained manner at various heel angles until the tyres are run in. This running in procedure is essential if the tyres are to achieve maximum grip.



WARNING

New tyres losing grip on wet roads and at extreme bank angles

Risk of accident

- Ride carefully and avoid extremely sharp inclines.

BRAKES

How can stopping distance be minimised?

Each time the brakes are applied, a load distribution shift takes place with the load shifting forward from the rear to the front wheel. The sharper the motorcycle decelerates, the more load is shifted to the front wheel. The higher the wheel load, the more braking force can be transmitted without the wheel locking. To optimise stopping distance, apply the front brakes rapidly and keep on increasing the

88 RIDING

force you apply to the brake lever. This makes the best possible use of the dynamic increase in load at the front wheel. Remember to pull the clutch at the same time. In the extreme sudden-stop braking situations that are trained so frequently, braking force is applied as rapidly as possible and with the rider's full force applied to the brake levers; under these circumstances the dynamic shift in load distribution cannot keep pace with the increase in deceleration and the tyres cannot transmit the full braking force to the surface of the road.

BMW Motorrad ABS prevents the front wheel from locking up.



WARNING

Rear wheel lift due to severe braking

Risk of falling

- When you brake sharply, bear in mind that ABS control cannot always be relied on to prevent the rear wheel from lifting clear of the ground.

Emergency braking

If you brake sharply from a speed in excess of 50 km/h, the brake light flashes rapidly as a warning for road users behind you.

If you brake until your speed is less than 15 km/h, the hazard warning lights start to flash as well. The hazard warning lights switch off automatically as soon as you start to accelerate and vehicle speed reaches 20 km/h.

Descending mountain passes



WARNING

Braking mostly with the rear brake on mountain descents

Brake fade, destruction of the brakes due to overheating

- Use both front and rear brakes, and make use of the engine's braking effect as well.

Wet and dirty brakes

Wetness and dirt on the brake discs and the brake pads diminish braking efficiency. Delayed braking action or poor braking efficiency must be reckoned with in the following situations:

- Riding in the rain or through puddles of water.
- After the vehicle has been washed.
- Riding on salted or gritted roads.
- After work has been carried on the brakes, due to traces of oil or grease.
- Riding on dirt-covered surfaces or off-road.



WARNING

Wetness and dirt result in diminished braking efficiency

Risk of accident

- Apply the brakes lightly while riding to remove wetness and dirt, or dismount and clean the brakes.
- Think ahead and brake in good time until full braking efficiency is restored.

ABS Pro

Physical limits applicable to motorcycling



WARNING

Braking when cornering

Risk of crash despite ABS Pro

- Invariably, it remains the rider's responsibility to adapt riding style to riding conditions.
- Do not take risks that would negate the additional safety offered by this system.

Possibility of a fall not precluded

Although ABS Pro and Dynamic Brake Control provide the rider with valuable assistance and constitutes a huge advance in safety for braking with the motorcycle banked for cornering, it cannot under any circumstances be considered as redefining the physical limits that apply to motorcycling. It is still possible for these limits to be overshoot due to misjudgement or rider error. In extreme cases this can result in a crash.

Use on public roads

ABS Pro and Dynamic Brake Control help make the motorcycle even safer for riding on public roads. When the brakes are applied because of an unforeseen hazard when the motorcycle is banked for cornering, within the physical limits that apply to motorcycling the ABS Pro system prevents the wheels from locking and skidding away. In panic braking, Dynamic Brake Control increases the braking effect and intervenes if the throttle grip is accidentally turned during braking.

 ABS Pro was not developed to enhance individual braking performance with the motorcycle banked into corners.

PARKING YOUR MOTORCYCLE

Side stand

- Switch off the engine.



ATTENTION

Poor ground underneath the stand

Risk of damage to parts if vehicle topples

- Always check that the ground under the stand is level and firm.



ATTENTION

Additional weight placing strain on the side stand

Risk of damage to parts if vehicle topples

- Do not sit or lean on the vehicle while it is propped on the side stand.
- Extend the side stand and prop the motorcycle on the stand.
- If the camber of the roadway permits, turn the handlebars all the way to the left.
- On a gradient, the motorcycle should always face uphill; select 1st gear.

REFUELLING

Fuel grade

Requirement

For optimum fuel consumption, fuel should be sulphur-free or as low-sulphur as possible.



ATTENTION

Engine operation with leaded fuel

Damage to catalytic converter

- Do not attempt to run the vehicle on leaded fuel or fuel with metallic additives (e.g. manganese or iron).

- Fuels with a maximum ethanol content of 15%, that is E15, can be used.



Fuel additives clean the fuel injection system and the combustion zone. It is advisable to use fuel additives when the engine is operated with low-grade fuel or if the vehicle is to be out of use for a lengthy period of time. More information is available from your authorised BMW Motorrad retailer.



Recommended fuel grade



Premium unleaded (maximum 15% ethanol, E15)
95 ROZ/RON
90 AKI



Alternative fuel grade



Regular unleaded (maximum 15% ethanol, E15)
91 ROZ/RON
87 AKI



» Pay attention to the following symbols in the fuel filler cap and on the fuel pump:



Refuelling



WARNING

Fuel is highly flammable

Risk of fire and explosion

- Do not smoke. Never bring a naked flame near the fuel tank.

ATTENTION

Component damage

Component damage caused by overfilled fuel tank

- Overfilling the fuel tank will cause excess fuel to penetrate the carbon canister and cause component damage.
- Fill the fuel tank up to the lower edge of the filler neck only.

ATTENTION


Wetting of plastic surfaces by fuel

Damage to the surfaces (surfaces become unsightly or dull)

- Clean plastic surfaces immediately after contact with fuel.
- Make sure the ground is level and firm and place the motorcycle on its stand.



- Open the protective cap **2**.
- Use the ignition key to unlock filler cap of fuel tank **1** by turning it clockwise, and flip the cap open.



- Refuel with fuel of the grade stated below; do not fill the tank past the bottom edge of the filler neck.

 When refuelling after running on reserve, make sure that you top up the tank to a level above reserve, so that the new level is detected and the fuel reserve indicator light is switched off.

 The "usable fuel capacity" specified in the technical data is the quantity that the fuel tank could hold if refilled after it had been run dry and the engine had cut out due to a lack of fuel.



Usable fuel capacity

approx. 18 l



Reserve fuel

approx. 3.5 l

- Press the fuel filler cap down firmly to close.
- Remove the key and close the protective cap.

SECURING MOTORCYCLE FOR TRANSPORTATION

- Make sure that all components that might come into contact with straps used to secure the motorcycle are adequately protected against scratching. Use adhesive tape or soft cloths, for example, for this purpose.



ATTENTION


Vehicle topples to side when being lifted on to stand

Risk of damage to parts if vehicle topples

- Secure the vehicle to prevent it toppling, preferably with the assistance of a second person.

- Push the motorcycle onto the transportation flat and hold it in position: do not place it on the side stand.

94 RIDING



» The vehicle's springs are compressed.




ATTENTION

Trapping of components

Component damage

- Do not trap components such as brake lines or cable legs.
- At the front, secure the tensioning straps to the bottom fork bridge on both sides.



- At the rear, secure the tensioning straps to the brackets of the rear footrest on both sides and tension them.
- Uniformly tighten all the straps.

ENGINEERING DETAILS

07

GENERAL INSTRUCTIONS	98
ANTILOCK BRAKE SYSTEM (ABS)	98
DYNAMIC BRAKE CONTROL	101
TRACTION CONTROL (ASC/DTC)	102
RIDING MODE	103
DYNAMIC ENGINE BRAKE CONTROL	105
ADAPTIVE HEADLIGHT	106

GENERAL INSTRUCTIONS

To find out more about engineering go to:

bmw-motorrad.com/technology

ANTILOCK BRAKE SYSTEM (ABS)

How does ABS work?

The amount of braking force that can be transferred to the road depends on factors that include the coefficient of friction of the road surface. Loose stones, ice and snow or a wet road all have much lower coefficients of friction than a clean and dry asphalt surface. The lower the coefficient of friction, the longer the stopping distance.

If the rider increases the brake pressure to the extent that the brake force exceeds the maximum transferable limit, the wheels start to lock and the vehicle loses its directional stability; a fall is imminent. Before this situation can occur, ABS intervenes and adapts braking pressure to the maximum transferable braking force. The wheels continue to turn and the driving stability is retained irrespective of the road condition.

What are the effects of surface irregularities?

Surface irregularities can cause the wheels to lose contact temporarily with the road surface.

If this happens the braking force that can be transmitted to the road can drop to zero. If the brakes are applied under these circumstances the ABS has to reduce braking force to ensure that directional stability is maintained when the wheels regain contact with the road surface. At this instant the ABS must assume an extremely low coefficient of friction, so that the wheels will continue to rotate under all imaginable circumstances, because this is the precondition for ensuring directional stability. As soon as it registers the actual circumstances, the system reacts instantly and adjusts braking force accordingly to achieve optimum braking.

Rear wheel lift

Under very severe and sudden deceleration, however, it is possible that the BMW Motorrad ABS will be unable to prevent the rear wheel from lifting clear of the ground. If this happens the outcome can be a highsidings situation in

which the motorcycle can flip over.



WARNING

Rear wheel lift due to severe braking

Risk of falling

- When you brake sharply, bear in mind that ABS control cannot always be relied on to prevent the rear wheel from lifting clear of the ground.

What is the design baseline for BMW Motorrad ABS?

Within the limits imposed by physics, the BMW Motorrad ABS ensures directional stability on any surface.

At speeds above 4 km/h, within the limits imposed by physics the BMW Motorrad ABS can ensure directional stability on any surface. Limitations inherent to the design principle mean that at lower speeds the BMW Motorrad ABS cannot provide optimum assistance on all surfaces.

The system is not optimised for special requirements that apply under extreme competitive situations off-road or on the track.

Special situations

The speeds of the front and rear wheels are compared as one means of detecting a wheel's incipient tendency to lock. If the system registers implausible values for a lengthy period the ABS function is deactivated for safety reasons and an ABS fault message is issued. Self-diagnosis has to complete before fault messages can be issued. In addition to problems with the BMW Motorrad ABS, exceptional riding conditions can also cause a fault message to be issued:

- Riding for a lengthy period with the front wheel lifted off the ground (wheelie).
- Rear wheel rotating with the vehicle held stationary by applying the front brake (burn-out).
- Heating up with the motorcycle on the centre stand or an auxiliary stand, engine idling or with a gear engaged.

100 ENGINEERING DETAILS

–Rear wheel locked for a lengthy period, for example while descending off-road.

If a fault message is issued on account of exceptional riding conditions, you can reactivate the ABS function by switching the ignition off and on again.

How important is regular maintenance?



WARNING

Brake system not regularly serviced

Risk of accident

- In order to ensure that the BMW Motorrad ABS is always maintained in optimum condition, it is essential for you to comply strictly with the specified inspection intervals.

Safety reserves

The potentially shorter braking distances which BMW Motorrad ABS permits must not be used as an excuse for careless riding. ABS is primarily a means of ensuring a safety margin in genuine emergencies.



WARNING

Braking when cornering

Risk of accident despite ABS

- Invariably, the rider bears responsibility for assessing road and traffic conditions and adopting his or her style of riding accordingly.
- Do not take risks that would negate the additional margin of safety offered by this system.

ABS Pro

ABS Pro increases safety, particularly when braking in bends. ABS Pro prevents the wheels from locking even under sharp braking. ABS Pro reduces abrupt changes in steering force, particularly in shock-braking situations, counteracting the vehicle's otherwise natural but undesirable tendency to straighten up.

ABS intervention

Technically speaking, depending on the riding situation ABS Pro adapts ABS intervention to the motorcycle's bank angle. Signals for rate of roll and rate of yaw and lateral acceleration are used

to calculate bank angle. They come from the angular rate sensor, an integral component of Dynamic Traction Control DTC.

As the motorcycle is heeled over more and more as it banks into a corner, an increasingly strict limit is imposed on the brake-pressure gradient for the start of brake application. This slows the build-up of brake pressure to a corresponding degree. Additionally, pressure modulation is more uniform across the range of ABS intervention.

Advantages for the rider

The advantages of ABS Pro for the rider are sensitive response and high braking and directional stability combined with best-case deceleration of the motorcycle, even when cornering.

DYNAMIC BRAKE CONTROL

—with riding modes Pro^{OE}

How Dynamic Brake Control works

The Dynamic Brake Control function assists the rider in emergency braking situations.

Detection of emergency braking

—Sudden, sharp application of the front brake is interpreted as emergency braking.

Behaviour in emergency braking

—If emergency braking occurs at a speed in excess of 10 km/h, the ABS function is further assisted by Dynamic Brake Control.

Behaviour during accidental actuation of the throttle grip

—If the throttle is accidentally opened (throttle grip position > 5 %) during emergency braking, Dynamic Brake Control ensures the desired braking effect by ignoring actuation of the throttle grip. The effectiveness of emergency braking is ensured.

—If the throttle is closed (throttle grip position < 5 %) while Dynamic Brake Control is in action, the engine torque requested by the ABS brake system is restored.

—If emergency braking ceases and the rider still has not changed the position of the throttle grip, Dynamic Brake Control steadily ramps engine torque

102 ENGINEERING DETAILS

back to the rider's requested level.

TRACTION CONTROL (ASC/DTC)

How does traction control work?

Traction control is available in two versions

- without** provision for the bank angle: Automatic Stability Control ASC
- ASC is a rudimentary function intended to prevent falls.
- with** provision for bank angle: Dynamic Traction Control DTC
- DTC regulation is more delicate and more comfortable thanks to the additional bank angle and acceleration information.

Traction control compares the front and rear wheel circumferential velocities. The differential is used to compute slip as a measure of the reserves of stability available at the rear wheel. If slip exceeds a certain limit, the engine management system intervenes and adapts engine torque accordingly. BMW Motorrad ASC/DTC is designed as an assistant system for the rider and for use on public roads. The extent to

which the rider affects ASC/DTC control can be considerable (weight shifts when cornering, items of luggage loose on the motorcycle), especially when the style of riding takes rider and machine close to the limits imposed by physics. The system is not optimised for special requirements that apply under extreme competitive conditions off-road or on the track. The BMW Motorrad ASC/DTC can be deactivated in these cases.



WARNING

Risky riding

Risk of accident despite ASC/DTC

- Invariably, it remains the rider's responsibility to adapt riding style to riding conditions.
- Do not take risks that would negate the additional safety offered by this system.

Special situations

In accordance with the laws of physics, the ability to accelerate is restricted more and more as the angle of heel increases. Consequently, there can be a perceptible lag in acceleration out of very tight bends

The speeds of the front and rear wheels are compared as one means of detecting the rear wheel's incipient tendency to spin or slip sideways. If the system registers implausible values for a lengthy period the ASC/DTC function is deactivated for safety reasons and an ASC/DTC fault message is issued. Self-diagnosis has to complete before fault messages can be issued. The BMW Motorrad ASC/DTC can issue a fault message under the exceptional riding conditions outlined below:

Exceptional riding conditions:

- Riding for a lengthy period with the front wheel lifted off the ground (Wheelie) with ASC/DTC deactivated.
- Rear wheel rotating with the vehicle held stationary by application of the front brake (burn-out).
- Warming up with the motorcycle on an auxiliary stand, in neutral or with a gear engaged.

The ASC/DTC is reactivated by switching the ignition off and on again and then riding at a minimum speed.



Minimum speed for activation of ASC/DTC

min 5 km/h

–without riding modes Pro^{OE}
When riding on a slippery surface, never snap the throttle twistgrip fully closed without pulling the clutch at the same time. Engine braking torque can cause the rear wheel to lock, with a corresponding loss of stability. The BMW Motorrad ASC is unable to control a situation of this nature.

RIDING MODE

Selection

To adjust the motorcycle to the road condition and the desired driving experience, the following riding modes can be selected:

- RAIN
- ROAD

- with riding modes Pro^{OE}
- DYNA

For each of these riding modes, there is a matching setting for the ABS and ASC/DTC systems and for throttle response.

104 ENGINEERING DETAILS

ASC/DTC can be switched off in each riding mode. The explanations below always refer to the dynamic safety systems that are switched on.

Throttle response

- In RAIN riding mode: Restrained
- In ROAD riding mode: Optimum
- with riding modes Pro^{OE}
- In DYNA riding mode: Direct

ABS

- The rear wheel lift-off detection is activated in all riding modes.
- ABS Pro is fully available in all riding modes. The tendency of the motorcycle to straighten up when the brakes are applied with the machine banked for cornering is reduced to a minimum.
- In RAIN and ROAD riding modes, the ABS is set up for on-road riding.
- with riding modes Pro^{OE}
- In DYNA riding mode, the ABS is set up for on-road riding.

ASC

- ASC is set up for on-road riding.
- ASC provides high driving stability in ROAD riding mode and maximum driving stability in RAIN riding mode.

- with riding modes Pro^{OE}

DTC

Tyres

- In the DTC settings RAIN, ROAD and DYNA, DTC is set up for on-road riding with road tyres.

Driving stability

- In the DTC setting RAIN, DTC intervenes early to maximise riding stability.
- In the DTC setting ROAD, DTC intervenes later than in the RAIN riding mode. This prevents the rear wheel from spinning whenever possible.
- In the DTC settings for RAIN and ROAD, the front wheel is prevented from lifting.
- In the DTC setting DYNA, DTC intervenes later than in the DTC setting ROAD, so slight drift can be induced when exiting corners and brief wheelies are also possible.

Mode changes

The riding mode can be changed while the vehicle is stationary with the ignition on. It is possible to change it while driving under the following conditions:

- No drive torque on the rear wheel.
- No brake pressure in the brake system.

The following steps must be taken to change the riding mode:

- Close the throttle twistgrip.
- Release the brake levers.
- with cruise control^{OE}
- Deactivate adaptive cruise control.

The desired riding mode is initially preselected. The mode change does not take place until the systems in question are all in the appropriate state. The selection menu does not disappear from the display until the mode change has taken place.

DYNAMIC ENGINE BRAKE CONTROL

–with riding modes Pro^{OE}

How does dynamic engine brake control work?

The purpose of dynamic engine brake control is to prevent the unstable riding states that can be produced by excessive engine braking moment acting on the rear wheel. Depending on the road condition and riding dynamic, excessive braking torque can produce a sharp rise in rear-wheel slip and impair directional stability. Dynamic engine brake control limits this slip at the rear wheel to a safe, mode-dependent regulated slip.

Causes for excessive slip at the rear wheel:

- Riding with engine overrun on a surface with a low coefficient of friction (e.g. wet leaves).
- Rear-wheel hop when rider downshifts.
- Sharp braking during sporty riding.

In the same way as BMW Motorrad ASC, dynamic engine brake control compares the wheel circumferential velocities of the front and rear

106 ENGINEERING DETAILS

wheels. Dynamic engine brake control uses this differential to compute slip as a measure of the reserve of stability available at the rear wheel.

If slip overshoots the applicable limit, the throttle valves are opened very slightly to increase engine torque. Slip is reduced and the vehicle is stabilised.

Effect of dynamic engine brake control

- In RAIN and ROAD riding modes: Maximum stability
- In DYNA riding mode:
Compared with the RAIN and ROAD riding modes, reduced intervention

headlight is optimised for bank angles up to 25 °.

The adaptive cornering headlight is activated under the following conditions:

- Bank angle is more than 7 °.
- Speed is higher than 10 km/h.
- The low-beam headlight is switched on.

ADAPTIVE HEADLIGHT

- with adaptive head light^{OE}

Function

In addition to the bulbs for low beam, high beam and daytime riding light, or side light, the headlight has two separate LED elements complete with their own reflectors. The LED elements are activated as a function of bank angle in addition to the low-beam headlight, enabling the headlight to illuminate the inside of the bend as the motorcycle banks for cornering. The adaptive cornering

MAINTENANCE

08

GENERAL NOTES	110
TOOLKIT	111
FRONT-WHEEL STAND	111
REAR-WHEEL STAND	112
ENGINE OIL	112
BRAKE SYSTEM	114
CLUTCH	119
TYRES	119
WHEEL RIMS	120
WHEELS	120
LIGHTING	129
JUMP-STARTING	130
BATTERY	132
FUSES	134
DIAGNOSTIC CONNECTOR	135

GENERAL NOTES

The Maintenance chapter describes straightforward procedures for checking and replacing certain wear parts.

Microencapsulated screws

The microencapsulation is a chemical thread-locker. An adhesive compound creates a secure connection between bolt and nut or between screw and component. Consequently, microencapsulated screws are for once-only use and are not intended for re-installation after being slackened.

After removal of the screw, clean the internal thread to remove all traces of thread-locking compound. Always use new microencapsulated screws when re-assembling. Consequently, prior to disassembly make sure that you have suitable tools for cleaning the threads and a new replacement for each screw to be removed. If the job is not done correctly there is no guarantee that the screw will remain secure, which means that you would be putting yourself at risk!


Further information

Special tightening torques are listed as applicable. The tightening torques for the threaded fasteners on your vehicle are listed in the section entitled "Technical data".

You will find information on more extensive maintenance and repair work in the repair manual on DVD for your vehicle, available from your authorised BMW Motorrad retailer.

Some of the work calls for special tools and a thorough knowledge of the technology involved. If you are in doubt, consult a specialist workshop, preferably your authorised BMW Motorrad retailer.

TOOLKIT



- 1** Open-ended spanner
Width across flats 14/17
–Adjust the mirror arm (➡ 64).
–Adjust the spring pre-load for front wheel (➡ 68).
- 2** Reversible screwdriver blade
With star-head and plain-tip ends
–Adjust the rebound-stage damping for front wheel (➡ 71).
–Adjust the compression-stage damping for front wheel (➡ 70).
–Adjust the damping for rear wheel (➡ 71).
- 3** Screwdriver handle
–Top up the engine oil (➡ 113).
–Use with screwdriver insert
- 4** Torx wrench, T20
- 5** Plastic cap

- 5** –Adjust the spring pre-load for front wheel (➡ 68).

FRONT-WHEEL STAND

Installing front-wheel stand



ATTENTION

Use of the BMW Motorrad front-wheel stand without also using the auxiliary stand

Risk of damage to parts if vehicle topples

- Place the motorcycle on an auxiliary stand before lifting the front wheel with the BMW Motorrad front-wheel stand.

- Make sure the motorcycle is standing firmly.
- Place the motorcycle on an auxiliary stand; BMW Motorrad recommends the BMW Motorrad auxiliary stand.
- Install the rear-wheel stand (➡ 112).

112 MAINTENANCE



- See the instructions issued with the front-wheel stand for the details of the correct procedure for installation.
- BMW Motorrad offers an auxiliary stand suitable for every vehicle. Your BMW Motorrad retailer will be happy to help you with the selection of a suitable auxiliary stand.

REAR-WHEEL STAND

Installing rear-wheel stand



- The description of how to fit the rear-wheel stand correctly will be found in the instructions for the stand.
- BMW Motorrad offers an auxiliary stand suitable for every

vehicle. Your BMW Motorrad retailer will be happy to help you with the selection of a suitable auxiliary stand.

ENGINE OIL

Checking engine oil level




ATTENTION

Misinterpretation of oil level reading, because oil level is temperature-dependent (the higher the temperature, the higher the oil level)

Engine damage

- Check the oil level only after a lengthy ride or when the engine is at operating temperature.
 - Switch off the engine when it is at operating temperature.
 - Make sure the ground is level and firm and hold the motorcycle upright.
 - Wait five minutes for the oil to drain into the oil pan.
-  To protect the environment, BMW Motorrad recommends occasionally checking the engine oil after a journey of at least 50 km.




ATTENTION

Vehicle toppling sideways

Risk of damage to parts if vehicle topples

- Secure the vehicle, preferably with the assistance of a second person, so that it cannot topple sideways.
- Check the oil level in the display **1**.



Engine oil, specified level

Between **MIN** and **MAX** marks

If the oil level is below the MIN mark:


- Top up the engine oil (→ 113).

If the oil level is above the MAX mark:

- Have the oil level corrected by a specialist workshop, preferably an authorised BMW Motorrad retailer.

Topping up engine oil

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Wipe the area around the oil filler opening clean.
- Insert cross-head end of reversible screwdriver insert **1** into screwdriver handle **2** (on-board toolkit) and use the tool for additional leverage.
- Engage the tool from the toolkit in oil filler plug **3** and turn the plug counter-clockwise.
- Remove oil filler plug **3**.



ATTENTION

Use of insufficient engine oil or too much engine oil

Engine damage

- Always make sure that the oil level is correct.
- Top up the engine oil to the specified level.



Engine oil, quantity for topping up

max 0.5 l (Difference between MIN and MAX)

- Check the engine oil level (112).
- Install oil filler plug 3.

BRAKE SYSTEM

Checking function of brakes

- Pull the front brake lever.
 - » The pressure point must be clearly perceptible.
 - Press the footbrake lever.
 - » The pressure point must be clearly perceptible.
- If pressure points are not clearly perceptible:




ATTENTION

Work on brake system not in compliance with correct procedure


Risk to operational reliability of the brake system

- Have all work on the brake system undertaken by trained and qualified specialists.
 - Have the brakes checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.
- ### Checking brake pad thickness, front brakes
- Make sure the ground is level and firm and place the motor-cycle on its stand.



- Visually inspect the left and right brake pads to ascertain their thickness. Viewing direction: between wheel and front

suspension toward the brake pads **1**.



Brake-pad wear limit,
front

1.0 mm (friction pad only, without backing plate. The wear indicators (grooves) must be clearly visible.)

If the wear indicating marks are no longer clearly visible:



WARNING

Brake-pad thickness less than permissible minimum

Diminished braking effect, damage to the brakes

- In order to ensure the dependability of the brake system, do not permit the brake pads to wear past the minimum permissible thickness.

- Have the brake pads replaced by a specialist workshop,

preferably an authorised BMW Motorrad retailer.

Checking brake pad thickness, rear brakes

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Visually inspect the brake pads to ascertain their thickness. Viewing direction: from the left toward the brake caliper.



Brake-pad wear limit,
rear

1.0 mm (friction pad only, without backing plate. Make sure that the brake disc is not visible through the bore in the inboard brake block.)

If the brake disc is visible:



WARNING

Brake-pad thickness less than permissible minimum


Diminished braking effect, damage to the brakes

- In order to ensure the dependability of the brake system, do not permit the brake pads to wear past the minimum permissible thickness.

- Have the brake pads replaced by a specialist workshop, preferably an authorised BMW Motorrad retailer.

Brake pad wear

The rear wheel brake has a brake-pad wear indicator.



Shaft **1** with three marker rings **2** is between the brake pads.

How to interpret the marks:

- 3 rings visible: brake-pad thickness is at least 75 %
- 2 rings visible: brake pad thickness is at least 50 %
- 1 ring visible: brake pad thickness is at least 25 %
- No ring visible: wear limit has been reached, check as described above

Checking brake-fluid level, front brakes



WARNING

Not enough brake fluid in brake fluid reservoir, or contaminants in brake fluid

Considerably reduced braking power due to presence of air, contaminants or water in the brake system

- Cease operation of the vehicle immediately and do not ride it until the fault has been rectified.
- Check the brake-fluid levels at regular intervals.
- Always make sure that the lid of the brake fluid reservoir and the area around the lid are cleaned before opening.
- Make sure that only fresh brake fluid from a sealed container is used.

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Turn the handlebars to a position in which the brake fluid reservoir is horizontal.
- Check the brake fluid level in sight glass **1**.



Wear of the brake pads causes the brake fluid level in the reservoir to sink.



Brake fluid level, front

Brake fluid, DOT4

It is not permissible for the brake fluid level to be below the MIN mark. (Brake-fluid reservoir horizontal, motorcycle upright.)

118 MAINTENANCE

If the brake fluid level drops below the permitted level:

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

Checking brake-fluid level, rear brakes



WARNING

Not enough brake fluid in brake fluid reservoir, or contaminants in brake fluid

Considerably reduced braking power due to presence of air, contaminants or water in the brake system

- Cease operation of the vehicle immediately and do not ride it until the fault has been rectified.
- Check the brake-fluid levels at regular intervals.
- Always make sure that the lid of the brake fluid reservoir and the area around the lid are cleaned before opening.
- Make sure that only fresh brake fluid from a sealed container is used.
- Make sure the ground is level and firm and place the motor-

cycle on its stand. Keep the vehicle upright.



- Check the brake fluid level in brake fluid reservoir for rear wheel brake **1**.

 Wear of the brake pads causes the brake fluid level in the reservoir to sink.



Brake fluid level, rear

Brake fluid, DOT4

It is not permissible for the brake fluid level to be below the **MIN** mark. (Brake fluid reservoir horizontal)

If the brake fluid level drops below the permitted level:

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

CLUTCH

Checking clutch function

- Pull the clutch lever.
 - » The pressure point must be clearly perceptible.
- If the pressure point is not clearly perceptible:
- Have the clutch checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.

TYRES

Checking tyre pressure



WARNING

Incorrect tyre pressure

Impaired handling characteristics of the motorcycle, shorter useful tyre life

- Always check that the tyre pressures are correct.



WARNING

Tendency of valve inserts installed vertically to open by themselves at high riding speeds

Sudden loss of tyre pressure

- Install valve caps fitted with rubber sealing rings and tighten firmly.

- Place the motorcycle on its stand on firm, even ground.
- Check tyre pressures against the data below.



Tyre pressure, front

2.5 bar (tyre cold)



Tyre pressure, rear

2.7 bar (One-up, tyre cold)

2.9 bar (two-up and with luggage, tyre cold)

With incorrect tyre pressure:

- Correct tyre pressure.

Checking tyre tread depth



WARNING

Riding with badly worn tyres

Risk of accident due to impaired handling

- If applicable, have the tyres changed in good time before they wear to the minimum tread depth permitted by law.
 - Place the motorcycle on its stand on firm, even ground.
 - Measure the tyre tread depth in the main tread grooves with wear marks.
-  Wear indicators are built into the main profile grooves on each tyre. The tyre is worn out when the tyre tread has worn down to the level of the marks. The locations of the marks are indicated on the edge of the tyre, e.g. by the letters TI, TWI or by an arrow. If the tyre tread is worn to minimum:
- Replace tyre or tyres, as applicable.

WHEEL RIMS

Checking rims

- Place the motorcycle on its stand on firm, even ground.
- Visually inspect the rims for defects.
- Have damaged rims inspected by a specialist workshop and replaced if necessary, preferably by an authorised BMW Motorrad dealer.

Checking spokes

- Place the motorcycle on its stand on firm, even ground.
- Use a screwdriver handle or similar object to brush over the spokes and pay attention to the sequence of sounds. If the sequence of sounds is irregular:
- Have the spokes checked by a specialist workshop, preferably by an authorised BMW Motorrad Retailer.

WHEELS

Effect of wheel size on chassis and suspension control systems

Wheel size is very important as a parameter for the running-gear control systems such as ABS, for example. In particular, the diameter and the width of a vehicle's wheels are programmed into the control unit

and are fundamental to all calculations. Any change in these influencing variables, caused for example by a switch to wheels other than those installed ex-works, can have serious effects on the performance of the control systems.

The sensor rings are essential for correct road-speed calculation, and they too must match the motorcycle's control systems and consequently cannot be changed.


If you decide that you would like to fit non-standard wheels to your motorcycle, it is very important to consult a specialist workshop beforehand, preferably an authorised BMW Motorrad retailer. In these cases, the data programmed into the control units has to be changed to suit the new wheel sizes.

Removing front wheel

 The front-wheel cover has to be detached on one side to facilitate wheel removal/installation.

- Place the motorcycle on an auxiliary stand. BMW Motorrad recommends you use the BMW Motorrad rear-wheel stand.

- Install the rear-wheel stand ( 112).
- Lift the front of the motorcycle until the front wheel is clear of the ground, preferably using a BMW Motorrad front-wheel stand.
- Install the front-wheel stand ( 111).




- Loosen screws **1**.




- Disengage the sensor cable from holders **2**.
- Remove screw **1** and remove wheel speed sensor **3** from its bore.


122 MAINTENANCE



- Remove screws **1** on the left side.
- Disengage holder **2** for the sensor cable and brake caliper **3**.



- Remove screws **1** on the right side and disengage brake caliper **2**.



- Force brake pads **1** slightly apart by rocking brake caliper **2** back and forth against brake disc **3**.



ATTENTION

Unwanted inward movement of the brake pads

Component damage on attempt to install the brake caliper or because brake pads have to be forced apart

- Do not operate the brakes with a brake caliper not correctly secured.



ATTENTION

Use of hard or sharp-edged objects in proximity to component

Component damage

- Take care not to scratch components; cover or mask as necessary.

- Carefully pull the brake calipers back and out until clear of the brake discs.



- Slacken screw **2**, but **do not remove it**.
- Slacken clamping bolts **1** on left and right.
- Press quick-release axle slightly toward the inside, so as to be better able to grip it on the right-hand side.
- Remove screw **2**.



- Withdraw quick-release axle **3**, support the front wheel when doing this.
- Set down front wheel and roll forwards out of the front suspension.



- Remove spacing bushing **4** from the front wheel hub.

Installing front wheel



WARNING

Use of a non-standard wheel

Malfunctions during ABS and ASC/DTC intervention

- See the information on the effect of wheel size on the ABS and ASC/DTC systems at the start of this chapter.



ATTENTION

Tightening threaded fasteners to incorrect tightening torque

Damage, or threaded fasteners work loose

- Always have the security of the fasteners checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.

124 MAINTENANCE



- Lubricate the friction face of spacer bushing **4**.



Lubricant

Optimoly TA

- Insert spacer bush **4**, turned with the collar facing out, into the wheel hub on the left-hand side.



ATTENTION

Front wheel installed wrong way round

Risk of accident

- Note direction-of-rotation arrows on tyre or rim.
- Roll the front wheel into position in the front suspension.



- Lubricate quick-release axle **3**.



Lubricant

Optimoly TA




WARNING

Improper installation of the quick-release axle

Loosening of the front wheel

- After securing the brake calipers and relieving the front forks, tighten the quick-release axle and the axle clamping to the specified tightening torque.
- Lift the front wheel and insert quick-release axle **3**.
 - Remove front-wheel stand and firmly compress front forks several times. Do not operate the brake lever in this process.
 - Install the front-wheel stand (111).



- Install screw **2**. Counter-hold quick-release axle on the right side.

 Screw to quick-release axle

50 Nm


- Tighten clamping bolts **1** on the left and right to the specified torque.



 Clamping screws in axle holder

Tightening sequence: Tighten screws six times in alternate sequence


19 Nm



- Hold right brake caliper **2** in position and install screws **1**.

 Brake caliper on tele-scopic fork

38 Nm



- Hold left brake caliper **3** and holder for sensor cable **2** in position.
- Install screws **1**.

 Brake caliper on tele-scopic fork

38 Nm

126 MAINTENANCE



- Insert wheel speed sensor **3** into its bore and install screw **1**.



Wheel-speed sensor to fork leg

8 Nm

- Insert the sensor cable into holders **2**.




WARNING

Brake pads not lying against the brake disc

Risk of accident due to delayed braking effect.

- Before driving, check that the brakes respond without delay.
- Operate the brake several times until the brake pads are bedded.



- Tighten screws **1**.




Wheel cover, front, to forks

5 Nm

- Remove the front-wheel stand.
- Extend the side stand.
- Remove the rear-wheel stand.
- Place the motorcycle on its side stand.

Removing rear wheel


- Lift the motorcycle, preferably with a BMW Motorrad rear-wheel stand.
- Engage first gear.
- Install the rear-wheel stand (112).

**CAUTION****Hot exhaust system**


Risk of burn injury

- Do not touch a hot exhaust system.

- Slacken screw **1** of the clamp and slip the clamp to the rear.
- Do not remove the sealing grease from the clamp.



- Remove screw **1** and retaining plate **2** of the holder of the silencer from the passenger footrest.
- Work silencer **3** to the rear to remove and lay it on a padded surface.



- Support the wheel and remove screws **1**.
- Roll the rear wheel out toward the rear.

Installing rear wheel**WARNING****Use of a non-standard wheel**

Malfunctions during ABS and ASC/DTC intervention

- See the information on the effect of wheel size on the ABS and ASC/DTC systems at the start of this chapter.

ATTENTION

Tightening threaded fasteners to incorrect tightening torque

Damage, or threaded fasteners work loose


- Always have the security of the fasteners checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.
- Clean the wheel centring spigot and the contact surfaces of the wheel hub.

ATTENTION

Use of hard or sharp-edged objects in proximity to component

Component damage

- Take care not to scratch components; cover or mask as necessary.
- Seat the rear wheel on the rear-wheel adapter.



- Install screws **1**.




Rear wheel to wheel carrier


Tightening sequence: Tighten in diagonally opposite sequence

60 Nm


- Slip the silencer on to the pipe at the exhaust-flow control valve.



- Align silencer **3**, hold retaining plate **2** in position and install screw **1**, but do not tighten the screw yet.



- Align the clamp with recess **1** at retaining lug **2**.
» Retaining lug engages recess in the clamp.



- Tighten screw **1**.

 Clamp to silencer and exhaust manifold

28 Nm



- Tighten screw **1**.

 Silencer to passenger frame

19 Nm

- Extend the side stand.
- Remove the rear-wheel stand.
- Place the motorcycle on its side stand.

LIGHTING

Replacing LED light sources



WARNING

Vehicle overlooked in traffic due to failure of the lights on the vehicle

Safety risk

- Always replace a faulty bulb at the earliest possible opportunity. Consult a specialist workshop, preferably an authorised BMW Motorrad Retailer.

130 MAINTENANCE

All light sources of the vehicle are LED light sources. The service life of the LED light sources is longer than the presumed vehicle service life. If an LED light source is faulty contact a specialist workshop, preferably an authorised BMW Motorrad retailer.

JUMP-STARTING



CAUTION

Touching live parts of the ignition system when the engine is running

Electric shock

- Do not touch parts of the ignition system when the engine is running.



ATTENTION

Excessive current flowing when the motorcycle is jump-started

Wiring smoulders/ignites or damage to the on-board electronics

- If the motorcycle has to be jump-started connect the leads to the battery terminals; never attempt to jump-start the engine by connecting leads to the on-board socket.



ATTENTION

Contact between crocodile clips of jump leads and vehicle

Risk of short-circuit

- Use jump leads fitted with fully insulated crocodile clips at both ends.




ATTENTION

Jump-starting with a voltage greater than 12 V


Damage to the on-board electronics

- Make sure that the battery of the donor vehicle has a voltage rating of 12 V.

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Remove the passenger seat (▮▮▮ 60).
- Remove the rider's seat (▮▮▮ 60).



- Unclip cover **1** at the bottom (**arrow**) and work it up to remove.




- Begin by connecting one end of the red jump lead to remote positive terminal **1** and the other end to the positive terminal of the donor battery.
- Connect one end of the black jump lead to your vehicle's remote ground terminal **2** and

- the other end to the negative terminal of the donor battery.
- Run the engine of the donor vehicle during jump-starting.
- Start the engine of the vehicle with the discharged battery in the usual way; if the engine does not start, wait a few minutes before repeating the attempt in order to protect the starter motor and the donor battery.

 Do not use proprietary start-assist sprays or other products to start the engine.

- Allow both engines to idle for a few minutes before disconnecting the jump leads.
- Disconnect the jump lead from remote ground terminal **2** first, then disconnect the second jump lead from remote positive terminal **1**.



- Install cover **1**.
- Install the rider's seat (▮▮▮ 60).
- Install the passenger seat (▮▮▮ 60).

BATTERY

Maintenance instructions

Correct upkeep, recharging and storage will prolong the life of the battery and are essential if warranty claims are to be considered.

Compliance with the points below is important in order to maximise battery life:

- Keep the surface of the battery clean and dry.
- Do not open the battery.
- Do not top up with water.
- Be sure to read and comply with the instructions for charging the battery on the following pages.
- Do not turn the battery upside down.



ATTENTION

On-board electronics (e.g. clock) draining connected battery

Battery is deep-discharged; this voids the guarantee

- Connect a float charger to the battery if the motorcycle is to remain out of use for more than four weeks.



BMW Motorrad has developed a float charger specially designed for compatibility with the electronics

of your motorcycle. Using this charger, you can keep the battery charged during long periods of disuse, without having to disconnect the battery from the motorcycle's on-board systems. You can obtain additional information from your authorised BMW Motorrad dealer.

Recharging connected battery



ATTENTION

Unsuitable chargers connected to a socket

Damage to charger and vehicle electronics

- Use suitable BMW chargers. The suitable charger is available from your authorised BMW Motorrad dealer.

- Remove any devices that are connected to the socket.
- Comply with the operating instructions of the charger.
- Charge the battery connected to the vehicle from the socket.



The motorcycle's on-board electronics know when the battery is fully charged. The on-board socket is switched off when this happens.

 If you are unable to charge the battery through the on-board socket, you may be using a charger that is not compatible with your motorcycle's electronics. In this case, directly charge the battery at the terminals of the battery that has been disconnected from the vehicle.



ATTENTION

Recharging a fully discharged battery via the power socket or extra socket

Damage to the vehicle electronics

- If a battery has discharged to the extent that it is completely flat (battery voltage less than 12 V, indicator lights and multifunction display remain off when the ignition is switched on) always charge the **disconnected** battery with the charger connected directly to the battery terminals.



ATTENTION

Charging the battery that is connected to the vehicle via the battery terminals

Damage to the on-board electronics

- Disconnect the battery at the battery terminals before charging.
 - Directly charge the disconnected battery on the terminals.
- #### **Recharging disconnected battery**
- Charge the battery using a suitable charger.
 - Comply with the operating instructions of the charger.
 - Once the battery is fully charged, disconnect the charger's terminal clips from the battery terminals.
-  The battery has to be recharged at regular intervals in the course of a lengthy period of disuse. See the instructions for caring for your battery. Always fully recharge the battery before restoring it to use.

134 MAINTENANCE

Replacing battery

If the battery is faulty consult a specialist workshop, preferably an authorised BMW Motorrad retailer.

FUSES

Replacing fuses



ATTENTION

Jumping of blown fuses

Risk of short-circuit and fire

- Never attempt to jumper a blown fuse.
 - Always replace a defective fuse with a new fuse of the same amperage.
-
- Switch off the ignition.
 - Make sure the ground is level and firm and place the motorcycle on its stand.
 - Remove the passenger seat (►► 60).
 - Remove the rider's seat (►► 60).


» The fuse box is unlocked and can be pulled to the left and disengaged from holder **2**.

- Remove the fuse box from holder **2**.
- Press lock **4** on each side and remove cap **3**.




If fuse defects recur frequently have the electric circuits checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.

- Consult the fuse assignment diagram below and replace the defective fuse.
- » Fuse assignment (►► 135)
- Re-install cap **3**. Make sure that lock **4** engages.
- Push the fuse box into holder **2** until hook **1** engages.
- Install the rider's seat (►► 60).
- Install the passenger seat (►► 60).



- Press hook **1**.

Fuse assignment



Fuse 1

10 A (Instrument cluster, alarm system DWA, ignition switch, OBD diagnostic socket, cut-off relay coil)



Fuse 2

4 A (Sensor box, multifunction switch, left)

DIAGNOSTIC CONNECTOR

Disengaging diagnostic socket



CAUTION

Incorrect procedure followed when loosening the diagnostic connector for the on-board diagnosis

Motorcycle experiences malfunctions

- Only have the diagnostic connector loosened by a specialist workshop or other authorised persons during your next BMW Service appointment.
- Have the work performed by appropriately trained staff.
- Refer to the vehicle manufacturer specifications.

- Remove the passenger seat (→ 60).
- Remove the rider's seat (→ 60).


136 MAINTENANCE



- Press locks **1**.
- Disengage diagnostic socket **2** from holder **3**.
 - » The interface to the diagnosis and information system can be connected to the diagnostic connector **2**.

Securing diagnostic socket

- Disconnect the interface for the diagnosis and information system.



- Insert diagnostic socket **2** into holder **3**.
 - » The locks **1** engage.
- Install the rider's seat (►► 60).
- Install the passenger seat (►► 60).

ACCESSORIES

09

GENERAL INSTRUCTIONS	140
USB CHARGING SOCKET	140
LUGGAGE	141
PASSENGER FRAME	142
TAIL-HUMP COVER	147
OPTIONAL ACCESSORIES	149

GENERAL INSTRUCTIONS



CAUTION

Use of other-make products

Safety risk

- BMW Motorrad cannot examine or test each product of outside origin to ensure that it can be used on or in connection with BMW vehicles without constituting a safety hazard. Country-specific official authorisation does not suffice as assurance. Tests conducted by these instances cannot make provision for all operating conditions experienced by BMW vehicles and, consequently, they are not sufficient in some circumstances.
- Use only parts and accessories approved by BMW for your vehicle.

BMW has conducted extensive testing of the parts and accessory products to establish that they are safe, functional and suitable. Consequently, BMW accepts responsibility for the products. BMW accepts no liability whatsoever for parts and accessories that it has not approved.

All modifications must be in compliance with legal requirements. Make sure that the vehicle does not infringe the national road-vehicle construction and use regulations applicable in your country. Your BMW Motorrad dealer can offer expert advice on the choice of genuine BMW parts, accessories and other products. To find out more about accessories go to: **bmw-motorrad.com/equipment**

USB CHARGING SOCKET

Notes on use:

Charge current

This is a 5 V USB charging interface that provides a maximum charge current of 2.4 A.

Automatic shutdown

The USB charging sockets are shut down automatically under the following circumstances:

- If battery charge state is too low, to maintain the motorcycle's start capability.
- If the maximum load capacity as stated in the technical data is exceeded.
- During the starting operation.

Connection of electrical devices

You can start using electrical devices connected to the USB charging sockets only when the ignition is switched on. The power supply to the sockets is switched off no more than 15 minutes after the ignition is switched off, in order to prevent overloading of the on-board electrics.

While riding in the rain, you should disconnect the device from the interface in order to protect against damage. To prevent dirtying, keep the protective cover closed when no device is connected.

Cable routing

Note the following with regard to the routing of cables from USB charging sockets to items of electronic equipment:

- Make sure that cables do not impede the rider.
- Make sure that cables do not restrict the steering angle or obstruct handling.
- Make sure that cables cannot be trapped.

LUGGAGE

Securing luggage to motorcycle



WARNING

Handling adversely affected by overloading and imbalanced loads

Risk of falling

- Do not exceed the permissible gross weight and be sure to comply with the instructions on loading.



- Secure luggage (e.g. rear softbag) to lashing eyes **1**.
- Note the maximum payload.



Payload of rear softbag

- with rear softbag^{OA}
- max 10 kg

» You can obtain additional information on luggage systems and how to secure them correctly from your authorised BMW Motorrad retailer.

PASSENGER FRAME

Removing passenger frame



ATTENTION

Hard or sharp-edged components

Scratches and damage to paintwork


- Use a suitable soft cover or mask off the areas at risk.




An additional optional accessory (bracket for silencer) has to be installed if the passenger frame is removed. Detailed information is available from your authorised BMW Motorrad dealer or on the internet at www.bmw-motorrad.com.

Also observe the general notes at the beginning of this chapter.


- Place the motorcycle on its stand on firm, even ground.
- Install the rear-wheel stand (➡ 112).
- Remove the passenger seat (➡ 60).
- Remove the rider's seat (➡ 60).



- Remove screws **1** and remove left footrest system **2**.




- Remove screw **1** and washer **2**.
- Remove screws **3**.

**ATTENTION****Trapping of components**

Component damage


- Do not trap components such as brake lines or cable legs.

- Disengage cable ties **2** from lines **1**.
- Remove screws **3**.




- Remove screws **1** and work passenger frame **2** to the rear to remove.

—with bracket for silencer^{OA}



- Remove rubber decoupler **1** and shouldered bushing **3** from the passenger frame removed beforehand.
- Secure rubber decoupler **1** in bracket **2** for the silencer and install shouldered bushing **3** from the right.



- Hold bracket **1** for the silencer in position at rear frame **2**.
- Tighten screws **3** and **4**.




Bracket for the silencer
on the rear frame

—with bracket for silencer^{OA}

19 Nm ◁

144 ACCESSORIES

—with bracket for silencer^{OA}




- Align silencer **1** with bracket **2**, hold washer **3** in position and install screw **4**.



Silencer to bracket

10 Nm ◀




- Hold left footrest system **1** in position at rear frame **2** and install screws **3**.



Footrest system to rear frame

19 Nm

Loading correctly; passenger frame not fitted



WARNING

Handling adversely affected by overloading and imbalanced loads

Risk of falling

- Do not exceed the permissible gross weight and be sure to comply with the instructions on loading.

- Once the rear-seat frame has been removed, it is essential to comply with the load limit specified for luggage frame **1** (see illustration).



Luggage frame capacity

max 8 kg

Installing passenger frame




ATTENTION

Hard or sharp-edged components

Scratches and damage to paintwork


- Use a suitable soft cover or mask off the areas at risk.

- Parking your motorcycle (▶ 142).
- Install the rear-wheel stand (▶ 112).
- Remove the rider's seat (▶ 60).




- Remove screws **1** and remove left footrest system **2**.


—with bracket for silencer^{OA}



- Remove screw **1** and washer **2**.




- Remove screws **1** and **2**.
- Remove bracket **3** for the silencer.◁



- Insert passenger frame **1** from the rear and loosely install screws **2**.

146 ACCESSORIES



- Loosely install screw **1** and lock washer **2**.
- Install screws **3**.



Rear seat frame to rear frame


19 Nm

- Tighten screw **1**.



Silencer to passenger frame

19 Nm



ATTENTION

Trapping of components

Component damage


- Do not trap components such as brake lines or cable legs.

- Secure lines **1** with cable ties **2**.
- Install screws **3**.




Rear seat frame to rear frame

19 Nm




- Tighten screws **1**.




Rear seat frame to luggage frame

8 Nm

- Remove all masking tape.



- Hold left footrest system **1** in position at rear frame **2** and install screws **3**.



Footrest system to rear frame

19 Nm


- Install the rider's seat (► 60).
- Install the passenger seat (► 60).
- Remove the rear-wheel stand.

TAIL-HUMP COVER


—with tail-hump cover^{OA}

Installing tail-hump cover


- Remove the passenger seat (► 60).
- Remove the rider's seat (► 60).



- Remove screws **1** and keep them carefully for re-use.
- Remove retaining strap **2**.



- Install retainer **1** underneath retaining bridge for rider's seat **2**.
- Install screws **3** with washers **4**.




Retaining bridge to rear frame

8 Nm

- Install the rider's seat (► 60).

148 ACCESSORIES




- Insert tail-hump cover **1** into the retaining bracket, ensuring that the spacer buffers **4** of the tail-hump cover are positioned in the retaining bracket.
- Tighten screw **2** until hand-tight with motorcycle seat key **3**.


Removing tail-hump cover



- Remove screw **2** with motorcycle seat key **3**.
- Pull the tail-hump cover **1** towards the rear and remove.



- Remove screws **3** and washers **4**.
- Remove retainer **1** underneath retaining bridge for rider's seat **2**.



- Install retaining strap **2** underneath retaining bridge for rider's seat **3**.
- Install screws **1**.



Retaining bridge to rear frame

8 Nm

- Install the rider's seat (► 60).
- Install the passenger seat (► 60).

OPTIONAL ACCESSORIES

Available optional accessories



Your BMW Motorrad dealer can offer expert advice on the choice of genuine BMW parts, accessories and other products such as the aluminium tail-hump cover and the cover for the rear frame, for example. You can examine all the optional accessories from BMW Motorrad by visiting: **bmw-motorrad.com**.

CARE

10

CARE PRODUCTS	152
WASHING THE VEHICLE	152
CLEANING EASILY DAMAGED COMPONENTS	153
CARE OF PAINTWORK	154
PAINT PRESERVATION	155
LAYING UP MOTORCYCLE	155
RESTORING MOTORCYCLE TO USE	155

CARE PRODUCTS

BMW Motorrad recommends that you use the cleaning and care products you can obtain from your authorised BMW Motorrad dealer. The substances in BMW Motorrad Care Products have been tested in laboratories and in practice; they provide optimised care and protection for the materials used in your vehicle.



ATTENTION

Use of unsuitable cleaning and care products

Damage to vehicle parts

- Do not use solvents such as cellulose thinners, cold cleaners, fuel or the like, and do not use cleaning products that contain alcohol.



ATTENTION

Use of strongly acidic or strongly alkaline cleaning agents

Damage to vehicle parts

- Dilute in accordance with the dilution ratio stated on the packaging of the cleaning agent.
- Do not use strongly acidic or strongly alkaline cleaning agents.

WASHING THE VEHICLE

BMW Motorrad recommends that you use BMW insect remover to soften and wash off insects and stubborn dirt on painted parts prior to washing the vehicle.

To prevent stains, do not wash the motorcycle immediately after it has been exposed to strong sunlight and do not wash it in the sun.

Make sure that the vehicle is washed frequently, especially during the winter months. To remove road salt, clean the motorcycle with cold water immediately after every trip.

**WARNING**

Wet brake discs and brake pads after vehicle wash, after riding through water and in rainy conditions

Diminished braking effect, risk of accident

- Apply the brakes in good time to allow the friction and heat to dry the brake discs and brake pads.

**ATTENTION**

Effect of road salt intensified by warm water

Corrosion

- Use only cold water to wash off road salt.

**ATTENTION**

Damage due to high water pressure from high pressure cleaners or steam cleaners

Corrosion or short circuit, damage to labels, seals, hydraulic brake system, electrical system and the motorcycle seat

- Exercise restraint when using a steam jet or high pressure cleaning equipment.

CLEANING EASILY DAMAGED COMPONENTS

Plastics

**ATTENTION**

Use of unsuitable cleaning agents

Damage to plastic surfaces

- Do not use cleaning agents that contain alcohol, solvents or abrasives.
- Do not use insect-remover pads or cleaning pads with hard, scouring surfaces.

Trim panel components

Clean trim panel components with water and BMW Motorrad solvent cleaner.

Headlight glass and lenses made of plastic

Remove dirt and insects with a soft sponge and plenty of water.



Soften stubborn dirt and insects by covering the affected areas with a wet cloth.



Clean with water and sponge only.



Do not use any chemical cleaning agents.

154 CARE

Chrome

Carefully clean chrome sections with a generous amount of water and motorcycle cleaner from the care series BMW Motorrad Care Products. This applies especially where road salt has been in use. For an additional treatment, use BMW Motorrad metal polish.

Radiator

Clean the radiator regularly to prevent overheating of the engine due to inadequate cooling. For example, use a garden hose with low water pressure.



ATTENTION

Bending of radiator fins

Damage to radiator fins

- Take care not to bend the radiator fins when cleaning.

Rubber

Treat rubber components with water or BMW rubber-care products.



ATTENTION

Application of silicone sprays to rubber seals

Damage to the rubber seals

- Do not use silicone sprays or care products that contain silicon.

CARE OF PAINTWORK

The long-term effects of materials that are damaging to paint can be prevented by regular vehicle washes, particularly if your vehicle is ridden in areas susceptible to high levels of air pollution or natural contamination, for example tree resin or pollen.

Particularly aggressive materials, however, should be removed immediately, otherwise changes to or discolouration of the paint can result. These include, for example, spilled fuel, oil, grease, brake fluid or bird excrement. For this, we recommend BMW Motorrad solvent cleaner followed by BMW Motorrad gloss polish for preservation.

Contamination of the paint surface can be seen particularly clearly after a vehicle wash. These areas should be cleaned immediately using benzine or spirit, applied with a clean cloth or cotton pad. BMW Motorrad recommends that tar spots be removed using BMW tar remover. The paint should then be preserved in these areas.

PAINT PRESERVATION

If water no longer rolls off the paint, the paint must be preserved.

For paint preservation, BMW Motorrad recommends the use of BMW Motorrad gloss polish or agents containing carnauba wax or synthetic wax.

LAYING UP MOTORCYCLE

- Fill the motorcycle's fuel tank.



Fuel additives clean the fuel injection system and the combustion zone. It is advisable to use fuel additives when the engine is operated with low-grade fuel or if the vehicle is to be out of use for a lengthy period of time. More information is available from your authorised BMW Motorrad retailer.

- Clean the motorcycle.
- Remove the battery.
- Spray the brake and clutch lever pivots and the side stand pivot mounts with a suitable lubricant.
- Coat bright metal and chrome-plated parts with an acid-free grease (e.g. Vaseline).
- Stand the motorcycle in a dry room in such a way that there

is no load on either wheel (preferably using the front-wheel and rear-wheel stands from BMW Motorrad).

RESTORING MOTORCYCLE TO USE

- Remove the protective wax coating.
- Clean the motorcycle.
- Install the battery.
- Checklist (➡ 82).

TECHNICAL DATA

11

TROUBLESHOOTING CHART	158
SCREW CONNECTIONS	159
FUEL	162
ENGINE OIL	162
ENGINE	163
CLUTCH	163
TRANSMISSION	164
FINAL DRIVE	164
FRAME	164
CHASSIS AND SUSPENSION	165
BRAKES	166
WHEELS AND TYRES	166
ELECTRICAL SYSTEM	167
DIMENSIONS	168
WEIGHTS	168
PERFORMANCE FIGURES	169

TROUBLESHOOTING CHART

Engine does not start or is difficult to start.

Possible cause	Rectification
Emergency off switch (kill switch)	Kill switch in operating position
Side stand is extended and gear is engaged.	Retract the side stand.
Gear is engaged and clutch is not pressed.	Select neutral or pull the clutch lever.
Fuel tank is empty.	Refuelling (➡ 91).
Battery is flat.	Recharging connected battery (➡ 132).
Overheating protection for starter motor has been activated. Starter motor can only be operated for a limited period of time.	Allow the starter motor to cool down for approx. 1 minute before using it again.

SCREW CONNECTIONS

Front wheel	Value	Valid
Brake caliper on telescopic fork		
M10 x 65	38 Nm	
Clamping screws in axle holder		
M8 x 35	Tightening sequence: Tighten screws six times in alternate sequence 19 Nm	
Bolt in quick-release axle		
M20 x 1.5 18	50 Nm	
Rear wheel	Value	Valid
Rear wheel to wheel carrier		
M10 x 53 x 1.25	Tightening sequence: Tighten in diagonally opposite sequence 60 Nm	
Mirror arm	Value	Valid
Mirror (locknut) to adapter		
M10 x 1.25	Left-hand thread, 22 Nm	
Adapter to clamping block		
M10 x 14 - 4.8	25 Nm	

160 TECHNICAL DATA

Mirror arm	Value	Valid
Mirror to spacer sleeve		
M5 x 20	3 Nm	–with Option 719 milled parts package Classic II ^{OE} or –with Option 719 milled parts package Shadow II ^{OE}

Headlight	Value	Valid
Headlight to bracket		
M8 x 40	19 Nm	

Front-wheel cover	Value	Valid
Wheel cover, front, to forks		
M5 x 20	5 Nm	

Frame	Value	Valid
Footrest system to rear frame		
M8 x 25	19 Nm	
Rear seat frame to rear frame		
M8 x 30	19 Nm	
Rear seat frame to luggage frame		
M6 x 20	8 Nm	

Frame	Value	Valid
Retaining bridge to rear frame		
M6 x 14.5	8 Nm	
Exhaust system	Value	Valid
Clamp to silencer and exhaust manifold		
M8 x 40 - 10.9	28 Nm	
Silencer to passenger frame		
M8 x 40	19 Nm	
Bracket for the silencer on the rear frame		
M8 x 30	19 Nm	–with bracket for silencer ^{OA}
M8 x 25	19 Nm	
Silencer to bracket		
M8 x 40	10 Nm	–with bracket for silencer ^{OA}

162 TECHNICAL DATA

FUEL

Recommended fuel grade	 Premium unleaded (maximum 15% ethanol, E15)  95 ROZ/RON 90 AKI
Alternative fuel grade	 Regular unleaded (maximum 15% ethanol, E15)  91 ROZ/RON 87 AKI
Usable fuel capacity	approx. 18 l
Reserve fuel	approx. 3.5 l
Fuel consumption	5.1 l/100 km, according to WMTC
CO2 emission	119 g/km, according to WMTC
Exhaust emissions standard	EU 5
–with Canada export ^{NV}	TIER 2, measured in accordance with FTP75

ENGINE OIL

Engine oil, capacity	max 3.95 l, with filter change
Specification	SAE 15W-50, API SJ / JASO MA2, Additives (e.g. molybdenum-based) are not permissible because they can attack coated components of the engine, BMW Motorrad recommends BMW Motorrad ADVANTEC Pro oil.
Engine oil, quantity for topping up	max 0.5 l, Difference between MIN and MAX

ENGINE

Engine number location	Crankcase, bottom right, below cylinder
Engine type	A72B12A
Engine design	Four-stroke opposed twin, air-cooled with oil-cooled exhaust ports, installed longitudinally, two overhead camshafts and four radially positioned valves per cylinder, electronic engine management
Displacement	1170 cm ³
Cylinder bore	101 mm
Piston stroke	73 mm
Compression ratio	12.0:1
Nominal capacity	80 kW, at engine speed: 7250 min ⁻¹
Torque	116 Nm, at engine speed: 6000 min ⁻¹
Maximum engine speed	max 8500 min ⁻¹
Idle speed	1150 ^{±50} min ⁻¹ , Engine at regular operating temperature

CLUTCH

Clutch type	Single-plate dry clutch
-------------	-------------------------

164 TECHNICAL DATA

TRANSMISSION

Type of transmission	Constant-mesh six-speed transmission with helical-cut gearing
Gearbox transmission ratios	1.737, Primary transmission ratio 2.375 (38:16 teeth), 1st gear 1.696 (39:23 teeth), 2nd gear 1.296 (35:27 teeth), 3rd gear 1.065 (33:31 teeth), 4th gear 0.939 (31:33 teeth), 5th gear 0.848 (28:33 teeth), 6th gear

FINAL DRIVE

Type of final drive	Shaft drive with bevel gears
Type of rear suspension	Cast aluminium single swinging arm featuring BMW Motorrad Paralever
Gear ratio of final drive	2.910 (32/11 teeth)
Rear axle differential oil	SAE 70W-80 / Hypoid Axle G3

FRAME

Frame type	Tubular spaceframe with effective drive unit
Type plate location	Front left frame on steering head
Position of the vehicle identification number	Main frame front right at bottom

CHASSIS AND SUSPENSION

Front wheel

Type of front suspension	Upside-down telescopic forks, 46 mm in diameter, adjustable rebound and compression stage
Spring travel, front	120 mm, at wheel

Rear wheel

Type of rear suspension	Cast aluminium single swinging arm featuring BMW Motorrad Paralever
Type of rear-wheel suspension	Central spring strut with coil spring, adjustable rebound stage damping and spring pre-load
Spring travel at rear wheel	120 mm, At wheel
Recommended suspension setting for one-up riding	Spring preload, Turn the dial counter-clockwise as far as it will go Damping, Turn the adjusting screw clockwise as far as it will go, then back it off 1.5 turns
Recommended suspension setting for two-up riding	Spring preload, Turn the adjuster as far as it will go clockwise Damping action, Turn the adjusting screw in the clockwise direction till the limit position and then 0.75 rotations back

166 TECHNICAL DATA

BRAKES

Front wheel

Type of front brake	Twin disc brakes with 4-piston fixed calipers
Brake-pad material, front	Sintered metal
Brake disc thickness, front	min 4 mm, Wear limit
Play of brake controls (Front brake)	0.7...1.7 mm, on the piston

Rear wheel

Type of rear brake	Single-disc brake with 2-piston floating caliper
Brake-pad material, rear	Organic material
Brake disc thickness, rear	min 4.5 mm, Wear limit
Play of brake controls (Rear brake)	0.5...0.9 mm, At piston

WHEELS AND TYRES

Recommended tyre combinations	An overview of currently approved tyres is available from your authorised BMW Motorrad Retailer or on the Internet at bmw-motorrad.com .
Speed category, front/rear tyres	V, required at least: 240 km/h

Front wheel

Front-wheel type	Spoked wheel
Front-wheel rim size	3.50" x 17"
Tyre designation, front	120 / 70 ZR 17
Load index, front tyre	min. 58
Permissible front-wheel imbalance	max 5 g

Rear wheel

Rear-wheel type	Spoked wheel
Rear wheel rim size	5.50" x 17"
Tyre designation, rear	180 / 55 ZR 17
Load index, rear tyre	min. 73
Permissible rear-wheel imbalance	max 5 g

Tyre pressures

Tyre pressure, front	2.5 bar, tyre cold
Tyre pressure, rear	2.7 bar, One-up, tyre cold 2.9 bar, two-up and with luggage, tyre cold

ELECTRICAL SYSTEM**Fuses**

Fuse 1	10 A, Instrument cluster, alarm system DWA, ignition switch, OBD diagnostic socket, cut-off relay coil
Fuse 2	4 A, Sensor box, multifunction switch, left

Battery

Battery type	AGM battery (Absorbent Glass Mat)
Battery rated voltage	12 V
Battery rated capacity	14 Ah

Spark plugs

Spark plugs, manufacturer and designation	NGK MAR8AI-10DS
---	-----------------

168 TECHNICAL DATA

Lighting

Bulb for low-beam and high-beam headlight	LED
Bulb for parking light	LED
Bulb for tail light/brake light	LED
Bulbs for turn indicators	LED
Light source for the number plate light	LED

DIMENSIONS

Length of motorcycle	2105 mm, measured over rear wheel
Height of motorcycle	1240 mm, with mirrors, at DIN unladen weight
Width of motorcycle	865 mm, using the hand lever
Height of rider's seat	805 mm, without rider, at DIN unladen weight
Rider's inside-leg arc, heel to heel	1785 mm, without rider, at DIN unladen weight

WEIGHTS

Vehicle kerb weight	222 kg, DIN unladen weight, ready for road, 90 % load of fuel, without optional extras (OE)
Permissible gross vehicle weight	430 kg
Maximum payload	208 kg

PERFORMANCE FIGURES

Top speed	>200 km/h
-----------	-----------

SERVICE

12

REPORTING SAFETY-RELEVANT DEFECTS	172
BMW MOTORRAD SERVICE	173
BMW MOTORRAD SERVICE HISTORY	173
BMW MOTORRAD MOBILITY SERVICES	174
MAINTENANCE WORK	174
MAINTENANCE SCHEDULE	176
MAINTENANCE CONFIRMATIONS	177
SERVICE CONFIRMATIONS	191

REPORTING SAFETY-RELEVANT DEFECTS

—with Canada export^{NV}

If you think that your motorcycle has a fault which may cause an accident, injury or death, you must inform the NHTSA (National Highway Traffic Safety Administration) immediately and BMW of North America, LLC.

If the NHTSA receives other similar complaints, it may open an investigation. If it finds that a safety defect exists in a group of vehicles, the NHTSA may order the manufacturer to perform a recall and remedy campaign. However, the NHTSA cannot become involved in individual problems between you, your retailer, or BMW of North America, LLC.

You can contact the NHTSA by calling the Vehicle Safety hotline on 1-888-327-4236 (teletypewriter TTY for the hearing impaired: 1-800-424-9153) for free, by visiting the website at [http:// www.safercar.gov](http://www.safercar.gov) or by writing to Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590. Further information on vehicle safety is available at [http:// www.safercar.gov](http://www.safercar.gov).

Canadian customers who wish to report a safety-related defect to Transport Canada, Defect Investigations and Recalls can call the toll-free hotline 1-800-333-0510. You can also obtain other information about motor vehicle safety from [http:// www.tc.gc.ca/roadsafety](http://www.tc.gc.ca/roadsafety).

BMW MOTORRAD SERVICE

BMW Motorrad has an extensive network of dealerships in place to look after you and your motorcycle in more than 100 countries. Authorised BMW Motorrad dealerships have the technical information and the technical know-how to carry out reliably all maintenance and repair work on your BMW.

You can locate the nearest authorised BMW Motorrad retailer by visiting our website: **bmw-motorrad.com**



WARNING

Maintenance and repair work not in compliance with correct procedure

Risk of accident due to consequential damage

- BMW Motorrad recommends having work of this nature carried out on the vehicle by a specialist workshop, preferably an authorised BMW Motorrad dealer.

In order to help ensure that your BMW is always in optimum condition, BMW Motorrad recommends compliance with the maintenance intervals specified for your motorcycle.

Have all maintenance and repair work carried out confirmed in the "Service" chapter in this manual. Evidence of regular maintenance is essential for generous treatment of claims submitted after the warranty period has expired.

Your authorised BMW Motorrad retailer can provide information on BMW services and the work undertaken as part of each service.

BMW MOTORRAD SERVICE HISTORY

Entries

Maintenance work that has been carried out is entered in the proof of maintenance. The entries are like a Service Booklet and provide proof of regular maintenance.

When an entry is made in the electronic service booklet of the vehicle, service-relevant data is saved in the central IT

174 SERVICE

systems of BMW AG, Munich, Germany.

If there is a change in vehicle owner, the data saved in the electronic service booklet can also be viewed by the new vehicle owner. A BMW Motorrad retailer or a specialist workshop can also view data that is stored in the electronic service booklet.

Objection

The vehicle owner can object to entries being made by the BMW Motorrad retailer or a specialist workshop in the electronic service booklet along with the corresponding storage of data in the vehicle and transfer of data to the vehicle manufacturer for the period of time that they are the vehicle owner. In this instance, no entry is made in the electronic service booklet of the vehicle.

BMW MOTORRAD MOBILITY SERVICES

As the owner of a new BMW motorcycle, in the event of a breakdown you can benefit from the protection afforded by the various BMW Motorrad mobility services (e.g. BMW Mobile Service, breakdown

service, vehicle recovery service).

Your authorised BMW Motorrad dealer will be happy provide information about the mobility services available to you.

MAINTENANCE WORK

BMW pre-delivery check

Your authorised BMW Motorrad dealer conducts the BMW pre-delivery check before handing over the vehicle to you.

BMW Running-in check

The BMW running-in check has to be performed when the vehicle has covered between 500 km and 1200 km.

BMW Service

The BMW Service is carried out once a year; the extent of servicing can vary, depending on the age of the vehicle and the distance it has covered. Your authorised BMW Motorrad dealer confirms that the service work has been carried out and enters the date when the next service will be due.

For riders with a high mileage it may be necessary to have a service before the specified deadline. In this case, a corresponding maximum mileage

is entered in the service confirmation. If this mileage is reached before the next service deadline, the service must be brought forward.

The service-due indicator in the multifunction display reminds you about one month or 1000 km in advance when the time for a service is approaching, on the basis of the programmed values.

To find out more about service, go to:

bmw-motorrad.com/service

The scope of maintenance work required for your vehicle can be found in the following maintenance schedule:

MAINTENANCE SCHEDULE

	500 -1200 km 300 - 750 mls	10 000 km 6 000 mls	20 000 km 12 000 mls	30 000 km 18 000 mls	40 000 km 24 000 mls	50 000 km 30 000 mls	60 000 km 36 000 mls	70 000 km 42 000 mls	80 000 km 48 000 mls	90 000 km 54 000 mls	100 000 km 60 000 mls	12 months	24 months
1	X												
2												X	
3		X	X	X	X	X	X	X	X	X	X	X ^a	
4			X		X		X		X		X		X ^b
5		X	X	X	X	X	X	X	X	X	X		
6					X				X			X ^c	X ^c
7			X		X		X		X		X		
8			X		X		X		X		X		
9					X ^d				X ^d				
10				X			X			X			
11												X ^e	X ^e

- 1 BMW running-in check (including oil change)
- 2 BMW Service, standard scope
- 3 Engine-oil change, with filter
- 4 Oil change in bevel gears rear
- 5 Check valve clearances
- 6 Change transmission oil
- 7 Replace all spark plugs
- 8 Replace air-filter element
- 9 Replace belt for alternator
- 10 Oil change in the telescopic forks
- 11 Change brake fluid, entire system

- a annually or every 10000 km (whichever comes first)
- b every 2 years or every 20000 km (whichever comes first)
- c for the first time after one year, then every two years or 40000 km (whichever comes first)
- d every six years or every 40000 km (whichever comes first)
- e for the first time after one year, then every two years

MAINTENANCE CONFIRMATIONS

BMW Service standard scope

The repair tasks in the BMW Service standard scope are listed below. The actual scope of maintenance work applicable for your vehicle may vary.

- Performing vehicle test with BMW Motorrad diagnosis system
- Visual inspection of clutch system
- Checking steering-head bearing
- Visual inspection of the brake lines, brake hoses and connections
- Checking front brake pads and brake discs for wear
- Checking brake-fluid level, front wheel brake
- Checking rear brake pads and brake disc for wear
- Checking brake-fluid level, rear wheel brake
- Checking tyre pressure and tread depth
- Check the side stand's ease of movement
- Checking spoke tension, adjusting if necessary
- Check lighting and signalling system
- Function test, engine start suppression
- Final inspection and check for road safety
- Setting service-due date and countdown distance with BMW Motorrad diagnosis system
- Checking battery state of charge
- Confirming BMW service in on-board literature

178 SERVICE

BMW pre-delivery check
carried out

at _____

Stamp, signature

BMW Running-in Check
carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Oil change in rear bevel gears	☐	☐
Checking valve clearance	☐	☐
Change gearbox oil	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Replacing belt for generator	☐	☐
Oil change in telescopic front forks	☐	☐
Changing brake fluid, front brakes	☐	☐
Changing brake fluid, rear brakes	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Oil change in rear bevel gears	☐	☐
Checking valve clearance	☐	☐
Change gearbox oil	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Replacing belt for generator	☐	☐
Oil change in telescopic front forks	☐	☐
Changing brake fluid, front brakes	☐	☐
Changing brake fluid, rear brakes	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Oil change in rear bevel gears	☐	☐
Checking valve clearance	☐	☐
Change gearbox oil	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Replacing belt for generator	☐	☐
Oil change in telescopic front forks	☐	☐
Changing brake fluid, front brakes	☐	☐
Changing brake fluid, rear brakes	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Oil change in rear bevel gears	☐	☐
Checking valve clearance	☐	☐
Change gearbox oil	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Replacing belt for generator	☐	☐
Oil change in telescopic front forks	☐	☐
Changing brake fluid, front brakes	☐	☐
Changing brake fluid, rear brakes	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Oil change in rear bevel gears	☐	☐
Checking valve clearance	☐	☐
Change gearbox oil	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Replacing belt for generator	☐	☐
Oil change in telescopic front forks	☐	☐
Changing brake fluid, front brakes	☐	☐
Changing brake fluid, rear brakes	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Oil change in rear bevel gears	☐	☐
Checking valve clearance	☐	☐
Change gearbox oil	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Replacing belt for generator	☐	☐
Oil change in telescopic front forks	☐	☐
Changing brake fluid, front brakes	☐	☐
Changing brake fluid, rear brakes	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Oil change in rear bevel gears	☐	☐
Checking valve clearance	☐	☐
Change gearbox oil	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Replacing belt for generator	☐	☐
Oil change in telescopic front forks	☐	☐
Changing brake fluid, front brakes	☐	☐
Changing brake fluid, rear brakes	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Oil change in rear bevel gears	☐	☐
Checking valve clearance	☐	☐
Change gearbox oil	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Replacing belt for generator	☐	☐
Oil change in telescopic front forks	☐	☐
Changing brake fluid, front brakes	☐	☐
Changing brake fluid, rear brakes	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Oil change in rear bevel gears	☐	☐
Checking valve clearance	☐	☐
Change gearbox oil	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Replacing belt for generator	☐	☐
Oil change in telescopic front forks	☐	☐
Changing brake fluid, front brakes	☐	☐
Changing brake fluid, rear brakes	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Oil change in rear bevel gears	☐	☐
Checking valve clearance	☐	☐
Change gearbox oil	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Replacing belt for generator	☐	☐
Oil change in telescopic front forks	☐	☐
Changing brake fluid, front brakes	☐	☐
Changing brake fluid, rear brakes	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Oil change in rear bevel gears	☐	☐
Checking valve clearance	☐	☐
Change gearbox oil	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Replacing belt for generator	☐	☐
Oil change in telescopic front forks	☐	☐
Changing brake fluid, front brakes	☐	☐
Changing brake fluid, rear brakes	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Oil change in rear bevel gears	☐	☐
Checking valve clearance	☐	☐
Change gearbox oil	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Replacing belt for generator	☐	☐
Oil change in telescopic front forks	☐	☐
Changing brake fluid, front brakes	☐	☐
Changing brake fluid, rear brakes	☐	☐

Notes

Stamp, signature

DECLARATION OF CONFORMITY FOR ELECTRONIC IMMOBILISER	195
CERTIFICATE FOR ELECTRONIC IMMOBILISER	201
DECLARATION OF CONFORMITY FOR ANTI-THEFT ALARM SYSTEM	203

Declaration of Conformity

Radio equipment electronic immobiliser (EWS)

Simplified EU Declaration of Conformity acc. Radio Equipment Directive 2014/53/EU after 12.06.2016 and during transition period



Technical information

Frequency Band: 134 kHz
(Transponder: TMS37145 /
TypeDST80, TMS3705
Transponder Base Station IC)
Output Power: 50 dBμV/m

Manufacturer and Address

Manufacturer: BECOM Electronics GmbH
Address: Technikerstraße 1,
A-7442 Hochstraß

Austria

Hiermit erklärt BECOM Electronics GmbH, dass der Funkanlagentyp EWS4 der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: <http://www.becom.at/de/download/>

Belgium

Le soussigné, BECOM Electronics GmbH, déclare que l'équipement radioélectrique du type EWS4 est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: <http://www.becom.at/de/download/>

Bulgaria

С настоящото BECOM Electronics GmbH декларира, че този тип радиосъоръжение EWS4 е в съответствие с Директива 2014/53/ЕС. Цялостният текст на ЕС декларацията за съответствие може да се намери на следния интернет адрес: <http://www.becom.at/de/download/>

Cyprus

Με την παρούσα ο/η BECOM Electronics GmbH, δηλώνει ότι ο ραδιοεξοπλισμός EWS4 πληροί την οδηγία 2014/53/ΕΕ.

Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: <http://www.becom.at/de/download/>

Czech Republic

Tímto BECOM Electronics GmbH prohlašuje, že typ rádiového zařízení EWS4 je v souladu se směrnicí 2014/53/EU.

Úplné znění EU prohlášení o shodě je k dispozici na této internetové adrese:

<http://www.becom.at/de/download/>

Germany

Hiermit erklärt BECOM Electronics GmbH, dass der Funkanlagentyp EWS4 der Richtlinie 2014/53/EU entspricht.

Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: <http://www.becom.at/de/download/>

Denmark

Hermed erklærer BECOM Electronics GmbH, at radioudstyrstypen EWS4 er i overensstemmelse med direktiv 2014/53/EU. EU-overensstemmelseserklæringens fulde tekst kan findes på følgende internetadresse: <http://www.becom.at/de/download/>

Estonia

Käesolevaga deklareerib BECOM Electronics GmbH, et käesolev raadioseadme tüüp EWS4 vastab direktiivi 2014/53/EL nõuetele.

ELi vastavusdeklaratsiooni täielik tekst on kättesaadav järgmisel internetiaadressil: <http://www.becom.at/de/download/>

Spain

Por la presente, BECOM Electronics GmbH declara que el tipo de equipo radioeléctrico EWS4 es conforme con la Directiva 2014/53/UE.

El texto completo de la declaración UE de conformidad está disponible en la dirección Internet siguiente: <http://www.becom.at/de/download/>

Finland

BECOM Electronics GmbH vakuuttaa, että radiolaitetyypin EWS4 on direktiivin 2014/53/EU mukainen.

EU-vaatimustenmukaisuusvakuutus on täysimittainen teksti on saatavilla seuraavassa internetosoitteessa:
<http://www.becom.at/de/download/>

France

Le soussigné, BECOM Electronics GmbH, déclare que l'équipement radioélectrique du type EWS4 est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante : <http://www.becom.at/de/download/>

United Kingdom

Hereby, BECOM Electronics GmbH declares that the radio equipment type EWS4 is in compliance with Directive 2014/53/EU
The full text of the EU declaration of conformity is available at the following internet address: <http://www.becom.at/de/download/>

Greece

Με την παρούσα ο/η BECOM Electronics GmbH, δηλώνει ότι ο ραδιοεξοπλισμός EWS4 πληροί την οδηγία 2014/53/ΕΕ.
Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: <http://www.becom.at/de/download/>

Croatia

BECOM Electronics GmbH ovime izjavljuje da je radijska oprema tipa EWS4 u skladu s Direktivom 2014/53/EU.
Cjeloviti tekst EU izjave o sukladnosti dostupan je na sljedećoj internetskoj adresi: <http://www.becom.at/de/download/>

Hungary

BECOM Electronics GmbH igazolja, hogy a EWS4 típusú rádióberendezés megfelel a 2014/53/EU irányelvnek.
Az EU-megfelelőségi nyilatkozat teljes szövege elérhető a következő internetes címen: <http://www.becom.at/de/download/>

Ireland

Hereby, BECOM Electronics GmbH declares that the radio equipment type EWS4 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: <http://www.becom.at/de/download/>

Italy

Il fabbricante, BECOM Electronics GmbH, dichiara che il tipo di apparecchiatura radio EWS4 è conforme alla direttiva 2014/53/UE. Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: <http://www.becom.at/de/download/>

Lithuania

Aš, BECOM Electronics GmbH, patvirtinu, kad radijo įrenginių tipas EWS4 atitinka Direktyvą 2014/53/ES.

Visas ES atitikties deklaracijos tekstas prieinamas šiuo interneto adresu: <http://www.becom.at/de/download/>

Luxembourg

Le soussigné, BECOM Electronics GmbH, déclare que l'équipement radioélectrique du type EWS4 est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: <http://www.becom.at/de/download/>

Latvia

Ar šo BECOM Electronics GmbH deklarē, ka radioiekārta EWS4 atbilst Direktīvai 2014/53/ES. Pilns ES atbilstības deklarācijas teksts ir pieejams šādā interneta vietnē: <http://www.becom.at/de/download/>

Malta

B'dan, BECOM Electronics GmbH, niddikjara li dan it-tip ta' tagħmir tar-radju EWS4 huwa konformi mad-Direttiva 2014/53/UE. It-test kollu tad-dikjarazzjoni ta' konformità tal-UE huwa disponibbli f'dan l-indirizz tal-Internet li ġej: <http://www.becom.at/de/download/>

Netherlands

Hierbij verklaar ik, BECOM Electronics GmbH, dat het type radioapparatuur EWS4 conform is met Richtlijn 2014/53/EU. De volledige tekst van de EU-conformiteitsverklaring kan worden geraadpleegd op het volgende internetadres: <http://www.becom.at/de/download/>

Poland

BECOM Electronics GmbH niniejszym oświadcza, że typ urządzenia radiowego EWS4 jest zgodny z dyrektywą 2014/53/UE. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: <http://www.becom.at/de/download/>

Portugal

O(a) abaixo assinado(a) BECOM Electronics GmbH declara que o presente tipo de equipamento de rádio EWS4 está em conformidade com a Diretiva 2014/53/UE. O texto integral da declaração de conformidade está disponível no seguinte endereço de Internet: <http://www.becom.at/de/download/>

Romania

Prin prezenta, BECOM Electronics GmbH declară că tipul de echipamente radio EWS4 este în conformitate cu Directiva 2014/53/UE. Textul integral al declarației UE de conformitate este disponibil la următoarea adresă internet: <http://www.becom.at/de/download/>

Sweden

Härmed försäkrar BECOM Electronics GmbH att denna typ av radioutrustning EWS4 överensstämmer med direktiv 2014/53/EU. Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande webbadress: <http://www.becom.at/de/download/>

Slovenia

BECOM Electronics GmbH potrjuje, da je tip radijske opreme EWS4 skladen z Direktivo 2014/53/EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: <http://www.becom.at/de/download/>

Slovakia

BECOM Electronics GmbH týmto vyhlasuje, že rádiové zariadenie typu EWS4 je v súlade so smernicou 2014/53/EÚ.

Úplné EÚ vyhlásenie o zhode je k dispozícii na tejto internetovej adrese:

<http://www.becom.at/de/download/>

FCC Approval

Ring aerial in the ignition switch



To verify the authorization of the ignition key, the electronic immobilizer exchanges information with the ignition key via the ring aerial.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.



Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. ◀

Approbation de la FCC

Antenne annulaire présente dans le commutateur d'allumage



Pour vérifier l'autorisation de la clé de contact, le système d'immobilisation électronique échange des informations avec la clé de contact via l'antenne annulaire.

Le présent dispositif est conforme à la partie 15 des règles de la FCC. Son utilisation est soumise aux deux conditions suivantes :

- (1) Le dispositif ne doit pas produire d'interférences nuisibles, et
- (2) le dispositif doit pouvoir accepter toutes les interférences extérieures, y compris celles qui pourraient provoquer une activation inopportune.



Toute modification qui n'aurait pas été approuvée expressément par l'organisme responsable de l'homologation peut annuler l'autorisation accordée à l'utilisateur pour utiliser le dispositif. ◀

Declaration of Conformity

Radio equipment anti-theft alarm (DWA)

Simplified EU Declaration of Conformity acc. Radio Equipment Directive 2014/53/EU after 12.06.2016 and during transition period



Technical information

Frequency Band:
433.05-434.79 MHz
Output Power: 10 mW e.r.p.

Manufacturer and Address

Manufacturer: Meta System S.p.A.
Address: Via Galimberti 5 42124
Reggio Emilia - Italy

Austria

Hiermit erklärt Meta System S.p.A., dass der Funkanlagentyp TXBMWMR der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: <https://docs.metasystem.it/>

Belgium

Le soussigné, Meta System S.p.A., déclare que l'équipement radioélectrique du type TXBMWMR est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: <https://docs.metasystem.it/>

Bulgaria

С настоящото Meta System S.p.A. декларира, че този тип радиосъоръжение TXBMWMR е в съответствие с Директива 2014/53/ЕС. Цялостният текст на ЕС декларацията за съответствие може да се намери на следния интернет адрес: <https://docs.metasystem.it/>

Cyprus

Με την παρούσα ο/η Meta System S.p.A., δηλώνει ότι ο ραδιοεξοπλισμός TXBMWMR πληροί την οδηγία 2014/53/ΕΕ. Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: <https://docs.metasystem.it/>

Czech Republic

Tímto Meta System S.p.A. prohlašuje, že typ rádiového zařízení TXBMWMR je v souladu se směrnicí 2014/53/EU. Úplné znění EU prohlášení o shodě je k dispozici na této internetové adrese: <https://docs.metasystem.it/>

Germany

Hiermit erklärt Meta System S.p.A., dass der Funkanlagentyp TXBMWMR der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: <https://docs.metasystem.it/>

Denmark

Hermed erklærer Meta System S.p.A., at radioudstyrstypen TXBMWMR er i overensstemmelse med direktiv 2014/53/EU. EU-overensstemmelseserklæringens fulde tekst kan findes på følgende internetadresse: <https://docs.metasystem.it/>

Estonia

Käesolevaga deklareerib Meta System S.p.A., et käesolev raadioseadme tüüp TXBMWMR vastab direktiivi 2014/53/EL nõuetele. ELi vastavusdeklaratsiooni täielik tekst on kättesaadav järgmisel internetiaadressil: <https://docs.metasystem.it/>

Spain

Por la presente, Meta System S.p.A. declara que el tipo de equipo radioeléctrico TXBMWMR es conforme con la Directiva 2014/53/UE. El texto completo de la declaración UE de conformidad está disponible en la dirección Internet siguiente: <https://docs.metasystem.it/>

Finland

Meta System S.p.A. vakuuttaa, että radiolaitetyyppi TXBMWMR on direktiivin 2014/53/EU mukainen. EU-vaatimustenmukaisuusvakuutuksen täysimittainen teksti on saatavilla seuraavassa internetosoitteessa: <https://docs.metasystem.it/>

France

Le soussigné, Meta System S.p.A., déclare que l'équipement radioélectrique du type TXBMWMMR est conforme à la directive 2014/53/UE

Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante : <https://docs.metasystem.it/>

United Kingdom

Hereby, Meta System S.p.A. declares that the radio equipment type TXBMWMMR is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://docs.metasystem.it/>

Greece

Με την παρούσα ο/η Meta System S.p.A., δηλώνει ότι ο ραδιοεξοπλισμός TXBMWMMR πληροί την οδηγία 2014/53/ΕΕ. Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: <https://docs.metasystem.it/>

Croatia

Meta System S.p.A. ovime izjavljuje da je radijska oprema tipa TXBMWMMR u skladu s Direktivom 2014/53/EU. Cjeloviti tekst EU izjave o sukladnosti dostupan je na sljedećoj internetskoj adresi: <https://docs.metasystem.it/>

Hungary

Meta System S.p.A. igazolja, hogy a TXBMWMMR típusú rádióberendezés megfelel a 2014/53/EU irányelvnek. Az EU-megfelelőségi nyilatkozat teljes szövege elérhető a következő internetes címen: <https://docs.metasystem.it/>

Ireland

Hereby, Meta System S.p.A. declares that the radio equipment type TXBMWMMR is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://docs.metasystem.it/>

Italy

Il fabbricante, Meta System S.p.A., dichiara che il tipo di apparecchiatura radio TXBMWMMR è conforme alla direttiva 2014/53/UE. Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: <https://docs.metasystem.it/>

Lithuania

Aš, Meta System S.p.A., patvirtinu, kad radijo įrenginių tipas TXBMWMR atitinka Direktyvą 2014/53/ES.

Visas ES atitikties deklaracijos tekstas prieinamas šiuo interneto adresu: <https://docs.metasystem.it/>

Luxembourg

Le soussigné, Meta System S.p.A., déclare que l'équipement radioélectrique du type TXBMWMR est conforme à la directive 2014/53/UE.

Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: <https://docs.metasystem.it/>

Latvia

Ar šo Meta System S.p.A. deklarē, ka radioiekārta TXBMWMR atbilst Direktīvai 2014/53/ES.

Pilns ES atbilstības deklarācijas teksts ir pieejams šādā interneta vietnē: <https://docs.metasystem.it/>

Malta

B'dan, Meta System S.p.A., niddikjara li dan it-tip ta' tagħmir tar-radju TXBMWMR huwa konformi mad-Direttiva 2014/53/UE.

It-test kollu tad-dikjarazzjoni ta' konformità tal-UE huwa disponibbli f'dan l-indirizz tal-Internet li ġej: <https://docs.metasystem.it/>

Netherlands

Hierbij verklaar ik, Meta System S.p.A., dat het type radioapparatuur TXBMWMR conform is met Richtlijn 2014/53/EU.

De volledige tekst van de EU-conformiteitsverklaring kan worden geraadpleegd op het volgende internetadres: <https://docs.metasystem.it/>

Poland

Meta System S.p.A. niniejszym oświadcza, że typ urządzenia radiowego TXBMWMR jest zgodny z dyrektywą 2014/53/UE. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: <https://docs.metasystem.it/>

Portugal

O(a) abaixo assinado(a) Meta System S.p.A. declara que o presente tipo de equipamento de rádio TXBMWMR está em conformidade com a Diretiva 2014/53/UE.

O texto integral da declaração de conformidade está disponível no seguinte endereço de Internet: <https://docs.metasystem.it/>

Romania

Prin prezenta, Meta System S.p.A. declară că tipul de echipamente radio TXBMWMR este în conformitate cu Directiva 2014/53/UE. Textul integral al declarației UE de conformitate este disponibil la următoarea adresă internet: <https://docs.metasystem.it/>

Sweden

Härmed försäkrar Meta System S.p.A. att denna typ av radioutrustning TXBMWMR överensstämmer med direktiv 2014/53/EU. Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande webbadress: <https://docs.metasystem.it/>

Slovenia

Meta System S.p.A. potrjuje, da je tip radijske opreme TXBMWMR skladen z Direktivo 2014/53/EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: <https://docs.metasystem.it/>

Slovakia

Meta System S.p.A. týmto vyhlasuje, že rádiové zariadenie typu TXBMWMR je v súlade so smernicou 2014/53/EÚ. Úplné EÚ vyhlásenie o zhode je k dispozícii na tejto internetovej adrese: <https://docs.metasystem.it/>

208 INDEX

A

Abbreviations and symbols, 4

ABS

Engineering details, 98

Indicator and warning

light, 30

Self-diagnosis, 84

Accessories

General instructions, 140

Adaptive Headlight, 106

Engineering details, 106

Ambient temperature

Outside temperature

warning, 29

Anti-theft alarm

activating, 53

adjusting, 54

deactivating, 54

Indicator light, 19

operating, 53

Warning, 31

ASC

Engineering details, 102

Indicator and warning

light, 30

operating, 55

Self-diagnosis, 85

switching off, 55

switching on, 55

Average consumption

Display: CONS, 47

Average speed

Display: SPEED, 47

Average values

resetting, 48

B

Battery

Maintenance instructions, 132

Position on the vehicle, 16

recharging connected

battery, 132

recharging disconnected

battery, 133

Replacing battery, 134

Technical data, 167

Vehicle voltage too low, 29

Beam throw

adjusting, 65

Brake fluid

Checking fluid level,

front, 117

Checking fluid level, rear, 118

Reservoir, front, 15

Reservoir, rear, 15

Brake pads

checking front, 114

checking rear, 115

Running in, 87

Brakes

ABS Pro, 100

ABS Pro depending on riding
mode, 89

Adjusting handbrake lever, 67

Checking function, 114

Checking operation, 114

Dynamic Brake Control

depending on riding

mode, 89

Safety instructions, 87

Technical data, 166

Wear indicator, 116

C

Care

Chrome, 154

Paintwork preservation, 155

Chassis and suspension

Technical data, 165

Checklist, 82

Clock
 Display: CLOCK, 45
 Setting clock, 49
 Clutch
 Adjusting clutch lever, 66
 Checking function, 119
 Fluid reservoir, 14
 Technical data, 163
 Coolant temperature
 Display: ENG TMP, 45
 Cruise control
 operating, 57
 Currency, 6
 Current consumption
 Display: CONS C, 47
D
 Damping
 adjusting, 70
 Date
 Display: DATE, 47
 Setting date, 50
 Daytime riding lights
 automatic daytime riding
 light, 42
 Diagnostic connector
 disengaging, 135
 securing, 136
 Dimensions
 Technical data, 168
 Display
 Adjusting display bright-
 ness, 49
 Distance recorders
 resetting, 48
 DTC
 Engineering details, 102
 Self-diagnosis, 86
 switching on, 55

Dynamic Brake Control, 101
 Engineering details, 101
 Dynamic engine brake
 control, 105
E
 Electrical system
 Technical data, 167
 Emergency off switch (kill
 switch), 18
 operating, 40
 Engine, 28
 Engine electronics indicator
 light, 27
 Severe fault, 27
 starting, 83
 Technical data, 163
 Engine oil
 Checking fill level, 112
 Filler neck, 15
 Fill-level indicator, 14
 Technical data, 162
 topping up, 113
 Equipment, 5
F
 Final drive
 Technical data, 164
 Frame
 Technical data, 164
 Front-wheel stand
 installing, 111
 Fuel
 Filler neck, 14
 Fuel reserve, 32
 Refuelling, 91
 Technical data, 162
 Fuel reserve
 Display distance: KM R, 45
 Indicator light, 32

210 INDEX

Fuses

- Fuse assignment, 135
- replacing, 134
- Technical data, 167

G

General views

- Indicator and warning lights, 22
- Instrument cluster, 19
- Left multifunction switch, 17
- left side of vehicle, 14
- Multifunction displays, 23
- Right handlebar fitting, 18
- right side of vehicle, 15
- Underneath the seat, 16

H

Hazard warning flashers

- Control, 17
- operating, 43

Headlight

- Adjusting headlight beam throw, 65
- Adjustment for right-hand/left-hand traffic, 65
- Headlight beam throw, 65

Headlight courtesy delay

- feature, 41

Heated handlebar grips

- operating, 59

Horn, 17

I

Ignition

- switching off, 39
- switching on, 38

Immobiliser

- Spare key, 39
- Warning, 27

Indicator lights, 19

- Overview, 22

Instrument cluster

- Ambient-light brightness sensor, 19
- Overview, 19
- Setting units, 51

J

Jump-starting, 130

K

Keys, 38

L

Lighting

- Indicator light for faulty bulb, 29
- Replacing LED light sources, 129
- Technical data, 168

Lights

- automatic daytime riding light, 42
- Control, 17
- Headlight courtesy delay feature, 41
- Headlight flasher, operating, 41
- High-beam headlight, operating, 41
- Low-beam headlight, 40
- Parking lights, operating, 41
- Side light, 41

Luggage

- lashing, 141

M

- Maintenance
 - Maintenance schedule, 176
- Maintenance confirmations, 177
- Maintenance intervals, 174
- Mirrors
 - adjusting, 64
- Mobility services, 174
- Motorcycle
 - care, 150
 - cleaning, 150
 - lashing, 93
 - laying up, 155
 - parking, 90
 - restoring to use, 155
- Multifunction display, 19
 - Exiting SETUP, 52
 - Overview, 23
 - Selecting reading, 45
 - SETUP, 49
- Multifunction switch
 - Overview, left side, 17
 - Overview, right side, 18

O

- Odometer
 - Display: KM, 45
- On-board voltage
 - Display: VOLTGE, 47

P

- Parking, 90
- Passenger frame
 - installing, 145
 - removing, 142
- Passenger seat
 - installing, 60
 - Lock, 15
 - removing, 60

- Payload table
 - Sign, 16
- Performance figures
 - Technical data, 169
- Power socket
 - Position on the vehicle, 14
- Pre-Ride-Check, 83

R

- Rear-wheel stand
 - installing, 112
- Refuelling, 91
- Rev. counter, 19
- Rider's seat
 - installing, 60
 - removing, 60
- Riding mode, 56
 - Engineering details, 103
- Riding time
 - Display: RDTIME, 47
- Running in, 86

S

- Safety instructions
 - for brakes, 87
 - for riding, 80
- Screw connections, 159
- Service, 173
 - Reporting safety-relevant defects, 172
 - Service history, 173
- Service-due indicator, 33
- Settings
 - Display: SETUP ENTER, 45
- SETUP
 - exiting, 52
 - resetting, 52
 - selecting, 49
- Spark plugs
 - Technical data, 167
- Speedometer, 19, 23

212 INDEX

Spring preload

Adjuster, rear, 15

adjusting, 68

Starting, 83

Control, 18

Steering lock, 38

T

Tail-hump cover, 147, 148

Technical data

Battery, 167

Brakes, 166

Chassis and suspension, 165

Clutch, 163

Dimensions, 168

Electrical system, 167

Engine, 163

Engine oil, 162

Final drive, 164

Frame, 164

Fuel, 162

Fuses, 167

General notes, 5

Lighting, 168

Performance figures, 169

Spark plugs, 167

Standards, 5

Transmission, 164

Weights, 168

Wheels and tyres, 166

Toolkit

Position on the vehicle, 16

Torques, 159

Traction control

ASC, 102

DTC, 102

Transmission

Technical data, 164

Trip recorder

Display: KM 1 or KM A, 45

Troubleshooting chart, 158

Turn indicators

Control, 17

operating, 43

Type plate

Position on the vehicle, 14

Tyre pressures

Sign, 16

Tyres

Checking inflation pressure, 119

Checking tread depth, 119, 120

Checking tyre pressure, 119

Pressures, 167

Running in, 87

Technical data, 166

U

USB charging socket

Position on the vehicle, 14

V

Vehicle Identification Number

Position on the vehicle, 15

W

Warning indicator lights, 28

ABS, 30

Anti-theft alarm, 31

ASC/DTC, 30

Bulb faulty, 29

Electronic immobiliser, 27

Engine electronics, 27

Engine warning, 27

Fuel reserve, 32

Mode of presentation, 24

Outside temperature

warning, 29

- Overview, 22
- Vehicle voltage too low, 29
- Warning light, drive malfunction, 28
- Warning lights, 19
- Warnings, overview, 25
- Weights
 - Technical data, 168
- Wheels
 - Change of size, 120
 - Checking rims, 120
 - Checking spokes, 120
 - Installing front wheel, 123
 - Installing rear wheel, 127
 - Removing front wheel, 121
 - Removing rear wheel, 126
 - Technical data, 166

Details described or illustrated in this booklet may differ from the vehicle's actual specification as purchased, the accessories fitted or the national-market specification. No claims will be entertained as a result of such discrepancies.

Dimensions, weights, fuel consumption and performance data are quoted to the customary tolerances.

The right to modify designs, equipment and accessories is reserved.

Errors and omissions excepted.

© 2020 Bayerische Motoren
Werke Aktiengesellschaft
80788 Munich, Germany
Not to be reproduced by any
means whatsoever, wholly or in
part, without the written per-
mission of BMW Motorrad,
After Sales.
Original rider's manual, printed
in Germany.

Important data for refuelling:

Fuel

Recommended fuel grade



Premium unleaded (maximum 15% ethanol, E15)



95 ROZ/RON
90 AKI

Alternative fuel grade



Regular unleaded (maximum 15% ethanol, E15)



91 ROZ/RON
87 AKI

Usable fuel capacity

approx. 18 l

Reserve fuel

approx. 3.5 l

Tyre pressures

Tyre pressure, front

2.5 bar, tyre cold

Tyre pressure, rear

2.7 bar, One-up, tyre cold
2.9 bar, two-up and with luggage,
tyre cold

You can find further information on all aspects
of your vehicle at: bmw-motorrad.com

BMW recommends **ADVANTEC**
ORIGINAL BMW ENGINE OIL

Order No.: 01 40 9 830 251
06.2020, 1st edition, 01

