



**BMW
MOTORRAD**

RIDER'S MANUAL

M 1000 RR



MAKE LIFE A RIDE

Vehicle data

Model

Vehicle Identification Number

Colour code

Date of first registration

Registration number

Dealership details

Person to contact in Service department

Ms/Mr

Phone number

Dealership address/phone number (company stamp)

YOUR BMW.

We congratulate you on your choice of a vehicle from BMW Motorrad and welcome you to the community of BMW riders. Familiarise yourself with your new vehicle so that you can ride it safely and confidently in all traffic situations.

About this rider's manual

Read this rider's manual carefully before starting to use your new BMW. It contains important information on how to operate the controls and how to make the best possible use of all your BMW's technical features.

In addition, it contains information on maintenance and care to help you maintain your vehicle's reliability and safety, as well as its value.

If the time comes to sell your BMW, please remember to hand over this rider's manual to the new owner. It is an important part of the vehicle.

We hope you will enjoy riding your BMW and that all your journeys will be pleasant and safe

BMW Motorrad.

01 GENERAL INSTRUCTIONS	2	04 OPERATION	44
Overview	4	Ignition switch/steering lock	46
Abbreviations and symbols	4	Emergency-off switch (kill switch)	47
Equipment	5	Lights	48
Technical data	5	Hazard warning lights	49
Currency	6	Turn indicators	50
Additional sources of information	6	Dynamic Traction Control (DTC)	50
Certificates and operating licences	6	Riding mode	52
Data memory	6	Adaptive cruise control	53
		Hill Start Control	55
		Shift light	57
		Anti-theft alarm (DWA)	58
		Heated grips	59
		On-board computer	60
		Front and rear seats	61
02 GENERAL VIEWS	12	05 TFT DISPLAY	64
General view, left side	14	General notes	66
General view, right side	15	Principle	67
Under the rider's seat	16	Pure Ride view	73
Multifunction switch, left	17	General settings	74
Multifunction switch, right	18	Bluetooth	75
Instrument cluster	19	My vehicle	78
		Navigation	81
03 STATUS INDICATORS	20	Media	83
Indicator and warning lights	22	Telephone	83
TFT display in Pure Ride view	23	Display software version	84
TFT display in Menu view	24	Display licence information	84
Warning indicators	25		

06 ADJUSTMENT	86	Launch Control	130
Mirrors	88	Pit Lane Limiter	132
Headlight	88	DTC	133
Brakes	88	Chassis and suspension settings for racing	135
Adjusting clutch lever	89	Removing and installing mirrors	135
Footrest system	90	Removing and installing number-plate carrier	139
Steering	92	Switching off ABS when riding on the race track	144
Spring preload	93	Gearshift-pattern reverser	145
Damping	95		
Swinging arm	98	09 ENGINEERING DETAILS	148
Riding height	101	General notes	150
		Antilock Brake System (ABS)	150
07 RIDING	104	Dynamic Traction Control (DTC)	153
Safety information	106	Riding mode	155
Regular check	108	Dynamic Brake Control	157
Starting	109	Gear Shift Assistant	158
Running in	111	Hill Start Control (Hill Start Control Pro)	159
Shifting gear	112		
Shift light	113	10 MAINTENANCE	162
Brakes	114	General notes	164
Parking your motorcycle	116	Toolkit	165
Refuelling	117	Front-wheel stand	166
Securing motorcycle for transportation	119		
08 ON THE RACE TRACK	122		
Status indicators for racing	124		
LAPTIMER	127		
Vehicle settings for racing	128		
RACE PRO riding modes	129		

Rear-wheel stand	166
Engine oil	167
Brake system	168
Clutch	173
Coolant	174
Tyres	175
Wheel rims	176
Wheels	176
Chain	183
Lighting	187
Trim panel components	187
Jump-starting	191
Battery	192
Fuses	194
Diagnostic connector	196

11 ACCESSORIES 198

General notes	200
Connector for optional accessories	200
USB charging socket	202

12 CARE 204

Care products	206
Washing the vehicle	206
Cleaning easily damaged components	207
Care of paintwork	208
Paintwork preservation	209
Laying up motorcycle	209
Restoring motorcycle to use	209

13 TECHNICAL DATA 210

Troubleshooting chart	212
Threaded fasteners	214
Fuel	217
Engine oil	218
Coolant	218
Engine	218
Clutch	219
Transmission	219
Final drive	219
Frame	220
Chassis and suspension	220
Brakes	221
Wheels and tyres	221
Electrical system	222
Anti-theft alarm	223
Dimensions	223
Weights	224
Performance figures	224

14 SERVICE 226

Reporting safety-relevant defects	228
BMW Motorrad Service	229
BMW Motorrad Service history	229
BMW Motorrad mobility services	230
Maintenance work	230
BMW Service	230
Maintenance schedule	232
Maintenance confirmations	233

Service confirmations	247
------------------------------	------------

APPENDIX	250
-----------------	------------

Declaration of conformity for electronic immobiliser (EWS)	251
---	------------

Certificate for electronic immobiliser (EWS)	257
---	------------

Declaration of conformity for TFT	259
--	------------

Certificate for TFT	265
----------------------------	------------

Declaration of conformity for anti-theft alarm system (DWA)	268
--	------------

INDEX	274
--------------	------------

GENERAL INSTRUCTIONS

01

OVERVIEW	4
ABBREVIATIONS AND SYMBOLS	4
EQUIPMENT	5
TECHNICAL DATA	5
CURRENCY	6
ADDITIONAL SOURCES OF INFORMATION	6
CERTIFICATES AND OPERATING LICENCES	6
DATA MEMORY	6

4 GENERAL INSTRUCTIONS

OVERVIEW

An important aspect of this rider's manual is that it can be used for quick and easy reference. Consulting the extensive index at the end of this rider's manual is the fastest way to find information on a particular topic or item. To first read an overview of your motorcycle, please go to Chapter 2. All maintenance and servicing work on the motorcycle is documented in the "Service" section. The record of the maintenance work you have had performed on your vehicle is a precondition for generous treatment of goodwill claims.

ABBREVIATIONS AND SYMBOLS

 **CAUTION** Low-risk hazard. Non-avoidance can lead to slight or moderate injury.

 **WARNING** Medium-risk hazard. Non-avoidance can lead to fatal or severe injury.

 **DANGER** High-risk hazard. Non-avoidance leads to fatal or severe injury.



ATTENTION Special notes and precautionary measures. Non-compliance can lead to damage to the vehicle or accessory and, consequently, to voiding of the warranty.



NOTICE Specific instructions on how to operate, control, adjust or look after items of equipment on the vehicle.

- Instruction.
- » Result of an activity.
-  Reference to a page with more detailed information.
- ◁ Indicates the end of a passage relating to specific accessories or items of equipment.
-  Tightening torque.
-  Technical data.
- NV National-market version.

OE	Optional equipment. The vehicles are assembled complete with all the BMW Motorrad optional equipment originally ordered.
OA	Optional accessories. You can obtain BMW Motorrad optional accessories through your authorised BMW Motorrad dealer; optional accessories have to be retrofitted to the vehicle.
ABS	Anti-lock brake system.
DTC	Dynamic Traction Control.
DWA	Anti-theft alarm.
EWS	Electronic immobiliser.

EQUIPMENT

When you ordered your BMW Motorrad, you chose various items of custom equipment. These operating instructions describe the optional equipment (OE) offered by BMW and selected optional accessories (OA). This explains why the manual

may also contain descriptions of equipment that you might not have selected. Please note, too, that on account of country-specific differences, your motorcycle might not be exactly as illustrated.

If your motorcycle contains equipment that has not been described, its description can be found in a separate manual.

TECHNICAL DATA

All dimensions, weights and power ratings stated in the operating instructions are quoted to the standards and comply with the tolerance requirements of the Deutsches Institut für Normung e.V. (DIN). Technical data and specifications in this rider's manual serve as reference points. The vehicle-specific data may deviate from these, for example as a result of selected optional equipment, the national-market version or country-specific measuring procedures. Detailed values can be taken from the vehicle registration documents, or can be obtained from your authorised BMW Motorrad retailer or another qualified service partner or specialist workshop. The specifications in

6 GENERAL INSTRUCTIONS

the vehicle documents always have priority over the information provided in this rider's manual.

CURRENCY

The high safety and quality standards of BMW motorcycles are maintained by constant development work on designs, equipment and accessories. Because of this, your motorcycle may differ from the information supplied in the Rider's Manual. Nor can BMW Motorrad entirely rule out errors and omissions. We hope you will appreciate that no claims can be entertained on the basis of the data, illustrations or descriptions in these operating instructions.

ADDITIONAL SOURCES OF INFORMATION

Authorised BMW Motorrad retailer

Your authorised BMW Motorrad retailer will be happy to answer any questions you may have.

Internet

The operating instructions for your vehicle, operating and installation instructions for accessories and general information about BMW Motorrad, in relation to technology, for example, are available for download from **www.bmw-motorrad.com/manuals**.

CERTIFICATES AND OPERATING LICENCES

The certificates for the vehicle and the official operating licences for accessories can be downloaded from **bmw-motorrad.com/certification**.

DATA MEMORY

General

Control units are installed in the vehicle. Control units process data that they receive, for example, from vehicle sensors, or that they generate themselves or exchange between each other. Some control units are required for the vehicle to function safely or provide assistance during riding, for example assistance systems. In addition, control units enable comfort or infotainment functions.

Information on data that has been stored or exchanged can be obtained from the manufacturer of the vehicle, for example via a separate booklet.

Personal reference

Each vehicle is identified with a clear vehicle identification number. Depending on the country, the vehicle identification number, the number plate and the corresponding authorities can be referenced to ascertain the vehicle owner. There are also other ways to use data obtained from the vehicle to trace the rider or vehicle owner, for example using the Connected-Drive user account.

Data protection rights

In accordance with applicable data protection laws, vehicle users have certain rights in relation to the manufacturer of the vehicle or in relation to companies which collect or process personal data. Vehicle users have the right to obtain full information at no cost from persons or entities storing personal data of the vehicle user.

These entities may include:

- Manufacturer of the vehicle
- Qualified service partners
- Specialist workshops
- Service providers

Vehicle users have the right to request information on what personal data has been stored, for what purpose the data is used, and where the data comes from. To obtain this information, proof of ownership or use is required.

The right to information also includes information about data that has been shared with other companies or entities. The website of the vehicle manufacturer contains the applicable data protection information. This data protection information includes information on the right to have data deleted or corrected. The manufacturer of the vehicle also provides their contact details and those of the data protection officer on their website.

The vehicle owner can also request that a BMW Motorrad Retailer or another qualified service partner or specialist workshop read out the data that is stored in the vehicle for a charge.

8 GENERAL INSTRUCTIONS

The vehicle data is read out using the legally prescribed socket for on-board diagnosis (OBD) in the vehicle.

Legal requirements for the disclosure of data

As part of its legal responsibilities, the manufacturer of the vehicle is obligated to make its stored data available to the relevant authorities. This data is provided in the required scope in individual cases, for example to clarify a criminal offence. In the context of applicable laws, public agencies are entitled in individual cases to read out data from the vehicle themselves.

Operating data in the vehicle

Control units process data to operate the vehicle.

This includes, for example:

- Status reports of the vehicle and its individual components, for example wheel revolutions, wheel speed, deceleration
- Environmental conditions, for example temperature

The data is only processed in the vehicle itself and is generally non-permanent. The data is not stored beyond the operating period.

Electronic components, for example control units, contain components for storing technical information. Information can be temporarily or permanently stored on the vehicle condition, component loads, incidents or errors.

This information is generally used to document the condition of a component, a module, a system or the surrounding area, for example:

- Operating conditions of system components, for example filling levels, tyre pressure
- Malfunctions and faults in important system components, for example light and brakes
- Response of the vehicle in special riding situations, for example engagement of the driving dynamics systems
- Information on incidents resulting in damage to the vehicle

The data is necessary for the provision of control unit functions. Furthermore, the data is used to detect and rectify malfunctions and to enable the vehicle manufacturer to optimise vehicle functions.

The vast majority of this data is non-permanent and is only processed in the vehicle it-

self. Only a small amount of the data is stored in incident or fault memories as required by events.

If services are accessed, for example repairs, service processes, warranty cases and quality assurance measures, this technical information can be read out of the vehicle together with the vehicle identification number.

The information can be read out by a BMW Motorrad Retailer or another qualified service partner or specialist workshop. The legally stipulated socket for on-board diagnosis (OBD) in the vehicle is used to read out the data. The data is obtained, processed and used by the relevant parts of the retailer network. The data is used to document the technical conditions of the vehicle, to help with error localization, to comply with warranty obligations and to improve quality.

In addition, the manufacturer has various product monitoring obligations arising from product liability legislation. To meet these obligations, the vehicle manufacturer requires

technical data from the vehicle. The data from the vehicle can also be used to check warranty claims from the customer. Error and incident memories in the vehicle can be reset during servicing or repair work by a BMW Motorrad Retailer or another qualified service partner or specialist workshop.

Data input and data transfer in the vehicle

General

Depending on the equipment, comfort and customised settings can be stored in the vehicle and can be changed or reset at any time.

This includes, for example:

- Chassis and suspension settings

If required, data can be entered in the entertainment and communication system of the vehicle, for example using a smartphone.

Depending on the individual equipment, this includes:

- Multimedia data, such as music for playback
- Contacts data for use in connection with a communication system or an integrated navigation system
- Entered destinations

10 GENERAL INSTRUCTIONS

–Data on the use of internet services. This data can be stored locally in the vehicle or is located on a device that is connected to the vehicle, for example smartphone, USB stick, MP3 player. If this data is stored in the vehicle, the data can be deleted at any time.

This data is transferred to third parties only if personally requested within the context of using online services. This depends on the selected settings when using the services.

Incorporation of mobile end devices

Depending on the equipment, mobile end devices connected to the vehicle, for example smartphones, can be controlled using the operating elements of the vehicle.

The image and sound of the mobile end device can then be output via the multimedia system. At the same time, specific information is transferred to the mobile end device. Depending on the type of integration, this includes, for example, position data and additional general vehicle information. This enables optimal use of the

selected apps, for example navigation or music playback. The type of additional data processing is determined by the provider of the respective app. The scope of the possible settings depends on the corresponding app and the operating system of the mobile end device.

Services

General

If the vehicle has a wireless connection, this enables the exchange of data between the vehicle and other systems. The wireless connection is enabled by the vehicle's own transmitter and receiver unit or using personally integrated mobile end devices, for example smartphones. Online functions can be used using this wireless connection. These include online services and apps that are provided by the vehicle manufacturer or by other providers.

Services of the vehicle manufacturer

For online services of the vehicle manufacturer, the individual functions are described at suitable points, for example rider's manual, website of the manufacturer. At the same time, information

is also provided on the relevant data protection law. Personal data may be used to provide online services. Data is exchanged using a secure connection, for example with the IT systems provided by the vehicle manufacturer.

Obtaining, processing and using personal data outside of the normal provision of services requires legal permission, contractual agreement or consent. It is also possible to have the entire data connection activated or deactivated. Statutory functions are excluded from this.

Services from other providers

When using online services from other providers, these services are subject to the responsibility and the data protection and operating conditions of the individual provider. The vehicle manufacturer has no influence on the content that is exchanged in this instance. Information on the type, scope and purpose of the data capture and use of personal data as part of the services of third parties can be ascertained from the individual provider.


GENERAL VIEWS

02


GENERAL VIEW, LEFT SIDE	14
GENERAL VIEW, RIGHT SIDE	15
UNDER THE RIDER'S SEAT	16
MULTIFUNCTION SWITCH, LEFT	17
MULTIFUNCTION SWITCH, RIGHT	18
INSTRUMENT CLUSTER	19

14 GENERAL VIEWS

GENERAL VIEW, LEFT SIDE




- 1 Rebound-stage damping, front wheel (➡ 96)
Spring preload at front wheel (➡ 93)
Compression-stage damping, front wheel (➡ 95)
- 2 Compression-stage damping, rear wheel (➡ 96)
Spring preload at rear wheel (➡ 94)
- 3 Lock for tail-hump cover (➡ 61)
- 4 Tyre pressures table
Chain settings
- 5 Rebound-stage damping, rear wheel (➡ 97)
- 6 Steering damper (➡ 92)

GENERAL VIEW, RIGHT SIDE


- 1** Brake-fluid reservoir, rear
(172)
- 2** Vehicle identification number (on the steering-head bearing)
Type plate (on steering-head bearing)
- 3** Brake-fluid reservoir, front
(171)
- 4** Coolant expansion tank
(174)
- 5** Engine oil level indicator
(167)
- 6** Oil filler opening (168)

16 GENERAL VIEWS

UNDER THE RIDER'S SEAT




- 1 Battery (➡ 192)
- 2 Payload table
- 3 Toolkit (➡ 165)
- 4 USB charging socket (➡ 202)
- 5 Diagnostic connector (➡ 196)
- 6 Fuses (➡ 194)

MULTIFUNCTION SWITCH, LEFT

- 1 Switch off DTC (▮▮▮ 50)
- 2 High-beam headlight and headlight flasher (▮▮▮ 48)
- 3 Adaptive cruise control (▮▮▮ 53)
- 4 Hazard warning lights (▮▮▮ 49)
- 5 Adapt DTC (▮▮▮ 133)
- 6 Turn indicators (▮▮▮ 50)
- 7 Horn
- 8 Multi-Controller Controls (▮▮▮ 67)
- 9 MENU rocker button (▮▮▮ 67)


18 GENERAL VIEWS

MULTIFUNCTION SWITCH, RIGHT



- 1** Heated grips (▮▮▮▮▶ 59)
- 2** Riding mode (▮▮▮▮▶ 52)
- 3** Emergency-off switch (kill switch) (▮▮▮▮▶ 47)
- 4** Starter button (▮▮▮▮▶ 109)
Race start with Launch Control (▮▮▮▮▶ 130)

INSTRUMENT CLUSTER



- 1** Indicator and warning lights (➡ 22)
- 2** Shift light (➡ 113)
- 3** TFT display (➡ 23)
- 4** DWA light-emitting diode (➡ 58)
- 5** Photosensor (for adapting the brightness of the instrument lighting)


STATUS INDICATORS

03

INDICATOR AND WARNING LIGHTS	22
TFT DISPLAY IN PURE RIDE VIEW	23
TFT DISPLAY IN MENU VIEW	24
WARNING INDICATORS	25


22 STATUS INDICATORS

INDICATOR AND WARNING LIGHTS



- 1** Turn indicators, left
(50)
- 2** High-beam headlight
(48)
- 3** General warning light
(25)
- 4** Turn indicators, right
(50)
- 5** Warning light, drive mal-
function (35)
- 6** DTC (39)
- 7** ABS (144)


TFT DISPLAY IN PURE RIDE VIEW



- 1** Hill Start Control (➡ 41)
- 2** Rev. counter (➡ 73)
- 3** Speedometer
- 4** Top status line (➡ 71)
- 5** Adaptive cruise control (➡ 53)
- 6** RACE PRO riding mode (➡ 129)
- 7** Speed Limit Info (➡ 72)
Adapt DTC (➡ 133)
- 8** Riding mode (➡ 52)
- 9** Gear indicator; "N" indicates neutral.
- 10** Clock (➡ 74)
- 11** Connection status (➡ 76)
- 12** Muting (➡ 74)
- 13** Operating help
- 14** Heating stages, handlebar grips (➡ 59)

24 STATUS INDICATORS

TFT DISPLAY IN MENU VIEW



- | | |
|---|--|
| 1 Hill Start Control (➡ 41) | 13 Heating stages, handlebar grips (➡ 59) |
| 2 Speedometer | 14 Menu section |
| 3 Adaptive cruise control (➡ 53) | |
| 4 Speed Limit Info (➡ 72)
Adapt DTC (➡ 133) | |
| 5 RACE PRO riding mode (➡ 129) | |
| 6 Riding mode (➡ 52) | |
| 7 Top status line (➡ 71) | |
| 8 Gear indicator; "N" indicates neutral. | |
| 9 Clock (➡ 74) | |
| 10 Connection status (➡ 76) | |
| 11 Muting (➡ 74) | |
| 12 Operating help | |


WARNING INDICATORS

Mode of presentation

Warnings are indicated by the corresponding warning lights. Warnings are indicated by the 'General' warning light showing in combination with a dialogue in the TFT display. The 'General' warning light shows yellow or red, depending on the urgency of the warning.




The status of the 'General' warning light matches the most urgent warning. The possible warnings are listed on the next pages.



Check Control display

The messages differ in how they show on the display. Different colours and symbols are used depending on priority:

- Green CHECK OK **1**: no message, optimum values.
- White circle with small "i" **2**: information.
- Yellow warning triangle **3**: Warning, value not ideal.
- Red warning triangle **3**: Warning, value critical



Values display

Symbols **4** differ in how they show on the display. The colours used differ and reflect the urgency of the message. Along with numerical values with units, texts **5** are displayed as well:

Colour of the symbol

- Green: (OK) Current value is ideal.
- Blue: (Cold!) Current temperature is too low.
- Yellow: (Low! / High!) Current value is too low or too high.
- Red: (Hot! / High!) Current temperature or value is too high.


26 STATUS INDICATORS

–White: (---) No valid value available. Dashes are displayed instead of a numerical value.

 The assessment of some values is only possible from a certain journey duration or speed. If a measured value is still not being displayed because the conditions for measurement have not been met, dashes are displayed instead as a placeholder. If there are no valid measured values, there will be no assessment in the form of a coloured symbol.

ledged by tilting the Multi-Controller to the left.

–Check Control messages are dynamically attached as additional tabs on the pages in the *My vehicle* menu ( 69). You can go to the message again as long as the fault persists.



Check Control dialogue

Messages are output as Check Control dialogues **1**.

–If there are two or more Check Control messages of equal priority, the messages keep changing in the order of their occurrence until they are acknowledged.

–If symbol **2** is actively displayed, it can be acknow-

Warnings, overview

Indicator and warning lights	Display text	Meaning
	 is displayed in yellow.	Voltage of the vehicle electrical system too low (→ 31)
	 Vehicle voltage low.	
 lights up yellow.	 is displayed in yellow.	Voltage of the vehicle electrical system critical (→ 31)
	 Vehicle voltage critical!	
 flashes yellow.	 is displayed in yellow.	Charging voltage critical (→ 32)
	 Battery voltage critical!	
 lights up yellow.	 The faulty bulb is displayed.	Bulb faulty (→ 32)
 lights up yellow.	 Light control failure!	Vehicle lighting failed (→ 33)
	 Alarm system batt. capacity weak.	Anti-theft alarm battery weak (→ 33)
	 Alarm system battery empty.	Anti-theft alarm battery flat (→ 34)
 lights up yellow.	 Coolant temperature too high!	Coolant temperature too high (→ 34)
 lights up.	 Engine!	Drive malfunction (→ 35)
 flashes red.		Serious drive malfunction (→ 35)
 flashes.		

28 STATUS INDICATORS

Indicator and warning lights	Display text	Meaning
 lights up yellow.	 No communication with engine control.	Engine control failed (➡ 35)
 lights up.		
 lights up yellow.	 Fault in the engine control.	Engine in emergency-operation mode (➡ 35)
 flashes red.	 Serious fault in the engine control!	Serious fault in engine control (➡ 36)
	 Drop sensor faulty.	Drop sensor defective (➡ 36)
	 Cannot start engine.	Motorcycle dropped (➡ 37)
 lights up yellow.	 Side stand monitoring faulty.	Side stand monitoring is faulty (➡ 37)
 flashes.		ABS self-diagnosis not completed (➡ 37)
 lights up.	 Off!	ABS deactivated (➡ 37)
	 ABS deactivated.	
 lights up yellow.	 Limited ABS availability!	ABS fault (➡ 38)
 lights up.		
 lights up yellow.	 ABS failure!	ABS failed (➡ 38)
 lights up.		

Indicator and warning lights	Display text	Meaning
 lights up yellow.	 ABS Pro failure!	ABS Pro failed (▮▮▮ 38)
 lights up.		
 quick-flashes.		DTC intervention (▮▮▮ 39)
 slow-flashes.		DTC self-diagnosis not completed (▮▮▮ 39)
 lights up.	 Off!	DTC switched off (▮▮▮ 39)
	 Traction control deactivated.	
 lights up yellow.	 Traction control failure!	DTC fault (▮▮▮ 40)
 lights up.		
 lights up yellow.	 Traction control limited!	DTC restricted (▮▮▮ 40)
 lights up.		
	 Fuel reserve reached. Go to a filling station soon	Fuel down to reserve (▮▮▮ 41)
	 shows green.	Hill Start Control active (▮▮▮ 41)
	 flashes yellow.	Hill Start Control automatically deactivated (▮▮▮ 41)
	 is displayed.	Hill Start Control cannot be activated (▮▮▮ 41)

30 STATUS INDICATORS

Indicator and warning lights	Display text	Meaning
	flashes.	Gear not trained ( 42)
 flashes green.		Hazard warning lights system
 flashes green.		is switched on ( 42)
Shift light lights up or flashes.	L-Con not available. Clutch too hot. is displayed.	Launch Control not ready ( 42)
	 is displayed in white.	Service due ( 43)
	Service due!	
 lights up yellow.	 is displayed in yellow.	Service-due date has passed ( 43)
	Service over-due!	

Voltage of the vehicle electrical system too low



is displayed in yellow.



Vehicle voltage low. Switch off unnecessary consumers.

The voltage of the vehicle electrical system is too low. If you continue to ride the motorcycle the on-board electronics will drain the battery.

Possible cause:

Consumers with high power consumption are in operation (such as heated body warmers), too many consumers are in operation at one time, or battery faulty.

- Switch off non-essential consumers or disconnect them from the vehicle's electrical system.
- If the fault persists or occurs without consumers connected, have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

Voltage of the vehicle electrical system critical



lights up yellow.



is displayed in yellow.



Vehicle voltage critical! Consumers were switched off. Check battery condition.



WARNING

Failure of the vehicle systems

Risk of accident

- Do not continue your journey.

The voltage of the vehicle electrical system is critical. If you continue to ride the motorcycle the on-board electronics will drain the battery.

Possible cause:

Consumers with high power consumption are in operation (such as heated body warmers), too many consumers are in operation at one time, or battery faulty.

- Switch off non-essential consumers or disconnect them from the vehicle's electrical system.
- If the fault persists or occurs without consumers connected, have the fault rectified as quickly as possible by a specialist workshop, preferably an

32 STATUS INDICATORS

authorised BMW Motorrad retailer.

Charging voltage critical



flashes yellow.



is displayed in yellow.



Battery voltage critical! Accident risk. Stop driving.



WARNING

Failure of the vehicle systems

Risk of accident

- Do not continue your journey.

The battery is not being charged. If you continue to ride the motorcycle the on-board electronics will drain the battery.

Possible cause:

Alternator or alternator drive faulty, battery faulty or fuse has blown.

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

Bulb faulty



lights up yellow.



The faulty bulb is displayed:



High beam faulty!



Front left turn indicator faulty! or
Front right turn indicator faulty!



Low-beam headlight faulty!



Front side light faulty!



Tail light faulty!



Brake light faulty!



Rear left turn indicator faulty! or
Rear right turn indicator faulty!



Number plate light faulty!

—Have it checked by a specialist workshop.

**WARNING****Vehicle overlooked in traffic due to failure of the lights on the vehicle**

Safety risk

- Always replace a faulty bulb at the earliest possible opportunity. Consult a specialist workshop, preferably an authorised BMW Motorrad Retailer.

Possible cause:

One or more bulbs faulty.

- Identify faulty bulb or bulbs by visual check.
- Have LED light sources replaced as complete units; consult a specialist workshop, preferably an authorised BMW Motorrad retailer.



If the license-plate carrier is removed in preparation for a race-track session, the electronics interpret this as a defective light and the corresponding warning appears on the display. Deactivating the Light warnings function in the RACETRACK CONFIGURATION menu suppresses this warning.

Vehicle lighting failed

lights up yellow.



Light control failure! Have it checked by a specialist workshop.

**WARNING****Vehicle overlooked in traffic on account of failure of the vehicle lighting**

Safety risk

- Have the fault rectified as soon as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

The vehicle lighting has partially or completely failed.

Possible cause:

Light control has diagnosed a communication fault.

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

Anti-theft alarm battery weak –with anti-theft alarm (DWA)^{OE}

Alarm system batt. capacity weak. No restrictions. Make an

34 STATUS INDICATORS

appointment at a specialist workshop.

 This error message shows briefly only after the Pre-Ride-Check completes.

Possible cause:

The integral battery in the anti-theft alarm has lost a significant proportion of its original capacity. There is no assurance of how long the anti-theft alarm can remain operational if the vehicle's battery is disconnected.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad Retailer.

Anti-theft alarm battery flat —with anti-theft alarm (DWA) ^{OE}

 Alarm system battery empty. No independent alarm. Make an appointment at a specialist workshop.

 This error message shows briefly only after the Pre-Ride-Check completes.

Possible cause:

The integral battery in the anti-theft alarm has lost its entire original capacity. There is no assurance that the anti-theft alarm will be operational if the

vehicle's battery is disconnected.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad Retailer.

Coolant temperature too high

 lights up yellow.

 Coolant temperature too high! Check coolant level. Continue driving in part. load to cool down.



ATTENTION

Riding with overheated engine

Engine damage

- Compliance with the information set out below is essential.

Possible cause:

The coolant level is too low.

- Check the coolant level (➡ 174).

If the coolant level is too low:

- Allow the engine to cool down.
- Top up coolant (➡ 175).
- Have the cooling system checked by a specialist workshop, preferably by a BMW Motorrad partner.

Possible cause:

The coolant temperature is too high.

- If possible, ride in the part-load range to cool down the engine.
- If the coolant temperature is frequently too high, have the fault rectified as soon as possible by a specialist workshop, preferably an authorised BMW Motorrad Retailer.

Drive malfunction



lights up.



Engine! Have it checked by a specialist workshop.

Possible cause:

The engine control unit has diagnosed a fault that affects pollutant emissions and/or reduces power.

- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad retailer.
- » You can continue riding; pollutant emissions are higher than the threshold values.

Serious drive malfunction



flashes red.



flashes.

Possible cause:

The engine control unit has diagnosed a fault that can lead to damage to the exhaust system.

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

» It is possible to continue to ride but not recommended.

Engine control failed



lights up yellow.



lights up.



No communication with engine control. Multiple sys. affected. Ride carefully to the next specialist workshop.

Engine in emergency-operation mode



lights up yellow.



Fault in the engine control. Onward journey possible. Ride carefully to next specialist workshop.

36 STATUS INDICATORS



WARNING

Unusual ride characteristics when engine running in emergency-operation mode

Risk of accident

- Avoid accelerating sharply and overtaking.

Possible cause:

The engine control unit has diagnosed a fault. In exceptional cases, the engine stops and refuses to start. Otherwise, the engine runs in emergency operating mode.

- You can continue to ride, but bear in mind that the usual engine power or the full range of engine rpm might not be available.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad Retailer.

Serious fault in engine control



flashes red.



Serious fault in the engine control! Riding at mod. speed pos. Damage possible. Have checked by workshop.



WARNING

Engine damage when running in emergency-operation mode

Risk of accident

- Ride slowly, avoid accelerating sharply and overtaking.
- If possible, have the vehicle picked up and have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad Retailer.

Possible cause:

The engine control unit has diagnosed a fault which may cause severe secondary faults. The engine is in emergency-operation mode.

- It is possible to continue to ride but not recommended.
- Avoid high load and rpm ranges if possible.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad Retailer.

Drop sensor defective



Drop sensor faulty. Have it checked by a specialist workshop.

Possible cause:

The drop sensor is not available.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad Retailer.

Motorcycle dropped



Cannot start engine. Stand motorcycle upright. Switch ignition on/off. Start the engine.

Possible cause:

The drop sensor has detected a drop and has cut out the engine.

- Hold the vehicle upright and check it for damage.
- Switch the ignition off and then on again or switch the kill switch on and then off again.

Side stand monitoring is faulty



lights up yellow.



Side stand monitoring faulty. Onward journey possible. Engine stop. when stationary! Have checked by workshop.

Possible cause:

The side-stand switch or its wiring are damaged. The engine is shut down when speed drops below 5 km/h. You cannot resume your journey.

- Consult a specialist workshop, preferably an authorised BMW Motorrad retailer.

ABS self-diagnosis not completed



flashes.

Possible cause:



ABS self-diagnosis not completed

The ABS function is not available because self-diagnosis did not complete. (The motorcycle has to reach a defined minimum speed for the wheel sensors to be checked: min 5 km/h)

- Pull away slowly. Bear in mind that the ABS function is not available until self-diagnosis has completed.

ABS deactivated



lights up.



Off!

38 STATUS INDICATORS



ABS deactivated.

Possible cause:

The rider has switched off the ABS system.

- Switch on the ABS function (▮▮▮▮ 145).

ABS fault



lights up yellow.



lights up.



Limited ABS availability! Onward journey possible. Ride carefully to next specialist workshop.

Possible cause:

The ABS control unit has detected a fault. The partially integral function and the Dynamic Brake Control function have failed. The ABS function is available, subject to restrictions.

- You can continue to ride.

Bear in mind the more detailed information on certain situations that can lead to an ABS fault message (▮▮▮▮ 152).

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an

authorised BMW Motorrad retailer.

ABS failed



lights up yellow.



lights up.



ABS failure! Onward journey possible. Ride carefully to next specialist workshop.

Possible cause:

The ABS control unit has detected a fault. The ABS function is not available.

- You can continue to ride.

Bear in mind the more detailed information on certain situations that can lead to an ABS fault message (▮▮▮▮ 152).

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

ABS Pro failed



lights up yellow.



lights up.



ABS Pro failure! Onward journey possible. Ride carefully

to next specialist workshop.

Possible cause:

The ABS Pro control unit has detected a fault. The ABS Pro function is not available. The ABS function is still available. ABS provides support only for braking in straight-ahead driving.

- You can continue to ride. Bear in mind the more detailed information on certain situations that can lead to an ABS Pro fault message (➡ 152).
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

DTC intervention



quick-flashes.

The DTC has detected a degree of instability at the rear wheel and has intervened to reduce torque. The indicator and warning light flashes for longer than DTC intervention lasts. This affords the rider visual feedback on control intervention even after the critical situation has been dealt with.

DTC self-diagnosis not completed



slow-flashes.

Possible cause:



DTC self-diagnosis not completed

The DTC function is not available, because self-diagnosis did not complete. (The motorcycle has to reach a defined minimum speed with the engine running for the wheel sensors to be checked: min 5 km/h)

- Pull away slowly. Bear in mind that the DTC function is not available until self-diagnosis has completed.

DTC switched off



lights up.



Off!



Traction control deactivated.

Possible cause:

The rider has switched off the DTC system.

- Switch on DTC (➡ 51).

40 STATUS INDICATORS

DTC fault



lights up yellow.



lights up.



Traction control failure! Onward journey possible. Ride carefully to next specialist workshop.

Possible cause:

The DTC control unit has detected a fault.



ATTENTION

Damaged components

Damage to sensors, for example, which causes malfunctions

- Do not transport any objects underneath the driver or passenger seat.
- Secure the toolkit.
- Do not damage the angular rate sensor.
- Bear in mind that the DTC function is not available.
- You can continue to ride. Bear in mind the more detailed information on situations that can lead to a DTC fault (154).
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an

authorised BMW Motorrad retailer.

DTC restricted



lights up yellow.



lights up.



Traction control limited! Onward journey possible. Ride carefully to next specialist workshop.

Possible cause:

The DTC control unit has detected a fault.



ATTENTION

Damaged components

Damage to sensors, for example, which causes malfunctions

- Do not transport any objects underneath the driver or passenger seat.
- Secure the toolkit.
- Do not damage the angular rate sensor.
- Bear in mind that the DTC function is restricted.
- You can continue to ride. Bear in mind the more detailed information on situations that can lead to a DTC fault (154).

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

Fuel down to reserve



Fuel reserve reached. Go to a filling station soon.



WARNING

Irregular engine operation or engine shutdown due to lack of fuel

Risk of accident, damage to catalytic converter

- Do not run the fuel tank dry.

Possible cause:

The fuel tank contains no more than the reserve quantity of fuel.



Fuel reserve

approx. 4 l

- Refuel (►► 118).

Hill Start Control active



shows green.

Possible cause:

Hill Start Control (►► 159) has been activated by the rider.

- Switch off Hill Start Control.
- Operate Hill Start Control Pro (►► 56).

Hill Start Control automatically deactivated



flashes yellow.

Possible cause:

Hill Start Control has been automatically deactivated.

- Side stand has been extended.
 - » Hill Start Control is deactivated when the side stand is extended.
- Engine has been switched off.
 - » Hill Start Control is deactivated when the engine is switched off.
- Operate Hill Start Control Pro (►► 56).

Hill Start Control cannot be activated



is displayed.

Possible cause:

Hill Start Control cannot be activated.

- Retract the side stand.
 - » Hill Start Control is operational only with the side stand retracted.
- Start the engine.
 - » Hill Start Control is operational only while the engine is running.

42 STATUS INDICATORS

Gear not trained

N The gear indicator flashes.
The Pro shift assistant is not available.

Possible cause:

The gearbox sensor is not fully trained.

- Engage neutral gear **N** and, with the vehicle at a standstill, let the engine run for at least 10 seconds to train the idle gear.

- Engage all gears with clutch actuation and ride at least 10 seconds with the engaged gear.

» The gear indicator starts to flash when the gearbox sensor has been trained successfully.

– The Gear Shift Assistant Pro operates as described (158) once the transmission sensor has been completely taught-in.

- If the training process was not successful, have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad Retailer.

Hazard warning lights system is switched on

 flashes green.



flashes green.

Possible cause:

The driver has switched on the hazard warning lights system.

- Operating hazard warning flashers (49).

Launch Control not ready

Shift light lights up or flashes.

L-Con not available.

Clutch too hot. is displayed.

Possible cause:

The number of racing starts possible with Launch Control has been exceeded.

- Allow the clutch to cool.
- Operate the Launch Control (131).

Service-due indicator



If service is overdue, the due date or the odometer reading at which service was due is accompanied by the general warning light showing yellow.

If the service is overdue, a yellow CC message is displayed. Exclamation marks also draw your attention to the displays for service, service appointment and countdown distance in the MY VEHICLE and SERVICE REQUIREMENTS menu screens.



If the service-due indicator appears more than a month before the service date, the current date has to be corrected. This situation can occur if the battery was disconnected.

Service due



is displayed in white.

Service due! Have service performed by a specialist workshop. Possible cause:

Service is due because of the driving performance or the date.

- Have your motorcycle serviced regularly by a specialist workshop, preferably by an authorised BMW Motorrad Retailer.
- » The operational and road safety of the motorcycle remain intact.
- » The motorcycle's value is maintained as best as possible.

Service-due date has passed



lights up yellow.



is displayed in yellow.

Service overdue! Have service performed by a specialist workshop. Possible cause:

Service is overdue because of the driving performance or the date.

- Have your motorcycle serviced regularly by a specialist workshop, preferably by an authorised BMW Motorrad Retailer.
- » The operational and road safety of the motorcycle remain intact.
- » The motorcycle's value is maintained as best as possible.

OPERATION

04

IGNITION SWITCH/STEERING LOCK	46
EMERGENCY-OFF SWITCH (KILL SWITCH)	47
LIGHTS	48
HAZARD WARNING LIGHTS	49
TURN INDICATORS	50
DYNAMIC TRACTION CONTROL (DTC)	50
RIDING MODE	52
ADAPTIVE CRUISE CONTROL	53
HILL START CONTROL	55
SHIFT LIGHT	57
ANTI-THEFT ALARM (DWA)	58
HEATED GRIPS	59
ON-BOARD COMPUTER	60
FRONT AND REAR SEATS	61

46 OPERATION


IGNITION SWITCH/STEERING LOCK

Keys

You receive 2 vehicle keys. If a key is lost or mislaid, consult the notes on the electronic immobiliser (EWS) (► 47). Ignition switch/steering lock, fuel filler cap lock and lock for the tail-hump cover are all operated with the same key.


Engaging steering lock

- Turn the handlebars all the way to the left.




- Turn the ignition key to position 1, while moving the handlebars slightly.
 - » Ignition, lights and all function circuits switched off.
 - » Steering lock engaged.
 - » Vehicle key can be removed.

Switching on ignition



- Turn the ignition key to position 1.
 - » Side lights and all function circuits switched on.
 - » Engine can be started.
 - » Pre-Ride-Check is performed. (► 109)
 - » ABS self-diagnosis is in progress. (► 110)
 - » DTC self-diagnosis is in progress. (► 111)

Switching off ignition



- Turn the ignition key to position 1.
 - » Lights switched off.
 - » Handlebars not locked.
 - » Vehicle key can be removed.

Electronic immobiliser (EWS)

The on-board electronics access the data saved in the ignition key via a ring aerial in the ignition lock. The engine control unit will not permit the engine to be started unless the key is identified as "authorised".

 A second ignition key attached to the same ring as the ignition key used to start the engine could "irritate" the electronics, in which case the enabling signal for starting is not issued.

Always keep the ignition keys separate from each other.

If you lose your key, you can have it barred by your authorised BMW Motorrad retailer. If you wish to do this, you will need to bring all other keys for the motorcycle with you. The engine cannot be started by a barred key, but a key that has been barred can subsequently be reactivated.

You can obtain emergency/extra keys only through an authorised BMW Motorrad retailer. The keys are part of an integrated security system, so the retailer is under an obligation to check the legitimacy of all applications for replacement/extra keys.

EMERGENCY-OFF SWITCH (KILL SWITCH)



1 Emergency-off switch (kill switch)

WARNING

Operation of the kill switch while riding

Risk of fall due to rear wheel locking

- Do not operate the kill switch when riding.

The emergency off switch is a kill switch for switching off the engine quickly and easily.

48 OPERATION



- A** Engine switched off
B Normal operating position (run)

LIGHTS

Switching on low-beam headlight

- Switch on the ignition.
- Start the engine.



- Alternatively: pull switch **1** when ignition switched on.

Side light

The side lights switch on automatically when the ignition is switched on.



The side lights place a strain on the battery. Do not switch the ignition on for longer than absolutely necessary.

High-beam headlight and headlight flasher

- Switch on the ignition (→ 46).



- Push switch **1** forward to switch on the high-beam headlight.
- Pull switch **1** back to operate the headlight flasher.

Headlight courtesy delay feature

- Switch off the ignition.



- Immediately after switching off the ignition, pull switch **1** back and hold it in that position until the headlight courtesy delay feature comes on.
 - » The vehicle's lights come on for one minute and then switch off automatically.
 - This can be used to light up the path to the house door after the vehicle has been parked, for example.

Parking lights

- Switch off the ignition (▮▮▮▮ 46).



- Immediately after switching off the ignition, push button **1** to the left and hold it

in that position until the parking lights come on.

- Switch the ignition on and off again to switch off the parking lights.

HAZARD WARNING LIGHTS

Operating hazard warning flashers

- Switch on the ignition (▮▮▮▮ 46).

 The hazard warning flashers place a strain on the battery. Do not use the hazard warning flashers for longer than absolutely necessary.



- Press button **1** to switch on the hazard warning lights system.
 - » Ignition can be switched off.
- To switch off the hazard warning lights system, switch on the ignition if necessary and press button **1** again.

Immediately after button **1** is pressed, DTC system status **ON** is displayed.

 lights up.

Possible DTC system status **OFF!** is displayed.

- Release button **1** once the status has changed.

The new DTC system status **OFF!** appears briefly on the display.

 remains lit.

» The DTC function is switched off.

Switching on DTC



- Press and hold down button **1** until the DTC indicator light changes status. Immediately after button **1** is pressed, DTC system status **OFF!** is displayed.

 goes out; if self-diagnosis has not completed it starts flashing.

Possible DTC system status **ON** is displayed.

- Release button **1** once the status has changed.

 remains off or continues to flash.

The new DTC system status **ON** appears briefly on the display.

» The DTC function is switched on.

- You also have the option of switching the ignition off and then on again.



An DTC fault has occurred if the DTC indicator and warning light shows when the motorcycle accelerates to a speed in excess of the minimum stated below after the ignition was switched off and then on again.

min 5 km/h

- For more information on Dynamic Traction Control, see the section entitled "Engineering details":
 - » How does Dynamic Traction Control work? (153)

52 OPERATION

RIDING MODE

Using riding modes

BMW Motorrad has developed operational scenarios for your motorcycle from which you can select the scenario suitable for your situation:

- RAIN: Riding on rain-wet roads.
- ROAD: Riding on dry roads.
- DYNAMIC: Dynamic riding on dry roads.
- RACE: riding on race tracks with sport tyres or slicks.
- RACE PRO 1/2/3: riding on race tracks while considering individual settings made by the rider.

The RACE PRO riding modes are available only after activation of the race-track configuration (118 ▶ 128).

The respective optimum interplay of engine characteristic, ABS control and DTC control is provided for each of these scenarios.

Selecting riding mode



- Press button **1**.




The riding mode currently active **2** is sent to the back and is displayed in the pop-up **3**. The guide **4** indicates how many riding modes are available.



- Repeatedly press button **1** until the riding mode you want is displayed.
- The following steps must be taken to change the riding mode:
 - Close the throttle twistgrip.
 - Release the brake levers.
 - Deactivate adaptive cruise control.


ADAPTIVE CRUISE CONTROL

Display when adjusting settings (Speed Limit Info not active)



The symbol **1** for adaptive cruise control is displayed in the Pure Ride view and the top status line.

Display when adjusting settings (Speed Limit Info active)



The symbol **1** for adaptive cruise control is displayed in the Pure Ride view and the top status line.

Switching on adaptive cruise control



- Slide switch **1** to the right.
- » Button **2** is enabled for operation.

54 OPERATION

Setting road speed



- Short-push button **1** forward.



Adjustment range for
adaptive cruise control


20...210 km/h



Indicator light for cruise
control lights up.

- » The motorcycle maintains
your current cruising speed
and the setting is saved.


Accelerating



- Short-push button **1** forward.
 - » Speed is increased by approx.
1 km/h each time you push
the button.
- Push button **1** forward and
hold it in this position.

- » The motorcycle accelerates
smoothly.
- » The current speed is main-
tained and saved if button **1**
is not pushed again.

Decelerating



- Short-push button **1** back.
 - » Speed is reduced by 1 km/h
each time you push the but-
ton.
- Push button **1** back and hold
it in this position.
 - » The motorcycle decelerates
smoothly.
 - » The current speed is main-
tained and saved if button **1**
is not pushed again.

Deactivating adaptive cruise control

- Brake, pull the clutch lever or
turn the throttle grip (close
the throttle by turning the grip
back past the idle position)
to deactivate adaptive cruise
control.

 For safety reasons, adaptive cruise control is automatically deactivated when Gear Shift Assistant Pro downshifts.

 For safety reasons, adaptive cruise control is automatically deactivated whenever ABS or DTC intervention occurs. If DTC is deactivated by the rider, adaptive cruise control is deactivated as well.

» Indicator light for adaptive cruise control goes out.

Resuming former cruising speed



• Short-push button **1** back to return to the speed saved beforehand.

 Opening the throttle does not deactivate cruise control. When the twistgrip is released the motorcycle decelerates only to the speed saved in memory, even if the rider intended slowing to a lower speed.

 Indicator light for cruise control lights up.

Switching off adaptive cruise control




• Slide switch **1** to the left.

» The system is deactivated.

» Button **2** is disabled.

HILL START CONTROL

Display



Symbol **1** for Hill Start Control appears in the Pure Ride view and in the top status line.

56 OPERATION

Operating Hill Start Control Pro Requirement

Vehicle stationary and upright,
engine running.



ATTENTION

Failure of Hill Start Control

Risk of accident


- Apply the brakes manually to hold the vehicle.



The drive-off assistant Hill Start Control Pro is only a comfort system to enable easier riding off on gradients and should not be confused with an electromechanical holding brake.



The Hill Start Control Pro drive-off assistant should not be used on inclines of over 40 %.



- Apply firm pressure to handbrake lever **1** or to the foot-

brake lever and then quickly release the lever.

- Alternatively, apply the brake for about one second beyond the vehicle reaching a standstill on an incline of at least 3 %.



shows green.

» Hill Start Control Pro is activated.

- To switch off the Hill Start Control Pro, operate the brake lever **1** or footbrake lever again.



If Hill Start Control Pro has been deactivated by means of the handbrake lever, automatic Hill Start Control is deactivated for the next 4 m.



disappears.

- Alternatively, ride off in 1st or 2nd gear.



When riding off, Hill Start Control Pro is automatically deactivated.



disappears as soon as the brake is fully released.

» Hill Start Control Pro is deactivated.

- See the section entitled "Engineering details" for more

58 OPERATION

ANTI-THEFT ALARM (DWA)

—with anti-theft alarm (DWA) ^{OE}

Activation

- Switch on the ignition (▮▮▮▮ 46).
- Customising anti-theft alarm settings (▮▮▮▮ 59).
- Switch off the ignition.
- » If the alarm system is activated, then the alarm system will be automatically activated when the ignition is switched off.
- » Activation takes approximately 30 seconds to complete.
- » Turn indicators flash twice.
- » Confirmation tone sounds twice (if programmed).
- » Anti-theft alarm is active.

Alarm signal

A DWA alarm can be triggered by:

- motion sensor
- switch-on attempt with an unauthorised vehicle key
- disconnection of the DWA anti-theft alarm from the motorcycle's battery (DWA internal battery in the anti-theft alarm provides power - alarm tone only, the turn indicators do not flash)

All functions are sustained even if the internal battery of the DWA anti-theft alarm system is flat; the only difference is that an alarm cannot be triggered if the system is disconnected from the motorcycle's battery.

An alarm lasts for approximately 26 seconds. While an alarm is in progress an alarm tone sounds and the turn indicators flash. The type of alarm tone can be set by an authorised BMW Motorrad dealer.

If an alarm was triggered while the motorcycle was unattended, the rider is notified accordingly by an alarm tone sounding once when the ignition is switched on. The DWA LED then indicates the reason for the alarm for one minute.

Light signals issued by the DWA LED:

- Flashes 1x: motion sensor 1
- Flashes 2x: motion sensor 2
- Flashes 3x: ignition switched on with unauthorised vehicle key
- Flashes 4x: disconnection of the anti-theft alarm from the motorcycle's battery
- Flashes 5x: motion sensor 3

DWA deactivating

- Switch on the ignition.
- » Turn indicators flash once.
- » Confirmation tone sounds once (if programmed).
- » Anti-theft alarm (DWA) is deactivated.

Customising anti-theft alarm settings

- Switch on the ignition (🔑 46).
- Go to the Settings, Vehicle settings, Alarm system menu.
- » The following adaptation settings are available:
 - Adapt Warning signal
 - Switch Tilt sensor on and off
 - Switch Arming tone on and off
 - Switch Arm automatically on and off

Possible settings

Warning signal: set the increasing and decreasing or intermittent alarm tone.

Tilt sensor: activate inclination sensor to monitor the inclination of the vehicle. The DWA responds, for example, to wheel theft or being towed away.

 When the vehicle is going to be transported, deactivate the tilt sensor to pre-

vent the anti-theft alarm (DWA) from being triggered.

Arming tone: confirmation alarm tone after having activated/deactivated the DWA in addition to flashing turn indicators.

Arm automatically: automatic activation of the alarm function when switching off the ignition.

HEATED GRIPS

Operating heated handlebar grips

 The heating in the heated handlebar grips can be activated only when the engine is running.

 The increase in power consumption caused by having the heated handlebar grips switched on can drain the battery if you are riding at low engine speeds. If the charge level is low, the heated handlebar grips are switched off to ensure the battery's starting capability.

- Start the engine (🔑 109).

60 OPERATION



- Repeatedly press button **1** until desired heating stage **2** appears in front of heated grip symbol **3**.

The handlebar grips have three-stage heating.



Low heating power



Medium heating power



High heating power

» The 3rd stage is for heating the grips quickly: it is advisable to switch back to a lower stage as soon as the grips are warm.

» The selected heating stage will be saved if you allow a certain length of time to pass without making further changes.

- To switch off the heated grips, repeatedly press button **1** until heated grip symbol **3** disappears.

ON-BOARD COMPUTER

Calling up the on-board computer

- Go to the **My vehicle** menu.
- Scroll to the right until the **ON-BOARD COMPUTER** menu screen is displayed.

Resetting on-board computer

- Calling up the on-board computer (➡ 60).
- Press down the **MENU** rocker button.
- Select **Reset all values** or **Reset individual values** and confirm.

The following values can be reset:

- Break
- Journey
- Current (TRIP 1)
- Speed
- Consump.

Calling up the trip computer

- Calling up the on-board computer (➡ 60).
- Scroll to the right until the **TRIP COMPUTER** menu screen is displayed.

Resetting trip computer

- Calling up the trip computer (➡ 60).
- Press down the **MENU** rocker button.

- Select Autom. reset or Reset all values and confirm.
- » If Autom. reset is selected, the on-board computer is automatically reset if a minimum of 6 hours have passed and the date has changed since the ignition was switched off.

FRONT AND REAR SEATS

Removing tail-hump cover

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Use ignition key **1** to unlock lock for tail-hump cover **2**.
- Remove tail-hump cover **2**; to do so, unhook fixing **3**.

Installing tail-hump cover



- Position tail-hump cover **1**; hook in fixing **2** while doing so.
- Press tail-hump cover **1** downwards and lock.

Removing passenger seat

—with two-up riding package^{OE}

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Use ignition key **1** to unlock lock for passenger seat **2**.
- Remove passenger seat **2**; to do so, unhook fixing **3**.
- Remove the ignition key from the lock and place the pas-

62 OPERATION

senger seat, upholstered side down, on a clean surface.


Installing passenger seat

—with two-up riding package ^{OE}



- Position passenger seat **1**; hook in fixing **2** while doing so.
- Press passenger seat **1** downwards and lock.


Removing rider's seat



- Push the rider's seat cover **1** forward slightly on the seat cushion surface and expose tab **2**.
- Using the tool from the on-board toolkit, remove screw **3**.

- Lift up the rider's seat **1** at the rear and unhook fixing **4**.
- Place the seat, upholstered side down, on a clean surface.

Installing rider's seat



- Insert rider's seat **1** into the fixing **4** at the front and position it.
- Push the rider's seat cover **1** forward slightly on the seat cushion surface and expose tab **2**.
- Position and install bolt **3**.

TFT DISPLAY

05

GENERAL NOTES	66
PRINCIPLE	67
PURE RIDE VIEW	73
GENERAL SETTINGS	74
BLUETOOTH	75
MY VEHICLE	78
NAVIGATION	81
MEDIA	83
TELEPHONE	83
DISPLAY SOFTWARE VERSION	84
DISPLAY LICENCE INFORMATION	84

GENERAL NOTES

Warnings



WARNING

Using a smartphone during the journey or while the engine is running

Risk of accident

- Always observe the relevant road traffic regulations.
- Do not use the smartphone during the journey (apart from applications that do not require operation, e.g. making telephone calls with the hands-free system).



WARNING

Distraction from the road and loss of control

Operating the integrated information system and communication devices while driving results in a risk of accident

- Operate those systems or devices only when the traffic situation allows for it.
- If necessary, stop and operate the systems or devices when stationary.

Connectivity functions

Connectivity functions include media, telephony and navigation. Connectivity functions can be used if the TFT display is connected to a mobile device and a helmet (76). For more information on the Connectivity functions go to **bmw-motorrad.com/connectivity**



If the fuel tank is between the mobile device and the TFT display, the Bluetooth connection may be restricted. BMW Motorrad recommends storing the device above the fuel tank (e.g. in your jacket pocket).



Depending on the mobile device, the scope of the Connectivity functions may be restricted.

BMW Motorrad Connected app

The BMW Motorrad Connected app contains usage and vehicle information. For some functions, such as navigation, the app must be installed on the mobile device and connected to the TFT display. The app is used to start route guidance and adjust the navigation.


 On some mobile devices, e.g. those with iOS operating systems, the BMW Motorrad Connected App must be opened before use.

Currency

The TFT display may be updated after the publication date. Because of this, your motorcycle may differ from the information supplied in the Rider's Manual. Up-to-date information is available at: **bmw-motorrad.com/service**

PRINCIPLE

Controls



All contents of the display are operated using Multi-Controller **1** and the MENU **2** rocker button.

Depending on the context, the following functions are possible.

Multi-Controller functions Turn the Multi-Controller upward:

- Move the cursor upwards in lists.
- Adjust settings.
- Increase volume.

Turn the Multi-Controller downward:

- Move the cursor downwards in lists.
- Adjust settings.
- Decrease volume.

Tilt the Multi-Controller to the left:

- Activate the function in accordance with the operation feedback.
- Activate the function to the left or back.
- Go back to the Menu view after making the settings.
- In the Menu view: Change up one level.
- In the My Vehicle menu: advance one menu screen.

Tilt the Multi-Controller to the right:

- Activate the function in accordance with the operation feedback.
- Confirm selection.
- Confirm settings.
- Advance a menu step.
- Scroll to the right in lists.

68 TFT DISPLAY

–In the My Vehicle menu: advance one menu screen.

MENU rocker button functions

 Instructions given by the navigation system are displayed in a dialogue box if the Navigation menu has not been called up. Operation of the MENU rocker button is temporarily restricted.

Short-press the top section of the MENU button:

- In the Menu view: Change up one level.
- In Pure Ride view: Select the display for the top status line.

Long-press the top section of the MENU button:

- In Menu view: Call up Pure Ride view.
- In Pure Ride view: Change operating focus to the Navigator.

Short-press the bottom section of the MENU button:


- Change down a level.
- No function if the lowest hierarchical level has been reached.

Long-press the bottom section of the MENU button:


- Change back to the last menu after a previous menu change effected by long-pressing the

top section of the MENU button.

Operating pointers in the main menu



Operating pointers show whether interactions are possible, and which ones.




Meaning of the operating pointers:

- Operating pointer 1: Left end reached.
- Operating pointer 2: You can scroll to the right.
- Operating pointer 3: You can scroll down.
- Operating pointer 4: You can scroll to the left.

—Operating pointer **5**: Right end reached.

Operating pointers in submenus

In addition to the operating pointers in the main menu, there are additional operating pointers in the submenus.




Meaning of the operating pointers:

- Operating pointer **1**: The current display is in a hierarchical menu. One symbol represents one submenu level. Two symbols represent two or more submenu levels. The colour of the symbol changes, depending on whether you can return to a higher level.
- Operating pointer **2**: One more submenu level can be accessed.
- Operating pointer **3**: There are more entries than can be displayed.

Display Pure Ride view

- Long-press the top section of the MENU rocker button.

Switching functions on and off




Some menu items have a check box in front of them. The check box shows whether the function is on or off. Action symbols after the menu items indicate what action you can trigger by short-tilting the Multi-Controller to the right.

Examples for switching on and off:

- Symbol **1** shows that the function is switched on.
- Symbol **2** shows that the function is switched off.
- Symbol **3** shows that the function can be switched off.
- Symbol **4** shows that the function can be switched on.

70 TFT DISPLAY

Calling up menu



- Display Pure Ride view (see page 69).
- Short-press the bottom section of button **2**.

The following menus can be called up:

- My vehicle
- Sport
- Navigation
- Media
- Telephone
- Settings

- Repeatedly short-push Multi-Controller **1** to the right until the menu item you want is highlighted.
- Short-press the bottom section of button **2**.

 The Settings menu can only be called up when the vehicle is stationary.

Moving cursor in lists



- Call up the menu (see page 70).
- To move the cursor down in a list, turn Multi-Controller **1** down until the entry you want is highlighted.
- To move the cursor up in a list, turn Multi-Controller **1** up until the entry you want is highlighted.

Confirming selection




- Select the desired entry.
- Short-push Multi-Controller **1** to the right.

Call up the last menu used

- In Pure Ride view: press and hold the MENU rocker button.
- » The last menu used is called up. The last entry highlighted is selected.

System status displays

The system status is displayed in the lower area of the menu if a function is switched on or off.



Example of what the system statuses mean:

- System status 1: DTC function is switched on.

Selecting display of the top status line

Requirement

The vehicle is at a standstill. The Pure Ride view is displayed.

- Switch on the ignition (III 46).
- » The TFT display shows all the information necessary for riding on public roads from the on-board computer (e.g. TRIP 1) and the trip com-

puter (e.g. TRIP 2). The information can be displayed in the top status line.

- Select the content of the top status line (III 72).



- Long-press button 1 to obtain the Pure Ride view.
- Repeatedly short-press button 1 to select the value in the top status line 2.

The following values can be displayed:

- Total distance Total
- Current distance 1
- Current distance 2
- Intake air temp. INTAKE



Consumption 1 (Average)



Consumption 2 (Average)



Riding time 1



Riding time 2

72 TFT DISPLAY



Break 1



Break 2



Speed 1 (Average)



Speed 2 (Average)



Fuel tank level



Range

Selecting content of the top status line

- Navigate to Settings, Display, Status line content.
- Switch on the desired displays.
- » You can switch between the selected displays in the top status line. If no displays are selected, only the range will be displayed.

Adjust settings



- Select and confirm the desired settings menu.
- Turn Multi-Controller **1** down until the setting you want is highlighted.
- If an operating pointer shows, tilt Multi-Controller **1** to the right.
- If no operating pointer shows, tilt Multi-Controller **1** to the left.
- » The setting is saved.

Switching Speed Limit Info on or off

Requirement

Vehicle is connected to a compatible mobile device. The BMW Motorrad Connected app is installed on the mobile device.

- Speed Limit Info shows the maximum speed permitted at the time, if this information is made available by the publisher of the map material in the navigation system.

- Navigate to Settings, Display.
- Switch Speed Limit Info on or off.

 The Speed Limit Info is not available if Settings, Racetrack is activated.

PURE RIDE VIEW

Rev. counter



- 1 Scale
- 2 Low engine speed range
- 3 Upper/red engine speed range
- 4 Unit for engine speed display:
1000 revolutions per minute
- 5 Needle
- 6 Secondary indicator

 The red engine speed range changes depending on the coolant temperature: The colder the engine, the lower the engine speed at which the red engine speed range starts.

The warmer the engine, the higher the speed at which the red engine speed range starts. When operating temperature is reached, the display of the red engine speed range no longer changes.

Range



The range readout **1** indicates how far you can ride with the fuel remaining in the tank. This distance is calculated on the basis of average consumption and the quantity of fuel on board.

–When the vehicle is propped on its side stand the slight angle of inclination means that the sensor cannot register the fuel level correctly.

This is the reason why the range is recalculated only when the side stand is in the retracted position.

–The range is shown together with a warning once the fuel reserve has been reached.

74 TFT DISPLAY

- After a refuelling stop, range is recalculated if the amount of fuel in the tank is greater than the reserve quantity.
- The calculated range is only an approximate figure.

GENERAL SETTINGS

Adjusting volume

- Connect rider's and passenger's helmet (➡ 77).
- Increase volume: turn the multi-controller upwards.
- Decrease volume: turn the multi-controller downwards.
- Mute: turn the multi-controller all the way down.

Setting the date

- Switch on the ignition (➡ 46).
- Navigate to Settings, System settings, Date and time, Set date.
- Set Day, Month and Year.
- Confirm setting.

Set date format

- Navigate to Settings, System settings, Date and time, Date format.
- Select the desired setting.
- Confirm setting.

Setting clock

- Switch on the ignition (➡ 46).
- Navigate to Settings, System settings, Date and time, Set time.

- Set Hour and Minute.

Setting time format

- Navigate to Settings, System settings, Date and time, Time format.
- Select the desired setting.
- Confirm setting.

Setting units of measurement

- Navigate to Settings, System settings, Units.
- The following units of measurement can be set:
- Distance covered
 - Pressure
 - Temperature
 - Speed
 - Consumption

Setting language

- Navigate to Settings, System settings, Language.
- The following languages can be set:
- German
 - English (UK)
 - English (US)
 - Spanish
 - French
 - Italian
 - Dutch
 - Polish
 - Portuguese
 - Turkish
 - Russian
 - Ukrainian
 - Chinese
 - Japanese

- Korean
- Thai

Adjusting brightness

- Navigate to `Settings`, `Display`, `Brightness`.
- Adjust display brightness.
- » When ambient brightness drops below a defined threshold, the display is dimmed to the brightness set here.

Resetting all settings

- All the settings in the `Settings` menu can be reset to the factory settings.
- Call up the `Settings` menu.
- Select `Reset all` and confirm.

The settings in the following menus are reset:

- Vehicle settings
- System settings
- Connections
- Display
- Information

- » Existing Bluetooth connections are not deleted.

BLUETOOTH

Short-range wireless technology

Bluetooth is a short-range wireless technology. Bluetooth devices are short-range devices transmitting on the license-free ISM band (Industrial, Scientific, Medical) between 2.402 GHz and 2.480 GHz. They can be operated anywhere in the world without a licence being required.

Although Bluetooth is designed to establish and sustain robust connections over short distances, as with every other wireless technology disruptions are possible. Interference can affect connections or connections can sometimes fail. Particularly when multiple devices operate in a Bluetooth network, with wireless technology of this nature it is not possible to ensure fault-free communications in every situation.

Possible sources of interference:

- interference zones due to transmission masts and similar.
- devices with non-compliant Bluetooth implementations.

76 TFT DISPLAY

–proximity of other Bluetooth-compatible devices.

Pairing

Two Bluetooth devices have to recognise each other before they can communicate. This process of mutual recognition is known as pairing. When two devices have paired they remember each other, so the pairing process is conducted only once, on initial contact.

 On some mobile devices, e.g. those with iOS operating systems, the BMW Motorrad Connected App must be opened before use.

During the pairing process, the TFT display searches for other Bluetooth-compatible devices within its reception range. The conditions that have to be satisfied before the audio system can recognise another device are as follows:

- The device's Bluetooth function must be active
- The device must be "visible" to others
- The device must support the A2DP profile
- Other Bluetooth-compatible devices must be OFF (e.g. mobile phones and navigation systems).

Please consult the operating instructions for your communication system.

Pairing

- Call up the **Settings, Connections** menu.
- » Bluetooth connections can be established, managed and deleted in the **CONNECTIONS** menu. The following Bluetooth connections are displayed:

- Mobile device
- Rider's helmet
- Passenger helm.

The connection status for mobile devices is displayed.

Connect mobile device

- Pairing ( 76).
- Activate the mobile device's Bluetooth function (see mobile device's operating instructions).
- Select **Mobile device** and confirm.
- Select **Pair new mobile device** and confirm.

Mobile devices are being searched for.



The Bluetooth symbol flashes in the bottom status line during pairing.

Mobile devices found are displayed.

- Select and confirm mobile device.
- Follow the instructions on the mobile device.
- Confirm that the code matches.
- » The connection is established and the connection status updated.
- » If the connection is not established, consult the troubleshooting chart in the section entitled "Technical data". (►►► 212)
- » Depending on the mobile device, telephone data is transferred to the vehicle automatically.
- » Telephone data (►►► 84)
- » If the telephone book is not displayed, consult the troubleshooting chart in the section entitled "Technical data". (►►► 213)
- » If the Bluetooth connection does not work as expected, consult the troubleshooting chart in the section entitled "Technical data". (►►► 213)

Connect rider's and passenger's helmet

- Pairing (►►► 76).
- Select Rider's helmet or Passenger helm. and confirm.
- Make the helmet's communication system visible.
- Select Pair new rider's helmet or Pair new passenger helmet and confirm. Helmets are searched for.



The Bluetooth symbol flashes in the bottom status line during pairing.

Helmets found are displayed.

- Select and confirm helmet.
- » The connection is established and the connection status updated.
- » If the connection is not established, consult the troubleshooting chart in the section entitled "Technical data". (►►► 212)
- » If the Bluetooth connection does not work as expected, consult the troubleshooting chart in the section entitled "Technical data". (►►► 213)


Deleting connections

- Call up the Settings, Connections menu.
- Select Delete connections.
- To delete an individual connection, select the connection and confirm.
- To delete all connections, select Delete all connections and confirm.

78 TFT DISPLAY


MY VEHICLE

Start screen




- 1 Check Control display
(25)
- 2 Coolant temperature
(34)
- 3 Range (73)
- 4 Odometer
- 5 Service display (42)
- 6 On-board voltage
(192)

Operating pointers



- Operating pointer **1**: Indicators showing how far you can scroll to the left or right.
- Operating pointer **2**: Indicator showing the position of the current menu screen.

Scrolling through menu screens



- Call up the **My vehicle** menu.
- To scroll to the right, short-press Multi-Controller **1** to the right.
- To scroll to the left, short-press Multi-Controller **1** to the left.

The **My Vehicle** menu contains the following screens:

- **MY VEHICLE**
- **ON-BOARD COMPUTER**
- **TRIP COMPUTER**
- **SERVICE REQUIREMENTS**
- **Check Control messages** (if any)
- For more information on tyre pressures and Check Control messages, see the section on displays (► 25).

 Check Control messages are attached dynamically to the menu screens as additional tabs in the **My vehicle** menu.

On-board computer and trip computer

The **ON-BOARD COMPUTER** and **TRIP COMPUTER** menu screens display vehicle and trip data, such as average values.

Service requirements



When the next service is due within less than a month or

80 TFT DISPLAY

within 1000 km, a white Check
Control message is displayed.

NAVIGATION

Warnings



WARNING

Using a smartphone during the journey or while the engine is running

Risk of accident

- Always observe the relevant road traffic regulations.
- Do not use the smartphone during the journey (apart from applications that do not require operation, e.g. making telephone calls with the hands-free system).



WARNING

Distraction from the road and loss of control

Operating the integrated information system and communication devices while driving results in a risk of accident

- Operate those systems or devices only when the traffic situation allows for it.
- If necessary, stop and operate the systems or devices when stationary.

Precondition

The vehicle is connected via Bluetooth to a compatible mobile device.

The BMW Motorrad Connected app is installed on the connected mobile device.



On some mobile devices, e.g. those with iOS operating systems, the BMW Motorrad Connected App must be opened before use.

Entering destination address

- Connect mobile device (📶➡ 76).
- Call up the BMW Motorrad Connected app and start the route guidance.
- Call up the Navigation menu in the TFT display.
 - » Active route guidance is displayed.
 - » If active route guidance is not displayed, consult the troubleshooting chart in the section entitled "Technical data". (🔧➡ 213)

Selecting destination from recent destinations

- Call up the Navigation, Recent destinations menu.
- Select and confirm destination.

82 TFT DISPLAY

- Select Start route guidance.

Selecting destination from favourites

- The FAVOURITES menu displays all destinations which have been saved as favourites in the BMW Motorrad Connected app. You cannot use the TFT display to add favourites to the list.
- Call up the Navigation, Favourites menu.
- Select and confirm destination.
- Select Start guidance.

Entering special destinations

- Special destinations, such as points of interest, can be displayed on the map.
- Call up the Navigation, POIs menu.

The following locations can be selected:

- At current location
- At destination
- Along the route
- Select where the special destinations should be looked for. e.g. the following special destination can be selected:
 - Filling station
- Select and confirm the special destination.
- Select Start route guidance and confirm.

Setting route criteria

- Call up the Navigation, Route criteria menu. The following criteria can be selected:
 - Route type
 - Avoid
- Select desired Route type.
- Switch desired Avoid on or off.

The number of avoidances activated is displayed in brackets.

Ending route guidance

- Call up the Navigation, Active route guidance menu.
- Select End route guidance and confirm.

Switching spoken instructions on or off

- Connect rider's and passenger's helmet (📶 77).
- The navigation can be read out by a computer voice. For this purpose, Spoken instruction must be switched on.
- Call up the Navigation, Active route guidance menu.
- Switch Spoken instruction on or off.

Repeating last spoken instruction


- Call up the Navigation, Active route guidance menu.
- Select Current instruction and confirm.

MEDIA

Precondition

The vehicle is connected to a compatible mobile device and helmet.

Control music playback



- Call up the Media menu.
-  BMW Motorrad recommends setting the volume on the mobile end device for media and calls to maximum before setting off.
- Adjust the volume ( 74).
- Next track: Short-tilt Multi-Controller **1** to the right.
- Last track or start of the current track: Short-tilt Multi-Controller **1** to the left.

- Fast forward: Long-tilt Multi-Controller **1** to the right.
- Rewind: Long-tilt Multi-Controller **1** to the left.
- Call up context menu: Press bottom part of button **2**.

 Depending on the mobile device, the scope of the Connectivity functions may be restricted.

- » The following functions can be used in the context menu:
- Playback or Pause.
 - Select the Now playing, All artists, All albums or All tracks category for search and playback.
 - Select Playlists.

You can make the following adjustments in the Audio settings submenu:

- Switch Shuffle on or off.
- Select Repeat: Off, One (current track) or All.


TELEPHONE

Precondition

The vehicle is connected to a compatible mobile device and helmet.

84 TFT DISPLAY

Telephone calls



- Call up the Telephone menu.
- Accept call: Tilt Multi-Controller 1 to the right.
- Reject call: Tilt Multi-Controller 1 to the left.
- End call: Tilt Multi-Controller 1 to the left.

Muting

During active phone calls, the microphone in the helmet can be muted.

Phone calls with multiple participants

While a phone call is in progress, a second call can be accepted. The first phone call is put on hold. The number of active calls is shown in the Telephone menu. It is possible to switch between two phone calls.

Telephone data

Depending on the mobile device, when pairing (76) completes telephone data are automatically sent to the vehicle.

Phone book: List of contacts saved on the mobile device

Call list: List of calls with the mobile device

Favourites: List of favourites saved on the mobile device

DISPLAY SOFTWARE VERSION

- Navigate to Settings, Information, Software version.

DISPLAY LICENCE INFORMATION

- Navigate to Settings, Information, Licences.

ADJUSTMENT


06

MIRRORS	88
HEADLIGHT	88
BRAKES	88
ADJUSTING CLUTCH LEVER	89
FOOTREST SYSTEM	90
STEERING	92
SPRING PRELOAD	93
DAMPING	95
SWINGING ARM	98
RIDING HEIGHT	101

88 ADJUSTMENT

MIRRORS

Adjusting mirrors



- Pivot the mirror to the correct position by pressing gently at the edge of the glass.

HEADLIGHT

Headlight adjustment for right- or left-hand traffic

This motorcycle has a symmetric-beam low-beam headlight. If the motorcycle is ridden in a country where the opposite rule of the road applies, its symmetric low-beam headlight means that no measures are necessary to prevent the headlight beam from dazzling oncoming traffic.

Headlight beam throw and spring preload

The headlight beam throw generally remains constant by adjustment of the spring preload to the load status.



If there are doubts about the correct headlight beam throw, have the setting checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.

BRAKES

Adjusting handbrake lever




WARNING

Adjusting the handbrake lever while riding

Risk of accident

- Do not attempt to adjust the handbrake lever unless the motorcycle is at a standstill.



- Turn adjuster knob **1** to the desired position.




The adjuster is easier to turn if you push the brake lever forward.

» Adjustment options:

—from position 1: narrowest span between handlebar grip and brake lever

- to position 6: largest span between handlebar grip and brake lever

–with Billet pack^{OE}



- Turn adjustment lever **1** to the desired position.

 The adjuster is easier to turn if you push the brake lever forward.

» Adjustment options:

- From position **A**: narrowest span between handlebar grip and handbrake lever.
- In 5 steps toward position **B** to increase the span between handlebar grip and handbrake lever.<

ADJUSTING CLUTCH LEVER

Clutch




WARNING

Adjusting the clutch lever while riding

Risk of accident

- Adjust the clutch lever only when the motorcycle is at a standstill.



- Turn adjuster knob **1** to the desired position.


 The adjuster is easier to turn if you push the clutch lever forward.

» Adjustment options:

- Position 1: narrowest span between handlebar grip and clutch lever
- Position 5: widest span between handlebar grip and clutch lever

90 ADJUSTMENT

—with Billet pack^{OE}



- Turn adjustment lever **1** to the desired position.

 The adjuster is easier to turn if you push the clutch lever forward.

» Adjustment options:


- From position **A**: narrowest span between handlebar grip and clutch lever.
- In 4 steps in direction of position **B** for enlarging the distance between handlebar grip and clutch lever.◁

FOOTREST SYSTEM

—with Billet pack^{OE}

Adjusting rotor

- Setting of the rotor is the same on the right and left.
- The position of the rotor must be set identically on the right and left.



- Rotor **3** enables foot clearance and foot position to be adjusted.
- Slacken screw **1** in toothed bushing **2** until toothed bushing **2** can be eased out of rotor **3**.
- » Rotor **3** can be adjusted to any of 6 positions around its axis of rotation.
- » Rotor **3** can be adjusted to any of 5 positions along its longitudinal axis.
- Install rotor **3** in the desired position and tighten screw **1** in toothed bushing **2**.



Screw connection for footrest adjustment

Thread-locking compound: mechanical

20 Nm

**WARNING**

Incorrectly adjusted footrest as a result of movement of the rotor.


Risk of falling

- The footrest setting must be adjusted accordingly if the rotor has moved.

- The footrest may only fold upwards and slightly towards the rear.

Adjusting footrest hinge

- Setting of the footrest joint is the same on the right and left.



- Slacken screw **3**.
» Footrest joint **1** can be turned.
- Set footrest joint **1** to the reading on scale **2** corresponding to the position of the rotor.

 The scale is a guide for correct positioning of the footrest joint in combination with the setting selected for the rotor. For example, if the

rotor is moved one position clockwise, the footrest joint has to be moved one position counter-clockwise.


- Tighten screw **3**.



Clamping bolt for rider footrest

Thread-locking compound:
mechanical

20 Nm

Adjusting footbrake lever peg

- Foot clearance and height relative to peg **2** can be adjusted by turning to different positions.
- Slacken screw **1**.
- Turn peg **2** to the desired position.
- Tighten screw **1**.




Peg to footbrake lever

Thread-locking compound:
micro-encapsulated

10 Nm

92 ADJUSTMENT

Adjusting gearshift lever peg



- Foot clearance can be adjusted by repositioning peg **2**.
- Loosen screw **1**.
 - » Peg **2** can be repositioned along the longitudinal axis.
- Set the desired foot clearance and tighten screw **1**.




Folding peg

10 Nm

STEERING

Adjusting steering damper



WARNING

Adjusting the steering damper while riding.

Risk of accident

- Do not attempt to adjust the steering damper unless the motorcycle is at a standstill.

- To increase damping: turn adjusting screw **1** in direction **A**.
- To reduce damping: turn adjusting screw **1** in direction **B**.



Steering damper basic setting

Turn adjusting screw to the limit position in direction **A**, then turn it 6 clicks in direction **B** (Public roads).

Turn adjusting screw to the limit position in direction **A**, then turn it 4 clicks in direction **B** (Racing).

SPRING PRELOAD

Adjustment


Front spring preload has to be adjusted to suit the rider's weight. Increase spring preload for heavier loads, decrease spring preload for lighter loads. It is essential to set spring preload of the rear suspension to suit the load carried by the motorcycle. Increase spring preload when the vehicle is heavily loaded and reduce spring preload accordingly when the vehicle is lightly loaded.

Lifting the motorcycle

To adjust the spring preload, an engine lifter is required; however this subject will not be dealt with in detail. If you are not sure whether this work is within your capability, contact a specialist workshop, preferably an authorised BMW Motorrad retailer.

Adjusting spring preload for front wheel

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Lift the motorcycle with an engine lifter until there is no load on the front wheel.



- Measure distance **D** from bottom edge **1** of the slider tube to front axle **2**.
- Remove the engine lifter.
- Make sure the ground is level and firm and place the motorcycle on its stand.
- Apply the rider's weight to the motorcycle.
- With the assistance of a second person, measure the distance **D** between the points **1** and **2** again and calculate the difference (compression) between the measured values.




Load-dependent adjustment of spring preload

Negative spring displacement of front wheel

35 mm (with rider 85 kg)

94 ADJUSTMENT



WARNING


Spring preload setting and spring-strut damping setting not matched.

Impaired handling.

- Adjust spring-strut damping to suit spring preload.
- To reduce the compression (increase of spring preload), turn adjusting screw **3** using toolkit in direction **A**. The toolkit includes an appropriate adapter that protects the screw from scratches.
- To increase the compression (reduction of spring preload), turn adjusting screw **3** using toolkit in direction **B**. The toolkit includes an appropriate adapter that protects the screw from scratches.


Adjusting spring preload for rear wheel

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Use the engine lifter to raise the vehicle until the weight is completely off the rear wheel.



- Measure distance **D** between number plate carrier **1** and axle **2**.
- Remove the engine lifter.
- Make sure the ground is level and firm and place the motorcycle on its stand.
- Subject the motorcycle to load with a rider, and possibly with luggage.
- With the assistance of a second person, measure the distance **D** between the points **1** and **2** again and calculate the difference (compression) between the measured values.

	Load-dependent adjustment of spring preload
Suspension compression at rear wheel	
30 mm (with rider 85 kg)	

**WARNING****Spring preload setting and spring-strut damping setting not matched.**

Impaired handling.

- Adjust spring-strut damping to suit spring preload.
- Loosen screw **1** with toolkit.
- To reduce compression (increase spring preload), use the tool from the on-board toolkit to turn adjusting ring **2** in direction **A**.
- To increase compression (reduce spring preload), use the tool from the on-board toolkit to turn adjusting ring **2** in direction **B**.

- Tighten screw **1** to the specified tightening torque.



Screw in adjusting ring

6 Nm

DAMPING**Adjustment**

Damping must be adapted to suit the condition of the surface on which the motorcycle is ridden and to suit spring preload.

- An uneven surface requires softer damping than a smooth surface.
- An increase in spring preload requires firmer damping, a reduction in spring preload requires softer damping.

Adjusting compression-stage damping for front wheel

- Adjust compression-stage damping using adjusting screw **1** and the yellow scale on the left fork leg.

96 ADJUSTMENT



- To increase damping: Use the tool from the on-board toolkit to turn the adjusting screw so that mark **2** points to a higher value on the scale.
- To reduce damping: Use the tool from the on-board toolkit to turn the adjusting screw so that mark **2** points to a lower value on the scale.



Compression stage, basic setting, front

Position 5 (with rider 85 kg)

Adjusting rebound-stage damping for front wheel



- Adjust rebound-stage damping using adjusting screw **1**

and the red scale on the right fork leg.



- To increase damping: Use the tool from the on-board toolkit to turn the adjusting screw so that mark **2** points to a higher value on the scale.
- To reduce damping: Use the tool from the on-board toolkit to turn the adjusting screw so that mark **2** points to a lower value on the scale.




Rebound stage, basic setting, front

Position 5 (with rider 85 kg)

Adjusting compression-stage damping for rear wheel

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Adjust compression-stage damping using adjusting screw **1**.



- To increase the stiffness of the damping characteristic: Use the tool from the on-board toolkit to turn the adjusting screw clockwise in the **+** direction.
- To reduce the stiffness of the damping characteristic: Use the tool from the on-board toolkit to turn the adjusting screw counter-clockwise in the **-** direction.



Compression stage, basic setting, rear

Turn adjusting screw **1** to the limit position in direction **+**, then turn it 5 clicks in direction **-**. (with rider 85 kg)

Adjusting rebound-stage damping for rear wheel



CAUTION

Hot exhaust system

Risk of burn injury


- Do not touch a hot exhaust system.

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Adjust rebound-stage damping using adjusting screw **1**.

98 ADJUSTMENT



- To increase the stiffness of the damping characteristic: Use the tool from the on-board toolkit to turn adjusting screw **1** in direction **A**.
- To reduce the stiffness of the damping characteristic: Use the tool from the on-board toolkit to turn adjusting screw **1** in direction **B**.



Rebound stage, basic setting, rear

Turn adjuster knob to the limit position in direction **A**, then turn it 5 clicks in direction **B**. (with rider 85 kg)

SWINGING ARM

Adjusting swinging arm

The swinging arm pivot point can be adjusted to any of five stages. Additional tools such as an engine lifter or footrest stand are required, however, they will not be dealt with in detail here. If you are not sure whether this work is within

your capability, contact a specialist workshop, preferably an authorised BMW Motorrad retailer.

Adjusting swinging arm pivot point

- Make sure the ground is level and firm and place the motorcycle on its stand.




ATTENTION

Vehicle toppling to side


Risk of damage to parts if vehicle topples

- Make sure that the vehicle is secured so that it cannot topple sideways.
-
- Lift motorcycle with an engine lifter or another suitable jack, so that there is no load on the rear wheel swinging arm.




- Loosen quick-release axle nut **1**.
- Loosen lock nuts **3** on left and right.


- Use the adjusting screws **2** on left and right to significantly increase chain sag.
- Make sure that scale readings **4** are the same on left and right.



- Remove nut **1** and washer **2**.
- Remove fixing screw **3**.




- Loosen swinging arm axle **1**.
- Remove nut **2**.



- Remove fixing screw **1**.
- Alternately turn right bush **2** and left bush in steps of no more than 90° until the desired position is reached.
- Install fixing screw **1**.

Positioning of the swinging arm pivot point bush in the main frame, right

5 Nm



- Alternately turn left bush **2** and right bush in steps of no more than 90° until the desired position is reached.


100 ADJUSTMENT

- Ensure that the left **2** and right bushes are fixed in the same position **(mark)**.
- Install fixing screw **1**.



Positioning of the swinging arm pivot point bush in the main frame, left

8 Nm



- Install nut **1** with washer **2** and tighten to specified torque, while counter-holding the swinging arm axle.



Nut on swinging arm axle

Thread-locking compound: mechanical

100 Nm

- Install nut **2** and tighten to the specified tightening torque.



Nut for swinging arm pivot point bush on frame

Thread-locking compound: Loctite 270, High strength


70 Nm

- Tighten swinging arm axle **1** to the specified torque.



Swinging arm axle on frame

5 Nm



- Use the adjusting screws **2** on left and right to adjust chain sag.
- Check chain sag (▮ 185).
- Make sure that scale readings **4** are the same on left and right.

- Tighten lock nuts **3** on left and right to the specified tightening torque.



Locknut of the final-drive chain tensioning screw

19 Nm

- Tighten quick-release axle nut **1** to the specified tightening torque.



Rear quick-release axle in swinging arm

Thread-locking compound: mechanical

125 Nm

- Check chain sag (➡ 185).
- Remove the engine lifter.
- After the swinging arm pivot point has been changed, the ride height has to be corrected at the eccentric strut.
- Adjust the ride height to swinging arm pivot point setting (➡ 101).

RIDING HEIGHT

Adjusting the riding height

Ride height at the rear suspension can be adjusted by means of the eccentric strut. When adjusting the ride height, bear in mind that with certain setting combinations, the clearances to different components cannot be guaranteed. There-

fore, after making changes, the clearance to the rear wheel swinging arm and rear wheel must always be checked. Additional tools such as an engine lifter or footrest stand are required for adjusting the riding height; however, they will not be dealt with in detail here. If you are not sure whether this work is within your capability, contact a specialist workshop, preferably an authorised BMW Motorrad retailer.

Adjusting ride height to swinging arm pivot point setting

- Make sure the ground is level and firm and place the motorcycle on its stand.



ATTENTION

Vehicle toppling to side

Risk of damage to parts if vehicle topples

- Make sure that the vehicle is secured so that it cannot topple sideways.
- Lift the motorcycle with an engine lifter, so that there is no load on the rear wheel swinging arm.

102 ADJUSTMENT



- Remove the engine lifter.

- Loosen clamping screw **1**.
- Remove fixing screw **2**.
- Turn eccentric **3** to the desired position (notch).



Setting of eccentric strut to compensate for swinging-arm pivot point adjustment

Swinging arm pivot point basic setting position 5: (Eccentric position: -1)

Swinging arm pivot point position 4: (Eccentric position: 0)

Swinging arm pivot point position 3/2/1: (Eccentric position: +3)

- Install fixing screw **2**.



Positioning, eccentric

8 Nm

- Tighten clamping screw **1**.



Clamp, eccentric

10 Nm

RIDING

07

SAFETY INFORMATION	106
REGULAR CHECK	108
STARTING	109
RUNNING IN	111
SHIFTING GEAR	112
SHIFT LIGHT	113
BRAKES	114
PARKING YOUR MOTORCYCLE	116
REFUELLING	117
SECURING MOTORCYCLE FOR TRANSPORTATION	119

SAFETY INFORMATION

Rider's equipment

Do not ride without the correct clothing! Always wear

- Helmet
- Suit
- Gloves
- Boots

This applies even to short journeys, and to every season of the year. Your authorised BMW Motorrad retailer will be glad to advise you on the correct clothing for every purpose.



WARNING

Loose textiles, items of luggage or straps snagged by open rotating parts of the vehicle (wheels, drive shaft)

Risk of accident

- Make sure that loosely worn or carried textiles cannot be snagged by openly rotating parts of the vehicle.
- Keep all items of luggage and straps well clear of openly rotating parts of the vehicle.

Loading



WARNING

Handling adversely affected by overloading and imbalanced loads

Risk of falling

- Do not exceed the permissible gross weight and be sure to comply with the instructions on loading.
- Adjusting spring preload setting and damping to the total weight.

Speed

If you ride at high speed, always bear in mind that various boundary conditions can adversely affect the handling of your motorcycle:

- Settings of the spring-strut and shock-absorber system
- Imbalanced load
- Loose clothing
- Insufficient tyre pressure
- Poor tyre tread
- Etc.

Risk of poisoning

Exhaust fumes contain carbon monoxide, which is colourless and odourless but highly toxic.

**WARNING****Exhaust gases adversely affecting health**

Risk of asphyxiation

- Do not inhale exhaust fumes.
- Do not run the engine in an enclosed space.

**WARNING****Inhalation of harmful vapours**

Health hazard

- Do not inhale vapours from operating fluid and plastics.
- Use the vehicle only out-doors.

Risk of burn injury**CAUTION****Engine and exhaust system become very hot when the vehicle is in use**

Risk of burn injury

- When you park the vehicle make sure that no-one and no objects can come into contact with the hot engine and exhaust system.

Catalytic converter

If misfiring causes unburned fuel to enter the catalytic converter, there is a danger of overheating and damage.

The following guidelines must be observed:

- Do not run the fuel tank dry.
- Do not attempt to start or run the engine with a spark-plug cap disconnected.
- Stop the engine immediately if it misfires.
- Use only unleaded fuel.
- Comply with all specified maintenance intervals.

**ATTENTION****Unburned fuel in catalytic converter**

Damage to catalytic converter

- Note the points listed for protection of the catalytic converter.

Risk of overheating



ATTENTION

Engine running for prolonged period with vehicle at standstill

Overheating due to insufficient cooling; in extreme cases vehicle fire

- Do not allow the engine to idle unnecessarily.
- Ride away immediately after starting the engine.

Tampering



ATTENTION

Tampering with the motorcycle (e.g. engine management ECU, throttle valves, clutch)

Damage to the affected parts, failure of safety-relevant functions, voiding of warranty

- Do not tamper with the vehicle in any way that could result in tuned performance.

REGULAR CHECK

Comply with checklist

- At regular intervals, use the checklist below to check your motorcycle.

Always before riding off:

- Checking function of brakes (168).
- Check operation of the lights and signalling equipment.
- Checking clutch function (173).
- Checking tyre tread depth (176).
- Checking tyre pressure (175).
- For race-track riding: Check the engine oil level.
- Check that bags and luggage are securely held in place.

Every 3rd refuelling stop

- Check the engine oil level (167).
- Check the brake pad thickness, front brakes (169).
- Check the brake pad thickness, rear brakes (170).
- Check the brake-fluid level, front brakes (171).
- Check the brake-fluid level, rear brakes (172).
- Check the coolant level (174).
- Lubricate the chain (183).
- Check chain sag (185).
- Check the chain wear (186).

STARTING

Starting engine

- Switch on the ignition.
- » Pre-Ride-Check is performed. (109)
- » ABS self-diagnosis is in progress. (110)
- » DTC self-diagnosis is in progress. (111)
- Select neutral or, if a gear is engaged, pull the clutch lever.

 You cannot start the motorcycle with the side stand extended and a gear engaged. The engine will switch itself off if you start it with the gearbox in neutral and then engage a gear before retracting the side stand.

 To ensure rapid operational readiness of the catalytic converter, idle speed is increased for a short time after engine start.

- For a cold engine start and low temperatures: pull clutch.
- » Low temperatures can impact on the starting response. Repeated, brief application of load on the battery causes battery temperature to rise, so more battery power is available for starting the engine.



- Press starter button **1**.

 The start attempt is automatically interrupted if battery voltage is too low. Recharge the battery before you start the engine, or use jump leads and a donor battery to start.

See the subsection on jump starting in "Maintenance" for more details.

- » The engine starts.
- » Consult the troubleshooting chart below if the engine refuses to start. (212)

Pre-Ride-Check

The instrument cluster runs a test of the instruments and the indicator and warning lights when the ignition is switched on. This test is known as the Pre-Ride-Check. The check is aborted if you start the engine before it completes.

110 RIDING

Phase 1

All indicator and warning lights are switched on.

After a longer vehicle standstill period, an animation is displayed when the system starts up.

Phase 2

The 'General' warning light changes from red to yellow.

Phase 3

All the indicator and warning lights switched on beforehand are switched off.

The malfunction indicator lamp (MIL) does not go out until 15 seconds have elapsed.

If one of the indicator and warning lights did not switch on:

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

ABS self-diagnosis

BMW Motorrad Integral ABS performs self-diagnosis to ensure its operability. Self-diagnosis starts automatically when you switch on the ignition.

Phase 1

» Test of the diagnosis-compatible system components with the vehicle at a standstill.



flashes.

Phase 2

» Test of the wheel-speed sensors as the vehicle pulls away from rest.



flashes.

ABS self-diagnosis completed

» The ABS indicator and warning light goes out.



ABS self-diagnosis not completed

The ABS function is not available because self-diagnosis did not complete. (The motorcycle has to reach a defined minimum speed for the wheel sensors to be checked: min 5 km/h)

If an indicator showing an ABS fault appears when ABS self-diagnosis completes:

- You can continue to ride.
Bear in mind that neither the ABS function nor the integral braking function is available.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably

an authorised BMW Motorrad Retailer.

DTC self-diagnosis

BMW Motorrad DTC performs self-diagnosis to ensure its operability. Self-diagnosis is performed automatically when you switch on the ignition.

Phase 1

» Test of the diagnosis-compatible system components with the vehicle at a standstill.



slow-flashes.

Phase 2

» Pullaway test of the system components with diagnostic capability.



slow-flashes.

DTC self-diagnosis completed

» The DTC symbol no longer shows.

- Check all the indicator and warning lights.



DTC self-diagnosis not completed

The DTC function is not available, because self-diagnosis did not complete. (The motorcycle has to reach a defined minimum speed with the engine running for the wheel sensors to be checked: min 5 km/h)

If an indicator showing an DTC fault appears when DTC self-diagnosis completes:

- You can continue to ride.
Bear in mind that the DTC function is not available or the functionality might be subject to certain restrictions.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad Retailer.

RUNNING IN

Engine

- Until the first running-in check, vary the throttle opening and engine-speed range frequently; avoid riding at constant engine speed for prolonged periods.
- Try to do most of your riding during this initial period on twisting, fairly hilly roads.

112 RIDING

- Comply with the running-in speeds.



Running-in speed

$<7000 \text{ min}^{-1}$ (Odometer reading 0...300 km)

$<9000 \text{ min}^{-1}$ (Odometer reading 500...1000 km)

No full load (Odometer reading 0...1000 km)

- Note the mileage after which the running-in check should be carried out.



Mileage until the running-in check

500...1200 km

Brake pads

New brake pads have to be run in before they can achieve their optimum friction levels. The reduced braking effect can be compensated for by greater pressure on the brake lever.



WARNING

New brake pads

Longer stopping distance, risk of accident

- Apply the brakes in good time.

Tyres

New tyres have a smooth surface. This must be roughened by riding in a restrained manner at various heel angles until the tyres are run in. This running in procedure is essential if the tyres are to achieve maximum grip.



WARNING

New tyres losing grip on wet roads and at extreme bank angles

Risk of accident

- Ride carefully and avoid extremely sharp inclines.

SHIFTING GEAR

Gear Shift Assistant Pro



See the section entitled "Engineering details" for more information on Gear Shift Assistant Pro.



For safety reasons, adaptive cruise control is automatically deactivated when Gear Shift Assistant Pro downshifts.




- You select the gear in the usual way by means of the foot-operated shift lever.
- » The sensor **1** on the gearshift rod registers the gearshift request and triggers shift assistance.
- » When riding at a steady speed in a low gear at high engine rpm, an attempt to shift gear without pulling the clutch can cause a severe load-change reaction. BMW Motorrad recommends disengaging the clutch for shifts in these circumstances. It is advisable to avoid using the shift assistant at engine speeds close to the limits at which the governor cuts in to limit engine rpm.
- » Shift assistance is not available in the following situations:
 - With clutch lever pulled.
 - Gearshift lever not in its initial position

- Upshifts with the throttle valve closed (engine overrun) and when slowing
- Downshifts with throttle valve open and when accelerating.
- After a gearshift, the shift lever has to be fully released before another gearshift with the shift assistant can take place.

SHIFT LIGHT

Function



- Shift light **1** indicates that the engine speed at which the rider should upshift is approaching.
- Shift light flashes at preset frequency: Approaching upshift rpm
 - Shift light goes out: Engine revving at upshift rpm

The engine-speed thresholds and the way in which the shift light indicates the various states can be customised by navigating to **Settings**, **Vehicle settings**, also

see the section on operation (▮▮▮▮▶ 57).

BRAKES

How can stopping distance be minimised?

Each time the brakes are applied, a load distribution shift takes place with the load shifting forward from the rear to the front wheel. The sharper the motorcycle decelerates, the more load is shifted to the front wheel. The higher the wheel load, the more braking force can be transmitted.

To optimise stopping distance, apply the front brakes rapidly and keep on increasing the force you apply to the brake lever. This makes the best possible use of the dynamic increase in load at the front wheel. Remember to pull the clutch at the same time. BMW Motorrad ABS Pro prevents the front wheel from locking up.

In the "emergency braking situations" that are trained so frequently, braking force is applied as rapidly as possible and with the rider's full force applied to the brake levers; under these circumstances the dynamic shift in load distribu-

tion cannot keep pace with the increase in deceleration and the tyres cannot transmit the full braking force to the surface of the road. In the absence of load on the wheel the ABS has to intervene to prevent the front wheel from locking even if the brakes are applied only very lightly. This leads to a reduced braking effect.

Emergency braking

If you brake sharply from a speed in excess of 50 km/h, the brake light flashes rapidly as a warning for road users behind you.

If you brake until your speed is less than 15 km/h, the hazard warning lights start to flash as well. The hazard warning lights switch off automatically as soon as you start to accelerate and vehicle speed reaches 20 km/h.

Descending mountain passes



WARNING

Braking mostly with the rear brake on mountain descents

Brake fade, destruction of the brakes due to overheating

- Use both front and rear brakes, and make use of the engine's braking effect as well.

Wet and dirty brakes

Wetness and dirt on the brake discs and the brake pads diminish braking efficiency.

Delayed braking action or poor braking efficiency must be reckoned with in the following situations:

- Riding in the rain or through puddles of water.
- After the vehicle has been washed.
- Riding on salted or gritted roads.
- After work has been carried on the brakes, due to traces of oil or grease.
- Riding on dirt-covered surfaces or off-road.



WARNING

Wetness and dirt result in diminished braking efficiency

Risk of accident

- Apply the brakes lightly while riding to remove wetness and dirt, or dismount and clean the brakes.
- Think ahead and brake in good time until full braking efficiency is restored.

ABS Pro

Physical limits applicable to motorcycling



WARNING

Braking when cornering

Risk of crash despite ABS Pro

- Invariably, it remains the rider's responsibility to adapt riding style to riding conditions.
- Do not take risks that would negate the additional safety offered by this system.



ABS Pro is activated in the RAIN, ROAD and DYNAMIC riding modes. In the Dynamic Pro riding mode, ABS Pro can be parametrised

to suit the rider's individual needs and preferences.

Possibility of a fall not precluded

Although ABS Pro and Dynamic Brake Control provide the rider with valuable assistance and constitute a huge advance in safety for braking with the motorcycle banked for cornering, they cannot under any circumstances be considered as re-defining the physical limits that apply to motorcycling. It is still possible for these limits to be overshoot due to misjudgement or rider error. In extreme cases this can result in a crash.

Use on public roads

ABS Pro and Dynamic Brake Control help make the motorcycle even safer for riding on public roads. When the brakes are applied because of an unforeseen hazard when the motorcycle is banked for cornering, within the physical limits that apply to motorcycling the ABS Pro system prevents the wheels from locking and skidding away. In emergency braking, Dynamic Brake Control increases the braking effect and intervenes if the throttle grip is

accidentally turned during braking.



ABS Pro was not developed to enhance individual braking performance with the motorcycle banked into corners.

PARKING YOUR MOTORCYCLE

Side stand

- Switch off the engine.
- On a gradient, the motorcycle should always face uphill; select 1st gear.



ATTENTION

Poor ground underneath the stand

Risk of damage to parts if vehicle topples

- Always check that the ground under the stand is level and firm.

- Extend the side stand and prop the motorcycle on the stand.



ATTENTION

Additional weight placing strain on the side stand

Risk of damage to parts if vehicle topples

- Do not sit or lean on the vehicle while it is propped on the side stand.

- If the camber of the roadway permits, turn the handlebars all the way to the left.

REFUELLING

Fuel grade Requirement

For optimum fuel consumption, fuel should be sulphur-free or as low-sulphur as possible.



ATTENTION

Engine operation with leaded fuel

Damage to catalytic converter

- Do not attempt to run the vehicle on leaded fuel or fuel with metallic additives (e.g. manganese or iron).

- Observe the maximum ethanol content of the fuel.



Fuel additives clean the fuel injection system and the combustion zone. It is advisable to use fuel additives

when the engine is operated with low-grade fuel or if the vehicle is to be out of use for a lengthy period of time. More information is available from your authorised BMW Motorrad retailer.



Recommended fuel grade



Super Plus, unleaded
(maximum 5% ethanol,
E5)
98 ROZ/RON
93 AKI



Alternative fuel grade



Super unleaded (power-
and consumption-re-
lated restrictions.) (max-
imum 10% ethanol,
E10)
95 ROZ/RON
90 AKI



» Pay attention to the following symbols in the fuel filler cap and on the fuel pump:



118 RIDING

Refuelling



WARNING

Fuel is highly flammable

Risk of fire and explosion

- Do not smoke. Never bring a naked flame near the fuel tank.



WARNING

Escape of fuel due to heat-induced expansion if fuel tank is overfilled

Risk of falling

- Do not overfill the fuel tank.




ATTENTION

Wetting of plastic surfaces by fuel

Damage to the surfaces (surfaces become unsightly or dull)

- Clean plastic surfaces immediately after contact with fuel.
- Make sure the ground is level and firm and place the motorcycle on its side stand.



- Open protective flap **1**.
- Unlock fuel tank cap **2** by turning the ignition key clockwise and pop the cap open.



- Refuel with fuel of the grade stated above; do not fill the tank past the bottom edge of the filler neck.
-  When refuelling after running on reserve, make sure that you top up the tank to a level above reserve, so that the new level is detected and the fuel reserve indicator light is switched off.

 The "usable fuel capacity" specified in the technical data is the quantity that the fuel tank could hold if refilled after it had been run dry and the engine had cut out due to a lack of fuel.



Usable fuel capacity

approx. 16.5 l



Fuel reserve

approx. 4 l

- Press the fuel tank cap down firmly to close.
- Remove the ignition key and close the protective cap.

SECURING MOTORCYCLE FOR TRANSPORTATION

- Make sure that all components that might come into contact with straps used to secure the motorcycle are adequately protected against scratching. Use adhesive tape or soft cloths, for example, for this purpose.




ATTENTION

Vehicle topples to side when being lifted on to stand

Risk of damage to parts if vehicle topples

- Secure the vehicle to prevent it toppling, preferably with the assistance of a second person.

- Push the motorcycle onto the transportation flat and hold it in position: do not place it on the side stand.



- Remove bolts **1** and fork partition **2**.




ATTENTION

Trapping of components

Component damage

- Do not trap components such as brake lines or cable legs.
- At the front, loop a strap over the bottom fork bridge on each side.
- Pull the straps down and tight.

suspension should be compressed as tightly as possible front and rear.



- After transport, position fork partition **2** and install bolts **1**.



Fork partition to fork bridge, bottom

Thread-locking compound:
micro-encapsulated

2 Nm



- At the rear, secure the straps to the rear frame on both sides and tighten the straps.
- Tighten all the straps uniformly; the vehicle's


ON THE RACE TRACK

08

STATUS INDICATORS FOR RACING	124
LAPTIMER	127
VEHICLE SETTINGS FOR RACING	128
RACE PRO RIDING MODES	129
LAUNCH CONTROL	130
PIT LANE LIMITER	132
DTC	133
CHASSIS AND SUSPENSION SETTINGS FOR RACING	135
REMOVING AND INSTALLING MIRRORS	135
REMOVING AND INSTALLING NUMBER-PLATE CARRIER	139
SWITCHING OFF ABS WHEN RIDING ON THE RACE TRACK	144
GEARSHIFT-PATTERN REVERSER	145


STATUS INDICATORS FOR RACING

Sport 1 display



- 1 Adapt DTC (▣▣▣▣ 133).
- 2 Maximum DTC torque reduction
- 3 Current DTC torque reduction
- 4 Rev. counter
- 5 Maximum braking deceleration
- 6 Current braking deceleration
- 7 Maximum lean angle
- 8 Current lean angle
- 9 Unit for rpm display:
1,000 revolutions per minute


Sport 2 display



- 1 Adapt DTC (11111 133).
- 2 Maximum DTC torque reduction
- 3 Current DTC torque reduction
- 4 Rev. counter
- 5 Difference between the last lap time and reference time or difference between current lap time and reference time
- 6 Reference time: fastest of the currently saved laps or all-time fastest saved lap (11111 127)
- 7 Current lap time
- 8 Unit for rpm display: 1,000 revolutions per minute
- 9 Operating help

126 ON THE RACE TRACK

Sport 3 display



- 1 Adapt DTC (▮▮▮▮▶ 133).
- 2 Maximum DTC torque reduction
- 3 Current DTC torque reduction
- 4 Rev. counter
- 5 Current lean angle
- 6 Maximum lean angle
- 7 Reference time: fastest of the currently saved laps or all-time fastest saved lap (▮▮▮▮▶ 127)
- 8 Current lap time
- 9 Operating help
- 10 Difference between the last lap time and reference time or difference between current lap time and reference time
- 11 Unit for rpm display: 1,000 revolutions per minute

LAPTIMER

Starting timing

- Call up the **Sport** menu and change to the **Sport 2** or **Sport 3** display.
- Start the engine.



- Press button **1**.
 - » Time recording is running.
- Every time you cross the start/finish line, press button **1** again to start recording for the next lap.
 - » The data of the preceding lap are written into memory.
 - » The time for the current lap starts again from 00:00:00.
 - » The stopped time for a lap is displayed for an adjustable **Disp. duration time** before the display switches to elapsed time for the current lap.
 - » Recording continues even if you exit the display mode during recording.

Ending time recording and managing times

Requirement

Sport 2 or **Sport 3** display is shown.

- Press down the **MENU** rocker button.
 - » The **LAPTIMER** menu is displayed.
 - Timing in progress can be ended with **Stop recording**.
 - You can go to the current lap times and riding data by using **Laps**. 99 laps can be saved. If the laps have not been deleted in the meantime, additional laps overwrite the first laps.
 - All laps can be deleted with **Delete all laps**.
 - You can use **Reset Best Ever** to reset the all-time best lap (**Best Ever**).

Adjusting laptimer

- Navigate to **Settings**, **Vehicle settings**, **Laptimer**. The following settings are available:
 - » **Debounce time**: If the headlight flasher has been actuated, the headlight flasher can be actuated again within this time without affecting lap time measurement.

128 ON THE RACE TRACK

- with M GPS-Laptrigger^{OE}
- » **Trigger:** Change of actuation. **Manual:** Actuation by headlight flasher. **External:** Actuation by M GPS-Laptrigger. Automatic signalling of each new lap and evaluation of the logged data require the optional M Datalogger accessory including GPS-Laptrigger.◀
 - » **Disp. duration:** Within this time, the stopped lap time is displayed before the current lap time is shown.
 - » **Reference:** Selection of which best time is displayed as a reference. **Best:** Best time of the current recording session or **Best Ever:** Best-ever measured time.
 - » **Best lap in progress:** When this function is activated, the difference between the current lap time and the reference time is displayed instead of the difference between the last lap time and the reference time.

Best-ever lap

The best-ever lap (**Best Ever**) is the fastest of all recorded laps and is updated once a faster lap has been recorded. The best-ever lap remains stored in memory even if the

recorded laps are deleted. This means that other races can subsequently be timed and the lap times of those races compared with the best-ever lap from earlier races. The best-ever lap can be deleted in the **LAPTIMER** menu. If the best-ever lap is from a saved recording, it is accompanied on the display by the relevant lap number. If the best-ever lap shows without a lap number, this means that it comes from a recording that has been deleted.

VEHICLE SETTINGS FOR RACING

Activating configuration for the race track

- Call up the **Settings** menu and activate **Racetrack**.
- Acknowledge the **In racetrack mode**, all **Connectivity functions** are deactivated. message.



The **Connectivity functions** **Media**, **Telephone** and **Navigation** are **deactivated** by switching on the race track functions.

- **Select Configuration.**

Configuration menu



The warning about faulty lights can be suppressed when riding on a race track.

The rpm of the Pit Lane Limiter can be adjusted (➡ 132).

With RACE PRO CONFIGURATION, vehicle parameters can be fine-tuned (➡ 129).

Light warnings: If the turn indicators or number plate carrier are removed in preparation for a race-track session, the vehicle electronics detect a bulb failure and the appropriate warning message is displayed. If **Light warnings** is deactivated, the warning message is suppressed.

RACE PRO RIDING MODES

Configuration for the race track

The RACE PRO riding modes enable pro-rider tweaks to be made to the ride-dynamics control systems. This means that individual rider requests, track characteristics and weather conditions can be taken into account.

The following parameters can be adjusted:

- Engine
- Engine Brake
- Traction (DTC)
- Wheelie (DTC)
- ABS

For further information about the parameters, see (➡ 155).

Three RACE PRO riding modes can be configured.

A RACE PRO riding mode can also be selected by pressing the MODE button (➡ 52).

If RACE PRO riding mode is activated, RAIN, ROAD and DYNAMIC riding modes are not available. Instead, it is possible to switch between the RACE, RACE PRO 1, RACE PRO 2 and RACE PRO 3 riding modes.

130 ON THE RACE TRACK


If RACE PRO riding mode is deactivated, all pre-defined riding modes are available again and the ROAD riding mode is selected.

Configuring RACE PRO riding modes

- Call up the Settings menu and activate Racetrack.
 - Select Configuration and activate RACE PRO riding mode.
 - Select Configuration.
- » The current configurations are shown as an overview.



- Select a configuration.



- Select a parameter.

» The current setting is displayed graphically and numerically. In addition, explanatory texts are displayed for the relevant setting.

– If a setting is also saved in a standard riding mode, this riding mode is specified.

- Change a setting as desired.

Restoring factory defaults

- Select a configuration.
- Scroll down the list of parameters and select the last entry Reset.

LAUNCH CONTROL

Racing start with Launch Control

Launch Control assists the rider by revving the engine to the ideal speed for a racing start.



Engine speed after activating Launch Control at full throttle

9000 min⁻¹

When Launch Control is active engine torque is reduced so that forward propulsion is maximised on the flat with the front wheel just starting to lift off the ground. Torque is temporarily reduced slightly when the electronics detect front-wheel lift. Engine rpm limitation is deactivated when the

motorcycle reaches a specified speed.

 Speed when deactivating engine speed limitation for Launch Control

approx. 70 km/h

Launch Control is turned off in the following circumstances:

- The third gear is engaged.
- The angle of inclination is greater than 30°.
- The engine or the ignition is switched off.

The number of consecutive starts using Launch Control is limited in order to protect the clutch. The number of possible starts remaining appears on the display, e.g. Launch Control: 3 starts still avail..

Operating Launch Control



CAUTION

Launch Control permits maximum acceleration, so unfamiliar riding situations can occur.

Risk of accident through increased acceleration.

- Use Launch Control only on race tracks.

- Bring vehicle to starting position.

» Vehicle is stationary, engine is running.



- Press and hold down starter button **1** until the display shows the number of starts with Launch Control still permitted.

» If no more starts are possible, L-Con not available. Clutch too hot. is displayed.

- Allow the clutch to cool.



Clutch cooling time

approx. 3 min (With engine running)

approx. 20 min (With engine stopped)

- Proceed in the normal way when starting; open the throttle only as far as necessary to reach the rpm limit.

132 ON THE RACE TRACK

- After engaging the clutch, open the throttle completely.
 - » Shift light lights up or flashes.
 - » Launch Control controls the optimum torque on the rear wheel and keeps the engine speed constant up to the speed specified below.
- Keep the throttle twistgrip fully open.



Speed when deactivating engine speed limitation for Launch Control

approx. 70 km/h

- » As soon as rpm limitation ceases, engine rpm increases because the throttle twistgrip is in the full-throttle position.
- » Throttle-twistgrip reaction is normal again.
- Depending on the racing circuit, upshift and lean into the bends.
 - » If in third gear or leaning further than 30°, the shift light disappears.
 - » The racing start with Launch Control is concluded.

PIT LANE LIMITER

Limiting the speed with the Pit Lane Limiter

The Pit Lane Limiter helps you to comply with a speed limit, e.g. in the pit lane. To do so, a maximum rpm is specified for the engine when riding in 1st gear.



The speed resulting from the maximum rotational speed is dependent on the ratio and tyre size.

Range of values

–3,500 to 8,000 rpm in increments of 100

Setting up Pit Lane Limiter

- Call up the Settings menu and activate Racetrack.
- Select Configuration.
- Activate Pit Lane Limiter.
- Select Configuration.
- Set up RPM.

Operating Pit Lane Limiter



- Ride in 1st gear.

- Press and hold down starter button **1**.
- Open throttle grip until the set maximum rpm has been reached.
- » The ignition is interrupted to limit engine speed.



WARNING

As soon as the starter button is released the vehicle accelerates in accordance with the position of the throttle twistgrip.

Risk of crashing due to severe jerk forward if throttle twistgrip in full load position.

- Do not fully open the throttle twistgrip; instead, turn it only to the position at which the engine reaches its speed-limit rpm.


- Release starter button **1**.
- » The vehicle accelerates at the maximum rate.

DTC

DTC adjustment

The DTC controls permissible rear-wheel slip in accordance with your selected riding mode. The control can be adjusted in detail in the configuration of the RACE PRO riding modes.

Configuring RACE PRO riding modes (130)



The DTC setting can be adjusted during riding via the DTC rocker button **1** on the left handlebar operating facility.

Adapting DTC

- Configuring RACE PRO riding modes (130).
- Select the desired RACE PRO riding mode.


 DTC can also be adjusted during riding.



If RACE PRO riding mode is activated, Speed Limit Info **1** is hidden and DTC

134 ON THE RACE TRACK

control value **2** is displayed instead.



- Press rocker button **1** upwards briefly in order to increase DTC control.



WARNING

Loss of stability because of rear wheel spinning when DTC control is reduced.

Risk of falling

- Reduce DTC for riding on racing circuits only.
 - Only change DTC control by one level at a time and carefully test the effects on drivability.
- Press DTC rocker button **1** downwards briefly in order to reduce DTC control.
 - » The set value is shown in the display and is between -7 and 7:
 - » 1 ... 7: Reduce slip at the rear wheel in a maximum of seven stages. 7 is the value corres-

ponding to earliest DTC intervention.

- » -1 ... -7: Increase slip at the rear wheel in a maximum of seven steps. -7 is the value corresponding to latest DTC intervention.
- » 0: Works default setting
- » DTC display hidden: DTC switched off.

DTC deactivation

On very loose surfaces (for example in a gravel trap of a race track), the DTC's attempts to control propulsive power might reduce drive to the extent that the rear wheel no longer turns. Under these circumstances, BMW Motorrad recommends temporarily switching off DTC. Bear in mind that the rear wheel will spin on the loose surface and close the throttle in good time before you reach a firm surface.

Traction control and wheelie suppression are also switched off by switching off DTC. Then reactivate DTC. Switching off DTC (🔌 50)

CHASSIS AND SUSPENSION SETTINGS FOR RACING

Observe the recommendations for racing:

Adjust the steering damper (► 92).

Adjust the spring preload at the rear wheel (► 94).

Adjust compression-stage damping at front wheel (► 95).

Adjust rebound-stage damping at front wheel (► 96).

Adjust rebound-stage damping at rear wheel (► 96).

Adjust compression-stage damping at rear wheel (► 97).

Adjust ride height (► 101).
Adjust swinging arm (► 98).

REMOVING AND INSTALLING MIRRORS

Removing mirrors




ATTENTION

Removal of the mirrors

Voiding of homologation for riding on public roads

- Do not ride on public roads without mirrors and turn indicators correctly installed.

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Remove screws **1**.
- Remove screws **2** with washers.
- Remove windscreen in the **direction of arrow**.



- Unclip air inlet flap at the top in the **direction of arrow** and remove downwards.

136 ON THE RACE TRACK



- Disconnect connector for right turn indicator **1** and left turn indicator **2**.
- Prevent moisture from making its way into open plug connections, preferably by inserting the corresponding blanking plugs from the BMW Motorrad M Cover Kit.

 If the mirrors with integrated turn indicators are removed in preparation for a race-track session, the electronics interpret this as a defective light and the corresponding warning appears on the display. Deactivating the **Light warnings** function in the **RACETRACK CONFIGURATION** menu suppresses this warning.



- Remove nuts **1** and **2** on the left and right and remove mirrors.
- Carefully thread out cable.




- Secure fairing **1** at the left and right fairing bracket **2**. If cable ties are used, affix adhesive tape as protection at the points where chafing might occur.

 Use the M Cover Kit from BMW Motorrad to cover the threaded holes for the screws so that the parts can subsequently be re-installed. The M Cover Kit includes blanking plugs to prevent moisture from making its

way into the vehicle electrical system.



- Position air inlet flap **1** and clip in at the top **2**.



- Position windscreen in the **direction of arrow**.
- Install screws **1**.
- Install screws **2** with the washers.




Windscreen to air intake


1 Nm

Installing mirrors

- Make sure the ground is level and firm and place the motor-cycle on its stand.
- Remove the trim panel fasteners.



- Remove screws **1**.
- Remove screws **2** with washers.
- Remove windscreen in the **direction of arrow**.



- Unclip air inlet flap at the top in the **direction of arrow** and remove downwards.

138 ON THE RACE TRACK




- Carefully thread in cable for turn indicators.
- Place left and right mirrors in the mountings **1**.



- Connect connector for right turn indicator **1** and left turn indicator **2**.
- Check operation of the turn indicators.



- Install nuts **1** and **2** on the rear of the fairing using the appropriate torque.




- Insert air inlet flap at the bottom **1** and clip in at the top **2**.



Mirror to front panel carrier

Thread-locking compound:
mechanical

8 Nm



- Position windscreen in the **direction of arrow**.

- Install screws **1**.
- Install screws **2** with the washers.



Windscreen to air intake

1 Nm

REMOVING AND INSTALLING NUMBER-PLATE CARRIER

Removing number plate carrier



ATTENTION


Removal of the number plate carrier

Voiding of homologation for riding on public roads


- With the number-plate carrier removed, do not ride the motorcycle on public roads.
- Make sure the ground is level and firm and place the motorcycle on its stand.
- with two-up riding package^{OE}
- Remove the passenger seat (→ 61).
- Remove the tail-hump cover (→ 61).



- Remove screws **1** and **2**.
- Unclip left and right rear trim panels carefully in the **direction of arrow**.



- Carefully unclip left and right rear trim panel **1**, first horizontally **2**, then vertically **3**.



- Remove cable strap **1**.


140 ON THE RACE TRACK

- Disconnect connector for number plate light **2** and left turn indicator **3**.


 If the license-plate carrier is removed in preparation for a race-track session, the electronics interpret this as a defective light and the corresponding warning appears on the display. Deactivating the Light warnings function in the RACETRACK CONFIGURATION menu suppresses this warning.




- Disconnect connector for right turn indicator **1**.



- Disengage cable for right turn indicator **1** from holders **4** and remove.
- Remove cables for left turn indicator **2** and number plate light **3**.




- Remove screws **1**, noting collared bushes **2**.



- Unhook number plate carrier **1** and remove downwards.
- Carefully thread out cable.

 Use the M Cover Kit from BMW Motorrad to cover the threaded holes for the screws so that the parts can subsequently be re-installed. The M Cover Kit includes blanking plugs to prevent moisture from making its way into the vehicle electrical system.

- Prevent moisture from making its way into open plug connections, preferably by inserting the corresponding blanking plugs from the BMW Motorrad M Cover Kit.



- Starting at the rear, carefully clip in left and right rear trim panels **1**, first vertically **2**, then horizontally **3**.



- Carefully clip in rear trim panel in the **direction of arrow**.
- Install bolts **1** and **2**.

—with two-up riding package^{OE}

- Install the passenger seat (→ 62).
- Install the tail-hump cover (→ 61).


142 ON THE RACE TRACK

Installing number plate carrier


- Make sure the ground is level and firm and place the motorcycle on its stand.
- with two-up riding package^{OE}
- Remove the passenger seat (▶▶▶ 61).
- Remove the tail-hump cover (▶▶▶ 61).




- Remove screws **1** and **2**.
- Unclip left and right rear trim panels carefully in the **direction of arrow**.



- Carefully unclip left and right rear trim panels **1**, first horizontally **2**, then vertically **3**.




- Position number plate carrier **1** and carefully thread in cable.
- Hook in number plate carrier **1**.




- Install screws **1** through collared bushes **2**.

Number plate carrier on rear frame

2 Nm




- Work cable for right turn indicator **1** into position and secure it in holders **4**.
- Work cables for left turn indicator **2** and number plate light **3** into position.



- Connect connector for number plate light **2** and left turn indicator **3**.
- Install cable strap **1**.
- Check operation of the light and the turn indicators.



- Connect connector for right turn indicator **1**.



- Carefully clip in left and right rear trim panels **1**, first vertically **2**, then horizontally **3**.

144 ON THE RACE TRACK



- Carefully clip in rear trim panel in the **direction of arrow**.

- Install bolts **1** and **2**.

—with two-up riding package^{OE}

- Install the passenger seat (▮▮▮ 62).
- Install the tail-hump cover (▮▮▮ 61).

SWITCHING OFF ABS WHEN RIDING ON THE RACE TRACK

Switching off ABS function Requirement

Number plate carrier is removed.

- Switch on the ignition (▮▮▮ 46).

 You have the option of deactivating the ABS function while the motorcycle is on the move.

- Press button **1** for at least three seconds.



lights up.

- » The ABS function is switched off.
- » The integral function is switched off.
- » Hill Start Control is still activated.
- » Dynamic Brake Control is also switched off when the ABS function is switched off.
- » When the RACE PRO riding modes are active, even after the ignition has been switched off and on again the ABS remains off in RACE PRO and RACE riding modes.
- For more information on brake systems with BMW Motorrad Integral ABS, see the section entitled "Engineering details":
 - » Partially integral brakes (▮▮▮ 150)

- » Hill Start Control function (159)
- » How Dynamic Brake Control works (157)

Switching on ABS function



- Press button **1** for at least 3 seconds.
 goes out; if self-diagnosis has not completed it starts flashing.
- » The ABS function is switched on.
- If the option **Racetrack** is deactivated in the menu **Settings**, ABS is also activated by switching the ignition off and on again.



An ABS fault has occurred if the ABS indicator and warning light shows when the motorcycle accelerates to a speed in excess of the minimum stated below after the ignition was switched off and then on again.

min 10 km/h

GEARSHIFT-PATTERN REVERSER

Shift pattern for racing

The shift pattern can be reversed for racing by changing the position of the selector rod. Reversing the shift pattern means that the gearshift lever is lifted up for 1st gear and pressed down for all the other gears. This is the reverse of the arrangement for riding on public roads.

Reversing the shift pattern




ATTENTION

Riding with shift pattern reversal on public roads

Voiding of homologation for riding on public roads


- Do not install the gearshift-pattern reverser for riding on public roads.

146 ON THE RACE TRACK



» The gearshift-pattern reverser for racing is set up.

- Clean thread **1**.
- Pull off protective cap **2** and slide on the gearshift rod **4**.
- Remove bolt **3** with washer.
- Transfer the gearshift rod **4** to the thread for the inverted gearshift pattern **1**.



- Insert bolt **1** through ball joint **2** and washer **3**.
- Install bolt **1** in thread for inverted gearshift pattern **4**.



Selector rod to gearshift lever

Thread-locking compound:
micro-encapsulated

8 Nm

- Install protective cap **5**.

ENGINEERING DETAILS

09

GENERAL NOTES	150
ANTILOCK BRAKE SYSTEM (ABS)	150
DYNAMIC TRACTION CONTROL (DTC)	153
RIDING MODE	155
DYNAMIC BRAKE CONTROL	157
GEAR SHIFT ASSISTANT	158
HILL START CONTROL (HILL START CONTROL PRO)	159

GENERAL NOTES

To find out more about engineering go to:

bmw-motorrad.com/technology

ANTILOCK BRAKE SYSTEM (ABS)

Partially integral brakes

Your motorcycle is equipped with partially integral brakes. Both front and rear brakes are applied when you pull the handbrake lever. The foot-brake lever acts only on the rear brake.



ATTENTION

Attempted burn-out despite Integral braking function

Damage to rear brake and clutch

- Burn-out must only occur from a vehicle standstill. Burn-out is not proper vehicle use and may therefore lead to fault messages.

How does ABS work?

The amount of braking force that can be transferred to the road depends on factors that include the coefficient of friction of the road surface. Loose stones, ice and snow or a wet

road all have much lower coefficients of friction than a clean, dry asphalt surface. The lower the coefficient of friction, the longer the braking distance. If the rider increases braking pressure to the extent that braking force exceeds the maximum transferable limit, the wheels start to lock and the motorcycle loses its directional stability; a fall is imminent. Before this situation can occur, ABS intervenes and adapts braking pressure to the maximum transferable braking force, so the wheels continue to turn and directional stability is maintained irrespective of the condition of the road surface.

What are the effects of surface irregularities?

Humps and surface irregularities can cause the wheels to lose contact temporarily with the road surface; if this happens the braking force that can be transmitted to the road can drop to zero. If the rider brakes in this situation, the ABS has to reduce the brake pressure in order to ensure driving stability when resuming contact with the road. Up to this point, BMW Motorrad Integral

ABS assumes an extremely low coefficient of friction (gravel, ice, snow) so that the road wheels turn in every conceivable situation and so ensure driving stability. As soon as it registers the actual circumstances, the system reacts instantly and adjusts braking force accordingly to achieve optimum braking.

What feedback does the rider receive from the BMW Motorrad ABS Pro?

If the ABS has to reduce braking force on account of the circumstances described above, vibration is perceptible through the brake lever.

When the brake lever is pulled, brake pressure is also built up at the rear wheel by the integral function. If the brake pedal is depressed after the brake lever is pulled, the brake pressure built up beforehand is perceptible as counter-pressure sooner than is the case when the brake pedal is depressed either before or at the same time as the brake lever is pulled.

Rear wheel lift

Where there is a high level of adhesion between the tyres and road, the front wheel is only blocked very late or not at all even when the brakes are applied forcefully. Consequently, ABS does not intervene until very late, if at all. Under these circumstances the rear wheel can lift off the ground, and the outcome can be a highsidings situation in which the motorcycle can flip over.



WARNING

Rear wheel lift due to severe braking

Risk of falling

- When you brake sharply, bear in mind that ABS control cannot always be relied on to prevent the rear wheel from lifting clear of the ground.

What is the design baseline for ABS?

Within the limits imposed by physics, the ABS ensures directional stability on any surface. The system is not optimised for special requirements that apply under extreme competitive situations on the track. The

driving behaviour should be adapted to actual driving skills and the road conditions.

Special situations

The speeds of the front and rear wheels are compared as one means of detecting a wheel's incipient tendency to lock. If the system registers implausible values for a lengthy period the ABS function is deactivated for safety reasons and an ABS fault message is issued. Self-diagnosis has to complete before fault messages can be issued. In addition to problems with the BMW Motorrad ABS Pro, exceptional riding conditions can lead to a fault message being issued.

Exceptional riding conditions:

- Heating up with the motor-cycle on an auxiliary stand, in neutral or with a gear engaged.
- Rear wheel locked by the engine brake for a lengthy period, for example while descending steep gradients.

If a fault message is issued on account of exceptional riding conditions, you can reactivate the ABS function by switching the ignition off and on again.

What significance devolves on regular servicing?



WARNING

Brake system not regularly serviced

Risk of accident

- In order to ensure that the BMW Motorrad ABS is always maintained in optimum condition, it is essential for you to comply strictly with the specified inspection intervals.

Safety reserves

The potentially shorter braking distances which ABS permits must not be used as an excuse for careless riding. It is primarily there to provide a safety reserve for emergency situations.



WARNING

Braking when cornering

Risk of accident despite ABS

- Invariably, the rider bears responsibility for assessing road and traffic conditions and adopting his or her style of riding accordingly.
- Do not take risks that would negate the additional margin of safety offered by this system.

ABS Pro

ABS Pro increases safety, particularly when braking in bends. ABS Pro prevents the wheels from locking even under sharp braking. ABS Pro reduces abrupt changes in steering force, particularly in shock-braking situations, counteracting the vehicle's otherwise natural but undesirable tendency to straighten up.

ABS intervention

Technically speaking, depending on the riding situation ABS Pro adapts ABS intervention to the motorcycle's bank angle. Signals for rate of roll and rate of yaw and lateral acceleration are used to calculate bank angle. They come from the angular rate sensor, an integral component of Dynamic Traction Control DTC. As the motorcycle is heeled over more and more as it banks into a corner, an increasingly strict limit is imposed on the brake-pressure gradient for the start of brake application. This slows the build-up of brake pressure to a corresponding degree. Additionally, pressure modulation is

more uniform across the range of ABS intervention.

Advantages for the rider

The advantages of ABS Pro for the rider are sensitive response and high braking and directional stability combined with best-case deceleration of the motorcycle, even when cornering.



ABS Pro is activated in the RAIN, ROAD and DYNAMIC riding modes. In the Dynamic Pro riding mode, ABS Pro can be parametrised to suit the rider's individual needs and preferences.

DYNAMIC TRACTION CONTROL (DTC)

How does Dynamic Traction Control work?

DTC takes the vehicle tilt into accounts, conveniently controls it and is useful for improving lap times on the racetrack. The Dynamic Traction Control system compares the speed of rotation at the circumferences of the front wheel and the rear wheel. The differential is used to compute slip as a measure of the reserves of stability available at the rear wheel. If slip exceeds a certain limit, the engine management

system intervenes and adapts engine torque accordingly. DTC can only provide support within the physical limits. The physical limits are strongly dependent on the road surface, road temperatures, tyre choice and tyre temperature. There is the danger of overheating when using unsuitable tyres on the race track.



WARNING

Risky riding

Risk of accident despite DTC

- Invariably, the rider bears responsibility for assessing road and traffic conditions and adopting his or her style of riding accordingly.
- Do not take risks that would negate the additional safety offered by this system.

Special situations

In accordance with the laws of physics, the ability to accelerate is restricted more and more as the angle of heel increases. Consequently, there can be a perceptible reduction in acceleration out of very tight bends.

With DTC, the speeds of the front and rear wheels are compared and the angle of heel taken into account as one means of detecting the rear wheel's incipient tendency to spin or slip sideways.

If the lean angle values are identified as implausible over an extended period of time, a substitute value is used for the lean angle or the DTC is switched off. Under these circumstances the indicator for a DTC fault shows. Self-diagnosis has to complete before fault messages can be issued. The BMW Motorrad traction control may switch off automatically under the exceptional riding conditions outlined below.

Exceptional riding conditions:

- Riding for a lengthy period with the front wheel lifted off the ground (wheelie).
- Rear wheel rotating with the vehicle held stationary by applying the front brake (burn-out).
- Heating up with the motorcycle on an auxiliary stand, in neutral or with a gear engaged.

When riding on a slippery surface, never snap the throttle twistgrip fully closed without pulling the clutch at the same time. Engine braking torque can cause the rear wheel to skid, with a corresponding loss of stability. The BMW Motorrad DTC is unable to control a situation of this nature.

RIDING MODE

Selection

To adjust the motorcycle to the road condition and the desired driving experience, the following riding modes can be selected:

- RAIN
- ROAD
- DYNAMIC
- RACE
- RACE PRO 1
- RACE PRO 2
- RACE PRO 3

When activated, the RACE PRO riding modes replace the RAIN, ROAD and DYNAMIC riding modes.

There are matched settings for the Engine, Engine Brake, Traction (DTC), Wheelie (DTC) and ABS systems in each riding mode.

In RACE PRO riding modes, the settings for the systems Engine, Engine Brake, Traction (DTC), Wheelie (DTC) and ABS can be individually adjusted.

Torque and throttle response

- In RAIN riding mode: Gentle throttle response, reduced torque in low gears.
- In ROAD and DYNAMIC riding modes: Optimum throttle response, reduced torque in low gears.
- In RACE riding mode: Optimum throttle response, maximum torque.
- In RACE PRO riding modes additionally: Soft throttle response, maximum torque.

Braking effect of the engine

- In RAIN and ROAD riding modes: Maximum braking effect of the engine.
- In DYNAMIC and RACE riding modes: Moderate braking effect of the engine.
- Additionally in the RACE PRO riding modes: minimal braking effect of the engine.

156 **ENGINEERING DETAILS**

Traction control (DTC)

- In RAIN riding mode: Maximum stability on wet roads. There may be reduced acceleration on dry roads.
- In ROAD riding mode: High stability on dry roads. Acceleration on dry roads might be slightly reduced.
- In DYNAMIC riding mode: High performance on dry roads. If road conditions are poor, optimum stability cannot be ensured.
- In RACE riding mode: Maximum performance. On a poor road surface or with unsuitable tyres such as touring tyres for example, stability might be impaired. In RACE PRO riding modes, traction control can be finely adjusted using the DTC rocker button while riding to ensure optimum performance.

Wheelie (DTC) – lifting of the front wheel

- In RAIN riding mode: Maximum stability. Efforts are made to suppress a Wheelie.
- In ROAD, DYNAMIC and RACE riding modes: Shallow Wheelie possible; optimum drive.
- In RACE PRO riding modes with setting 1: High Wheelie

possible. The rider must decelerate the rear wheel themselves in order to prevent the Wheelie. The system only intervenes late.

- In RACE PRO riding modes with setting 0: The system is deactivated.

ABS

- The rear wheel lift-off assistant is active in the RAIN, ROAD and DYNAMIC riding modes.
- In RAIN, ROAD and DYNAMIC riding modes, the ABS is set up for on-road riding.
- In RACE riding mode, ABS is set up for race-track riding.
- In RACE PRO riding modes: The deployment of ABS can be adjusted individually.

Mode changes

The riding mode can be changed while the vehicle is stationary with the ignition on. It is possible to change it while driving under the following conditions:

- No drive torque on the rear wheel.
- No brake pressure in the brake system.

The following steps must be taken to change the riding mode:

- Close the throttle twistgrip.
- Release the brake levers.
- Deactivate adaptive cruise control.

The desired riding mode is initially preselected. The mode change does not take place until the systems in question are all in the appropriate state. The selection menu does not disappear from the display until the mode change has taken place.

DYNAMIC BRAKE CONTROL

How Dynamic Brake Control works

 The Dynamic Brake Control function is active in all riding modes. It can only be deactivated in the RACE PRO riding modes by individually adjusting the ABS.

The Dynamic Brake Control function assists the rider in emergency braking situations.

Detection of emergency braking

- Sudden, sharp application of the front brake is interpreted as emergency braking.

Behaviour in emergency braking

- If emergency braking occurs at a speed in excess of 10 km/h, the ABS function is further assisted by Dynamic Brake Control.
- When partially integral braking at a high brake pressure gradient is initiated, Dynamic Brake Control increases the integral brake pressure at the rear wheel. The stopping distance shortens and controlled braking is possible.

Behaviour during accidental actuation of the throttle grip

- If the throttle is accidentally opened (throttle grip position > 5 %) during emergency braking, Dynamic Brake Control ensures the desired braking effect by ignoring actuation of the throttle grip. The effectiveness of emergency braking is ensured.
- If the throttle is closed (throttle grip position < 5 %) while Dynamic Brake Control is in action, the engine torque requested by the ABS brake system is restored.
- If emergency braking ceases and the rider still has not changed the position of the throttle grip, Dynamic Brake

158 ENGINEERING DETAILS

Control steadily ramps engine torque back to the rider's requested level.



The function of the Dynamic Brake Control is switched off at the same time as the ABS is switched off.

GEAR SHIFT ASSISTANT

Shift assistant Pro

Your vehicle is equipped with a shift assistant, a system originally developed for racing and now adapted for riding on public roads. It permits upshifts and downshifts without de-clutching or closing the throttle in virtually all load and rpm ranges.

Advantages

- 70-80 % of all gearshifts on a trip can be done without using the clutch.
- Less relative movement between rider and passenger because the shift pauses are shorter.
- It is not necessary to close the throttle valve when shifting under acceleration.
- When braking and downshifting (throttle valve closed), engine speed is adjusted by blipping the throttle.

–Shift time is shorter than a gearshift with clutch actuation.

In order for the system to identify a request for a gearshift, the rider has to move the shift lever from its idle position in the desired direction against the force of the spring through a certain "overtravel" at ordinary speed or rapidly and keep the shift lever in this position until the gearshift is completed. It is not necessary to increase the force applied to the shift lever while shifting is in progress. Once the gearshift has completed the shift lever has to be fully released before another gearshift with the Pro shift assistant can take place. Constantly maintain the corresponding load condition (throttle grip position) before and during gear shifts using the Gear Shift Assistant Pro. A change in the position of the throttle twistgrip during a gearshift can cause the function to abort and/or lead to a missed shift. The shift assistant Pro provides no assistance for the gear change if the rider declutches.

Downshifting

- Downshifting is assisted until maximum rpm for the target gear to be selected is reached. This prevents over-revving.

	Maximum engine speed
max 15100 min ⁻¹	

Upshifting

- The shift assistant provides no assistance if engine speed drops below idle during an upshift.

	Idle speed
1270±50 min ⁻¹ (Engine at regular operating temperature)	

HILL START CONTROL (HILL START CONTROL PRO)

Hill Start Control function

Hill Start Control Pro is a pullaway assistant that operates on the partially integral ABS system to prevent the vehicle from rolling back on a gradient, without the rider having to keep pressure applied to the brake lever. When Hill Start Control Pro is activated, pressure is built up in the rear brake system to keep

the machine at a standstill on a gradient.

The brake pressure in the brake system is dependent on the gradient.

Effect of an incline on brake pressure and drive-off behaviour

- If the motorcycle is stopped on a gentle incline, only low brake pressure is built up. In this case, the brakes are quickly released when driving off. The motorcycle can be moved off more gently. It is not necessary to turn the throttle grip again.
- If the motorcycle is stopped on a steep incline, high brake pressure is built up. In this case, the brakes take longer to release when driving off. More torque is required for driving off which also requires the rider to turn the throttle grip again.

Behaviour when the motorcycle rolls or slips

- If the vehicle starts to roll while Hill Start Control Pro is active, brake pressure is increased.
- If the rear wheel locks, the brake is released again after approx. 1 m. This prevents the vehicle slipping with a

160 ENGINEERING DETAILS

locked rear wheel, for example.

soon as the ignition is switched off.

Releasing brake when stopping the engine or time-out

Hill Start Control Pro is deactivated if the rider stops the engine by hitting the emergency-off switch (kill switch) or when the side stand is extended, or after time-out (10 minutes).

In addition to the indicator and warning lights, the rider should be made aware that Hill Start Control Pro has been deactivated by the following behaviour:

Brake warning jolt

- The brake is released briefly and reactivated immediately.
- This creates a jolt which the rider feels.
- The ABS brake system with partially integral function sets a speed of approx. 1-2 km/h.
- The rider must brake the motorcycle manually.
- After two minutes, or if the brake is actuated, the partially integral ABS brake system stops speed-control intervention.



The holding pressure is released immediately without a brake warning jolt as

MAINTENANCE

10

GENERAL NOTES	164
TOOLKIT	165
FRONT-WHEEL STAND	166
REAR-WHEEL STAND	166
ENGINE OIL	167
BRAKE SYSTEM	168
CLUTCH	173
COOLANT	174
TYRES	175
WHEEL RIMS	176
WHEELS	176
CHAIN	183
LIGHTING	187
TRIM PANEL COMPONENTS	187
JUMP-STARTING	191
BATTERY	192
FUSES	194
DIAGNOSTIC CONNECTOR	196

GENERAL NOTES

The Maintenance chapter describes straightforward procedures for checking and replacing certain wear parts.

Microencapsulated screws

The microencapsulation is a chemical thread-locker. An adhesive compound creates a secure connection between bolt and nut or between screw and component. Consequently, microencapsulated screws are for once-only use and are not intended for re-installation after being slackened.

After removal of the screw, clean the internal thread to remove all traces of thread-locking compound. Always use new microencapsulated screws when re-assembling. Consequently, prior to disassembly make sure that you have suitable tools for cleaning the threads and a new replacement for each screw to be removed. If the job is not done correctly there is no guarantee that the screw will remain secure, which means that you would be putting yourself at risk!


Further information

Special tightening torques are listed as applicable. The tightening torques for the threaded fasteners on your vehicle are listed in the section entitled "Technical data".

You will find information on more extensive maintenance and repair work in the repair manual on DVD for your vehicle, available from your authorised BMW Motorrad retailer.

Some of the work calls for special tools and a thorough knowledge of the technology involved. If you are in doubt, consult a specialist workshop, preferably your authorised BMW Motorrad retailer.

TOOLKIT



- 1** Lever
 - Adjust the spring preload for rear wheel (▮▮▮ 94).
 - Adjust the ride height to swinging arm pivot point setting (▮▮▮ 101).
- 2** Open-ended spanner
Width across flats 10/13
 - Removing battery (▮▮▮ 194).
 - Adjust the spring preload for front wheel (▮▮▮ 93).
- 3** Reversible screwdriver
blade
Slotted bit and Torx T25
 - Removing and installing trim panel components.
 - Remove the rider's seat (▮▮▮ 62).
 - Adjust the compression-stage damping for front wheel (▮▮▮ 95).
- 3**
 - Adjust the rebound-stage damping for front wheel (▮▮▮ 96).
 - Adjust the rebound-stage damping for rear wheel (▮▮▮ 97).
 - Adjust the compression-stage damping for rear wheel (▮▮▮ 96).
- 4** Replacement fuses
 - 7.5 A
 - 15 A
- 5** Plastic cap
 - Adjust the spring preload for front wheel (▮▮▮ 93).
- 6** Torx wrench, T30
 - Removing and installing trim panel components.

FRONT-WHEEL STAND

Installing front-wheel stand



ATTENTION

Use of the BMW Motorrad front wheel stand without accompanying use of centre stand or auxiliary stand

Risk of damage to parts if vehicle topples

- Place the motorcycle on its centre stand or another auxiliary stand before lifting the front wheel with the BMW Motorrad front-wheel stand.
- Make sure the motorcycle is standing firmly.
- Place the motorcycle on an auxiliary stand; BMW Motorrad recommends the BMW Motorrad rear-wheel stand.
- Installing rear-wheel stand (166).



- For a description of the correct mounting, refer to the instructions for the front-wheel stand.
- BMW Motorrad offers a suitable auxiliary stand for every vehicle. Your BMW Motorrad partner will be happy to assist you with the selection of the right auxiliary stand.

REAR-WHEEL STAND

Installing rear-wheel stand



- For a description of the correct mounting, refer to the instructions for the rear-wheel stand.
- BMW Motorrad offers a suitable auxiliary stand for every

vehicle. Your BMW Motorrad partner will be happy to assist you with the selection of the right auxiliary stand.

ENGINE OIL

Checking engine oil level



ATTENTION

Misinterpretation of oil level reading, because oil level is temperature-dependent (the higher the temperature, the higher the oil level)

Engine damage

- Check the oil level only after a lengthy ride or when the engine is at operating temperature.
- Make sure the engine is at operating temperature and hold the motorcycle upright.
- Allow the engine to idle for one minute.
- Switch off the ignition.
- Wait five minutes for the oil to drain into the oil pan.



To protect the environment, BMW Motorrad recommends occasionally checking the engine oil after a journey of at least 50 km.




ATTENTION

Vehicle toppling sideways

Risk of damage to parts if vehicle topples

- Secure the vehicle, preferably with the assistance of a second person, so that it cannot topple sideways.
- Check the oil level in the display **1**.



Engine oil, specified level

between **MIN** and **MAX** mark
(Engine at operating temperature, vehicle is in vertical position)



Engine oil, quantity for topping up

max 1.3 l (Difference between **MIN** and **MAX**)

If the oil level is below the minimum mark:

- Top up the engine oil (168).

If the oil level is above the maximum mark:

- Have the oil level corrected by a specialist workshop, preferably an authorised BMW Motorrad retailer.

Topping up engine oil

- Make sure the ground is level and firm and place the motorcycle on its stand.

- Wipe the area around the oil filler opening clean.



- Remove cap **1** of the oil filler opening.



ATTENTION

Use of insufficient engine oil or too much engine oil

Engine damage

- Always make sure that the oil level is correct.

- Top up the engine oil to the specified level.
- Check the engine oil level (167).
- Install cap of oil filler opening **1**.

BRAKE SYSTEM

Checking function of brakes

- Operate brake lever.
 - » The pressure point must be clearly perceptible.
- Press the footbrake lever.
 - » The pressure point must be clearly perceptible.

If pressure points are not clearly perceptible:




ATTENTION


Work on brake system not in compliance with correct procedure

Risk to operational reliability of the brake system

- Have all work on the brake system undertaken by trained and qualified specialists.
 - Have the brakes checked by a specialist workshop, preferably an authorised BMW Motorrad Retailer.
- ### Checking brake pad thickness, front brakes
- Make sure the ground is level and firm and place the motorcycle on its stand.
 - Turn the handlebars to the full-lock position.



- Visually inspect the left and right brake pads to ascertain their thickness. Viewing direction: from the rear toward brake pads **1**.



Brake-pad wear limit, front

min 1 mm (friction pad only, without backing plate. The wear indicators (grooves) must be clearly visible)

If the brake pads are worn:



WARNING

Brake-pad thickness less than permissible minimum

Diminished braking effect, damage to the brakes

- In order to ensure the dependability of the brake system, do not permit the brake pads to wear past the minimum permissible thickness.


- Have the brake pads replaced by a specialist workshop, preferably an authorised BMW Motorrad retailer.

Checking brake pad thickness, rear brakes

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Visually inspect the brake pads to ascertain their thickness. Viewing direction: From below toward brake pads **1**.



Brake-pad wear limit,
rear

min 1 mm (friction pad only,
without backing plate.)

If the brake pads are worn:

**WARNING****Brake-pad thickness less than permissible minimum**

Diminished braking effect, damage to the brakes

- In order to ensure the dependability of the brake system, do not permit the brake pads to wear past the minimum permissible thickness.

- Have the brake pads replaced by a specialist workshop, preferably an authorised BMW Motorrad retailer.

Checking brake-fluid level, front brakes

- Make sure the ground is level and firm and hold the motorcycle upright.
- Move the handlebars to the straight-ahead position.



- Check the brake fluid level in brake fluid reservoir **1**.



Wear of the brake pads causes the brake fluid level in the reservoir to sink.



Brake fluid level, front

Brake fluid, DOT4

It is not permissible for the brake fluid level to be below the **MIN** mark. (Brake fluid reservoir horizontal)

If the brake fluid level drops below the permitted level:



WARNING

Not enough brake fluid in brake fluid reservoir, or contaminants in brake fluid

Considerably reduced braking power due to presence of air, contaminants or water in the brake system

- Cease operation of the vehicle immediately and do not ride it until the fault has been rectified.
 - Check the brake-fluid levels at regular intervals.
 - Always make sure that the lid of the brake fluid reservoir and the area around the lid are cleaned before opening.
 - Make sure that only fresh brake fluid from a sealed container is used.
-
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

Checking brake-fluid level, rear brakes

- Make sure the ground is level and firm and hold the motorcycle upright.



- Check the brake fluid level in brake fluid reservoir for rear wheel brake **1**.



Wear of the brake pads causes the brake fluid level in the reservoir to sink.



Brake fluid level, rear

Brake fluid, DOT4

It is not permissible for the brake fluid level to be below the **MIN** mark. (Brake fluid reservoir horizontal)

If the brake fluid level drops below the permitted level:



WARNING

Not enough brake fluid in brake fluid reservoir, or contaminants in brake fluid

Considerably reduced braking power due to presence of air, contaminants or water in the brake system

- Cease operation of the vehicle immediately and do not ride it until the fault has been rectified.
 - Check the brake-fluid levels at regular intervals.
 - Always make sure that the lid of the brake fluid reservoir and the area around the lid are cleaned before opening.
 - Make sure that only fresh brake fluid from a sealed container is used.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad retailer.

CLUTCH

Checking clutch function

- Pull the clutch lever.
- » An increase in force with increasing actuation must be perceptible.

If no increase in force with increasing actuation is perceptible:


- Have the clutch checked by a specialist workshop, preferably an authorised BMW Motorrad Retailer.

Checking clutch-lever play Requirement

Engine is cold.

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Move the handlebars to the straight-ahead position.

174 MAINTENANCE



- Repeatedly pull clutch lever **1** tight against the grip.
- Pull clutch lever **1** gently until resistance is perceptible, observing the clutch play **A**.




Clutch-lever play

3...5 mm (measured on outer clutch lever, handlebars in straight-ahead position, with cold engine)

Clutch play is out of tolerance:

- Adjust the clutch play (➡ 174).

Adjusting clutch play



- Loosen lock nut **1**.

- To increase clutch play:
Tighten adjusting screw **2** into the handlebar fitting.
- To reduce clutch play: Back off adjusting screw **2** in the handlebar fitting.



Distance between adjusting screw and handlebar fitting (clutch-cable setting)


3 ± 1.5 mm

- Check the clutch-lever play (➡ 173).
- Tighten lock nut **1** while holding adjusting screw **2**.

COOLANT


Checking coolant level

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Turn the handlebars all the way to the left.



- Check the coolant level in expansion tank **1**. Viewing direction: From in front toward

the inside of the right side panel.



Coolant, specified level

Between **MIN** and **MAX**
marks on the expansion tank
(cold engine)

If the coolant drops below the permitted level:

- Top up the coolant.

Top up coolant



- Open cap **1** of the expansion tank.
- Top up coolant to the specified level using a suitable funnel.

 Coolant top-up quantity

0.15 | (Difference between
MIN and **MAX**)

2.4 | (Coolant circuit, total)

CoolantFROSTOX HT-12

- Check the coolant level (▮▮▮▮▶ 174).
- Close cap **1** of the expansion tank.

TYRES

Checking tyre pressure



WARNING

Incorrect tyre pressure

Impaired handling characteristics of the motorcycle, shorter useful tyre life

- Always check that the tyre pressures are correct.



WARNING

Tendency of valve inserts to open by themselves at high riding speeds

Sudden loss of tyre pressure

- Install valve caps fitted with rubber sealing rings and tighten firmly.
- Place the motorcycle on its stand on firm, even ground.

176 MAINTENANCE

- Check tyre pressures against the data below.

 Tyre pressure, front
2.5 bar (tyre cold)
 Tyre pressure, rear
2.9 bar (tyre cold)

If tyre pressure is too low:

- Correct tyre pressure.

Checking tyre tread depth



WARNING

Riding with badly worn tyres

Risk of accident due to impaired handling

- If applicable, have the tyres changed in good time before they wear to the minimum tread depth permitted by law.
- Place the motorcycle on its stand on firm, even ground.
- Measure the tyre tread depth in the main tread grooves with wear marks.



Wear indicators are built into the main profile grooves on each tyre. The tyre is worn out when the tyre tread has worn down to the level of the marks. The locations of the marks are indicated on the

edge of the tyre, e.g. by the letters TI, TWI or by an arrow.

If the tyre tread is worn to minimum:

- Replace tyre or tyres, as applicable.

WHEEL RIMS

Check wheel rims

- Place the motorcycle on its stand on firm, even ground.
- Visually inspect the rims for defects.
- Have damaged rims inspected by a specialist workshop and replaced if necessary, preferably by an authorised BMW Motorrad Retailer.

WHEELS

Effect of wheel size on chassis and suspension control systems


The wheel sizes play an essential role with DTC. In particular, the diameter and the width of the vehicle's wheels are programmed into the control unit and are fundamental to all calculations. Any change in these influencing variables, caused for example by a switch to wheels other than those installed ex-works, can have serious effects on the performance of the control systems.

The sensor rings are essential for correct road-speed calculation, and they too must match the motorcycle's control systems and consequently cannot be changed.

If you decide that you would like to fit non-standard wheels to your motorcycle, it is very important to consult a specialist workshop beforehand, preferably an authorised BMW Motorrad Retailer. In these cases, the data programmed into the control units has to be changed to suit the new wheel sizes.

Removing front wheel

- Place the motorcycle on an auxiliary stand; BMW Motorrad recommends the BMW Motorrad rear-wheel stand.
- Installing rear-wheel stand (▶ 166).
- Mask off the parts of the wheel rim that could be scratched in the process of removing the brake calipers.



- Disengage the cable for the wheel speed sensor from holding clips **1** and **2**.
- Remove screw **4** and remove the wheel speed sensor from its bore.





ATTENTION

Unwanted inward movement of the brake pads

Component damage on attempt to install the brake caliper or because brake pads have to be forced apart

- Do not operate the brakes with a brake caliper not correctly secured.
- Remove mounting bolts **3** of the left and right brake calipers.

178 MAINTENANCE



- Force brake pads **1** slightly apart by rocking brake caliper **2** back and forth against brake disc **3**.
- Carefully pull the brake calipers back and out until clear of the brake discs.
- Lift the front of the motorcycle until the front wheel is clear of the ground, preferably using a BMW Motorrad front-wheel stand.
- Installing front-wheel stand (► 166).



ATTENTION

Incorrect gap between sensor ring and wheel speed sensor due to misaligned threaded bush in front suspension

Damage to wheel speed sensor. ABS malfunction

- Left clamp locates the threaded bush; do not loosen or remove this clamp.

- Loosen clamping screws **2**.
- Support the wheel and remove quick-release axle **1**.
- Roll the front wheel forward to remove.

Install the front wheel



WARNING

Use of a non-standard wheel
Malfunctions in operation of ABS and DTC

- See the information on the effect of wheel size on the ABS and DTC systems at the start of this chapter.



ATTENTION

Tightening threaded fasteners to incorrect tightening torque

Damage, or threaded fasteners work loose

- Always have the security of the fasteners checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.



ATTENTION

Front wheel installed wrong way round

Risk of accident

- Note direction-of-rotation arrows on tyre or rim.




ATTENTION

Installation of front wheel not in compliance with correct procedure

Damage to wheel speed sensor

- Note the wheel-speed sensor when rolling in the front wheel.

- Roll the front wheel into position in the front suspension.



- Lubricate quick-release axle **1**.



Lubricant

Optimoly TA

- Raise the front wheel, install quick-release axle **1** and tighten to specified torque.




Quick-release axle in threaded bush

50 Nm

180 MAINTENANCE

- Tighten clamping screws **2** to the specified tightening torque.




 Clamping screws in axle holder

Tightening sequence: Tighten screws six times in alternate sequence

19 Nm


- Ease the brake calipers on to the brake discs.



- Place brake caliper **2** on left and position cable routing **3**.
- Install bolts **1** and tighten to the specified torque.

 Radial brake caliper on wheel axle clamp

38 Nm




- Secure cable for wheel speed sensor in holder **1**.
- Insert wheel speed sensor in the bore hole and secure with bolt **2**.

 Wheel-speed sensor, front to forkleg

Thread-locking compound: micro-encapsulated

8 Nm



- Place brake caliper **2** on the right and install bolts **1** to specified torque.




Radial brake caliper on wheel axle clamp

38 Nm

- Remove the adhesive tape from the wheel rim.
- Firmly pull the brake lever until the pressure point is perceptible, and repeat this operation several times.
- Remove the front-wheel stand and the auxiliary stand.


Removing rear wheel

- Lift the motorcycle, preferably with a BMW Motorrad rear-wheel stand.
- Installing rear-wheel stand (→ 166).
- Position a wooden block or similar underneath the rear wheel so that the wheel cannot drop while being removed.




- Remove axle nut **1** with washer.
- Loosen lock nuts **2** on left and right.

- Loosen adjusting screws **3** on left and right.
- Push the axle forward as far as it will go to slacken the chain.



- Remove quick-release axle **1**.



- Roll the rear wheel as far forward as possible and disengage chain **1** from the chain sprocket.
- Roll the rear wheel back until it is clear of the swinging arm.



The sprocket and the spacer bushes on left and right are loose fits in the wheel. Make sure that these parts are

182 MAINTENANCE

not damaged or get lost on removal.

Installing the rear wheel



ATTENTION

Change in tyre size

Effect on control systems

- If the rear wheel tyre size is changed from 190 / 55 ZR 17 to 200 / 55 ZR 17 or vice versa, the parameters of the control systems have to be re-coded by a specialist workshop, preferably an authorised BMW Motorrad dealer.




ATTENTION

Tightening threaded fasteners to incorrect tightening torque

Damage, or threaded fasteners work loose

- Always have the security of the fasteners checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.




- Check judder damping elements **2** for damage, deformation and wear; replace if necessary.
- Lubricate judder damping elements **2** and install.




Installation tool

Silicone spray


- Install chain sprocket carrier **1**.



- Roll rear wheel on the support into the swinging arm.



- Roll the rear wheel as far forward as possible and loop chain **1** over the chain sprocket.




- Lubricate quick-release axle **1**.



Lubricant

Optimoly TA

- Lift the rear wheel and work quick-release axle **1** through the adjustment plate in the brake-caliper carrier and the rear wheel.
- Make sure that the quick-release axle fits into the recess for the flats.



- Install axle nut **1** with washer, but do not tighten it at this point.



WARNING

Brake pads not lying against the brake disc

Risk of accident due to delayed braking effect.

- Before driving, check that the brakes respond without delay.
- Operate the brake several times until the brake pads are bedded.
- Adjust the chain sag (185).

CHAIN

Lubricating chain

- Switch the ignition off and select neutral.
- Clean the drive chain with a suitable cleaning product, dry it and apply chain lubricant.

184 MAINTENANCE

- Apply chain lubricant also to the sealing rings between chain rollers and chain links.



ATTENTION

Inadequate cleaning and lubrication of the drive chain

Accelerated wear

- Clean and lubricate the drive chain at regular intervals.
- Lubricate the chain more frequently if the motorcycle is ridden in wet, dusty or dirty conditions.



Lubricate the drive chain at regular intervals.

min 800 km

- To prolong chain life, BMW Motorrad recommends the use of BMW Motorrad chain lubricant or:



Lubricant

Chain spray, O-ring compatible

- Wipe off excess lubricant.

Lubricating and caring for low-maintenance chain

—with Competition package ^{OE}



ATTENTION

Inadequate cleaning and lubrication of the drive chain

Accelerated wear

- Clean and lubricate the drive chain at regular intervals.



The low-maintenance drive chain is cleaned and lubricated as part of the annual service. For optimum durability, the low-maintenance chain can also be lubricated at intervals by application of a chain lubricant suitable for low-maintenance chains. If riding involves above-average wear and tear due to exposure to salt or dust and dirt, carry out lubrication at correspondingly more frequent intervals.

- Switch the ignition off and select neutral.
- Clean the drive chain with a suitable cleaning product, dry it and apply chain lubricant. To prolong chain life, BMW Motorrad recommends the use of BMW Motorrad chain lubricant or:




Lubricant

Chain spray, O-ring compatible

- Wipe off excess lubricant.

Checking chain sag

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Turn the rear wheel until it reaches the position of least chain sag.



- Use a screwdriver to push the chain up at a point mid-way between the pinion and sprocket and measure difference **A**.

 For race-track sessions, BMW Motorrad recommends adjusting chain sag to a value close to the stated maximum and checking at shorter intervals.



Chain deflection


45...50 mm (Motorcycle with no weight applied, supported on its side stand)

If measured value is outside permitted tolerance:

- Adjust the chain sag (➡ 185).

Adjusting chain sag

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Loosen quick-release axle nut **1**.
- Loosen lock nuts **3** on left and right.
- Use the adjusting screws **2** on left and right to adjust chain sag.
- Check chain sag (➡ 185).



ATTENTION

Rear wheel at an angle because tensioning screws not adjusted to same setting

Accelerated wear at rear wheel and chain drive

- Make sure that the rear wheel is aligned to track correctly (same scale reading on both sides of the rear wheel swinging arm).
- Set to the same scale value **4** on both sides.
- Tighten lock nuts **3** on left and right to the specified tightening torque.



Locknut of the final-drive chain tensioning screw

19 Nm

- Tighten quick-release axle nut **1** to the specified tightening torque.



Rear quick-release axle in swinging arm

Thread-locking compound: mechanical

125 Nm


- Check chain sag (➡ 185).

Checking chain wear

Requirement

Chain tension is set correctly.

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Engage 1st gear.
- Turn the rear wheel in the normal direction of travel until the chain is tensioned.
- Determine the length of the chain underneath the rear wheel swinging arm above the middle of 10 rivets in 3 different places.




Permissible chain length

max 144 mm (measured from the **centre** of 10 rivets, chain pulled taut)

If the chain has stretched to the maximum permissible length:

- Consult a specialist workshop, preferably an authorised BMW Motorrad retailer.



- Check whether a rivet head **1** has twisted out of line. Rivet heads are parallel to the chain centreline **2**.
- Chain riveting is OK.

If one or more rivet heads have twisted out of line:

- Consult a specialist workshop, preferably an authorised BMW Motorrad retailer.

LIGHTING

Replacing LED light sources



WARNING

Vehicle overlooked in traffic due to failure of the lights on the vehicle

Safety risk

- Always replace a faulty bulb at the earliest possible opportunity. Consult a specialist workshop, preferably an authorised BMW Motorrad Retailer.


All light sources of the vehicle are LED light sources. The service life of the LED light sources is longer than the presumed vehicle service life. If an LED light source is faulty, please contact a specialist workshop, preferably an authorised BMW Motorrad Retailer.

TRIM PANEL COMPONENTS

Remove the side panel

 The procedure described here for the right side panel applies by analogy to the left side as well.

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Remove screws **1** (6 mm with collar).
- Remove screws **2** (3 mm with collar).
- Remove screw **3** (9 mm with collar).


188 MAINTENANCE



- Bend engine spoiler **2** downwards slightly and remove bolt **1**.




- Bend engine spoiler **2** downwards slightly and install bolt **1**.




- Loosen fairing side panel **1** from grommets **2** and remove.

Installing side panel



- Insert fairing side panel **1** into grommets **2**.



- Install screws **1** (6 mm with collar).
- Install screws **2** (3 mm with collar).
- Install screw **3** (9 mm with collar).


Removing tail-hump trim panel

—with two-up riding package^{OE}


- Remove the passenger seat (→ 61).
- Remove the tail-hump cover (→ 61).



- Remove screws **1** and **2**.
- Unclip left and right rear trim panels carefully in the **direction of arrow**.




- Carefully unclip left and right rear trim panel **1**, first horizontally **2**, then vertically **3**.




- Push the rider's seat cover **1** forward slightly on the seat

cushion surface and expose tab **2**.

- Remove screw **3**.
- Lift up the rider's seat **1** at the rear and unhook fixing **4**.
- Place the seat, upholstered side down, on a clean surface.




- Remove short screws **1** and long screws **3** from tail-hump trim panel **2**.
- Carefully unclip panels **4** in the **direction of arrow**.




- Lift tail-hump trim panel **1** in the **direction of arrow** and remove from retaining tab **2**.

190 MAINTENANCE


Installing tail-hump trim panel




- Position tail-hump trim panel **1** at retaining tab **2**.



- Insert rider's seat **1** into the fixing **4** at the front and position it.
- Push the rider's seat cover **1** forward slightly on the seat cushion surface and expose tab **2**.
- Position and install bolt **3**.



- Carefully clip in panels **4** in the **direction of arrow** to the tail-hump trim panel **2**.
- Install short screws **1** and long screws **3**.



- Carefully clip in left and right rear trim panels **1**, first vertically **2**, then horizontally **3**.



- Carefully clip in rear trim panel in the **direction of arrow**.
 - Install bolts **1** and **2**.
- with two-up riding package^{OE}
- Install the passenger seat (▶▶▶ 62).◀
 - Install the tail-hump cover (▶▶▶ 61).

JUMP-STARTING



CAUTION

Touching live parts of the ignition system when the engine is running

Electric shock

- Do not touch parts of the ignition system when the engine is running.



ATTENTION

Contact between crocodile clips of jump leads and vehicle

Risk of short-circuit

- Use jump leads fitted with fully insulated crocodile clips at both ends.



ATTENTION

Jump-starting with a voltage greater than 12 V

Damage to the on-board electronics

- Make sure that the battery of the donor vehicle does not exceed a voltage of 12 V.

- When jump-starting the engine, do not disconnect the battery from the on-board electrical system.
- Remove the rider's seat (▶▶▶ 62).
- Run the engine of the donor vehicle during jump-starting.
- Begin by connecting one end of the red jump lead to the positive terminal of the discharged battery and the other end to the positive terminal of the donor battery.
- Then connect one end of the black jump lead to the neg-

192 MAINTENANCE

active terminal of the donor battery, and the other end to the negative terminal of the discharged battery.

- Start the engine of the vehicle with the discharged battery in the usual way; if the engine does not start, wait a few minutes before repeating the attempt in order to protect the starter motor and the donor battery.
- Allow both engines to idle for a few minutes before disconnecting the jump leads.
- Disconnect the jump lead from the negative terminals first, then disconnect the second lead from the positive terminals.
- Install the rider's seat (► 62).

BATTERY

Maintenance instructions

Correct upkeep, recharging and storage will prolong the life of the battery and are essential if warranty claims are to be considered.

Compliance with the points below is important in order to maximise battery life:

- Keep the surface of the battery clean and dry.
- Do not open the battery.
- Do not top up with water.
- Be sure to read and comply with the instructions for charging the battery on the following pages.
- Do not turn the battery upside down.



ATTENTION

On-board electronics (e.g. clock) draining connected battery

Battery is deep-discharged; this voids the guarantee

- Connect a float charger to the battery if the motorcycle is to remain out of use for more than four weeks.



BMW Motorrad has developed a float charger specially designed for compatibility with the electronics of your motorcycle. Using this charger, you can keep the battery charged during long periods of disuse, without having to disconnect the battery from the motorcycle's on-board systems. You can obtain additional information from your authorised BMW Motorrad dealer.

Disconnecting battery from motorcycle

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Remove the rider's seat (➡ 62).
- with anti-theft alarm (DWA)^{OE}
- If applicable, switch off the DWA.◁




ATTENTION

Battery not disconnected in accordance with correct procedure

Risk of short-circuit

- Always proceed in compliance with the specified disconnection sequence.
- Remove bolt **1** and wiring harness negative terminal **2**, then push forward.
- Remove bolt **3** and wiring harness positive terminal **4**.

Connecting battery to motorcycle



ATTENTION

Battery not connected in accordance with correct procedure

Risk of short-circuit

- Always proceed in compliance with specified installation sequence.
 - Position wiring harness positive terminal **1** and install bolt **2**.
 - Position wiring harness negative terminal **3** and install bolt **4**.
 - Install the rider's seat (➡ 62).
 - with anti-theft alarm (DWA)^{OE}
 - Switch on DWA if necessary.◁
- ### Recharging battery
- Disconnecting battery from motorcycle (➡ 193).
 - Charge the battery using a suitable charger.

194 MAINTENANCE

- Comply with the operating instructions of the charger.
- Once the battery is fully charged, disconnect the charger's terminal clips from the battery terminals.

 The battery has to be recharged at regular intervals in the course of a lengthy period of disuse. See the instructions for caring for your battery. Always fully recharge the battery before restoring it to use.

- Connecting battery to motorcycle (➡ 193).

Removing battery

- Remove the rider's seat (➡ 62).
- Disconnecting battery from motorcycle (➡ 193).
- Lift the battery up and out: work it slightly back and forth if it is difficult to remove.

Installing battery

 If the vehicle has been disconnected from the battery for a significant time, the current date will have to be entered in the instrument cluster to guarantee correct operation of the service display.

- Place the battery in the battery compartment; positive terminal on the left in the direction of travel.
- Connecting battery to motorcycle (➡ 193).
- Install the rider's seat (➡ 62).
- Set the clock (➡ 74).

FUSES

Replacing fuses

- Switch off the ignition.
- Remove the rider's seat (➡ 62).



ATTENTION

Jumpering of blown fuses

Risk of short-circuit and fire

- Never attempt to jumper a blown fuse.
 - Always replace a defective fuse with a new fuse of the same amperage.
- Replace faulty fuse in accordance with the fuse allocation diagram.



- Remove the faulty fuse **2** upwards out of the slot.
- To replace the two fuses in fuse box **1**, pull the fuse box up and out of its holder. To do so, squeeze the retaining lugs on the left and right of the fuse box inward.

 If fuse defects recur frequently have the electric circuits checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.

- Install fuse box **1** in the holder.
- Install the rider's seat (► 62).

Fuse assignment



- 1** 15 A
Instrument cluster
Anti-theft alarm (DWA)
Ignition switch
Diagnostic connector
- 2** 7.5 A
Multifunction switch, left
- 3** 40 A
Alternator regulator

DIAGNOSTIC CONNECTOR

Disengaging diagnostic socket



CAUTION


Incorrect procedure followed when loosening the diagnostic connector for the on-board diagnosis

Motorcycle experiences malfunctions

- Only have the diagnostic connector loosened by a specialist workshop or other authorised persons during your next BMW Service appointment.
- Have the work performed by appropriately trained staff.
- Refer to the vehicle manufacturer specifications.

—with two-up riding package^{OE}


- Remove the passenger seat (→ 61).
- Remove the tail-hump cover (→ 61).



- Press locks **1**.
- Disengage diagnostic socket **2** from holder **3**.
- » The interface to the diagnosis and information system can be connected to the diagnostic connector **2**.

Securing diagnostic socket

- Disconnect the interface for the diagnosis and information system.



- Insert diagnostic socket **2** into holder **3**.
- » The locks **1** engage.
- with two-up riding package^{OE}
- Install the passenger seat (→ 62).

- Install the tail-hump cover (61).

ACCESSORIES

11

GENERAL NOTES	200
CONNECTOR FOR OPTIONAL ACCESSORIES	200
USB CHARGING SOCKET	202

GENERAL NOTES



CAUTION

Use of other-make products

Safety risk

- BMW Motorrad cannot examine or test each product of outside origin to ensure that it can be used on or in connection with BMW vehicles without constituting a safety hazard. Country-specific official authorisation does not suffice as assurance. Tests conducted by these instances cannot make provision for all operating conditions experienced by BMW vehicles and, consequently, they are not sufficient in some circumstances.
- Use only parts and accessories approved by BMW for your vehicle.

BMW accepts no liability whatsoever for parts and accessories that it has not approved. All modifications must be in compliance with legal requirements. Make sure that the vehicle does not infringe the national road-vehicle construction and use regulations applicable in your country.

Your authorised BMW Motorrad retailer can offer expert advice on the choice of genuine BMW parts, accessories and other products. To find out more about accessories go to:
bmw-motorrad.com/equipment


CONNECTOR FOR OPTIONAL ACCESSORIES

Equipment

The vehicle is fitted with the following plugs for optional accessories and racing accessories:

- Spring-travel sensor
- M data logger
- Optional accessory


Underneath the left side panel



- 1 Plug for optional accessories and racing accessories: Voltage supply and LIN Spring travel sensor for front forks (racing accessory)

Under the tail-hump trim panel


—with anti-theft alarm (DWA)^{OE}



- 1 Connector for DWA and M data logger
- 2 Anti-theft alarm system (DWA)


Under the tail-hump cover

—without anti-theft alarm (DWA)^{OE}



- 1 Terminating resistor
- 2 Connector for DWA and M data logger

Under the tail-hump cover



- 1 Connector for optional accessories, rear

Connecting optional accessories and racing accessories

Requirement

Remove the side panel, rear seat or tail-hump cover, as applicable, to gain access to the plugs.

- Removing fairing side panel with engine spoiler (➡ 187). —with two-up riding package^{OE}
- Remove the passenger seat (➡ 61).
- Remove the tail-hump cover (➡ 61).
- Removing tail-hump trim panel (➡ 188).
- Unlock the protective cap or terminating resistor, as applicable, and disconnect it from the plug.
- Connect the optional accessory or racing accessory, as applicable.

 Comply with the installation instructions supplied with the optional accessory or racing accessory.

 Tightening the cable ties has to be the last step in the process; this is in order to ensure that the wiring harness can be positioned correctly and that there is no strain on the cable legs with plugs.



ATTENTION

Dirt and damp penetrating inside open connectors

Malfunctions

- Reinstall the cap or terminating resistor, as applicable, after removing the plug.
- After removing the accessory: Reinstall the cap or terminating resistor, as applicable.
- Installing side panel (188).
—with two-up riding package^{OE}
- Install the passenger seat (62).
- Install the tail-hump cover (61).
- Installing tail-hump trim panel (190).

USB CHARGING SOCKET

Notes on use

Charge current

This is a 5 V USB charging interface that provides a maximum charge current of 2.4 A.

Automatic shutdown

The USB charging socket is shut down automatically under the following circumstances:

- If battery charge state is too low, to maintain the vehicle's start capability.
- If the maximum load capacity as stated in the technical data is exceeded.
- During the starting operation.

Connection of electrical devices

You can start using electrical devices connected to the USB charging socket only when the ignition is switched on. The power supply to the sockets is switched off no more than 15 minutes after the ignition is switched off, in order to prevent overloading of the on-board electrics.

BMW Motorrad recommends using the BMW Motorrad pouch for smartphone to protect your smartphone against water and vibration.

To prevent dirtying, keep the protective cover of the USB charging interface closed when no device is connected.

Cable routing

Make sure that cables are routed in such a way that they cannot be trapped.

CARE

12

CARE PRODUCTS	206
WASHING THE VEHICLE	206
CLEANING EASILY DAMAGED COMPONENTS	207
CARE OF PAINTWORK	208
PAINTWORK PRESERVATION	209
LAYING UP MOTORCYCLE	209
RESTORING MOTORCYCLE TO USE	209

CARE PRODUCTS

BMW Motorrad recommends that you use the cleaning and care products you can obtain from your authorised BMW Motorrad retailer. The substances in BMW Care Products have been tested in laboratories and in practice; they provide optimised care and protection for the materials used in your vehicle.



ATTENTION

Use of unsuitable cleaning and care products

Damage to vehicle parts

- Do not use solvents such as cellulose thinners, cold cleaners, fuel or the like, and do not use cleaning products that contain alcohol.



ATTENTION

Use of strongly acidic or strongly alkaline cleaning agents

Damage to vehicle parts

- Dilute in accordance with the dilution ratio stated on the packaging of the cleaning agent.
- Do not use strongly acidic or strongly alkaline cleaning agents.

WASHING THE VEHICLE

BMW Motorrad recommends that you use BMW insect remover to soften and wash off insects and stubborn dirt on painted parts prior to washing the vehicle.

To prevent stains, do not wash the motorcycle immediately after it has been exposed to strong sunlight and do not wash it in the sun.

Remove dirt from the fork legs at regular intervals.

Make sure that the vehicle is washed frequently, especially during the winter months.

To remove road salt, clean the motorcycle with cold water immediately after every trip.

**WARNING**

Wet brake discs and brake pads after vehicle wash, after riding through water and in rainy conditions

Diminished braking effect, risk of accident

- Apply the brakes in good time to allow the friction and heat to dry the brake discs and brake pads.

**ATTENTION**

Effect of road salt intensified by warm water

Corrosion

- Use only cold water to wash off road salt.

**ATTENTION**

Damage due to high water pressure from high pressure cleaners or steam cleaners

Corrosion or short circuit, damage to labels, seals, hydraulic brake system, electrical system and the motor-cycle seat

- Exercise restraint when using a steam jet or high pressure cleaning equipment.

CLEANING EASILY DAMAGED COMPONENTS

Plastics

Clean plastic parts with water and BMW plastic care emulsion. This includes in particular:

- Windscreen and slipstream deflectors
- Headlight lens made of plastic
- Glass cover of the instrument cluster
- Black, unpainted parts

**ATTENTION**

Use of unsuitable cleaning agents

Damage to plastic surfaces

- Do not use cleaning agents that contain alcohol, solvents or abrasives.
- Do not use insect-remover pads or cleaning pads with hard, scouring surfaces.



Soften stubborn dirt and insects by covering the affected areas with a wet cloth.

Carbon parts

Clean Carbon parts with water and a microfibre cloth.

208 CARE

TFT display

Clean the TFT display with warm water and washing-up liquid. Then dry it with a clean cloth, e.g. a paper towel.

Chrome

Carefully clean chrome parts with plenty of water and motorcycle cleaner from the BMW Motorrad Care Products range. This is particularly important to counter the effects of road salt. For an additional treatment, use BMW Motorrad metal polish.

Radiator

Clean the radiator regularly to prevent overheating of the engine due to inadequate cooling. For example, use a garden hose with low water pressure.



ATTENTION

Bending of radiator fins

Damage to radiator fins

- Take care not to bend the radiator fins when cleaning.

Rubber

Treat rubber components with water or BMW rubber-care products.



ATTENTION

Application of silicone sprays to rubber seals

Damage to the rubber seals

- Do not use silicone sprays or care products that contain silicon.

CARE OF PAINTWORK

Washing the vehicle regularly will help counteract the long-term effects of substances that can damage the paint, especially if your vehicle is ridden in areas with high air pollution or natural sources of dirt, for example tree resin or pollen. Remove particularly aggressive substances immediately, however, as otherwise the paint can be affected or become discoloured. Substances of this nature include spilt fuel, oil, grease, brake fluid and bird droppings. For this, we recommend BMW Motorrad solvent cleaner followed by BMW Motorrad gloss polish for preservation. Marks on the paintwork are particularly easy to see after the motorcycle has been washed. Remove stains of this kind at the earliest possible

opportunity, using benzine or petroleum spirit on a clean cloth or ball of cotton wool. BMW Motorrad recommends using BMW tar remover for removing specks of tar. Then apply preserving agent to the areas treated in this way.

PAINTWORK PRESERVATION

If water no longer rolls off the paint, the paint must be preserved.

For paint preservation, BMW Motorrad recommends the use of BMW Motorrad gloss polish or agents containing carnauba wax or synthetic wax.

LAYING UP MOTORCYCLE

- Fill the motorcycle's fuel tank.



Fuel additives clean the fuel injection system and the combustion zone. It is advisable to use fuel additives when the engine is operated with low-grade fuel or if the vehicle is to be out of use for a lengthy period of time. More information is available from your authorised BMW Motorrad retailer.

- Clean the motorcycle.
- Removing battery (➡ 194).

- Spray the brake and clutch lever pivots and the side stand pivot mounts with a suitable lubricant.
- Coat bright metal and chrome-plated parts with an acid-free grease (e.g. Vaseline).
- Stand the motorcycle in a dry room in such a way that there is no load on either wheel.

RESTORING MOTORCYCLE TO USE

- Remove the protective wax coating.
- Clean the motorcycle.
- Installing battery (➡ 194).
- Comply with checklist (➡ 108).

TECHNICAL DATA

13

TROUBLESHOOTING CHART	212
THREADED FASTENERS	214
FUEL	217
ENGINE OIL	218
COOLANT	218
ENGINE	218
CLUTCH	219
TRANSMISSION	219
FINAL DRIVE	219
FRAME	220
CHASSIS AND SUSPENSION	220
BRAKES	221
WHEELS AND TYRES	221
ELECTRICAL SYSTEM	222
ANTI-THEFT ALARM	223
DIMENSIONS	223
WEIGHTS	224
PERFORMANCE FIGURES	224

212 TECHNICAL DATA

TROUBLESHOOTING CHART

Engine does not start or is difficult to start.

Possible cause	Rectification
Side stand extended and gear engaged	Fold in side stand.
Gear engaged and clutch not pressed	Select neutral or pull the clutch lever.
No fuel in tank	Refuel (118).
Battery flat	Recharging battery (193).
Overheating protection for starter motor has been activated. Starter motor can only be operated for a limited period of time.	Allow the starter motor to cool down for approx. 1 minute before using it again.

The Bluetooth connection is not established.

Possible cause	Rectification
The steps required for pairing were not carried out.	Check the necessary steps for pairing in the operating instructions for the communication system.
Connectivity functions are deactivated because the race track functions are activated.	Go to Settings menu and deactivate Racetrack .
The communication system was not connected automatically despite successful pairing.	Switch off the helmet's communication system and reconnect it after a minute or two.
Too many Bluetooth devices are saved on the helmet.	All pairing entries on the helmet are deleted (see the communication system operating instructions).
There are other vehicles with Bluetooth-capable devices in the vicinity.	Avoid simultaneously pairing with more vehicles.

Bluetooth connection is interrupted.

Possible cause	Rectification
The Bluetooth connection to the mobile end device is interrupted.	Switch off energy saving mode.
The Bluetooth connection to the helmet is interrupted.	Switch off the helmet's communication system and reconnect it after a minute or two.
The volume in the helmet cannot be adjusted.	Switch off the helmet's communication system and reconnect it after a minute or two.

The telephone book is not displayed in the TFT display.

Possible cause	Rectification
The phone book was not transmitted to the vehicle.	Confirm transmission of the phone data (☛ 84) when pairing on the mobile end device.

Active route guidance is not displayed in the TFT display.

Possible cause	Rectification
Navigation from the BMW Motorrad Connected App was not transmitted.	The BMW Motorrad Connected App is opened on the connected mobile end device prior to departure.
The route guidance cannot be started.	Secure the mobile device's data connection and check the map data on the mobile end device.

214 TECHNICAL DATA

THREADED FASTENERS

Front wheel	Value	Valid
Quick-release axle in threaded bush		
M24 x 1.5	50 Nm	
Clamping screws in axle holder		
M8 x 35	Tightening sequence: Tighten screws six times in alternate sequence	
	19 Nm	
Radial brake caliper on wheel axle clamp		
M10 x 65	38 Nm	
Wheel-speed sensor, front to forkleg		
M6 x 16, Renew screw micro-encapsulated	8 Nm	
Rear wheel	Value	Valid
Locknut of the final-drive chain tensioning screw		
M8	19 Nm	
Nut for swinging arm pivot point bush on frame		
M36 x 0.75, Replace nut Loctite 270, High strength	70 Nm	

Rear wheel	Value	Valid
Nut on swinging arm axle		
M18 x 1.5, Replace nut mechanical	100 Nm	
Rear quick-release axle in swinging arm		
M24 x 1.5 mechanical	125 Nm	
Swinging-arm adapter to rear wheel swinging arm		
M8 x 30	20 Nm	
Screw in adjusting ring		
M5 x 16	6 Nm	
Spring strut at deflection lever		
M12 x 75 - 10.9 micro-encapsulated	100 Nm	
Mirrors	Value	Valid
Mirror to front panel carrier		
M6, Replace nut mechanical	8 Nm	
Footrest system	Value	Valid
Screw connection for footrest adjustment		
M8 x 40 mechanical	20 Nm	—with Billet pack ^{OE}

216 TECHNICAL DATA

Footrest system	Value	Valid
Clamping bolt for rider footrest		
M8 x 25 mechanical	20 Nm	–with Billet pack ^{OE}
Peg to footbrake lever		
M6 x 20 micro-encapsulated	10 Nm	–with Billet pack ^{OE}
Folding peg		
M6 x 16	10 Nm	–with Billet pack ^{OE}

Number plate carrier on rear frame	Value	Valid
Number plate carrier on rear frame		
M5 x 20, 9 mm collar	2 Nm	

Selector rod to gear-shift lever	Value	Valid
Selector rod to gear-shift lever		
M6 x 20, Replace screw micro-encapsulated	8 Nm	

FUEL

Recommended fuel grade	 Super Plus, unleaded (maximum 5% ethanol, E5) 98 ROZ/RON 93 AKI
Alternative fuel grade	 Super unleaded (power- and consumption-re- lated restrictions.) (max-  imum 10% ethanol, E10) 95 ROZ/RON 90 AKI
Usable fuel capacity	approx. 16.5 l
Fuel reserve	approx. 4 l
Fuel consumption	6.5 l/100 km, in accordance with WMTC
CO2 emission	151 g/km, in accordance with WMTC
Exhaust emissions standard	EU 5
–with Canada export ^{NV}	TIER 2, measured in accord- ance with FTP75

218 TECHNICAL DATA

ENGINE OIL

Engine oil, capacity	approx. 4.0 l, with filter change
Specification	SAE 5W-40, API SJ / JASO MA2, Additives (e.g. molybdenum-based) are not permissible because they can attack coated components of the engine, BMW Motorrad recommends BMW Motorrad ADVANTEC Ultimate oil.
Engine oil, quantity for topping up	max 1.3 l, Difference between MIN and MAX

BMW recommends **ADVANTEC**
ORIGINAL BMW ENGINE OIL

COOLANT

Coolant top-up quantity	0.15 l, Difference between MIN and MAX
	2.4 l, Coolant circuit, total
	Coolant FROSTOX HT-12

ENGINE

Engine number location	Crankcase, bottom part, right
Engine type	A12A10A
Engine design	Oil-/water-cooled four-stroke inline four, with four valves per cylinder
Displacement	999 cm ³
Cylinder bore	80 mm
Piston stroke	49.7 mm
Compression ratio	13.5:1

Nominal capacity	156 kW, at engine speed: 14500 min ⁻¹
–with Torque optimized calibration ^{OE} –with Canada export ^{NV}	132 kW, at engine speed: 11500 min ⁻¹
Torque	113 Nm, at engine speed: 11000 min ⁻¹
Maximum engine speed	max 15100 min ⁻¹
Idle speed	1270 ^{±50} min ⁻¹ , Engine at regular operating temperature

CLUTCH

Clutch type	Multi-plate oil-bath (anti-hopping)
-------------	-------------------------------------

TRANSMISSION

Type of transmission	Claw-shift 6-speed gearbox, integrated into engine block
Gearbox transmission ratios	1.652 (76:46 teeth), Primary transmission ratio 2.647 (45:17 teeth), 1st gear 2.091 (46:22 teeth), 2nd gear 1.727 (38:22 teeth), 3rd gear 1.500 (33:22 teeth), 4th gear 1.360 (34:25 teeth), 5th gear 1.261 (29:23 teeth), 6th gear

FINAL DRIVE

Type of final drive	Chain drive
Chain deflection	45...50 mm, Motorcycle with no weight applied, supported on its side stand

220 TECHNICAL DATA

Permissible chain length	max 144 mm, measured from the centre of 10 rivets, chain pulled taut
Number of teeth, rear-wheel drive (Pinion / sprocket)	17:46
Secondary transmission ratio	2.706

FRAME

Frame type	Aluminium composite bridge frame, load-bearing engine
Type plate location	Frame, front right on steering head
Position of the vehicle identification number	Frame, front right on steering head

CHASSIS AND SUSPENSION

Front wheel

Type of front suspension	Upside-down telescopic forks, diameter 45 mm, spring preload, rebound and compression stages adjustable
Spring travel, front	120 mm, at front wheel

Rear wheel

Type of rear suspension	Two-arm aluminium swinging arm
Design of the rear-wheel suspension	Central spring strut with coil spring, adjustable rebound-stage and compression-stage damping and spring preload
Spring travel, rear	118 mm, at rear wheel

BRAKES

Front wheel

Type of front brake	Twin disc brake, diameter 320 mm, 4-piston fixed caliper
Brake-pad material, front	Sintered metal
Brake disc thickness, front	5 mm, When new min 4.5 mm, Wear limit
Play of brake controls (Front brake)	5.2...15.2 mm, at the outer-most end of the stock handle-bar lever

Rear wheel

Type of rear brake	Single-disc brake, diameter 220 mm, 1-piston floating caliper
Brake-pad material, rear	Organic material
Brake disc thickness, rear	5 mm, When new min 4.5 mm, Wear limit
Blow-by clearance of the foot-brake lever	2...3 mm, between the foot-brake lever and footrest plate

WHEELS AND TYRES

Recommended tyre combinations	Your authorised BMW Motorrad retailer will be happy to supply an up-to-date list of the approved wheel/tyre combinations, or you can check the information posted on the bmw-motorrad.com website.
Speed category, front/rear tyres	W, required at least: 270 km/h

222 TECHNICAL DATA

Front wheel

Front-wheel type	Carbon wheel
Front-wheel rim size	3.50" x 17"
Tyre designation, front	120/70 ZR 17
Load index, front tyre	min 58 g/cm ³
Permissible front-wheel imbalance	max 5 g

Rear wheel

Rear-wheel type	Carbon wheel
Rear wheel rim size	6.00" x 17"
Tyre designation, rear	200/55 ZR 17
Load index, rear tyre	min 78 g/cm ³
Permissible rear-wheel imbalance	max 5 g

Tyre pressure

Tyre pressure, front	2.5 bar, tyre cold
Tyre pressure, rear	2.9 bar, tyre cold

ELECTRICAL SYSTEM

Fuses

Main fuse	40 A, Alternator regulator
Fuse 1	15 A, Anti-theft alarm system/ OBD/ignition switch/instrument cluster/isolating relay
Fuse 2	7.5 A, Multifunction switch left, sensor box

Battery

Battery type	Lithium-ion, maintenance-free
Battery rated voltage	13.2 V
Battery rated capacity	5 Ah

Spark plugs

Spark plugs, manufacturer and designation	NGK LMAR9FI-10G
---	-----------------

Lighting

Bulb for high-beam headlight	LED
Bulbs for the low-beam headlight	LED
Bulb for parking light	LED
Bulb for tail light/brake light	LED
Bulbs for turn indicators	LED
Light source for the number plate light	LED

ANTI-THEFT ALARM

Activation time on arming	approx. 30 s
Alarm duration	approx. 26 s

DIMENSIONS

Length of motorcycle	2073 mm, over rear wheel
Height of motorcycle	1197 mm, over windscreen, at DIN vehicle kerb weight
Width of motorcycle	848 mm, with mirrors 740 mm, without mounted parts
—with two-up riding package ^{OE}	765 mm, without mounted parts
Height of rider's seat	832 mm, without rider, at DIN vehicle kerb weight
Rider's inside-leg arc, heel to heel	1845 mm, without rider, at DIN vehicle kerb weight

224 TECHNICAL DATA

WEIGHTS

Vehicle kerb weight	192 kg, DIN vehicle kerb weight, ready for road, 90% load of fuel, without optional extras (OE)
Permissible gross vehicle weight	407 kg
Maximum payload	212 kg

PERFORMANCE FIGURES

Top speed	>200 km/h
–with Torque optimized calibration ^{OE}	>200 km/h
–with Canada export ^{NV}	

SERVICE

14

REPORTING SAFETY-RELEVANT DEFECTS	228
BMW MOTORRAD SERVICE	229
BMW MOTORRAD SERVICE HISTORY	229
BMW MOTORRAD MOBILITY SERVICES	230
MAINTENANCE WORK	230
BMW SERVICE	230
MAINTENANCE SCHEDULE	232
MAINTENANCE CONFIRMATIONS	233
SERVICE CONFIRMATIONS	247

REPORTING SAFETY-RELEVANT DEFECTS

—with Canada export^{NV}

If you think that your motorcycle has a fault which may cause an accident, injury or death, you must inform the NHTSA (National Highway Traffic Safety Administration) immediately and BMW of North America, LLC.

If the NHTSA receives other similar complaints, it may open an investigation. If it finds that a safety defect exists in a group of vehicles, the NHTSA may order the manufacturer to perform a recall and remedy campaign. However, the NHTSA cannot become involved in individual problems between you, your retailer, or BMW of North America, LLC.

You can contact the NHTSA by calling the Vehicle Safety hotline on 1-888-327-4236 (teletypewriter TTY for the hearing impaired: 1-800-424-9153) for free, by visiting the website at [http:// www.safercar.gov](http://www.safercar.gov) or by writing to Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590. Further information on vehicle safety is available at [http:// www.safercar.gov](http://www.safercar.gov).

Canadian customers who wish to report a safety-related defect to Transport Canada, Defect Investigations and Recalls can call the toll-free hotline 1-800-333-0510. You can also obtain other information about motor vehicle safety from [http:// www.tc.gc.ca/roadsafety](http://www.tc.gc.ca/roadsafety).

BMW MOTORRAD SERVICE

BMW Motorrad has an extensive network of retailers in place to look after you and your motorcycle in more than 100 countries. Authorised BMW Motorrad retailers have the technical information and the technical know-how to carry out reliably all maintenance and repair work on your BMW.

You can locate the nearest authorised BMW Motorrad retailer by visiting our website: **bmw-motorrad.com**



WARNING

Maintenance and repair work not in compliance with correct procedure

Risk of accident due to consequential damage

- BMW Motorrad recommends having work of this nature carried out on the vehicle by a specialist workshop, preferably an authorised BMW Motorrad dealer.

In order to help ensure that your BMW is always in optimum condition, BMW Motorrad recommends compliance with the maintenance intervals specified for your motorcycle.

Have all maintenance and repair work carried out confirmed in the "Service" chapter in this manual. Evidence of regular maintenance is essential for generous treatment of claims submitted after the warranty period has expired.

Your authorised BMW Motorrad retailer can provide information on BMW services and the work undertaken as part of each service.

BMW MOTORRAD SERVICE HISTORY

Entries

Maintenance work that has been carried out is entered in the proof of maintenance. The entries are like a Service Booklet and provide proof of regular maintenance.

When an entry is made in the electronic service booklet of the vehicle, service-relevant data is saved in the central IT

230 SERVICE

systems of BMW AG, Munich, Germany.

If there is a change in vehicle ownership, the data saved in the electronic service booklet can also be viewed by the new vehicle owner. A BMW Motorrad retailer or a specialist workshop can also view data that is stored in the electronic service booklet.

Objection

The vehicle owner can object to entries being made by the BMW Motorrad retailer or a specialist workshop in the electronic service booklet along with the corresponding storage of data in the vehicle and transfer of data to the vehicle manufacturer for the period of time that they are the vehicle owner. In this instance, no entry is made in the electronic service booklet of the vehicle.

BMW MOTORRAD MOBILITY SERVICES

If you have a new BMW motorcycle, you are protected by various of the BMW Motorrad mobility services in the event of a breakdown (e.g. BMW breakdown assistance, breakdown recovery, vehicle transport).

Find out from your authorised BMW Motorrad Retailer which mobility services are offered.

MAINTENANCE WORK

BMW pre-delivery check

Your authorised BMW Motorrad Retailer conducts the BMW pre-delivery check before handing over the vehicle to you.

BMW Running-in Check

The BMW running-in check must be carried out between 500 km and 1200 km.

BMW SERVICE

The BMW Service is carried out once a year; the extent of servicing can vary, depending on the age of the vehicle and the distance it has covered. Your authorised BMW Motorrad retailer confirms that the service work has been carried out and enters the date when the next service will be due.

Riders who cover long distances in a year might have to bring in their vehicles for service before the next scheduled date. It is to allow for these cases that a maximum odometer reading is entered as well in the confirmation of service. Servicing has to be brought forward if this odo-

meter reading is reached before the next scheduled date for the service.

The service display is a service-due indicator that appears on the TFT display to remind you about one month or 1000 km in advance when the time for a service is approaching, on the basis of the programmed values.

To find out more about service go to:

bmw-motorrad.com/service

The maintenance tasks necessary for your vehicle are set out in the maintenance schedule below:

232 SERVICE

MAINTENANCE SCHEDULE

	500 -1200 km 300 - 750 mls	10 000 km 6 000 mls	20 000 km 12 000 mls	30 000 km 18 000 mls	40 000 km 24 000 mls	50 000 km 30 000 mls	60 000 km 36 000 mls	70 000 km 42 000 mls	80 000 km 48 000 mls	90 000 km 54 000 mls	100 000 km 60 000 mls	12 months	24 months
1	X												
2												X ^a	
3		X	X	X	X	X	X	X	X	X	X	X ^a	
4				X			X			X			
5				X			X			X			
6				X			X			X			
7				X			X			X			
8				X			X			X			
9		X	X	X	X	X	X	X	X	X	X		
10				X			X			X			
11												X ^a	

- 1 BMW running-in check (including oil change)
- 2 BMW Service, standard scope
- 3 Engine-oil change, with filter
- 4 Engine service
- 5 Replace potentiometer for gear indicator
- 6 Replace oxygen control sensors
- 7 Check valve clearances
- 8 Replace all spark plugs
- 9 Replace air-filter element
- 10 Oil change in the telescopic forks

- 11 Change brake fluid, entire system
- ^a annually or every 10,000 km (whichever comes first)

MAINTENANCE CONFIRMATIONS

BMW Service standard scope

The repair tasks in the BMW Service standard scope are listed below. The actual scope of maintenance work applicable for your vehicle may vary.

- Performing vehicle test with BMW Motorrad diagnosis system
- Checking wear of the switching-cam adjusters with BMW Motorrad diagnostic system
- Visual inspection of the brake lines, brake hoses and connections
- Checking front brake pads and brake discs for wear
- Checking brake-fluid level, front wheel brake
- Checking rear brake pads and brake disc for wear
- Checking brake-fluid level, rear wheel brake
- Checking steering-head bearing
- Checking coolant level
- Checking clutch cable and clutch-lever play
- Checking clutch operation
- Checking and lubricating the chain drive
- Checking tyre pressure and tread depth
- Check the side stand's ease of movement
- Check lighting and signalling system
- Function test, engine start suppression
- Final inspection and check for road safety
- Setting service-due date and countdown distance with BMW Motorrad diagnosis system
- Checking battery state of charge
- Confirming BMW service in on-board literature

234 SERVICE

BMW pre-delivery check
carried out

at _____

Stamp, signature

BMW Running-in Check
carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Engine service	☐	☐
Replace potentiometer for gear indicator (as part of service)	☐	☐
Replace oxygen control sensors (as part of service)	☐	☐
Checking valve clearance	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Oil change in telescopic front forks	☐	☐
Change brake fluid in entire system	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Engine service	☐	☐
Replace potentiometer for gear indicator (as part of service)	☐	☐
Replace oxygen control sensors (as part of service)	☐	☐
Checking valve clearance	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Oil change in telescopic front forks	☐	☐
Change brake fluid in entire system	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Engine service	☐	☐
Replace potentiometer for gear indicator (as part of service)	☐	☐
Replace oxygen control sensors (as part of service)	☐	☐
Checking valve clearance	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Oil change in telescopic front forks	☐	☐
Change brake fluid in entire system	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Engine service	☐	☐
Replace potentiometer for gear indicator (as part of service)	☐	☐
Replace oxygen control sensors (as part of service)	☐	☐
Checking valve clearance	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Oil change in telescopic front forks	☐	☐
Change brake fluid in entire system	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Engine service	☐	☐
Replace potentiometer for gear indicator (as part of service)	☐	☐
Replace oxygen control sensors (as part of service)	☐	☐
Checking valve clearance	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Oil change in telescopic front forks	☐	☐
Change brake fluid in entire system	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Engine service	☐	☐
Replace potentiometer for gear indicator (as part of service)	☐	☐
Replace oxygen control sensors (as part of service)	☐	☐
Checking valve clearance	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Oil change in telescopic front forks	☐	☐
Change brake fluid in entire system	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Engine service	☐	☐
Replace potentiometer for gear indicator (as part of service)	☐	☐
Replace oxygen control sensors (as part of service)	☐	☐
Checking valve clearance	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Oil change in telescopic front forks	☐	☐
Change brake fluid in entire system	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Engine service	☐	☐
Replace potentiometer for gear indicator (as part of service)	☐	☐
Replace oxygen control sensors (as part of service)	☐	☐
Checking valve clearance	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Oil change in telescopic front forks	☐	☐
Change brake fluid in entire system	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Engine service	☐	☐
Replace potentiometer for gear indicator (as part of service)	☐	☐
Replace oxygen control sensors (as part of service)	☐	☐
Checking valve clearance	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Oil change in telescopic front forks	☐	☐
Change brake fluid in entire system	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Engine service	☐	☐
Replace potentiometer for gear indicator (as part of service)	☐	☐
Replace oxygen control sensors (as part of service)	☐	☐
Checking valve clearance	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Oil change in telescopic front forks	☐	☐
Change brake fluid in entire system	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Engine service	☐	☐
Replace potentiometer for gear indicator (as part of service)	☐	☐
Replace oxygen control sensors (as part of service)	☐	☐
Checking valve clearance	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Oil change in telescopic front forks	☐	☐
Change brake fluid in entire system	☐	☐

Notes

Stamp, signature

BMW Service

carried out

at _____

Odometer reading _____

Next service

at the latest

at _____

or, when reached earlier

Odometer reading _____

Work performed

	Yes	No
BMW Service	☐	☐
Oil change, engine, with filter	☐	☐
Engine service	☐	☐
Replace potentiometer for gear indicator (as part of service)	☐	☐
Replace oxygen control sensors (as part of service)	☐	☐
Checking valve clearance	☐	☐
Renewing all spark plugs	☐	☐
Renewing air cleaner insert	☐	☐
Oil change in telescopic front forks	☐	☐
Change brake fluid in entire system	☐	☐

Notes

Stamp, signature

248 SERVICE

[illegible]

DECLARATION OF CONFORMITY FOR ELECTRONIC IMMOBILISER (EWS)	251
CERTIFICATE FOR ELECTRONIC IMMOBILISER (EWS)	257
DECLARATION OF CONFORMITY FOR TFT	259
CERTIFICATE FOR TFT	265
DECLARATION OF CONFORMITY FOR ANTI-THEFT ALARM SYSTEM (DWA)	268

Declaration of Conformity

Radio equipment electronic immobiliser (EWS)

Simplified EU Declaration of Conformity acc. Radio Equipment Directive 2014/53/EU after 12.06.2016 and during transition period



Technical information

Frequency Band: 134 kHz
(Transponder: TMS37145 /
TypeDST80, TMS3705
Transponder Base Station IC)
Output Power: 50 dBμV/m

Manufacturer and Address

Manufacturer: BECOM Electronics GmbH
Address: Technikerstraße 1,
A-7442 Hochstraß

Austria

Hiermit erklärt BECOM Electronics GmbH, dass der Funkanlagentyp EWS4 der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: <http://www.becom.at/de/download/>

Belgium

Le soussigné, BECOM Electronics GmbH, déclare que l'équipement radioélectrique du type EWS4 est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: <http://www.becom.at/de/download/>

Bulgaria

С настоящото BECOM Electronics GmbH декларира, че този тип радиосъоръжение EWS4 е в съответствие с Директива 2014/53/ЕС. Цялостният текст на ЕС декларацията за съответствие може да се намери на следния интернет адрес: <http://www.becom.at/de/download/>

Cyprus

Με την παρούσα ο/η BECOM Electronics GmbH, δηλώνει ότι ο ραδιοεξοπλισμός EWS4 πληροί την οδηγία 2014/53/ΕΕ.

Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: <http://www.becom.at/de/download/>

Czech Republic

Tímto BECOM Electronics GmbH prohlašuje, že typ rádiového zařízení EWS4 je v souladu se směrnicí 2014/53/EU.

Úplné znění EU prohlášení o shodě je k dispozici na této internetové adrese:

<http://www.becom.at/de/download/>

Germany

Hiermit erklärt BECOM Electronics GmbH, dass der Funkanlagentyp EWS4 der Richtlinie 2014/53/EU entspricht.

Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: <http://www.becom.at/de/download/>

Denmark

Hermed erklærer BECOM Electronics GmbH, at radioudstyrstypen EWS4 er i overensstemmelse med direktiv 2014/53/EU. EU-overensstemmelseserklæringens fulde tekst kan findes på følgende internetadresse: <http://www.becom.at/de/download/>

Estonia

Käesolevaga deklareerib BECOM Electronics GmbH, et käesolev raadioseadme tüüp EWS4 vastab direktiivi 2014/53/EL nõuetele.

ELi vastavusdeklaratsiooni täielik tekst on kättesaadav järgmisel internetiaadressil: <http://www.becom.at/de/download/>

Spain

Por la presente, BECOM Electronics GmbH declara que el tipo de equipo radioeléctrico EWS4 es conforme con la Directiva 2014/53/UE.

El texto completo de la declaración UE de conformidad está disponible en la dirección Internet siguiente: <http://www.becom.at/de/download/>

Finland

BECOM Electronics GmbH vakuuttaa, että radiolaitetyypin EWS4 on direktiivin 2014/53/EU mukainen.

EU-vaatimustenmukaisuusvakuutus on täysimittainen teksti on saatavilla seuraavassa internetosoitteessa:
<http://www.becom.at/de/download/>

France

Le soussigné, BECOM Electronics GmbH, déclare que l'équipement radioélectrique du type EWS4 est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante : <http://www.becom.at/de/download/>

United Kingdom

Hereby, BECOM Electronics GmbH declares that the radio equipment type EWS4 is in compliance with Directive 2014/53/EU
The full text of the EU declaration of conformity is available at the following internet address: <http://www.becom.at/de/download/>

Greece

Με την παρούσα ο/η BECOM Electronics GmbH, δηλώνει ότι ο ραδιοεξοπλισμός EWS4 πληροί την οδηγία 2014/53/ΕΕ.
Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: <http://www.becom.at/de/download/>

Croatia

BECOM Electronics GmbH ovime izjavljuje da je radijska oprema tipa EWS4 u skladu s Direktivom 2014/53/EU.
Cjeloviti tekst EU izjave o sukladnosti dostupan je na sljedećoj internetskoj adresi: <http://www.becom.at/de/download/>

Hungary

BECOM Electronics GmbH igazolja, hogy a EWS4 típusú rádióberendezés megfelel a 2014/53/EU irányelvnek.
Az EU-megfelelőségi nyilatkozat teljes szövege elérhető a következő internetes címen: <http://www.becom.at/de/download/>

Ireland

Hereby, BECOM Electronics GmbH declares that the radio equipment type EWS4 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: <http://www.becom.at/de/download/>

Italy

Il fabbricante, BECOM Electronics GmbH, dichiara che il tipo di apparecchiatura radio EWS4 è conforme alla direttiva 2014/53/UE. Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: <http://www.becom.at/de/download/>

Lithuania

Aš, BECOM Electronics GmbH, patvirtinu, kad radijo įrenginių tipas EWS4 atitinka Direktyvą 2014/53/ES.

Visas ES atitikties deklaracijos tekstas prieinamas šiuo interneto adresu: <http://www.becom.at/de/download/>

Luxembourg

Le soussigné, BECOM Electronics GmbH, déclare que l'équipement radioélectrique du type EWS4 est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: <http://www.becom.at/de/download/>

Latvia

Ar šo BECOM Electronics GmbH deklarē, ka radioiekārta EWS4 atbilst Direktīvai 2014/53/ES. Pilns ES atbilstības deklarācijas teksts ir pieejams šādā interneta vietnē: <http://www.becom.at/de/download/>

Malta

B'dan, BECOM Electronics GmbH, niddikjara li dan it-tip ta' tagħmir tar-radju EWS4 huwa konformi mad-Direttiva 2014/53/UE. It-test kollu tad-dikjarazzjoni ta' konformità tal-UE huwa disponibbli f'dan l-indirizz tal-Internet li ġej: <http://www.becom.at/de/download/>

Netherlands

Hierbij verklaar ik, BECOM Electronics GmbH, dat het type radioapparatuur EWS4 conform is met Richtlijn 2014/53/EU. De volledige tekst van de EU-conformiteitsverklaring kan worden geraadpleegd op het volgende internetadres: <http://www.becom.at/de/download/>

Poland

BECOM Electronics GmbH niniejszym oświadcza, że typ urządzenia radiowego EWS4 jest zgodny z dyrektywą 2014/53/UE. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: <http://www.becom.at/de/download/>

Portugal

O(a) abaixo assinado(a) BECOM Electronics GmbH declara que o presente tipo de equipamento de rádio EWS4 está em conformidade com a Diretiva 2014/53/UE. O texto integral da declaração de conformidade está disponível no seguinte endereço de Internet: <http://www.becom.at/de/download/>

Romania

Prin prezenta, BECOM Electronics GmbH declară că tipul de echipamente radio EWS4 este în conformitate cu Directiva 2014/53/UE. Textul integral al declarației UE de conformitate este disponibil la următoarea adresă internet: <http://www.becom.at/de/download/>

Sweden

Härmed försäkrar BECOM Electronics GmbH att denna typ av radioutrustning EWS4 överensstämmer med direktiv 2014/53/EU. Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande webbadress: <http://www.becom.at/de/download/>

Slovenia

BECOM Electronics GmbH potrjuje, da je tip radijske opreme EWS4 skladen z Direktivo 2014/53/EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: <http://www.becom.at/de/download/>

Slovakia

BECOM Electronics GmbH týmto vyhlasuje, že rádiové zariadenie typu EWS4 je v súlade so smernicou 2014/53/EÚ.

Úplné EÚ vyhlásenie o zhode je k dispozícii na tejto internetovej adrese:

<http://www.becom.at/de/download/>

FCC Approval

Ring aerial in the ignition switch



To verify the authorization of the ignition key, the electronic immobilizer exchanges information with the ignition key via the ring aerial.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.



Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. ◀

Approbation de la FCC

Antenne annulaire présente dans le commutateur d'allumage



Pour vérifier l'autorisation de la clé de contact, le système d'immobilisation électronique échange des informations avec la clé de contact via l'antenne annulaire.

Le présent dispositif est conforme à la partie 15 des règles de la FCC. Son utilisation est soumise aux deux conditions suivantes :

- (1) Le dispositif ne doit pas produire d'interférences nuisibles, et
- (2) le dispositif doit pouvoir accepter toutes les interférences extérieures, y compris celles qui pourraient provoquer une activation inopportune.



Toute modification qui n'aurait pas été approuvée expressément par l'organisme responsable de l'homologation peut annuler l'autorisation accordée à l'utilisateur pour utiliser le dispositif. ◀

Declaration of Conformity

Radio equipment TFT instrument cluster

Simplified EU Declaration of Conformity acc. Radio Equipment Directive 2014/53/EU after 12.06.2016 and during transition period



Technical information

BT operating frq. Range:
2402 – 2480 MHz
BT version: 4.2 (no BTLE)
BT output power: < 4 dBm
WLAN operating frq. Range:
2412 – 2462 MHz
WLAN standards:
IEEE 802.11 b/g/n
WLAN output power: < 20 dBm

Manufacturer and Address

Manufacturer:
Robert Bosch Car Multimedia GmbH
Address: Robert Bosch Str. 200,
31139 Hildesheim, GERMANY

Austria

Hiermit erklärt Robert Bosch Car Multimedia GmbH, dass der Funkanlagentyp ICC6.5in der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: <http://cert.bosch-carmultimedia.net>

Belgium

Le soussigné, Robert Bosch Car Multimedia GmbH, déclare que l'équipement radioélectrique du type ICC6.5in est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: <http://cert.bosch-carmultimedia.net>

Bulgaria

С настоящото Robert Bosch Car Multimedia GmbH декларира, че този тип радиосъоръжение ICC6.5in е в съответствие с Директива 2014/53/ЕС. Цялостният текст на ЕС декларацията за съответствие може да се намери на следния интернет адрес: <http://cert.bosch-carmultimedia.net>

Cyprus

Με την παρούσα ο/η Robert Bosch Car Multimedia GmbH, δηλώνει ότι ο ραδιοεξοπλισμός ICC6.5in πληροί την οδηγία 2014/53/ΕΕ. Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: <http://cert.bosch-carmultimedia.net>

Czech Republic

Tímto Robert Bosch Car Multimedia GmbH prohlašuje, že typ rádiového zařízení ICC6.5in je v souladu se směrnicí 2014/53/EU. Úplné znění EU prohlášení o shodě je k dispozici na této internetové adrese: <http://cert.bosch-carmultimedia.net>

Germany

Hiermit erklärt Robert Bosch Car Multimedia GmbH, dass der Funkanlagentyp ICC6.5in der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: <http://cert.bosch-carmultimedia.net/>

Denmark

Hermed erklærer Robert Bosch Car Multimedia GmbH, at radioudstyrstypen ICC6.5in er i overensstemmelse med direktiv 2014/53/EU. EU-overensstemmelseserklæringens fulde tekst kan findes på følgende internetadresse: <http://cert.bosch-carmultimedia.net>

Estonia

Käesolevaga deklareerib Robert Bosch Car Multimedia GmbH, et käesolev raadioseadme tüüp ICC6.5in vastab direktiivi 2014/53/EL nõuetele. ELi vastavusdeklaratsiooni täielik tekst on kättesaadav järgmisel internetiaadressil: <http://cert.bosch-carmultimedia.net>

Spain

Por la presente, Robert Bosch Car Multimedia GmbH declara que el tipo de equipo radioeléctrico ICC6.5in es conforme con la Directiva 2014/53/UE. El texto completo de la declaración UE de conformidad está disponible en la dirección Internet siguiente: <http://cert.bosch-carmultimedia.net>

Finland

Robert Bosch Car Multimedia GmbH vakuuttaa, että radiolaitetyyppi ICC6.5in on direktiivin 2014/53/EU mukainen. EU-vaatimustenmukaisuusvakuutukseen täysimittainen teksti on saatavilla seuraavassa internetosoitteessa: <http://cert.bosch-carmultimedia.net>

France

Le soussigné, Robert Bosch Car Multimedia GmbH, déclare que l'équipement radioélectrique du type ICC6.5in est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: <http://cert.bosch-carmultimedia.net>

United Kingdom

Hereby, Robert Bosch Car Multimedia GmbH declares that the radio equipment type ICC6.5in is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <http://cert.bosch-carmultimedia.net>

Greece

Με την παρούσα ο/η Robert Bosch Car Multimedia GmbH, δηλώνει ότι ο ραδιοεξοπλισμός ICC6.5in πληροί την οδηγία 2014/53/ΕΕ. Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: <http://cert.bosch-carmultimedia.net>

Croatia

Robert Bosch Car Multimedia GmbH ovime izjavljuje da je radijska oprema tipa ICC6.5in u skladu s Direktivom 2014/53/EU. Cjeloviti tekst EU izjave o sukladnosti dostupan je na sljedećoj internetskoj adresi: <http://cert.bosch-carmultimedia.net>

Hungary

Robert Bosch Car Multimedia GmbH igazolja, hogy a ICC6.5in típusú rádióberendezés megfelel a 2014/53/EU irányelvnek. Az EU-megfelelőségi nyilatkozat teljes szövege elérhető a következő internetes címen: <http://cert.bosch-carmultimedia.net>

Ireland

Hereby, Robert Bosch Car Multimedia GmbH declares that the radio equipment type ICC6.5in is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <http://cert.bosch-carmultimedia.net>

Italy

Il fabbricante, Robert Bosch Car Multimedia GmbH, dichiara che il tipo di apparecchiatura radio ICC6.5in è conforme alla direttiva 2014/53/UE.

Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: <http://cert.bosch-carmultimedia.net>

Lithuania

Aš, Robert Bosch Car Multimedia GmbH, patvirtinu, kad radijo įrenginių tipas ICC6.5in atitinka Direktyvą 2014/53/ES.

Visas ES atitikties deklaracijos tekstas prieinamas šiuo interneto adresu: <http://cert.bosch-carmultimedia.net>

Luxembourg

Le soussigné, Robert Bosch Car Multimedia GmbH, déclare que l'équipement radioélectrique du type ICC6.5in est conforme à la directive 2014/53/UE.

Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: <http://cert.bosch-carmultimedia.net>

Latvia

Ar šo Robert Bosch Car Multimedia GmbH deklarē, ka radioiekārta ICC6.5in atbilst Direktīvai 2014/53/ES. Pilns ES atbilstības deklarācijas teksts ir pieejams šādā interneta vietnē: <http://cert.bosch-carmultimedia.net>

Malta

B'dan, Robert Bosch Car Multimedia GmbH, niddikjara li dan it-tip ta' tagħmir tar-radju ICC6.5in huwa konformi mad-Direttiva 2014/53/UE.

It-test kollu tad-dikjarazzjoni ta' konformità tal-UE huwa disponibbli f'dan l-indirizz tal-Internet li ġej: <http://cert.bosch-carmultimedia.net>

Netherlands

Hierbij verklaar ik, Robert Bosch Car Multimedia GmbH, dat het type radioapparatuur ICC6.5in conform is met Richtlijn 2014/53/EU.

De volledige tekst van de EU-conformiteitsverklaring kan worden geraadpleegd op het volgende internetadres: <http://cert.bosch-carmultimedia.net>

Poland

Robert Bosch Car Multimedia GmbH niniejszym oświadcza, że typ urządzenia radiowego ICC6.5in jest zgodny z dyrektywą 2014/53/UE.

Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: <http://cert.bosch-carmultimedia.net>

Portugal

O(a) abaixo assinado(a) Robert Bosch Car Multimedia GmbH declara que o presente tipo de equipamento de rádio ICC6.5in está em conformidade com a Diretiva 2014/53/UE. O texto integral da declaração de conformidade está disponível no seguinte endereço de Internet: <http://cert.bosch-carmultimedia.net>

Romania

Prin prezenta, Robert Bosch Car Multimedia GmbH declară că tipul de echipamente radio ICC6.5in este în conformitate cu Directiva 2014/53/UE.

Textul integral al declarației UE de conformitate este disponibil la următoarea adresă internet: <http://cert.bosch-carmultimedia.net>

Sweden

Härmed försäkrar Robert Bosch Car Multimedia GmbH att denna typ av radioutrustning ICC6.5in överensstämmer med direktiv 2014/53/EU.

Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande webbadress: <http://cert.bosch-carmultimedia.net>

Slovenia

Robert Bosch Car Multimedia GmbH potrjuje, da je tip radijske opreme ICC6.5in skladen z Direktivo 2014/53/EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: <http://cert.bosch-carmultimedia.net>

Slovakia

Robert Bosch Car Multimedia
GmbH týmto vyhlasuje, že rádiové
zariadenie typu ICC6.5in je v
súlade so smernicou 2014/53/EÚ.
Úplné EÚ vyhlásenie o zhode je k
dispozícii na tejto internetovej
adrese: [http://cert.bosch-
carmultimedia.net](http://cert.bosch-carmultimedia.net)

Declaration of Conformity

Radio equipment TFT instrument cluster

For all Countries without EU

Technical information

BT operating frq. Range:

2402 – 2480 MHz

BT version: 4.2 (no BTLE)

BT output power: < 4 dBm

WLAN operating frq. Range:

2412 – 2462 MHz

WLAN standards:

IEEE 802.11 b/g/n

WLAN output power: < 20 dBm

Manufacturer and Address

Manufacturer:

Robert Bosch Car Multimedia GmbH

Address: Robert Bosch Str. 200,
31139 Hildesheim, GERMANY

Turkey

Robert Bosch Car Multimedia

GmbH, ICC6.5in tipi telsiz

sisteminin 2014/53/EU

nolu yönetmeliğe uygun olduğunu

beyan eder. AB Uygunluk

Beyanı'nın tam metni, aşağıdaki

internet adresinden görülebilir:

[http://cert.bosch-](http://cert.bosch-carmultimedia.net)

[carmultimedia.net](http://cert.bosch-carmultimedia.net)

Brazil

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário.

Canada

This device complies with Industry Canada's licence-exempt RSSs and part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Korea

적합성평가에 관한 고시
R-CMM-RBR-ICC65IN
상호 : Robert Bosch Car
Multimedia GmbH모델명 :
ICC6.5in
기자재명칭 : 특정소출력 무선기기
(무선데이터통신시스템용 무선기기)
제조사 및 제조국가 : Robert
Bosch Car Multimedia GmbH /
포르투갈
제조년월 : 제조년월로 표기
이 기기는 업무용 환경에서 사용
할 목적으로 적합성평가를 받은
기기로서 가정용 환경에
서 사용하는 경우 전파간섭의 우
려가 있습니다.

Mexico

La operación de este equipo está sujeta a las siguientes dos condiciones:

- (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y
- (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

Taiwan, Republic of

根據 NCC 低功率電波輻射性電機
管理辦法 規定: 第十二條
經型式認證合格之低功率射頻電
機, 非經許可, 公司、商號或使用
者均不得擅自變更頻率、加大功率
或變更原設計之特性及功能。
第十四條
低功率射頻電機之使用不得影響飛
航安全及干擾合法通信; 經發現有
干擾現象時, 應立即停用, 並改善
至無干擾時方得繼續使用。
前項合法通信,
指依電信法規定作業之無線電通
信。
低功率射頻電機須忍受合法通信或
工業、科學及醫療用電波輻射性電
機設備之干擾。

Thailand

เครื่องโทรคมนาคมและอุปกรณ์นี้

มีความสอดคล้องตามข้อกำหนดของ กทช.

(This telecommunication equipments is in compliance with NTC requirements)

United States (USA)

This device complies with Industry Canada's licence-exempt RSSs and part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Declaration of Conformity

Radio equipment anti-theft alarm (DWA)

Simplified EU Declaration of Conformity acc. Radio Equipment Directive 2014/53/EU after 12.06.2016 and during transition period



Technical information

Frequency Band:
433.05-434.79 MHz
Output Power: 10 mW e.r.p.

Manufacturer and Address

Manufacturer: Meta System S.p.A.
Address: Via Galimberti 5 42124
Reggio Emilia - Italy

Austria

Hiermit erklärt Meta System S.p.A., dass der Funkanlagentyp TXBMWMR der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: <https://docs.metasystem.it/>

Belgium

Le soussigné, Meta System S.p.A., déclare que l'équipement radioélectrique du type TXBMWMR est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: <https://docs.metasystem.it/>

Bulgaria

С настоящото Meta System S.p.A. декларира, че този тип радиосъоръжение TXBMWMR е в съответствие с Директива 2014/53/ЕС. Цялостният текст на ЕС декларацията за съответствие може да се намери на следния интернет адрес: <https://docs.metasystem.it/>

Cyprus

Με την παρούσα ο/η Meta System S.p.A., δηλώνει ότι ο ραδιοεξοπλισμός TXBMWMR πληροί την οδηγία 2014/53/ΕΕ. Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: <https://docs.metasystem.it/>

Czech Republic

Tímto Meta System S.p.A. prohlašuje, že typ rádiového zařízení TXBMWMR je v souladu se směrnicí 2014/53/EU. Úplné znění EU prohlášení o shodě je k dispozici na této internetové adrese: <https://docs.metasystem.it/>

Germany

Hiermit erklärt Meta System S.p.A., dass der Funkanlagentyp TXBMWMR der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: <https://docs.metasystem.it/>

Denmark

Hermed erklærer Meta System S.p.A., at radioudstyrstypen TXBMWMR er i overensstemmelse med direktiv 2014/53/EU. EU-overensstemmelseserklæringens fulde tekst kan findes på følgende internetadresse: <https://docs.metasystem.it/>

Estonia

Käesolevaga deklareerib Meta System S.p.A., et käesolev raadioseadme tüüp TXBMWMR vastab direktiivi 2014/53/EL nõuetele. ELi vastavusdeklaratsiooni täielik tekst on kättesaadav järgmisel internetiaadressil: <https://docs.metasystem.it/>

Spain

Por la presente, Meta System S.p.A. declara que el tipo de equipo radioeléctrico TXBMWMR es conforme con la Directiva 2014/53/UE. El texto completo de la declaración UE de conformidad está disponible en la dirección Internet siguiente: <https://docs.metasystem.it/>

Finland

Meta System S.p.A. vakuuttaa, että radiolaitetyyppi TXBMWMR on direktiivin 2014/53/EU mukainen. EU-vaatimustenmukaisuusvakuutuksen täysimittainen teksti on saatavilla seuraavassa internetosoitteessa: <https://docs.metasystem.it/>

France

Le soussigné, Meta System S.p.A., déclare que l'équipement radioélectrique du type TXBMWMMR est conforme à la directive 2014/53/UE

Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante : <https://docs.metasystem.it/>

United Kingdom

Hereby, Meta System S.p.A. declares that the radio equipment type TXBMWMMR is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://docs.metasystem.it/>

Greece

Με την παρούσα ο/η Meta System S.p.A., δηλώνει ότι ο ραδιοεξοπλισμός TXBMWMMR πληροί την οδηγία 2014/53/ΕΕ. Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: <https://docs.metasystem.it/>

Croatia

Meta System S.p.A. ovime izjavljuje da je radijska oprema tipa TXBMWMMR u skladu s Direktivom 2014/53/EU. Cjeloviti tekst EU izjave o sukladnosti dostupan je na sljedećoj internetskoj adresi: <https://docs.metasystem.it/>

Hungary

Meta System S.p.A. igazolja, hogy a TXBMWMMR típusú rádióberendezés megfelel a 2014/53/EU irányelvnek. Az EU-megfelelőségi nyilatkozat teljes szövege elérhető a következő internetes címen: <https://docs.metasystem.it/>

Ireland

Hereby, Meta System S.p.A. declares that the radio equipment type TXBMWMMR is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://docs.metasystem.it/>

Italy

Il fabbricante, Meta System S.p.A., dichiara che il tipo di apparecchiatura radio TXBMWMMR è conforme alla direttiva 2014/53/UE. Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: <https://docs.metasystem.it/>

Lithuania

Aš, Meta System S.p.A., patvirtinu, kad radijo įrenginių tipas TXBMWMR atitinka Direktyvą 2014/53/ES.

Visas ES atitikties deklaracijos tekstas prieinamas šiuo interneto adresu: <https://docs.metasystem.it/>

Luxembourg

Le soussigné, Meta System S.p.A., déclare que l'équipement radioélectrique du type TXBMWMR est conforme à la directive 2014/53/UE.

Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: <https://docs.metasystem.it/>

Latvia

Ar šo Meta System S.p.A. deklarē, ka radioiekārta TXBMWMR atbilst Direktīvai 2014/53/ES.

Pilns ES atbilstības deklarācijas teksts ir pieejams šādā interneta vietnē: <https://docs.metasystem.it/>

Malta

B'dan, Meta System S.p.A., niddikjara li dan it-tip ta' tagħmir tar-radju TXBMWMR huwa konformi mad-Direttiva 2014/53/UE.

It-test kollu tad-dikjarazzjoni ta' konformità tal-UE huwa disponibbli f'dan l-indirizz tal-Internet li ġej: <https://docs.metasystem.it/>

Netherlands

Hierbij verklaar ik, Meta System S.p.A., dat het type radioapparatuur TXBMWMR conform is met Richtlijn 2014/53/EU.

De volledige tekst van de EU-conformiteitsverklaring kan worden geraadpleegd op het volgende internetadres: <https://docs.metasystem.it/>

Poland

Meta System S.p.A. niniejszym oświadcza, że typ urządzenia radiowego TXBMWMR jest zgodny z dyrektywą 2014/53/UE. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: <https://docs.metasystem.it/>

Portugal

O(a) abaixo assinado(a) Meta System S.p.A. declara que o presente tipo de equipamento de rádio TXBMWMR está em conformidade com a Diretiva 2014/53/UE.

O texto integral da declaração de conformidade está disponível no seguinte endereço de Internet: <https://docs.metasystem.it/>

Romania

Prin prezenta, Meta System S.p.A. declară că tipul de echipamente radio TXBMWMR este în conformitate cu Directiva 2014/53/UE. Textul integral al declarației UE de conformitate este disponibil la următoarea adresă internet: <https://docs.metasystem.it/>

Sweden

Härmed försäkrar Meta System S.p.A. att denna typ av radioutrustning TXBMWMR överensstämmer med direktiv 2014/53/EU. Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande webbadress: <https://docs.metasystem.it/>

Slovenia

Meta System S.p.A. potrjuje, da je tip radijske opreme TXBMWMR skladen z Direktivo 2014/53/EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: <https://docs.metasystem.it/>

Slovakia

Meta System S.p.A. týmto vyhlasuje, že rádiové zariadenie typu TXBMWMR je v súlade so smernicou 2014/53/EÚ. Úplné EÚ vyhlásenie o zhode je k dispozícii na tejto internetovej adrese: <https://docs.metasystem.it/>

274 INDEX

- A**
 - Abbreviations and symbols, 4
 - ABS, 144
 - Engineering details, 150
 - Self-diagnosis, 110
 - Status indicators, 37
 - Accessories
 - Connector for optional accessories, 200
 - General notes, 200
 - Air filter
 - Position in the vehicle, 15
 - Anti-theft alarm
 - Indicator light, 19
 - operating, 58
 - Warning light, 34
- B**
 - Battery
 - Charge, 193
 - connecting to motor-cycle, 193
 - disconnecting from motorcycle, 193
 - Indicator light for vehicle voltage, 31, 32
 - install, 194
 - Maintenance instructions, 192
 - Position on the vehicle, 16
 - remove, 194
 - Technical data, 222
 - Best-ever lap, 128
 - Bluetooth, 75
 - Pairing, 76
 - Brake fluid
 - Checking fluid level, front, 171
 - Checking fluid level, rear, 172
 - Reservoir, front, 15
 - Reservoir, rear, 15
 - Brake pads
 - checking front, 169
 - checking rear, 170
 - Running in, 112
 - Brakes
 - ABS Pro, 153
 - ABS Pro depending on riding mode, 115
 - Adjusting handlebar levers, 88
 - Checking function, 168
 - Checking operation, 168
 - Dynamic Brake Control depending on riding mode, 115
 - Safety information, 114
 - Technical data, 221
- C**
 - Care
 - Chrome, 208
 - Paintwork preservation, 209
 - Chain
 - Adjusting sag, 185
 - Checking sag, 185
 - Checking wear, 186
 - Lubricating, 183
 - Chassis and suspension
 - Technical data, 220
 - Check control
 - Dialogue, 25
 - Display, 25
 - Checklist, 108
 - Clock
 - adjusting, 74
 - Clutch
 - Adjusting clutch lever, 89
 - Adjusting play, 174
 - Checking function, 173
 - Checking play, 173
 - Technical data, 219

- Coolant
 - Checking fill level, 174
 - Indicator light for overheating, 34
 - Technical data, 218
 - Topping up, 175
- Cruise control, 17
 - operating, 53
- Currency, 6

D

- Damping
 - Adjuster, front, 14
 - Adjuster, rear, 14
 - adjusting, 95
- Diagnostic connector
 - disengaging, 196
 - Position on the vehicle, 16
 - securing, 196
- Dimensions
 - Technical data, 223
- Drop sensor
 - Indicator light, 37
- DTC, 17
 - Customising controls, 133
 - Engineering details, 153
 - Indicator and warning light, 39
 - operating, 50
 - Self-diagnosis, 111
 - switching off, 50
 - switching on, 51
- DWA
 - Technical data, 223
- Dynamic Brake Control, 157
 - Engineering details, 157

E

- Electrical system
 - Technical data, 222

- Emergency call
 - deactivating, 129
- Emergency off switch (kill switch), 18
 - operating, 47
- Engine, 35
 - Indicator light for engine control, 36
 - Indicator light for engine electronics, 35
 - parking, 46
 - starting, 109
 - Technical data, 218
 - Warning light, drive malfunction, 35
- Engine oil
 - Checking fill level, 167
 - Filler neck, 15
 - Fill-level indicator, 15
 - Technical data, 218
 - topping up, 168
- Equipment, 5

F

- Final drive
 - Technical data, 219
- Frame
 - Technical data, 220
- Front-wheel stand
 - Front-wheel stand, 166
- Fuel
 - Fuel grade, 117
 - refuelling, 118
 - Technical data, 217
- Fuel reserve
 - Range, 73
 - Warning, 41

276 INDEX

Fuses

- Position on the vehicle, 16
- replacing, 194
- Technical data, 222

G

General views

- Indicator and warning lights, 22
- Instrument cluster, 19
- Left multifunction switch, 17
- left side of vehicle, 14
- My vehicle, 78
- Right multifunction switch, 18
- right side of vehicle, 15
- TFT display, 23, 24
- Under the rider's seat, 16

H

Hazard warning flashers

- Control, 17, 18
- operating, 49

Headlight

- Headlight beam throw, 88
- Setting for right-hand/left-hand traffic, 88

Headlight courtesy delay

- feature, 48

Heated handlebar grips

- Control, 18
- operating, 59

Hill Start Control, 55, 159

- cannot be activated, 41
- Engineering details, 159
- Indicator and warning lights, 41

Hill Start Control Pro

- adjusting, 57
- Engineering details, 159
- operating, 56

Horn, 17

I

Ignition

- switching off, 46
- switching on, 46

Immobiliser

- Reserve key, 47

Indicator lights, 19

- Overview, 22

Instrument cluster

- Ambient-light brightness sensor, 19
- Overview, 19

J

Jump-starting, 191

K

Keys, 46

L

Laptimer

- adjusting, 127
- Ending timing, 127
- operating, 127
- Starting timing, 127

Launch control, 130

- Racing start, 131

Light warnings

- deactivating, 129

Lighting

- Indicator light for bulb fault, 32
- Replacing LED light sources, 187
- Technical data, 223

Lights

- Control, 17
- Headlight courtesy delay feature, 48
- Headlight flasher, operating, 48
- High-beam headlight, operating, 48
- Low-beam headlight, 48
- Parking lights, 49
- Side light, 48

Luggage

- Instructions for loading, 106

M**Maintenance**

- Maintenance schedule, 232

Maintenance confirmations, 233**Maintenance intervals, 230****Media**

- operating, 83

Menu

- calling up, 70

Mirrors

- adjusting, 88
- Removing and installing, 135

Mobility services, 230**Motorcycle**

- care, 204
- cleaning, 204
- laying up, 209
- parking, 116
- restoring to use, 209
- securing, 119

Multi-Controller, 17**Multifunction display**

- Status indicators for racing, 124

Multifunction switch

- Overview, left side, 17
- Overview, right side, 18

N**Navigation**

- operating, 81

Number-plate carrier

- Removing and installing, 139

O**On-board computer, 60****On-board voltage**

- Warning light, 31, 32

P**Pairing, 76****Parking, 116****Parking light, 49****Phone**

- operating, 83

Pit Lane Limiter, 132

- adjusting, 132

Pit-lane speed limiter

- Maximum rpm, setting, 132
- operating, 132

Pre-Ride-Check, 109**Pure Ride**

- Overview, 23

R**Race track, 129**

- Chassis and suspension settings, 135

Pit-lane speed limiter, 132**Racing start with Launch**

- Control, 131

Status indicators for

- racing, 122

278 INDEX

- RACE PRO, 129
 - configuring, 130
 - Restoring factory setting, 130
- Rear-wheel stand
 - installing, 166
- Refuelling, 118
 - Fuel grade, 117
- Rev. counter, 19
 - Rev. counter, 73
- Riding height
 - adjusting, 101
- Riding mode, 129
 - adjusting, 52
 - Control, 18
 - Engineering details, 155
- Running in, 111

S

- Safety instructions
 - for brakes, 114
 - for riding, 106
- Seats
 - Lock, 14
 - Removing and installing, 61
- Service, 229
 - Reporting safety-relevant defects, 228
 - Service history, 229
- Service-due indicator, 42
- Shift assistant, 112, 158
 - Engineering details, 158
 - Gear not trained, 42
 - Riding, 112
- Shift lever
 - Gearshift-pattern re-
verser, 145
- Shift light
 - adjust, 57
 - switching on/off, 57

- Shifting gear
 - Shift light, 113
- Spark plugs, 223
- Speed Limit Info
 - Switching on or off, 72
- Speedometer, 19
- Spring preload
 - Adjuster, front, 14
 - Adjuster, rear, 14, 15
 - adjusting, 93
- Starting, 109
 - Control, 18
- Status line, top
 - adjusting, 71, 72
- steering damper
 - adjusting, 92
 - Steering damper, 14
- Steering lock
 - Locking, 46
- Swinging arm
 - Adjusting swinging arm pivot
point, 98

T

- Tail-hump trim panel
 - install, 190
 - remove, 188
- Technical data
 - Anti-theft alarm, 223
 - Battery, 222
 - Brakes, 221
 - Chassis and suspension, 220
 - Clutch, 219
 - Coolant, 218
 - Dimensions, 223
 - Electrical system, 222
 - Engine, 218
 - Engine oil, 218
 - Final drive, 219
 - Frame, 220

- Fuel, 217
- Fuses, 222
- General notes, 5
- Lighting, 223
- Spark plugs, 223
- Standards, 5
- Transmission, 219
- Weights, 224
- Wheels and tyres, 221
- TFT display, 19
 - Control, 17
 - operating, 70, 71
 - Overview, 23, 24
 - Selecting display, 67
- Toolkit
 - Contents, 165
 - Position on the vehicle, 16
- Torques, 214
- Traction control, 153
 - DTC, 153
- Transmission
 - Technical data, 219
- Trim panels
 - Installing side panel, 188
 - Installing tail-hump trim panel, 190
 - Remove the side panel, 187
 - Removing tail-hump trim panel, 188
- Troubleshooting chart, 212
- Turn indicators
 - Control, 17
 - Control, right, 18
 - operating, 50
- Type plate
 - Position on the vehicle, 15
- Tyres
 - Checking tread depth, 175
 - Checking tyre pressure, 175
- Pressures, 222
- Running in, 112
- Table of tyre pressures, 14
- Technical data, 221
- U**
- USB charging socket
 - Position on the vehicle, 16
- V**
- Value
 - Display, 25
- Vehicle Identification Number
 - Position on the vehicle, 15
- W**
- Warning indicator lights, 35
 - ABS, 37
 - Anti-theft alarm, 34
 - Bulb faulty, 32
 - Coolant temperature, 34
 - Drop sensor, 37
 - DTC, 39
 - Engine control unit, 36
 - Engine electronics, 35
 - Fuel reserve, 41
 - Gear not trained, 42
 - Hill Start Control, 41
 - Mode of presentation, 25
 - My vehicle, 78
 - On-board voltage, 31, 32
 - Vehicle lighting failed, 33
 - Warning light, drive malfunction, 35
- Warning light, drive malfunction, 35
- Warning lights, 19
 - Overview, 22
- Warnings, overview, 27

280 INDEX

Weights

Payload table, 16

Technical data, 224

Wheels

Change of size, 176

Checking rims, 176

Install the front wheel, 179

Installing the rear wheel, 182

Removing front wheel, 177

Removing rear wheel, 181

Technical data, 221

Windscreen

Adjuster, 15

Details described or illustrated in this booklet may differ from the vehicle's actual specification as purchased, the accessories fitted or the national-market specification. No claims will be entertained as a result of such discrepancies.

Dimensions, weights, fuel consumption and performance data are quoted to the customary tolerances.

The right to modify designs, equipment and accessories is reserved.

Errors and omissions excepted.

© 2020 Bayerische Motoren
Werke Aktiengesellschaft
80788 Munich, Germany
Not to be reproduced by any
means whatsoever, wholly or in
part, without the written per-
mission of BMW Motorrad,
After Sales.
Original rider's manual, printed
in Germany.

Important data for refuelling:

Fuel

Recommended fuel grade	 Super Plus, unleaded (maximum 5% ethanol, E5) 98 ROZ/RON 93 AKI
Alternative fuel grade	 Super unleaded (power- and consumption-related restrictions.) (maximum 10% ethanol, E10)  95 ROZ/RON 90 AKI
Usable fuel capacity	approx. 16.5 l
Fuel reserve	approx. 4 l
Tyre pressure	
Tyre pressure, front	2.5 bar, tyre cold
Tyre pressure, rear	2.9 bar, tyre cold

You can find further information on all aspects of your vehicle at:
bmw-motorrad.com

BMW recommends **ADVANTEC**
ORIGINAL BMW ENGINE OIL

Order No.: 01 40 9 831 141
09.2020, 1st edition, 01

