


BMW Motorrad

Installation Instructions

Windscreen, tinted, for K 1200 R Sport



Before commencing work, you must read these Installation Instructions through carefully and make sure you understand everything they contain.

To put it as concisely as possible - safety always comes first. It's fun to fit accessories, but accessories add up to much more. Accessories make a standard motorcycle into your custom bike. Now, what about your abilities as a mechanic and your hands-on experience? Are you sure that you have all the special tools you'll need?

Your authorised BMW Motorrad dealer will be happy to install this retrofit kit professionally and at reasonable cost.

We offer our customers a very wide range of type-tested accessories and optional extras. This explains why these Installation Instructions cannot describe all the possible equipment combinations. Consequently, we have concentrated on the basic version of the model in question. The procedures for removing and installing accessory components are described in the applicable sets of installation instructions. Consult your authorised BMW Motorrad dealer if the instructions in question are no longer in your possession.

The symbols used to draw attention to safety instructions in this manual are as follows:



Warning

This symbol indicates precautions and measures which are essential in protecting the rider and other persons from severe or fatal injury.



Attention

Specific instructions and safety precautions intended to prevent damage to the motorcycle and accessories. Non-compliance can void the warranty.



Note

Specific instructions on how to operate, control, adjust or look after items of equipment on the motorcycle.



Tightening torque

Screws, bolts and nuts are tightened in accordance with the applicable DIN/ISO standards. Tightening torques that deviate from the standards are stated. Non-compliance can result in damage to the motorcycle or accessories or can endanger the rider.

- ▶ Start of the main activity
- ▷ Start of the secondary activity
- Instruction

- ◀ End of the main activity
- ◁ End of the secondary activity

© 2006 Copyright by:

BMW Motorrad, Service, D-80788 München

Not to be reproduced, translated or replicated in any way whatsoever, either wholly or in part, without written permission from BMW Motorrad.


Subject to change without notice. Errors and omissions excepted.

All rights reserved.

Windscreen, tinted, for K 1200 R Sport

Requisite tools

- Set of Torx wrenches
- Torque wrench



Retrofit kit

- Windscreen, tinted
- Installation Instructions

1

General instructions



Attention

If it is not standing firmly, the motorcycle could topple in the course of the operations described below. Always make sure that the motorcycle is stable and firmly supported.



Warning

Injury to persons
Keep children and household pets well away from the work zone.



Warning

Risk of injury by snagging or electrical short-circuit.
Remove all items of personal jewellery (rings, chains, wristwatch, etc.) before commencing work.



Note

Clean the mating faces prior to assembly.
Comply with the instructions for care of the product as stated in the Rider's Manual supplied with the motorcycle.




Note

Once the retrofit kit has been installed by the workshop, these installation instructions must be handed over to the customer.
Make sure that these installation instructions accompany the retrofit kit when it is passed on to a third party.

46 63 031 Removing and installing windscreen

Additional work: 46 52 510 Installing and removing special tool, rear-wheel stand (motorcycles without main stand) (not valid for: Centre stand)


2



► Removing windscreen


- Remove screws 1.
- Remove windscreen 2, noting the guides **arrows**.

3



► Installing windscreen

- Install flat nuts 1 removed beforehand in the windscreen with washers 2.



- Install windscreen 2, noting the guides **arrows**.
- Install screws 1.

Tightening torques		
Windscreen to fairing		
M5 x 16	2.4 Nm	

► **Final check of work performed**

- Check that
 - the work as performed achieved the intended purpose.
 - all reservoirs and containers have been filled and that all fluids and lubricants are at their correct levels.
 - all threaded fasteners released beforehand have been correctly retightened.
 - the fuel system is free of leaks.
 - the lights and signalling equipment are fully operational and that the motorcycle is roadworthy.
 - the brake pads of the front and rear brakes are bedded against the brake discs.



Always comply with the regulations regarding approval in the country of use.



Note

For the Federal Republic of Germany:

No entry required in the vehicle's registration papers.
